

2.2 Control System JL4G18-D

2.2.1 Specifications

2.2.1.1 Fastener Tightening Specifications

Applications	Model	Specifications	
		Metric (Nm)	US English (lb-ft)
Camshaft Position Sensor Retaining Bolts	M6X14	8-10	6.0-7.4
Crankshaft Position Sensor Retaining Bolts	M6X12	8-10	6.0-7.4
Ignition Coil Retaining Bolts	M6X35	7-11	5.2-7.8
Engine Control Module Retaining Bolts	M6X16	8-10	6.0-7.4
Engine Coolant Temperature Sensor Bolts	M12 × 1.5 × 6	15	11
Evaporative Emissions Canister	M6X20	7-9	5.2-6.7
Evaporative Emissions Canister Solenoid Valve Bracket Retaining Bolts	M6X20	7-9	5.2-6.7
Fuel Filter Mounting Bracket Assembly Retaining Bolts	M6X16	8-10	6.0-7.4
Fuel Filter Mounting Bracket Retaining Bolts	M6X16	8-10	6.0-7.4
Fuel Rail Retaining Bolts	M6X20	10	7
Fuel Tank Retaining Bolts	M10X30	38-46	28.1-34.0
Idle Air Control Valve Retaining Bolts	M4X10	2-3	1.5-2.2
Knock Sensor Retaining Bolts	M8X30	15-22	10.7-16.0
Intake Manifold Absolute Pressure and Temperature Sensor Retaining Bolts	M6X12	8-10	6.0-7.4
Oxygen Sensor Retaining Bolts	M18X8	44	32.6
Air-Conditioning Compressor Mounting Bolts	M8X80	25	18.2
Spark Plug Retaining Bolts	M14 × 1.25 × 22	20-30	14.8-22.2
Throttle Body Retaining Bolts	M8	20-25	14.8-18.5

2.2.1.2 Temperature Sensor Temperature and Resistance Correlation

Temperature (°C) / (°F)	Resistance (Ω)
-30/-22	26,000
-25/-13	19,000
-20/-4	15,000
-15/5	11,800
-10/14	9,000


Temperature (°C) / (°F)	Resistance (Ω)
-5/23	7,000
0/32	5,600
5/41	4,600
10/50	3,600
15/59	3,000
20/68	2,400
25/77	2,000
30/86	1,700
35/95	1,400
40/104	1,180
45/113	950
50/122	800
55/131	700
60/140	600
65/149	510
70/158	425
80/176	320
90/194	240
100/212	180
110/230	140
120/248	110
130/266	90

2.2.1.3 Altitude and Atmospheric Pressure Correlation

Altitude (m)/(ft)	Atmospheric Pressure (kPa)/(psi)
4,200/13,780	55/8
3,900/12,795	58/8.4
3,600/11,811	61/8.8
3,300/10,827	64/9.3
3,000/9,843	66/9.6
2,700/8,858	69/10
2,400/7,874	71/10.3

Altitude (m)/(ft)	Atmospheric Pressure (kPa)/(psi)
2,100/6,890	74/10.7
1,800/5,906	77/11.2
1,500/4,921	80/11.6
1,200/3,937	83/12
900/2,953	87/12.6
600/1,969	90/13.1
300/984	93/13.5
0	100/14.5

2.2.1.4 Intake Air Pressure Sensor Voltage and Pressure Diagram



2.2.2 Description and Operation

2.2.2.1 Overview

The engine use an electronic control system manufactured by UAES(United Automotive Electronic Systems Co., Ltd.). It consists of the engine control module (ECM), ECM working circuit, system input and output parts. ECM is located at the right side of the Air-Conditioning blower and is the engine control system control center. It continues to monitor the signals from various sensors and controls the various systems performance. Engine control module also performs system diagnostics, it can identify the operational malfunction and through the malfunction indicator light (MIL) to remind the driver and store DTC codes in order to facilitate maintenance personnel for maintenance.


If the engine control module is damaged, there is no single spare part within the module can be repaired. ECM must be replaced as a whole.

Input components: crankshaft position sensor (CKP), camshaft position sensor (CMP), intake air pressure and temperature sensors [intake air pressure sensor (MAP), with intake air temperature sensor (IAT)], knock sensor (KS), throttle position sensor (TPS), evaporation tank surface temperature sensor, engine coolant temperature sensor (ECT), vehicle speed sensor (VSS), pre-catalytic heated oxygen sensor (HO₂S), post-catalytic heated oxygen sensor (HO₂S), air conditioning pressure switch, power steering switch, defrost heating enable input, CAN information input, serial data bus input.

Output components: idle speed control valve (IAC) ,1-2-3-4-cylinder fuel injectors, ignition coils, variable valve timing solenoid valve (VVT), canister solenoid valve (EVAP), the main relay, pump relay and oil pump, cooling fan low speed relay, cooling fan high speed relay, air-conditioning compressor relay, CAN information output, serial data bus out.


2.2.2.2 Input Components

1. Crankshaft Position Sensor (CKP)




The crankshaft position sensor output can be used to determine crankshaft position and rotation speed. Crankshaft position sensor is a magnetic-electric sensor, which is installed in the front end of the transmission housing, and tightened with bolts, below the coolant temperature sensor. Flywheel signal plate and the crankshaft sensor is an integrated part. The sensor extends out through the bearing. The gap between the sensor and the signal plate teeth is below 1.2mm. The signal plate has 58 machined slots, of which 57 slots have a 6 ° interval. The last tooth slot is wider, used to generate synchronization pulses. When the crankshaft rotates, the sensor plate slot will change the sensor magnetic field, resulting in an induced voltage pulse. The 58th slot pulse is longer and can be used to identify a specific direction of the crankshaft, so that the engine control module (ECM) may at any time determine the direction of the crankshaft. Engine control module uses this information to generate the ignition timing and fuel injection pulse, and then controls the ignition coil and fuel injectors. Sensor signals pass through ECM harness connector EN01 terminal No.46,47 to ECM, if the engine control module detects the sensor signals erratic or incorrect, it will record DTC code P0321, P0322. and DTC code P0016 will be recorded when the camshaft relative position is not correct.

2. Camshaft Position Sensor (CMP)




Engine control module receives this signal as a sync pulse, according to an appropriate sequence to trigger the fuel injectors. Engine control module uses the camshaft position sensor signals to instruct cylinder No.1 piston position during power stroke. Engine control module then calculates the actual fuel injection sequence. If when the engine is running, the camshaft position sensor signal is lost, the fuel injection system will be converted to a fuel injection pulse based on the previous calculation of the fuel injection model, while the engine will continue to run. Even if the fault exists, the engine can be restarted. Sensor signals pass through ECM harness connector EN01 terminal No.42 to ECM. When the engine is running if the control module detects an incorrect camshaft position sensor signal, it will record DTC code P0340, P0341, P0342, P0343. DTC code P0016 will be recorded when the crankshaft relative position is incorrect.

3. Intake Air Pressure and Temperature Sensor




Intake air pressure and temperature sensor has an intake pressure sensing element and a thermistor. When the engine is working, the engine intake pressure sensing element produces the intake air pressure signal, negative temperature coefficient thermistor produces intake air temperature signal. This sensor detects intake manifold pressure change caused by engine load and speed changes. These changes will be converted to the voltage output. When the engine decelerates, the throttle body closes resulting in a relatively low intake manifold absolute pressure output. Intake manifold absolute pressure and vacuum degree is opposite. When the manifold pressure is high, the vacuum is low. MAP sensor is also used to measure atmospheric pressure. This measurement is calculated as part of the MAP calculation. When the ignition switch is turned on and the engine is not running, the engine control module reads atmospheric pressure as the intake manifold pressure, and adjusts the Air-Fuel ratio accordingly. With this kind of altitude compensation, the system can maintain a low emissions while maintaining maneuverability. Sensor signal passes through ECM harness connector EN01 terminal No.19 to ECM. When MAP sensor and its circuit malfunction occurs, DTC P0105, P0106, P0107, P0108 will be recorded. DTC code P0105, P0106, P0107, P0108 will be recorded when MAP sensor and its circuit have malfunctions. Engine control module provides 5V voltage to the thermistor and measure the voltages change to determine the intake air temperature. The engine control module obtains the intake air temperature by measuring the voltage. ECM uses this signal to adjust the injector pulse width and ignition timing. Sensor signals pass through ECM harness connector EN01 terminal No.25 to ECM. DTC code P0112, P0113 will be recorded when there is a circuit malfunction.

4. Knock Sensor (KS)




Knock sensor is a frequency response sensor, installed in the engine block the most sensitive to knocking part, the lower intake manifold. ECM uses knock sensor to detect knock intensity, and then to adjust the ignition advance angle, to effectively control knocking and optimize the engine power, fuel economy and emission levels. If the engine knocking occurs, ECM will receive the signal, filter out the non-knock signals and determine engine cycle calculated by camshaft and crankshaft position sensor signals. ECM determines the cylinder in which the knock occurs and will delay the ignition advance angle for this cylinder until the knock disappears. Then ECM advances the ignition advance angle until the ignition angle is best suited for the operating conditions at that time. Sensor signals pass through ECM harness connector EN01 terminal No.30,31 to ECM. DTC code P0327, P0328 will be recorded by ECM where there is a KS sensor malfunction.

5. Throttle Position Sensor (TPS)




Throttle position sensor is installed on the throttle body connected with the throttle shaft. Within the sensor, it is actually a sliding variable resistor, with a 5 V reference voltage and a ground provided by ECM. Engine control module monitors the signal voltage to calculate the throttle position. Because it is connected with the throttle shaft, so the output signal changes as the movement of the accelerator pedal. When the throttle is closed, the sensor output voltage is low, about 0.3-0.9 V. With the throttle opening the output voltage increases, when the throttle is fully open, the output voltage is about 4.5 V. Sensor signals pass through ECM harness connector EN01 terminal No.26 to ECM, ECM adjusts fuel injection amount based on this signal. DTC code P0122, P0123 will be recorded when there is a sensor circuit malfunction.

6. Engine Coolant Temperature Sensor (ECT)




Engine coolant temperature (ECT) sensor is a thermistor and its resistance changes as the temperature changes. It is installed in the engine coolant flow. When the coolant temperature is low, the resistance is high. At $-30\text{ }^{\circ}\text{C}$ ($-22\text{ }^{\circ}\text{F}$) the resistance is $26,000\ \Omega$; at $130\text{ }^{\circ}\text{C}$ ($266\text{ }^{\circ}\text{F}$), the resistance is $90\ \Omega$. ECM provides a 5 V voltage to the sensor. When the engine is cold, the voltage is high. When the engine is hot, the voltage is low. The coolant temperature signal is important to the ignition timing and fuel injection adjustment, while the signal is also transmitted to the instrument panel (IP) through the CAN network, used to display the current engine working temperature. Sensor signals pass through ECM harness connector EN01 terminal No.41 to ECM. DTC code P0117, P0118 will be recorded when there is a sensor or circuit malfunction.

7. Vehicle Speed Sensor (VSS)



The vehicle speed sensor is installed in the front transmission case, connected with differential speed sensor drive gear. Speed sensor is a Hall-style. The main relay controlled by ECM provides the sensor working power. When the vehicle is driving, the sensor output is a rectangular pulse signal. Sensor signals pass through ECM harness connector EN01 terminal No.57 to ECM. DTC code P0501 will be recorded when there is a sensor or wiring malfunction.

8. Pre-Catalytic Heated Oxygen Sensor (HO₂S)



Pre-Catalytic oxygen sensor is installed in the exhaust manifold, the three-way catalytic converter front-end, detecting the oxygen content of exhaust gas and sending ECM the indirect mixture concentration. ECM adjusts fuel injection pulse width, to make sure that the mixture ratio is close to the theoretical value of about 14.7. Oxygen sensor has a sensing element, which is a porous ceramic tube, the outer wall surrounded by the engine exhaust and inside connecting to the atmosphere. Sensing ceramic wall is a solid electrolyte containing an electric heating tube. When the sensor ceramic tube temperature reaches 350°C (662 °F), it has a solid electrolyte properties. Oxygen sensors work by converting ceramic oxygen ion concentration difference between inside and outside into a voltage signal output. The output voltage level is due to movement caused internal electronic ceramic tubes. If the mixture is rich, then the ceramic oxygen ion concentration difference between inside and outside is high, electrical potential difference is high, a large number of oxygen ions move from the inside to the outside, the output voltage is high (close to 800mV). If the mixture is lean, then the ceramic oxygen ion concentration difference between inside and outside is low, electrical potential difference is low, only a small amount of oxygen ions move from inside to outside, the output voltage is low (close to 200mV). Signal voltage suddenly

changes near the theoretical Air-Fuel ratio ($\lambda=1$). Sensor signals pass through ECM harness connector EN01 terminal No.45 to ECM. DTC code P0030, P0031, P0032, P0053, P0130, P0131, P0132, P0133, P0134, P2195, P2196 will be recorded when there is a sensor, wire or circuit malfunction.

9. Post-Catalytic Heated Oxygen Sensor (HO₂S)

Post-Catalytic oxygen sensor is installed on the three-way catalytic converter rear end. Its working principle is the same as the Pre-Catalytic oxygen sensor. If the three-way catalytic converter is working properly, fuel control system is in close-loop control, the sensor output voltage is stable at 0.45V. Sensor signals pass through ECM harness connector EN01 terminal No.29 to ECM. DTC code P0036, P0037, P0038, P0054, P0136, P0137, P0138, P0140, P2270, P2271 will be recorded if there is a sensor, signal or circuit malfunction. DTC code P0420 will be recorded if the Post-Catalytic oxygen sensor detects that three-way catalytic converter is not working properly.

10. Air-Conditioning Pressure Switch

Air-Conditioning pressure switch is installed in the Air-Conditioning high pressure side pipeline, mainly for Air-Conditioning system control. ECM command the compressor control relay only when correct signal is received, so that the electromagnetic compressor clutch pull-in. Switching signals pass through ECM harness connector EN01 terminal No.10, 44 to ECM. DTC code will not be recorded when there is a switch or circuit malfunction.

11. Power Steering Switch

Power steering switch is installed on the power steering pump. When the steering wheel is operated, power steering pump oil pressure changes due to increased power steering pump load. If at this point, the engine is in idle state, it will cause the engine idle fluctuate. In order to make the engine run smooth, after ECM receives the signal, it will increase the engine's torque. A typical way is to increase the fuel injection amount. Switching signals pass through ECM harness connector EN01 terminal No.12 to ECM. DTC code will not be recorded when there is a switch or circuit malfunction.

12. Defrost Heating Enable Input

The signal is provided by the BCM through a dedicated circuit and is a voltage signal. The rear defrosting heating block is essentially a resistance wire with fairly high heating power. The power consumption is relatively high. When the rear defrost heating starts, the generator load increases, causing the engine speed fluctuate. In order to make the engine run smoother, after ECM receives the signal, it increase the engine's torque output. Switching signals pass through ECM harness connector EN01 terminal No.24 to ECM. when the signal fails, ECM does not record the relevant DTC code.

13. CAN Information Input


ECM downloads signals via CAN from the network for its own needs. The most typical signals are: brake switch signal, ABS's work status. CAN_HI signal circuit connects to other CAN network modules through ECM harness connector EN01 terminal No.33. CAN_LO signal circuit connects to other CAN network modules through ECM harness connector EN01 terminal No.34. If ECM fails to communicate with other modules, it will record DTC code U0001, U0121, U0140, U0151, P1523.

14. Serial Data Bus Input

When the ignition switch is turned on, the Anti-theft ignition coil identifies whether the inserted key is an illegal key. The signal is transmitted by the security module to ECM. ECM determines whether to activate the engine Anti-theft locking system based on this signal, such as cutting off the ignition, fuel injection, start the circuit. ECM harness connector EN01 terminals No.15,23 are for serial data communication. The immobilizer system-related failures DTC codes are P1610, P1611, P1612, P1613, P1614.

2.2.2.3 Output Components

1. Idle Speed Control Valve (IAC)




Note

- A. Do not to push and pull IAC valve core shaft, otherwise it will damage the internal valve components.
- B. When washing the IAC valve carbon residue, do not let any cleaning agent enter the IAC valve inside, otherwise it will damage IAC valve.

IAC valve is installed on the throttle body. ECM controls the spool extended the amount to control the idle speed. Engine sends the control module voltage pulses to the IAC valve motor windings, so that IAC valve core shaft moves to the inside or outside a certain distance (step or a count) with each pulse. Shaft movement controls the air flow amount bypass the throttle, and then controls the engine idle speed. The expected idle speeds of all engine running conditions are programmed and set in the ECM calibration program. These settings includes engine speed based on engine coolant temperature, speed, battery voltage, and Air-Conditioning system pressure. Engine control module reads the correct IAC valve position to meet the expectations of stable, warm-up idle speed under different conditions. This information is stored in the engine read-only memory, even after the ignition switch is switched off, the information will not be cleared. If the engine control module power supply is disconnect, it will lead to an incorrect idle speed control. When starting, press the accelerator pedal half way until the engine control module learns idle speed control. ECM controls IAC valve through ECM harness connector EN01 terminals No.21,22,35,36. If the idle speed control valve position does not match the actual ECM required location, DTC code P0506, P0507 will be recorded. If idle speed control valve circuit has a malfunction, DTC code P0508, P0509, P0511 will be recorded.

2. Cylinder No.1,2,3,4 Fuel Injectors




Fuel injector is installed on the cylinder cover, in front of intake valve. Based on ECM's instructions, it injects fuel during specific period of time, to provide engine the fuel atomized fuel. It also plays a role of storing high-pressure fuel to eliminate fuel pump resonance caused by pumping fuel. The fuel pressure remains stable. Fuel injector is an electromagnetic controlled nozzle. The return spring inside the shell compresses needle valve and seal the exit. During injection, the electronic controller gives control signal, electromagnetic coil obtains power, producing the magnetic field to overcome the return spring pressure, needle gravity, friction, etc. lift the needle valve. Under the pressure fuel sprays out. As the needle valve only has rising and falling only two states, needle lift travel can not be adjusted. As long as the pressure difference is constant, fuel injection quantity only depends on the needle valve opening time that is opening electrical pulse width.

Note

When the fuel injector is blocked or not closed tight, the engine malfunction lamp may be lit. The detected DTC code is: oxygen sensor distortion, signal erratic or Air-Fuel ratio is not normal etc. At this point, carefully diagnose the component fault. Because when the fuel injector is blocked, the fuel injection amount is not controlled by ECM fuel injection pulse width. The oxygen sensor mixture concentration signal feedback to ECM will very different from the theoretical value. ECM will determine the oxygen sensor is not working properly. The system can not determine whether it is the oxygen sensor itself faulty or other associated components faulty. Pay attention to determine the failure component when diagnose such a fault.


ECM controls the fuel injectors through ECM harness connector EN01 terminals No.50,63,49,64. If a fuel injector or circuit is fault, DTC code P0201, P0202, P0203, P0204, P0261, P0262, P0264, P0265, P0267, P0268, P0270, P0271 will be recorded.

3. Ignition Coil




Cylinder No.1,4 ignition coil is located at top of the cylinder No. 4. Cylinder No.2,3 ignition coil is located at top of the cylinder No.2. Ignition coil primary winding low voltage will be transformed into the secondary winding high voltage. The spark plug discharges spark, igniting the air and fuel mixture inside the cylinder. Ignition coil consists of a primary winding, a secondary winding, iron core, shell and other components. When the primary winding is connected to ground, it will be charged. Once ECM cuts off the primary winding circuit, then charging will be terminated, while a high voltage induced in the secondary winding, so that spark plug discharges. Different from the ignition coil with a distributor, the ignition coil secondary winding is connected to a spark plug at each end, so the two spark plug discharge at the same time. ECM controls the ignition coil through ECM harness connector EN01 terminals No.3,7. When an ignition related fault occurs, DTC code P0300, P0301, P0302, P0303, P0304 will be recorded.

4. Variable Valve Timing Solenoid Valve (VVT)



VVT solenoid valve is located at the engine intake manifold side near the front. VVT magnetic valve is a 4-bit 4-pass solenoid valve, the working power supplied from main relay controlled by ECM. ECM controls VVT solenoid valve ground with a pulse width modulation signal. ECM controls VVT solenoid valve through ECM harness connector EN01 terminal No.2.

5. Canister Solenoid Valve (EVAP)




Canister control valve is located in the engine cylinder head cover side (transmission side) and is used to control the Canister clean air flow. ECM controls Canister valve according to engine load, engine temperature, speed and a series of signals. Through an integrated calculation, ECM gives electrical pulse duration and frequency (i.e. duty cycle) to control EVAP. Accumulated fuel vapor in the Canister, can cause environmental pollution once leaking. Canister solenoid valve is opened at the right time, so that the excessive fuel vapor after mixing with air entering into the intake manifold to

participate in combustion. Canister control valve consists of the electromagnetic coils, armature and valves. Canister inlet port has a filter. On one hand, air flow through the Canister control valve is related to ECM to the Canister control valve output electrical pulse duty cycle, on the other hand, it is related to the pressure difference between the Canister inlet port and outlet port. When there is no electrical pulse, the Canister control valve is closed. According to the engine sensors provided signals, ECM controls the Canister solenoid valve power-on time, indirectly controls the air flow amount. When the engine coolant temperature, engine working hours, engine load, etc. meet the preset requirements, ECM will command Canister solenoid valve work. Under the following conditions, Canister will not work:

- Engine cold start.
- Engine coolant temperature is relatively low.
- Engine idling.
- Engine heavy load.
- Important system sensor malfunction.


ECM controls Canister solenoid valve through ECM harness connector EN01 terminal No.37. When the EVAP solenoid valve and circuit are faulty, DTC code P0444, P0458 , P0459 will be recorded.

6. Main Relay




Main relay is controlled by ECM, when turning the ignition switch to "ON" position, battery voltage passes through the ignition switch to ECM 10 A fuse, and finally to ECM harness connector EN01 terminal No.17. ECM detects the terminal voltage, then controls the EN01 terminal No.32 to connect to ground. The main relay starts work and provides power to the Air-Conditioning compressor relay, cooling fan low speed relay, cooling fan high speed relay, pump relay, ECM wiring harness connector EN01 terminals No. 8 and 51, Canister solenoid valve, VVT solenoid valve, ignition coil, fuel injectors, Pre-Catalytic oxygen sensor heating, Post-Catalytic oxygen sensor heating and vehicle speed sensor. So when the main relay is not working properly, the engine will not work. ECM controls the main relay through ECM harness connector EN01 terminal No.32. ECM will not record the main relay associated DTC code.

7. Pump Relay (I) and Fuel Pump



Pump relay is located in the underhood fuse box. fuel pump is installed in the fuel tank. ECM controls fuel pump relay closing and the fuel pump work. The fuel pump and the motor are installed on the same axle inside the housing, and surrounded by fuel, cooled and lubricated by fuel. As the pump relay pulls in, battery provides power through fuel pump relay to fuel pump. Only when fuel pump relay is working and the engine is running, the electric fuel pump circuit is connected. When the engine stops running due to an accident, the fuel pump automatically stops. The electric fuel pump export maximum pressure is determined by the pressure relief valve installed on the fuel pump. The export maximum pressure is between 450 kPa and 650 kPa. Fuel system uses "no-return pipe system", which stabilize fuel pressure at around 400 kPa. ECM controls fuel pump relay through ECM harness connector EN01 terminal No.61. If the pump relay and its circuit are faulty, DTC code P0627, P0628, P0629 will be recorded.

8. High-Speed Cooling Fan Relay (A), Low-Speed Cooling Fan Relay (B)



Two cooling fan relays are in underhood fuse box, mainly used to control the high-low speed cooling fan operation. ECM controls the Low-Speed cooling fan relay through ECM harness connector EN01 terminal No.62. ECM controls the High-Speed cooling fan relay through ECM harness connector EN01 terminal No.52. when the cooling fan relay and the circuit are faulty, DTC code P0480, P0481, P0691, P0692, P0694 will be recorded.

9. Air-Conditioning Compressor Relay

Air-Conditioning compressor relay is located in I/P fuse box, and is an internal integrated type. It is mainly used to control the electromagnetic compressor clutch work. ECM controls Air-Conditioning compressor relay through ECM harness connector EN01 terminal No.60. when the Air-Conditioning compressor relay and the circuit are faulty, DTC code P0645, P0646, P0647 will be recorded. If the relay is damaged, only replace the I/P fuse box.

10. CAN Information Output

ECM sends information to other modules with CAN signals through the CAN network, to achieve network sharing, the most typical signals are: TPS, ECT, engine speed signals and so on. CAN_H signal communicates with other CAN network modules through ECM harness connector EN01 terminal No.33. CAN_L signal communicates with other CAN network modules through ECM harness connector EN01 terminal No.34. If ECM communication with other modules fails, DTC code U0001, U0121, U0140, U0151, P1523 will be recorded.

11. Serial Data Cable Output

The most typical serial data cable output application is the information exchange with the Anti-theft module. Scan tool diagnosis, data flow reading and other operations are also through the serial data cable. ECM harness connector EN01 terminals No.15,23 are for serial data communication.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



2.2.3 System Working Principle

2.2.3.1 System Working Principle

ECM calculates the basic fuel injection duration, Air-Fuel ratio close to the ideal mixture for the engine, and controls engine operation based on the engine's intake air quantity and engine speed signal. For example, in cold start, according to related signals, ECM increases the fuel injection and controls idle speed control valve actuator, to achieve a smooth start and controls the engine idle speed. In addition, ECM also has the fault self-diagnosis and protection function, when the engine fails, ECM can automatically diagnose and preserve the DTC code and, sends a warning through the fault indicator light. The stored code can appear again in certain trigger conditions. Once the sensor or actuator fail, ECM automatically start the backup system, to ensure the safety of the vehicle, maintain the vehicle driving ability. ECM can also communicate with scan tool. Scan tool can be used to read the stored DTC code and scan the current ECM operating system parameters, that is the data stream. Scan tool can also be used to drive the control system actuators for test, which provides a great convenience to diagnostic.

2.2.3.2 Fuel Injection Quantity Adjustment

At Startup, ECM calculates fuel injection time based on the engine speed, engine coolant temperature signal. After startup, ECM determines the basic fuel injection quantity based on the intake manifold absolute pressure sensor. After determining the basic fuel injection quantity, according to the different engine operating conditions, ECM adjusts the fuel injection as following:

- Start Up-Enrich Mixture: Starting condition is when the engine speed is below the specified value, the ignition switch is ON. Especially in the low temperature, in order to improve startup performance, ECM increases fuel injection time, and enriches the mixture.
- After Start-Enrich Mixture: The engine has just started, in order to maintain its running stability, ECM increases fuel injection amount according to the engine coolant temperature.
- Warm Up-Enrich Mixture: The engine temperature is low, gasoline evaporation is poor, ECM provides rich mixture. ECM increases fuel injection amount according to the engine coolant temperature.
- Heavy Load-Enrich Mixture: The engine power output is maximum, in order to ensure the engine work properly, ECM increases fuel injection duration according to throttle position, engine speed, air flow, engine coolant temperature signal. Increased fuel amount is up to 8% -30% of normal fuel injection amount.
- Acceleration-Enrich Mixture: When the engine is accelerating, for it to have dynamic, enrich the mixture. ECM increase the fuel injection amount according to air flow, engine speed, vehicle speed, throttle position (change rate), the engine coolant temperature sensor signal.
- Intake Air Temperature Adjustment: Air density changes as the temperature changes. In order to maintain a more accurate Air-Fuel ratio, ECM uses air density at 20°C (68 °F) as the standard value. ECM adjusts fuel injection according to measured intake air temperature signal. At low temperature, ECM increases fuel injection amount. At high temperature, ECM decreases fuel injection amount. The adjustment is up to 10%.
- idle Stability Adjustment: In the engine control system, when the intake manifold pressure increase, the idle speed drops. ECM adjusts fuel injection amount according to throttle position, engine speed, intake manifold absolute pressure sensor signal.
- Air-Fuel Ratio Feedback Adjustment: ECM adjusts fuel injection amount according to oxygen sensor signal. When engine starts, the mixture will be enriched. With heavy load, the engine coolant temperature below the set temperature and fuel supply cut off operating conditions, ECM is in close-loop control mode.
- Cut Off Fuel Supply: In order to achieve good fuel economy, lower emissions pollution, when the engine is in forced idle state, ECM cut off fuel supply temporarily according to throttle position, engine speed, engine coolant temperature sensor signal. During emergency deceleration, engine over speed, vehicle over speed, fuel supply will also be cut off temporarily.
- Voltage Adjustment: Power supply voltage affects fuel injection amount. When voltage is low, the actual injection duration is shorter than normal and the mixture is lean. It needs to be adjusted. ECM adjusts fuel injection amount according to high or low voltage. Power supply voltage signal is from the battery.

2.2.3.3 Fault Self-Diagnostic and Protection Function

In order to discover the engine electronically controlled gasoline injection system fault in time, and maintain the vehicle basic driving ability when a fault occurs, ECM has a fault diagnostic and self-protection function. ECM is equipped with a dedicated self-diagnostic circuit. When the engine is running, ECM continuously monitors various parts. Once ECM detects an abnormal situation, it will store the fault signal in memory, and displays DTC code.

In order to prevent vehicle can not be driven due to the sensor malfunction. ECM uses pre-stored sensor signals to continue to control engine operation.

For actuators, in order to prevent their failure affect safety, ECM can take measures to ensure the engine safety. At this point, ECM will send out warning signals and stop fuel injection.

In addition, ECM is also equipped with an emergency circuit. When the emergency control circuit receives an abnormal signal, ECM will enable the backup program. The fuel injection amount and ignition timing will be controlled according to the original set-up program, to maintain the vehicle basic driving ability.




دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

2.2.4 Component Locator

2.2.4.1 Fuel Injector, Idle Speed Control Valve and VVT Solenoid Valve




FE02-2002b

Legend

- 1. Fuel Rail Injector Subassembly
- 2. Idle Speed Control Valve
- 3. VVT Solenoid Valve

2.2.4.2 Throttle Position Sensor, Engine Coolant Temperature Sensor, Canister Solenoid Valve and Intake Air Pressure and Temperature Sensor




FE02-2003b

Legend

- 1. Throttle Position Sensor
- 2. Engine Coolant Temperature Sensor
- 3. Canister Solenoid Valve
- 4. Intake Air Pressure and Temperature Sensor

2.2.5 Disassemble View

2.2.5.1 Throttle Body Assembly




FE02-2004b


Legend

- | | |
|--|------------------------------------|
| 1. Idle Air Intake Channel | 5. Throttle Limit Screw |
| 2. Idle Speed Control Valve | 6. Throttle Cable Mounting Bracket |
| 3. Throttle Butterfly Valve Control Components | |
| 4. Throttle Position Sensor | |


2.2.6 Schematic


2.2.6.1 Schematic





FE02-2101b





FE02-2103b

2.2.7 Diagnostic Information and Procedures

2.2.7.1 Diagnostic Description

Before diagnose the control system, please refer to [2.2.2.1 Overview](#) and [2.2.3.1 System Working Principle](#). Understand and become familiar with control system working principle and then start systematic diagnosis, so that in the event of faults it will help determine the correct Diagnostic Steps, more importantly, it will also help to determine whether the customer described situation is normal or not.


Any control system fault diagnosis should start with "Control System Check" as a starting point. "Control System Check" will guide the service personnel to take the next logical step to diagnose the fault. Understand and the correct use of diagnostic flow charts can reduce diagnostic time and avoid misjudging a component.

2.2.7.2 Control System Check

Before the control system check, please do following preliminary checks:

1. Check the battery terminal voltage to ensure an adequate power supply and a stable voltage.
2. Check the battery cables, clean and tighten.
3. Check the easy to access system components whether there are obvious damages that may cause the symptoms, such as vacuum tube damage and the reliability of wiring harness connectors connection.
4. Check control module and battery ground points whether there are copper oxidizing or signs of loosening.
5. Check control system whether it is likely to affect the normal system operation after the installation of aftermarket equipments.

Diagnostic Steps:



No

Refer to [2.11.7.4 Engine Can Not Start](#)

Yes

Step 5 Select engine control module DTC code reading function. Is there any system DTC code?

No

Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 6 Record and clear the DTC code.

Next

Step 7 Verify fault symptoms.

Results	To Step
Fault does not appear.	Yes
Fault appears.	No

No

Go to step 9

Yes

Step 8 Simulate fault symptoms.

Next

Step 9 Check control system whether there is a DTC code.

Results	To Step
DTC Code	Yes
No DTC Code	No

No

Refer to [2.5.7.6 Fault Symptom Table](#)

Yes

Step 10 Repair according to the DTC code. Refer to [2.2.7.11 DTC Code Index](#).


Step 11 Connect the scan tool to a proper operated vehicle. Can the scan tool be turned on?

No

The scan tool failed. Replace the scan tool.

Yes

Step 12 Check datalink connector power supply circuit.



- (a) Turn the ignition switch to "ON" position.
- (b) Measure the voltage between datalink connector IP12 terminal 16 and a reliable ground.

Standard Voltage: 11-14 V


Is the voltage normal?

No

Check if the circuit between terminal 16 and the IF21 fuse open.

Yes

Step 13 Check datalink connector ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Measure the voltage between datalink connector IP12 terminal 4 and a reliable ground.

Standard Resistance: Less than 1 Ω

No

Check if the circuit between terminal 4 and the ground open.

Yes


Step 14 Is the engine running properly?

No

Engine immobilizer control module and ECM communication failure, check and repair the relevant components. Refer to [2.5.7.12 Engine Anti-theft Warning Lamp Flashing, Vehicle Can Not Start](#)

Yes

Step 15 Terminal continuity check.



- (a) Disconnect engine immobilizer control module IP25 wiring harness connector.
- (b) Test the terminal continuity using an ohmmeter.

Connecting Multimeter	Standard Value
IP12(7) - IP25(7)	Less than 1 Ω

- (c) Reconnect the engine immobilizer control module IP25 wiring harness connector.

Normal?

No

Repair or replace the wiring harness connector.

Yes

Step 16 Test to confirm.

Next

Step 17 End.

2.2.7.3 Intermittent Fault Check

Note

1. Clear DTC.
2. Carry out simulation tests.
3. Inspect and shake the wiring harnesses, connectors and terminals.

When DTC checks can not identify the fault, the fault occurs only occasionally in use. At this point you should test and confirm all circuits and components that can possibly lead to the fault. In many cases, carrying out the basic checks flow chart shown in the following can quickly and efficiently identify the Repair the faulty part. especially for harness connector poor contact.

Fault Definition: The fault currently does not appear, but the historical record indicates that the fault has appeared before. Or a customer reported the fault and had it repaired, but because the fault is not relevant to the DTC code, the fault symptoms do not appear.

Diagnostic Steps:

Step 1 Is the battery voltage normal?

- (a) Turn the ignition switch to "OFF" position.
- (b) Measure the battery voltage with a multimeter.

According to the Measure value, choose the appropriate diagnostic step.

Results	To Step
11 V or higher	Yes
Less than 11 V	No

No

Check the battery. Refer to [2.11.2.1 Battery Description and Operation](#)

Yes

Step 2 Check visually and physically.

This step is an important method to initially identify the fault location:

- (a) Check wiring harness for damage, wear and tear.
- (b) Check whether the wiring harness routed properly. Do not place wiring harness near a device with high voltage or high current running through:
 - Such as start motor, generator and other motor components. When these components are working, they will introduce great electromagnetic interference, thus affecting the proper signal transmission, resulting in system not working properly.
 - Ignition coil, ignition wires and other components.
- (c) Check whether there is a vacuum hose cracking, damage or distortion. Confirm the hoses correct connection and routing.
- (d) Check whether there is air intake system leak, for example, throttle body installation surface, idle speed control valve, intake manifold sealing surface and so on.
- (e) Check the engine control module (ECM) ground and the body ground whether there is oxidation, loose, incorrect position. The control system ground can not be changed at will, as this will affect the proper operation of the control system .
- (f) Check whether the battery positive and negative cable connections are reliable, whether there is loose, oxidation, corrosion and so on.

Next

Step 3 Check wiring harnesses and connectors.

- (a) Many intermittent faults are caused by vibration, distortion, uneven roads, improper operation of components or connectors dislocation.
- (b) If the circuit resistance is too high, it may result in components not working properly. Use a scan tool to drive the actuators, if not working, check whether the resistance in the circuit is too high or other faults.

Next

Step 4 Reproduce the fault and use instruments to record engine control module data.

- (a) Connect a scan tool and use the data record function to record road test data. After pressing the vehicle data recorder button, the scan tool can record engine control module data in the event of intermittent fault occurring, and then the data can be used to identify the fault location.
- (b) Another diagnostic method is when the vehicle is driven connect a digital multimeter to the suspicious circuit. Digital multimeter abnormal readings may indicate the fault location.

Next

Step 5 Intermittent malfunction indicator light, but a DTC code is not set in the system.

Following conditions may cause intermittent malfunction indicator light, but the system does not set the DTC codes:

- (a) Relay working abnormally, the engine control module controlled electromagnetic valves or switches causing electromagnetic interference.
- (b) Non-original or aftermarket accessories, such as a phone, alarm, lights or radio equipment, not installed properly.
- (c) Intermittent malfunction indicator light control circuit short to ground.
- (d) Engine control module ground loose.

Next

Step 6 Other checks.

- (a) Test whether Air-Conditioning compressor clutch diodes at both ends and other diodes are in open circuit.
- (b) Check charging system whether there are following conditions existing:
 - Generator rectifier fault within the electrical system may result in the communication signal interference.
 - Generator output voltage is correct or not. If the generator output voltage is lower than 9V or higher than 18V, repair the charging system.

Next

Step 7 Refer to fault symptom table.

2.2.7.4 Fault Symptom Table

If a fault occurred, but no DTC code stored within ECM, or the fault cause can not be identified in the basic checks, you should diagnose or exclude the fault based on the sequence listed in the following table.

Symptoms	Suspected Fault Items	Relevant Sections
Engine does not run.	1. Battery	"Starting/Charging System" in the 2.11.7 Diagnostic Information and Procedures .

Symptoms	Suspected Fault Items	Relevant Sections
<p>Fault Definition: When the ignition switch in the "ST" position, the engine crankshaft is not rotating.</p>	2. Starter	<p>"Engine Immobilizer System" in the 2.5.7 Diagnostic Information and Procedures.</p>
	3. Start Relay	
	4. Ignition Switch	
	5. BCM	
	6. Engine Immobilizer System	
	1. ECM Power Supply Circuit	
<p>Engine does not start, no sign of the vehicle starting.</p> <p>Fault Definition: When ignition switch in the "ST" position, the engine crankshaft rotates, but no sign of the vehicle starting.</p>	2. Crankshaft Position Sensor	This section 2.2.7.29 DTC P0321 P0322 .
	3. Camshaft Position Sensor	This section 2.2.7.31 DTC P0340-P0343 .
	4. Ignition System	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
	5. Fuel Pump Control Circuit	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
	6. Fuel Injector Working Circuit	
	7. ECM	This section 2.2.8.8 Engine Control Module Replacement .
	<p>Engine difficult to start</p> <p>Fault Definition: The engine crankshaft rotation is normal, but the vehicle can not be started in a long time. The engine is eventually started, but it may stop immediately.</p>	1. ECM Power Supply Circuit
2. Engine Coolant Temperature Sensor		This section 2.2.8.6 Engine Coolant Temperature Sensor Replacement .
3. Idle Air Control Valve (IAC) System		This section 2.2.8.1 Idle Air Control Valve Replacement .
4. Fuel Pump Relay, Fuel Pump, Fuel Injector, Fuel Contamination		"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
5. Ignition System: Ignition Wire, Spark Plug, Ignition Coil		"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
6. Excessive Engine Oil in Combustion Chamber and Valve Seal Leakage		"Mechanical System" in the 2.6.7 Diagnostic Information and Procedures .
7. Excessive Carbon Residue in Combustion Chamber		
8. Incorrect Assembly		
9. Incorrect Cylinder Compression Pressure		
<p>Poor idle, Unstable, Inaccurate or Stall</p> <p>Fault Definition: Engine running unstable during idle. In extreme cases, the engine or the vehicle will tremble. With the throttle opening at a certain</p>	1. ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .
	2. Air Cleaner Filter Blocked	---
	3. Fuel Pressure Abnormal	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
	4. Fuel Contamination	
	5. Injector Working Abnormal	

Symptoms	Suspected Fault Items	Relevant Sections	
<p>degree the engine idle speed may fluctuate. Any of above circumstance is likely serious enough to make the engine stall.</p> <p>کاران خودرو در ایران</p>	6. Idle Air Control Valve	This section 2.2.8.1 Idle Air Control Valve Replacement .	
	7. Crankcase Ventilation Valve	"Auxiliary Emissions Control Device" in the 2.4.6 Diagnostic Information and Procedures .	
	8. Evaporative Emission (EVAP) Canister Solenoid Valve	"Auxiliary Emissions Control Device" in the 2.4.6 Diagnostic Information and Procedures .	
	9. Knock Sensor (KS) System Ignition Delay	Ignition System "in the 2.10.7 Diagnostic Information and Procedures	
	10. Spark Plug: Incorrect thermal value, damp, crack, incorrect gap, excessive erosion, excessive carbon residue and contaminated by fuel		
	11. Spark Plug Wire Damage		
	12. Ignition Coil Damage		
	13. Crankshaft Position Sensor	This section 2.2.7.29 DTC P0321 P0322 .	
	14. Excessive Engine Oil in Combustion Chamber or Valve Seals Leakage	"Mechanical System" in the 2.6.7 Diagnostic Information and Procedures .	
	15. Incorrect cylinder compression pressure		
	16. Valve Stagnant or Leaking, Valve Spring Broken, Incorrect Valve Timing		
	17. Excessive Carbon Residue in Combustion Chamber		
	18. Electromagnetic interference (EMI) in voltage circuit may lead to engine Misfire. Use the scan tool to monitor the engine speed to detect electromagnetic interference. Engine speed parameter sudden increase while the actual engine speed is almost no change indicates presence of electromagnetic interference. If there is fault, check whether there is a high voltage part in the vicinity of the ignition control circuit.	---	
	19. Check engine mountings.	"Engine Mechanical System" in the 2.6.8.7 Engine Mount Replacement .	
	Engine stalls only when Air-Conditioning is working. Fault Definition: when Air-Conditioning is working,	1. Air-Conditioning signal circuit	"Air-Conditioning System" in the 8.2.7 Diagnostic Information and Procedures .
		2. Idle Air Control Valve Stagnant	This section 2.2.8.1 Idle Air Control Valve Replacement .

Symptoms	Suspected Fault Items	Relevant Sections
engine speed is not stable or engine stall.	3.ECM	This section 2.2.8.8 Engine Control Module Replacement .
Back fire, Pinging Fault Definition: Unburned gases from the combustion chamber entering into the intake manifold or exhaust system, ignited, producing a very loud pinging sound.	1.ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .
	2. Fuel Pressure Abnormal	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
	3. Fuel Contamination	
	4. Injector Working Abnormal	
	5. Air leakage in intake system and crankcase	
	6. Crankcase Ventilation Valve	"Auxiliary Emissions Control Devices" in the 2.4.6 Diagnostic Information and Procedures .
	7. Knock sensor (KS) system ignition delay too great	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
	8. Spark Plug: Thermal Value Incorrect, Damp, Crack, Gap Incorrect, Excessive Erosion, Excessive Carbon Residue, Contaminated by Fuel	
	9. Spark Plug Wire Damage	
	10. Ignition Coil Damage	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
	11. Engine coolant level too low, thermostat failure	"Engine Cooling System" in the 2.8.7 Diagnostic Information and Procedures .
High Fuel Consumption, Poor Fuel Economy Fault Definition: The actual road test fuel consumption is significantly higher than expected. In addition, the fuel consumption is also significantly higher than the previous road test.	1.ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .
	2. • Air-Conditioning or Defroster Always On • Tire Pressure Incorrect • Vehicle Overload • Accelerate too fast, too frequent	---
	3. Air Cleaner Filter Blocked	---
	4. Poor Fuel Quality, Fuel Contamination	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
	5. Fuel Pressure Abnormal	
	6. Injector Working Abnormal	
	7. Throttle Body Dirty	"Engine Mechanical System" in the 2.6.8.5 Throttle Body Assembly Replacement .
	8. Rich Gas and Air Mixture	This section 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .


Symptoms	Suspected Fault Items	Relevant Sections
	9. Air Leakage In Intake System and Crankcase System	"Auxiliary Emissions Control Devices" in the 2.4.6 Diagnostic Information and Procedures .
	10. Crankcase Ventilation Valve Stagnant	
	11. Knock Sensor (KS) system ignition delay too great	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
	12. Spark Plug: Thermal Value Incorrect, Damp, Crack, Gap Incorrect, Excessive Erosion, Excessive Carbon Residue, Contaminated by Fuel	
	13. Spark Plug Wire Damage	
	14. Ignition Coil Damage	
	15. Engine coolant level too low, thermostat failure	"Engine Cooling System" in the 2.8.7 Diagnostic Information and Procedures .
	16. Excessive engine oil in combustion chamber or valve seals leak	"Engine Mechanical System" in the 2.6.7 Diagnostic Information and Procedures .
	17. Cylinder Compression Pressure Incorrect	
	18. Valve stagnant or leak, broken valve spring, valve timing incorrect	
	19. Excessive Carbon Residue in Combustion Chamber	
	20. Vacuum Hose Cracking or Kink, Connection Unreliable	
	21. Exhaust not Smooth: Three-way Catalytic Converter Plug, Muffler Internal Damage	"Engine Exhaust System" in the 2.7.5 Diagnostic Information and Procedures .
	22. Braking System Dragging or Operation Abnormal	"Braking System" in the 6.4.4 Diagnostic Information and Procedures .
	23. Electromagnetic Interference (EMI) in the voltage circuit may lead to engine Misfire. Use the scan tool to monitor the engine speed to detect electromagnetic interference. Engine speed parameters sudden increase while the actual engine speed is almost no change indicates the presence of electromagnetic interference. If there is a fault, check whether there is a high voltage part in the vicinity of the ignition control circuit.	---

Symptoms	Suspected Fault Items	Relevant Sections	
<p>Surge</p> <p>Fault Definition: When the throttle position is stable the engine power changes. It feels as if the vehicle speed will rise and fall when there is no accelerator pedal position change.</p>	1. ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .	
	2. Air-conditioner Compressor	"Air-Conditioning System" in the 8.2.7 Diagnostic Information and Procedures .	
	3. Heated Oxygen Sensor Abnormal	This section 2.2.7.37 DTC P0560 P0562 P0563 .	
	4. Poor Fuel Quality, Fuel Contamination	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .	
	5. Fuel Pressure Abnormal		
	6. Injector Working Abnormal		
	7. The Air-Fuel Mixture Too Rich	This section 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .	
	8. The Air-Fuel Mixture Too Lean	This section 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .	
	9. Spark Plug: Thermal Value Incorrect, Damp, Crack, Gap Incorrect, Excessive Erosion, Excessive Carbon Residue, Contaminated by Fuel	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .	
	10. Spark Plug Wire Damage		
	11. Ignition Coil Damage		
		12. Intelligent Variable Valve Timing System	"Engine Mechanical System" in the 2.3.7 Diagnostic Information and Procedures .
		13. Vacuum Hose Cracking or Kink, Connection Unreliable	
<p>Power Shortage, Accelerate Pedal Stagnant or Soft to Press</p> <p>Fault Definition: The engine power output is lower than expected. When half-pressing the accelerator pedal, the vehicles accelerates a little or does not accelerate at all.</p>	1. ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .	
	2. Air Cleaner Filter Blocked	---	
	3. Poor Fuel Quality, Fuel Contamination	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .	
	4. Fuel Pressure Abnormal		
	5. Injector Working Abnormal		
	6. The Air-Fuel Mixture Too Rich	This section 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .	
	7. The Air-Fuel Mixture Too Lean		
	8. Knock Sensor (KS) System Ignition Delay Too Great	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .	
	9. Spark Plug: Thermal Value Incorrect, Damp, Crack, Gap Incorrect, Excessive Erosion, Excessive Carbon Residue, Contaminated by Fuel	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .	
	10. Spark Plug Wire Damage		
	11. Ignition Coil Damage		


Symptoms	Suspected Fault Items	Relevant Sections
	12. Crankshaft Position Sensor	This section 2.2.7.29 DTC P0321 P0322 .
	13. Excessive Engine Oil in Combustion Chamber or Valve Seals Leakage	"Engine Mechanical System" in the 2.6.7 Diagnostic Information and Procedures .
	14. Cylinder Compression Pressure Incorrect	
	15. Valve Stagnant, Valve Spring Broken, Valve Timing Incorrect	
	16. Excessive Carbon Residue in Combustion Chamber	"Engine Exhaust System" in the 2.7.5 Diagnostic Information and Procedures .
	17. Intelligent Variable Valve Timing System	
	18. Exhaust Not Smooth: Three-way Catalytic Converter Plug, Muffler Internal Damage	
Pinging, Knocking Fault Definition: The knocking sound increases during acceleration. With the throttle opening changes, the engine will produce a sharp metal knocking sound.	1. ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .
	2. Wrong Fuel Used	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
	3. Fuel Pressure Abnormal	
	4. Injector Working Abnormal	This section 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .
	5. The Air-Fuel Mixture Too Lean	
	6. Knock Sensor (KS) System Ignition Advance Too Great	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
	7. Spark Plug Thermal Value Incorrect	"Engine Cooling System" in the 2.8.7 Diagnostic Information and Procedures .
	8. Engine Cooling System: Engine coolant level is too low. The engine coolant is not the correct type. The engine coolant leaks. The cooling fan is not running.	
	9. Excessive Engine Oil in Combustion Chamber and Valve Seal Leakage	
	10. Cylinder Compression Pressure Too High	"Engine Mechanical System" in the 2.6.7 Diagnostic Information and Procedures .
	11. Excessive Carbon Residue in Combustion Chamber	
	12. Camshaft, Cylinder Head, Piston, Connecting Rod and Bearing Abnormal	

Symptoms	Suspected Fault Items	Relevant Sections
<p>Retardation, Engine Speed Decrease, Engine Speed Instable</p> <p>Fault Definition: When pressing the accelerator pedal, there is no immediate response. This fault may occur at any vehicle speed. The vehicles first starts (for example, after stopping off hours), this fault is usually more pronounced. In severe cases, this fault may lead to engine stall.</p>	1. ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .
	2. Intake Manifold Absolute Pressure (MAP) Sensor	This section 2.2.7.17 DTC P0105 P0106 P0107 P0108 .
	3. Fuel Pressure Abnormal	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
	4. Injector Working Abnormal	
	5. The Air-Fuel Mixture Too Rich	This section 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .
	6. The Air-Fuel Mixture Too Lean	
	7. Ignition System: Spark Plug Abnormal, Ignition Wire Abnormal	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
	8. Knock Sensor (KS) System Ignition Delay Too Great	
	9. Crankshaft Position Sensor	This section 2.2.7.29 DTC P0321 P0322 .
	10. Thermostat Abnormal	"Engine Cooling System" in the 2.8.7 Diagnostic Information and Procedures .
	11. Generators Working Abnormal	"Starting/Charging System" in the 2.11.7 Diagnostic Information and Procedures .
<p>Lack of Fuel Supply, Misfire</p> <p>Fault Definition: After the engine speed increases, there is continuous pulsation, or jitter, usually even more noticeable with the engine load increases. When the engine speed is above 1,500 rpm, the fault does not appear.</p>	1. ECM Power Supply Circuit	This section 2.2.7.37 DTC P0560 P0562 P0563 .
	2. Air Cleaner Filter Blocked	---
	3. Fuel Pressure Abnormal	"Fuel System" in the 2.3.7 Diagnostic Information and Procedures .
	4. Injector Working Abnormal	
	5. Idle Air Control Valve	This section 2.2.8.1 Idle Air Control Valve Replacement .
	6. The Air-Fuel Mixture Too Rich or Too Lean	This section 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .
	7. Knock Sensor (KS) System Ignition Delay Too Great	"Ignition System" in the 2.10.7 Diagnostic Information and Procedures .
	8. Spark Plug: Thermal Value Incorrect, damp, Crack, Gap Incorrect, Excessive Erosion, Excessive Carbon Residue, Contaminated by Fuel	
	9. Spark Plug Wire Damage	
	10. Ignition Coil Damage	
	11. Crankshaft Position Sensor	This section 2.2.7.29 DTC P0321 P0322 .
	12. Excessive Engine Oil in Combustion Chamber or Valve Seals Leakage	"Engine Mechanical System" in the 2.6.7 Diagnostic Information and Procedures .

Symptoms	Suspected Fault Items	Relevant Sections
Lack of Fuel Supply, Misfire Fault Definition: After the engine speed increases, there is continuous pulsation, or jitter, usually even more noticeable with the engine load increases. When the engine speed is above 1,500 rpm, the fault does not appear.	13. Cylinder Compression Pressure Incorrect	
	14. Valve Stagnant or Leakage	
	15. Camshaft Convex Corner Wear	
	16. Valve Timing Incorrect	
	17. Valve Spring Broken	
	18. Excessive Carbon Residue in Combustion Chamber	
	19. Camshaft, Cylinder Head, Piston, Connecting Rod and Bearing Abnormal	
	20. Exhaust Not Smooth: Three-way Catalytic Converter Plug, Muffler Internal Damage	"Engine Exhaust System" in the 2.7.5 Diagnostic Information and Procedures .
	21. Electromagnetic Interference (EMI) in the voltage circuit may lead to engine Misfire. Use the scan tool to monitor the engine speed to detect electromagnetic interference. Engine speed parameters sudden increase while the actual engine speed is almost no change indicates the presence of electromagnetic interference. If there is a fault, check whether there is a high voltage part in the vicinity of the ignition control circuit.	



2.2.7.5 ECM Connector Terminal Table



FE02-5003b

Note:

1. UB represents the battery voltage.
2. If there is no instructions, GND is 0 V or close to 0 V.

Terminal Number	Name	Wire	Terminal Description	Status	Specified Condition
1	-	-	-	-	-
2	AT-CVVT1	0.85 W/L	Intake Variable Cam Timing (Intake)	Idle	GND (<0.85 V)-UB of The PWM Wave
3	A-P-ZUE1I	0.85 W	Ignition Coil 1, Cylinder 4 Control	Idle	GND (<1.8 V)-UB of The PWM Wave clamping voltage (nominal) 400 V
4	AS-LSHHK	0.85 G/B	Post-Catalytic Heated Oxygen Sensor Control	When Heated	GND-UB of The PWM Wave
5	MM-ZUE	1.5 B	Ground (Ignition Ground)	All Status	0 Ω
6	AS-LSHVK	0.85 B/O	Pre-Catalytic Heated Oxygen Sensor Control	When Heated	GND-UB of The PWM Wave

Terminal Number	Name	Wire	Terminal Description	Status	Specified Condition
7	AP-ZUE2I	0.85 Y	Ignition Coil 2, Cylinder 3 Control	Idle	GND (<1.8 V)-UB of The PWM Wave, Clamping Voltage (Nominal) 400 V
8	U-U-UBR	1.5 B/R	Power Supply Controlled by The Main Relay	Ignition Switch "ON"	UB
9	-	-	-	-	-
10	E-S-PSW	0.5 W/V	Air-Conditioning Medium Voltage Switch	On or Off	GND or UB
11	-	-	-	-	-
12	E-S-EL1	0.5 Br/R	Power Steering Switch	On or Off	GND or UB
13	-	-	-	-	-
14	E-S-BR	0.5 G	Sensor Reference Voltage	Ignition Switch "ON"	5 V
15	B-D-DIAK	0.5 B/W	Diagnostic Wire K/Anti-theft Wire W	Sometimes	PWM Wave
16	U-U-UBD	0.5 R	Continuous Power Supply	All Status	UB
17	E-S-KL15	0.5 W/Y	Ignition Switch	Ignition Switch "ON"	UB
18	A-U-5V2	0.5 G	5V Power Supply 2	Ignition Switch "ON"	5 V
19	A-U-5V1	0.5 Br/Y	5V Power Supply 1	Ignition Switch "ON"	5 V
20	-	-	-	-	-
21	A-T-SMB	0.5 O	Idle Air Control Valve Phase B	Sometimes	ND (<0.45 V)-UB of The PWM Wave
22	A-T-SMA	0.5 G/Br	Idle Air Control Valve Phase A	Sometimes	GND (<0.45V)-UB of The PWM Wave
23	AS-SVS	0.5 P	SVS Anti-theft Wire R	When Lights On	<0.85 V
24	E-S-EL2	0.5 L	Air-Conditioning Control Module	Driver Instruction	GND or UB
25	E-A-TANS	0.5 Gy/R	Intake Air Temperature Sensor	Ignition Switch "ON"	0-5 V
26	E-A-DKG	0.5 G/Y	Throttle Body Position Sensor	Idle	
27	-	-	-	-	-
28	-	-	-	-	-
29	E-A-LSHK	0.5 L/Y	Post-Catalytic Heated Oxygen Sensor Control	Idle	
30	E-A-KS1A	0.5 L	Knock Sensor A-Side	Idle	PWM Wave, AB Conjugate Signal

Terminal Number	Name	Wire	Terminal Description	Status	Specified Condition
31	E-A-KS1B	0.5 L/W	Knock Sensor B-Side	Idle	
32	A-S-HR	0.5 B/R	Main Relay	Ignition Switch "ON"	<1.8 V
33	B-D-CANH	0.5 L/R	CAN Bus Interface		
34	B-D-CANL	0.5 Y/R	CAN Bus Interface		
35	A-T-SMC	0.5 L	Idle Air Control Valve Phase C	Sometimes	GND (<0.45 V)-UB of The PWM Wave
36	A-T-SMD	0.5 V/O	Idle Air Control Valve Phase D	Sometimes	GND (<0.45 V)-UB of The PWM Wave
37	A-T-TEV	0.5 B/Y	Canister Valve	Sometimes	GND (<0.85 V)-UB of The PWM Wave
38	-	-	-	-	-
39	M-R-SEN1	0.5 O/G	Sensor Ground 1		
40	M-R-SEN2	0.5 Gr	Sensor Ground 2		
41	E-A-TMOT	0.5 V	Engine Coolant Temperature Sensor Signal	Ignition Switch "ON"	0-5 V
42	E-S-ZYHA	0.5 R/B	Phase Sensor Signal		GND-UB of The PWM Wave
43	M-M-EL1	0.5 B	Ground (Electronics Ground)	All Status	0 Ω
44	E-S-AC	0.5 V/W	Air-Conditioning Switch	Driver Instruction	GND or UB
45	E-A-LSVK	0.5 L/R	Post-Catalytic Heated Oxygen Sensor Control	Ignition Switch "ON"	
46	E-F-DGB	0.5 Gy	Engine Speed Sensor B-Side	Magnetic-electric, Engine Running	Sin/Cos Wave, AB Conjugate Signal
47	E-F-DGA	0.5 G	Engine Speed Sensor A-Side		
48	M-M-ES1	0.5 B	Ground (Power Ground)	All Status	0 Ω
49	A-T-EV2	0.5 Y/V	Injector 3 (Cylinder No.3) Control	When Engine Running	GND (<0.9 V)-UB of The PWM Wave clamping voltage (nominal) 69 V
50	A-T-EV1	0.5 G/L	Injector 1 (Cylinder No.1) Control	When Engine Running	
51	U-U-UBR	0.5 B/R	Power Supply Controlled by The Main Relay	Ignition Switch "ON"	UB

Terminal Number	Name	Wire	Terminal Description	Status	Specified Condition
52	A-S-FAN2	0.5 Lg/R	High-Speed Fan Relay Control	The water temperature reaches the temperature that turns on High-Speed fan.	GND or UB
53	-	-	-	-	-
54	-	-	-	-	-
55	-	-	-	-	-
56	-	-	-	-	-
57	E-F-vfZ	0.5 Y	Vehicle Speed Signal	When the Vehicle is Driven	GND-UB of The PWM Wave
58	-	-	-	-	-
59	E-A-DS	0.5 L/B	Intake Air Pressure Sensor Signal	Ignition Switch "ON"	GND-UB
60	A-S-KOS	0.5 Y/R	Air-Conditioning Compressor Relay Control	ECM Command	GND (<2 V) or UB
61	A-S-EKP	0.5 G/R	Fuel Pump Relay Control	Ignition Switch "ON"	GND (2 V) or the UB
62	A-S-FAN1	0.5 Lg	Low-Speed Fan Relay Control	The water temperature teaches the temperature that turns on Low-Speed fan.	GND (1.35 V) or the UB
63	A-T-EV4	0.5 Y/B	Injector 2 (Cylinder No.2) Control	Engine Running	GND (<0.9 V)-UB of The PWM Wave clamping voltage (nominal) 69 V
64	A-T-EV3	0.5 B/L	Injector 4 (Cylinder No.4) Control	Engine Running	GND (<0.9 V)-UB of The PWM Wave clamping voltage (nominal) 69 V

2.2.7.6 DTC Code Type Definition

Fault Type	Definition
Type 2	Fire-related troubleshooting is generally defined as type 2. For cause of damage to catalytic converters Misfire MIL flashing lights to warn the driver immediately. With the emission deterioration fault caused by misfire, if the corresponding level of misfire is fully detected in three consecutive driving cycles, the MIL lamp is lit. The fault will be deleted after 40 continuous trouble-free warmed-up driving cycles.
Type 3	If a fault is detected in consecutive three driving cycles, the MIL lamp is lit. If the fault has been repaired after 3 consecutive driving cycles, the MIL lamp will be off. The fault will be deleted after 40 continuous trouble-free warmed-up driving cycles.

Type 4	The MIL lamp will be lit in 2.5s when a fault occurs. If the fault has been repaired after 3 consecutive driving cycles, the MIL lamp will be off. The fault will be deleted after 40 continuous trouble-free warmed-up driving cycles.
Type 5	A fault is confirmed after it is detected in 3 consecutive driving cycles, and the fault lamp will not be lit. If the fault is detected as repaired after 3 consecutive driving cycles, the fault has been repaired. The fault will be deleted after 40 continuous trouble-free warmed-up driving cycles.
Type 6	The fault is confirmed as soon as it occurs. The fault will be deleted after 40 continuous trouble-free warmed-up driving cycles. This type of fault does not trigger any lamp and is not readable by a universal scan tool.
Type 7	External testing tools activate the external fuel supply system fault diagnosis path. It is generally used in offline inspection or in a repair station. This type of fault does not trigger any lamp and is not readable by a universal scan tool.
Type 11	It is dedicated to fuel supply system diagnostic path. If a fault has been detected in 3 continuous driving cycles, the MIL lamp will be lit. If the fault is detected as repaired after 4 consecutive driving cycles, the MIL lamp will be off. The fault will be deleted after 40 continuous trouble-free warmed-up driving cycles.
Type 35	To identify and repair the fault is through timing. To remove the fault from the memory needs 20 driving cycle. It is generally readable for a universal scan tool and triggers flashing MIL lamp.
Type 38	To identify and repair the fault is through timing. Removal of the fault from memory is triggered by time. It is generally readable for a universal scan tool

2.2.7.7 DTC Code (DTC) list

DTC Code	Description	Type	Fault Lamp
P000A	Intake VVT Slow Response	5	OFF
P0010	VVT Intake Control Solenoid Valve Open Circuit	3	ON
P0012	The intake VVT is not at the default location when starting.	5	OFF
P0016	Improper Relative Installation Positions Between Camshaft and Crankshaft	3	ON
P0030	Pre-Catalytic Heated Oxygen Sensor Control Circuit Open	3	ON
P0031	Pre-Catalytic Heated Oxygen Sensor Control Circuit Short to Ground	3	ON
P0032	Pre-Catalytic Heated Oxygen Sensor Control Circuit Short to Power Supply	3	ON
P0036	Post-Catalytic Heated Oxygen Sensor Control Circuit Open	3	ON
P0037	Post-Catalytic Heated Oxygen Sensor Control Circuit Short to Ground	3	ON
P0038	Post-Catalytic Heated Oxygen Sensor Control Circuit Short to Power Supply	3	ON
P0053	Pre-Catalytic Heated Oxygen Sensor Internal Resistance Unreasonable	3	ON

DTC Code	Description	Type	Fault Lamp
P0054	Post-Catalytic Heated Oxygen Sensor Internal Resistance Unreasonable	3	ON
P0105	Intake Air Pressure Sensor Signal No Change (Frozen)	3	ON
P0106	Intake Air Pressure Sensor Malfunction	3	ON
P0107	Intake Air Pressure Sensor Circuit Short to Ground	3	ON
P0108	Intake Air Pressure Sensor Circuit Short to Power Supply	3	ON
P0112	Intake Air Pressure Sensor Circuit Voltage Too Low	3	ON
P0113	Intake Air Pressure Sensor Circuit Voltage Too High	3	ON
P0117	Engine Coolant Temperature Sensor Circuit Voltage Too Low	3	ON
P0118	Engine Coolant Temperature Sensor Circuit Voltage Too High	3	ON
P122	Throttle Position Sensor Circuit Voltage Lower Than Minimum Limit	3	ON
P123	Throttle Position Sensor Circuit Voltage Higher Than Maximum Limit	3	ON
P130	Pre-Catalytic Heated Oxygen Sensor Signal Unreasonable	3	ON
P131	Pre-Catalytic Heated Oxygen Sensor Signal Circuit Voltage Too Low	3	ON
P132	Pre-Catalytic Heated Oxygen Sensor Signal Circuit Voltage Too High	3	ON
P0133	Pre-Catalytic Heated Oxygen Sensor Aging	3	ON
P0134	Pre-Catalytic Heated Oxygen Sensor Signal Malfunction	3	ON
P0136	Post-Catalytic Heated Oxygen Sensor Signal Unreasonable	3	ON
P0137	Post-Catalytic Heated Oxygen Sensor Signal Circuit Voltage Too Low	3	ON
P0138	Post-Catalytic Heated Oxygen Sensor Signal Circuit Voltage Too High	3	ON
P0140	Post-Catalytic Heated Oxygen Sensor Signal Circuit Malfunction	3	ON
P0170	Air-Fuel Ratio After Catalyst Unreasonable Comparing to Closed-loop Control Self Learn	7	OFF
P0171	Air-Fuel Ratio After Catalyst Too Lean Comparing to Closed-loop Control Self Learn	7	OFF
P0172	Air-Fuel Ratio After Catalyst Too Rich Comparing to Closed-loop Control Self Learn	7	OFF
P0201	Cylinder No.1 Fuel Injector Control Circuit Open	3	ON
P0202	Cylinder No.2 Fuel Injector Control Circuit Open	3	ON

DTC Code	Description	Type	Fault Lamp
P0203	Cylinder No.3 Fuel Injector Control Circuit Open	3	ON
P0204	Cylinder No.4 Fuel Injector Control Circuit Open	3	ON
P0261	Cylinder No.1 Fuel Injector Control Circuit Short to Ground	3	ON
P0262	Cylinder No.1 Fuel Injector Control Circuit Short to Power Supply	3	ON
P0264	Cylinder No.2 Fuel Injector Control Circuit Short to Ground	3	ON
P0265	Cylinder No.2 Fuel Injector Control Circuit Short to Power Supply	3	ON
P0267	Cylinder No.3 Fuel Injector Control Circuit Short to Ground	3	ON
P0268	Cylinder No.3 Fuel Injector Control Circuit Short to Power Supply	3	ON
P0270	Cylinder No.4 Fuel Injector Control Circuit Short to Ground	3	ON
P0271	Cylinder No.4 Fuel Injector Control Circuit Short to Power Supply	3	ON
P0300	Multiple Cylinder Misfire	2	ON
P0301	Cylinder No.1 Misfire	2	ON
P0302	Cylinder No.2 Misfire	2	ON
P0303	Cylinder No.3 Misfire	2	ON
P0304	Cylinder No.4 Misfire	2	ON
P0321	Speed Reference Point Malfunction	3	ON
P0322	No Crankshaft Position Sensor Pulse Signal (Open or Short Circuit)	3	ON
P0327	Knock Sensor Signal Circuit Voltage Too Low	3	ON
P0328	Knock Sensor Signal Circuit Voltage Too High	3	ON
P0340	Camshaft Position Sensor Unreasonably Installed	3	ON
P0341	Camshaft Position Sensor Poor Connection	3	ON
P0342	Camshaft Position Sensor Circuit Short to Ground	3	ON
P0343	Camshaft Position Sensor Circuit Short to Ground Power Supply	3	ON
P0420	Catalytic Converter Oxygen Storage Capacity Aging (Emission Over the Limit)	3	ON
P0444	Canister Control Valve Control Circuit Open	3	ON
P0458	Canister Control Valve Control Circuit Voltage Too Low	3	ON
P0459	Canister Control Valve Control Circuit Voltage Too High	3	ON
P0480	Cooling Fan Relay Control Circuit Open (Low Speed)	5	OFF
P0481	Cooling Fan Relay Control Circuit Malfunction (High Speed)	5	OFF
P0501	Vehicle Speed Sensor Signal Unreasonable	3	ON
P0506	Idle Control Speed Lower Than Target	3	ON

DTC Code	Description	Type	Fault Lamp
P0507	Idle Control Speed Higher Than Target	3	ON
P0508	Stepper Motor Driver Pin Short to Ground	3	ON
P0509	Stepper Motor Driver Pin Short to Power Supply	3	ON
P0511	Stepper Motor Driver Pin Open Circuit	3	ON
P0560	System Battery Voltage Signal Unreasonable	5	OFF
P0562	Battery Voltage Too Low	5	OFF
P0563	Battery Voltage Too High	5	OFF
P0602	Electronic Control Unit Code Malfunction	3	ON
P0627	Fuel Pump Relay Control Circuit Open	3	ON
P0628	Fuel Pump Relay Control Circuit Short to Ground	3	ON
P0629	Fuel Pump Relay Control Circuit Short to Power Supply	3	ON
P0645	A/C Compressor Relay Control Circuit Open	5	OFF
P0646	A/C Compressor Relay Control Circuit Short to Ground	5	OFF
P0647	A/C Compressor Relay Control Circuit Short to Power Supply	5	OFF
P0650	MIL Lamp Driver Circuit Malfunction	3	ON
P0691	Cooling Fan Relay Control Circuit Short to Ground (Low Speed)	5	OFF
P0692	Cooling Fan Relay Control Circuit Short to Power Supply (Low Speed)	5	OFF
P0694	Cooling Fan Relay Control Circuit Short to Power Supply (High speed)	5	OFF
P1523	Airbag to ECU Signal Interrupted or Incorrect	5	OFF
P1610	Anti-theft Malfunction	38	Blink
P1611	Anti-theft Malfunction	38	Blink
P1612	Anti-theft Malfunction	35	Blink
P1613	Anti-theft Malfunction	35	Blink
P1614	Anti-theft Malfunction	35	Blink
P2088	VVT Intake Control Solenoid Valve Circuit Short to Ground	3	ON
P2089	VVT Intake Control Solenoid Valve Circuit Short to Power Supply	3	ON
P2177	Air-Fuel Ratio Closed-loop Self Learn Higher Than Maximum Limit	11	ON
P2178	Air-Fuel Ratio Closed-loop Self Learn Lower Than Minimum Limit	11	ON
P2187	Air-Fuel Ratio Closed-loop Self Learn Higher Than Maximum Limit (Low Load Zone)	11	ON
P2188	Air-Fuel Ratio Closed-loop Self Learn Lower Than Minimum Limit (Low Load Zone)	11	ON

DTC Code	Description	Type	Fault Lamp
P2195	Pre-Catalytic Oxygen Sensor Aging (Too Lean)	3	ON
P2196	Pre-Catalytic Oxygen Sensor Aging (Too Rich)	3	ON
P2270	Post-Catalytic Oxygen Sensor Aging (Too Lean)	3	ON
P2271	Post-Catalytic Oxygen Sensor Aging (Too Rich)	3	ON
U0001	CAN High-Speed Data Communication Cable Malfunction	6	OFF
U0121	Communication with ABS Controller Interrupted	6	OFF
U0140	Communication with BCM Interrupted	6	OFF
U0151	Communication with airbag control module Interrupted	6	OFF

2.2.7.8 DTC Fail-Safe Table

DTC code	Component	Fail-Safe Operation	Fail-Safe Lifting Condition
P0105, P0106, P0107 and P0108	Intake Manifold Pressure Sensor	ECM Alternative Pressure 1,013 kPa	Eligible Requirements Detected
P0112 and P0113	Intake Manifold Temperature Sensor	ECM Alternative Temperature 20.3°C (68.54 °F)	Eligible Requirements Detected
P0117 and P0118	Engine Coolant Temperature Sensor	ECM Alternative Water Temperature and Load-related Calculations, Up to 90°C (194 °F)	Eligible Requirements Detected
P0560, P0562 and P0563	Battery Voltage	Unreasonable fault occurs, ECM alternative voltage 14V	Eligible Requirements Detected
P0501	Vehicle Speed Sensor	No diagnose for idle, battery voltage, speed reference point	Eligible Requirements Detected
P0321	Speed Sensor Reference Point Signal	When a fault occurs, stop the misfire diagnostics.	Eligible Requirements Detected
P0322	Speed Sensor	NLDG Working	Eligible Requirements Detected
P0122 and P0123	Throttle Position Sensor	Stop fuel self learn and the catalytic converter diagnosis.	Eligible Requirements Detected
P0340, P0341, P0342 and P0343	Phase Sensor	Stop fuel self learn, oxygen sensor diagnosis and speed aging diagnosis.	Eligible Requirements Detected
P0506 and P0507	Idle Stepper Motor	Stop stepper motor self learn.	Eligible Requirements Detected
P1523	Airbag Controller Signal to ECU	Airbag Signal to Stop Fuel Supply Disabled	Eligible Requirements Detected

DTC code	Component	Fail-Safe Operation	Fail-Safe Lifting Condition
P0262, P0261, P0201, P0268, P0267, P0203, P0271, P0270, P0204, P0265, P0264, P0202	Injectors 1,2,3,4	Prolonged Fault, Misfire	Eligible Requirements Detected
P0030, P0031 and P0032	Pre-Catalytic Oxygen Sensor Circuit	Oxygen Sensor Internal Resistance Diagnosis Stop	Eligible Requirements Detected
P0036, P0037 and P0038	Post-Catalytic Oxygen Sensor Circuit	Oxygen Sensor Internal Resistance Diagnosis Stop	Eligible Requirements Detected
P0480, P0481, P0691, P0692 and P0694	High and Low-Speed Cooling Fan Relay	N/A	N/A
P0645, P0646 and P0647	Air-Conditioning Relay	N/A	N/A
P0627, P0628 and P0629	Fuel Pump Relay	Engine Can Not Start	
P0650	MIL Lamp Circuit	N/A	N/A
P0508, P0509, P0511	Stepper Motor Driver Stage Circuit	N/A	N/A
P0444, P0458 and P0459	Canister Driver Stage Circuit	Close Post-Catalytic Oxygen Sensor Control	Eligible Requirements Detected
U0140	BCM and ECM Communication	N/A	N/A
U0121	ABS and ECM Communication	N/A	N/A
U0151	Airbag Controller and ECM Communication	N/A	N/A
U0001	CAN	N/A	N/A
P0606	Electronic Control Unit Code Fault	N/A	N/A
P1610, P1611, P1612, P1613, P1614	Anti-theft Controller	Engine Can Not Start	Turn On Power, Anti-theft Authentication Successful
P0300, P0301, P0302, P10303, P0304	Spark Plug, Fuel Injector, Ignition Coil, etc.	One or More Cylinder Misfire	Restart
P0328, P0327	Knock Sensor	Ignition Angle Delay	Fault Repair, Knock Sensor Working Properly
P000A	VVT	Calculate the basic ignition angle when the camshaft adjustment is no longer considered.	Eligible Requirements Detected
P0012	VVT	Calculate the basic ignition angle when the camshaft adjustment is no longer considered.	Eligible Requirements Detected

DTC code	Component	Fail-Safe Operation	Fail-Safe Lifting Condition
P0016	Crankshaft and Camshaft Relative Installation Position	Misfire cylinder can not be determined. Cylinder group fuel injection.	Eligible Requirements Detected
P0010, P2088, P2089	VVT Circuit	Stop VVT diagnosis.	Eligible Requirements Detected
P0420	Catalytic Converter Oxygen Storage Capacity Aging (Emission Over Limit)	Stop catalytic converter related self learn.	Replace new three-way catalytic converter.
P0053	Pre-Catalytic Heated Oxygen Sensor Internal Resistance Unreasonable	Stop some diagnosis.	Check circuit fault or replace Pre-Catalytic heated oxygen sensor.
P0054	Post-Catalytic Heated Oxygen Sensor Internal Resistance Unreasonable	Stop some diagnosis.	Check circuit fault or replace Post-Catalytic heated oxygen sensor
P0130, P0131, P0132, P0134	Pre-Catalytic Heated Oxygen Sensor Signal Unreasonable	Entering Into Open-loop Control	Check circuit fault or replace Pre-Catalytic heated oxygen sensor.
P0133, P2195, P2196	Pre-Catalytic Heated Oxygen Sensor Aging	No	Replace Pre-Catalytic heated oxygen sensor.
P0136, P0137, P0138, P0140	Check Post-Catalytic heated oxygen sensor signal circuit.	Disconnect the Post-Catalytic heated oxygen sensor.	Check circuit fault or replace the Post-Catalytic heated oxygen sensor.
P2270, P2271	Post-Catalytic Heated Oxygen Sensor Aging	Disconnect the Post-Catalytic heated oxygen sensor.	Replace the Post-Catalytic heated oxygen sensor.
P2177	Air-Fuel ratio close-loop control self learn value is higher than maximum limit.	No Protection Needed	Check fuel line fault.
P2178	Air-Fuel ratio close-loop control self learn value is lower than minimum limit.	No Protection Needed	Check fuel line fault.
P2187	Air-Fuel ratio close-loop control self learn value is higher than maximum limit (Low-Load Zone).	No Protection Needed	Check fuel line fault.
P2188	Air-Fuel ratio close-loop control self learn value is lower than minimum limit (Low-Load Zone).	No Protection Needed	Check fuel line fault.

2.2.7.9 Data Stream List

By reading the "Data Stream List" on the scan tool, you can check switches, sensors, actuators working state without removing any parts. Before the control system diagnosis, observing and analyzing data is the first step, so that the diagnose time could be shortened.

Note

Data under normal conditions is listed in the following table for reference only. Do not determine whether a part is faulty solely based on these reference values. Under normal circumstances you can compare the vehicle that needs to be repaired with a normal working vehicle in the same state to determine the current vehicle diagnostic data is normal or not.

1. Run the engine to reach normal working temperature.
2. Turn the ignition switch to "OFF" position.
3. Connect the scan tool.
4. Turn the ignition switch to "ON" position.
5. Select "Engine"/"Read data stream".
6. Refer to the table and check all the data.

Data Stream Name	Ignition Switch "ON"	Idle Speed	2,500 rpm When	Diagnosis Description
Battery Voltage	12.04 V	13.51 V	13.72 V	ECM monitors the current charging system working conditions.
Engine Speed	0 rpm	800 rpm	2,500 rpm	The scan tool shows the current actual engine speed calculated by ECM through the crankshaft position sensor input.
Target Idle Speed (No Compensation)	800 rpm	800 rpm	1,500 rpm	The scan tool shows the target idle speed set by ECM and the current actual idle speed, said ECM instructions. ECM-based engine coolant temperature sensors signal and compensation signals for various engine loads in order to maintain desired engine idle speed.
Target Idle Speed (With Compensation)	800 rpm	800 rpm	800 rpm	
Vehicle Speed	0 km	0 km	0 km	-
Engine Coolant Temperature Sensor Voltage	0.5 V	0.5 V	0.4 V	The scan tool shows -40°C (-40 °F) to 130°C (266 °F). After heating, sensor (internal resistance decreases) voltage signal reduces. ECM will interpret the reduced voltage signal as engine warmed up. This signal is one of the conditions used to determine whether to activate the closed-loop fuel system control, and also an important injection timing reference signal.
Engine Coolant Temperature	91°C (196 °F)	89°C (192 °F)	94°C (201 °F)	
Intake Air Temperature Sensor	2.5 V	2.5 V	3.0 V	Sensor voltage is the value actually received by ECM. The intake air temperature is calculated by ECM using the received voltage signal according to the program. ECM apply the intake air temperature to adjust the fuel delivery and

Data Stream Name	Ignition Switch "ON"	Idle Speed	2,500 rpm When	Diagnosis Description
Intake Air Temperature	23°C (73.4 °F)	23°C (73.4 °F)	14°C (57.2 °F)	ignition timing according to the air density. The intake air temperature is also compared with the ECT to identify the start up of the heating wire of the heated oxygen sensor and diagnosis of evaporative emissions from cold start.
Ambient Temperature	10°C (50 °F)	10°C (50 °F)	10°C (50 °F)	Varies as the ambient temperature changes.
The Actual Intake Manifold Pressure Sensor Voltage	4.02 V	1.0 V	0.71 V	1. Equal to atmospheric pressure when engine is turned off. 2. Voltage first reduced and then increased when pressing the acceleration pedal hard.
The Actual Intake Manifold Pressure	1,020 kPa (148 psi)	340 kPa (49 psi)	260 kPa (38 psi)	3. After engine is turned off, the data stream shows the pressure is close to atmospheric pressure, voltage close to 5 V.
Intake Air Mass	0.0 g/s	10.2 g/s	29.4 g/s	
Stepper Motor Target Location	69 step	40 step	93 step	After engine is turned off, it shows 110 steps. Warmed vehicle idling state, it is typically about 30 to 45 steps. The number of steps increases as the load increases like Air-Conditioning turned on, up to 70 steps. With the increase in vehicle mileage, the stepper motor opening will increase. After cleaning the stepper motor and the intake air channel next to the throttle body, the steps will not decrease during the startup. But the engine speed will increase.
Throttle Angle ADC Signal	0.55 V	0.56 V	0.70 V	Throttle position sensor voltage is the voltage Measure by ECM. While the angle is calculated according to voltage. When at idle, the voltage is 0.3-0.9V. With full-throttle the voltage is 4.25-4.7V. The voltage increases as the throttle opening increases. The self learn value will become larger and larger when the throttle body is dirty and move up the zero value. After cleaning the throttle, the computer will automatically re-learn.
Calculating Throttle Position and Angle Signal	11.1%	11.23%	14.06%	
Calculating Throttle Position	0%	0%	2%	
Charging Time	3.6 ms	3.0 ms	3.0 ms	-

Data Stream Name	Ignition Switch "ON"	Idle Speed	2,500 rpm When	Diagnosis Description
Average Injector Pulse Width	0.0 ms	3.2 ms	2.4 ms	Scan tool shows 0-16ms. It indicates that in each engine cycle, the number of the engine control module command connected to each injector. The greater the fuel injector pulse width, the more the fuel is injected. Injector pulse width (PWM) increases as the engine load increases. If the engine receives increasing torque signal, it will increase the injection time. Many factors affect the fuel injection time, such as engine coolant temperature sensor, intake air temperature sensor, power supply voltage and fuel pressure.
Cylinder No.1 Spark Advance Angle	0°	6°	33.5°	At normal idle speed, the current ignition system advance angle is 7° ahead of TDC. This value is for repair reference only.
Knock Sensor Signal 1	0 V	0 V	0 V	ECM detects knock sensors amplitude and frequency to control the ignition timing. Ignition timing is placed in the position close to knocking to get the maximum torque.
Knock Sensor Signal 2	0 V	0 V	0 V	
Cylinder No.1 Ignition Delay	0.0°	0.0°	0.0°	
Cylinder No.2 Ignition Delay	0.0°	0.0°	0.0°	
Cylinder No.3 Ignition Delay	0.0°	0.0°	0.0°	ECM calculates according to knock sensor signals. If the knocking is detected, ECM controls the ignition advance angle delay.
Cylinder No.4 Ignition Delay	0.0°	0.0°	0.0°	
Group 1 Oxygen Sensor Integral Value (Short-Term Correction)	1.00	0.99	1.02	Based on feedback from oxygen sensor, increase or decrease the basic injection duration with a temporary value. It is useful only in the closed-loop control. When it is a positive value, ECM will increase the amount of fuel injected by increasing the injection duration. When it is a negative value, ECM will decrease the injection duration. When the short-term value is continuously lower or higher than the theoretical value, ECM will add this value to the long-term fuel value or deduct it from the long-term fuel value, in order to achieve optimum Air-Fuel ratio control.

Data Stream Name	Ignition Switch "ON"	Idle Speed	2,500 rpm When	Diagnosis Description
Group 1 Oxygen Sensor Voltage 1 (Pre-Catalytic Oxygen Sensor)	0.4 V	0.1-0.7 V	0.1-0.7 V	Under normal operating conditions, HO ₂ S output is 0.1-0.9V voltage. ECM receives this voltage signal and measures whether the Air-Fuel ratio is lean or rich. If ECM input signal voltage is lower than 0.45V, the Air-Fuel ratio is lean; if the input signal voltage is above 0.45V, the Air-Fuel ratio is rich. In the closed-loop control, ECM continuously detects HO ₂ S output signal to reduce or increase the fuel injection control pulse width to adjust.
Group 1 Oxygen Sensor Voltage 2 (Post-Catalytic Oxygen Sensor)	0.6 V	0.7 V	0.7 V	The Post-Catalytic oxygen sensor is installed after the catalytic converter or in exhaust pipe. The Post-Catalytic oxygen sensor output voltage is between 0 V-1V. Use the Post-Catalytic oxygen sensor signal to detect the catalytic converter efficiency. If the conversion efficiency of catalytic converters is good, the Post-Catalytic oxygen sensor signal is stable. If the catalytic converter is aging, toxic or Misfire and so on, the conversion efficiency of catalytic converters will decrease. The Post-Catalytic oxygen sensor signal will be similar to the Pre-Catalytic oxygen sensor signal.
Group 1 Oxygen Sensor Integral Value (Long-Term Adjustments)	1.0	1.0	1.0	The long-term fuel adjustment value is stored in ECM memory, because it is calculated as part of the basic injection duration. It will not be deleted when ignition switch is OFF. It affects the closed-loop control and open-loop control injection duration. ECM uses the short-term adjustment value to modify the long-term fuel adjustment value. It can not respond quickly to the instant changes. It only changes when ECM decides to use the short-term fuel adjustment value to adjust the long-term fuel adjustment value. Like the short-term fuel value adjustment, when the long-term value is 0%, it indicates that the basic injection duration does not need adjustment. Positive percentage indicates the fuel injection increase; while a negative percentage indicates the fuel injection decrease. The long-term value is for engine to control the entire range of injection duration. It is divided into two categories; long-term idle and long-term under load. When is engine speed is lower than 920 rpm and the air volume is 24kg/h, it monitors long-term idle. Because the relatively small amount of intake air,

Data Stream Name	Ignition Switch "ON"	Idle Speed	2,500 rpm When	Diagnosis Description
Ultimate Long-term Adjustment Factor	2.2%	2.2%	2.2%	adding more fuel or decrease fuel amount is need to control idle speed. Different from long-term idle, when the engine load is 30-75% and the air volume is 40-200kg/h, it monitors the long-term engine load and uses multiple-tuning to control idle speed.
Intake Camshaft PWM Control	5.86%	5.86%	5.8%	VVT intake camshaft position actuator current actual opening changes from 0% to 100%. The largest advance position is 100% and the maximum lag position is 0%.
Intake Valve Opening (As Opposed to LWOT)	8°	8°	8°	
Camshaft Overlap Angle	494°	494°	494°	
Idle Torque, Self Learn	1.8%	1.8%	1.3%	-
Idle Speed Control Target Torque Adjustment	0.0%	-0.3%	0%	-
Engine Relative Load	100%	18.2%	14.7%	-
Run-Time After a Speed Fault	0 min	0 min	0 min	-
Canister Control to Fuel Injection Amount	0%	0%	1.2%	Using Canister solenoid valve opening duty cycle control, the control signal is the pulse waveform and can be detected with an oscilloscope. This

Data Stream Name	Ignition Switch "ON"	Idle Speed	2,500 rpm When	Diagnosis Description
Canister Control Valve Duty Cycle	0%	0%	100%	parameter shows the evaporative emission control module commands (EVAP) solenoid valve Canister clean-up power supply time or duty cycle. 0% indicates that no clean-up carried out and 100% indicates always clean-up.
Canister Purification Rate	0%	0%	0.1%	Fuel evaporative emission control system prevents hydrocarbons (HC) overflow from the fuel tank into the atmosphere, polluting the environment. Collect the fuel vapor into the Canister. ECM controls solenoid valve (EVAP) to remove Canister collected fuel vapor steam and make it into the engine for combustion. In the actual repair work, compare the data stream to the actual solenoid valve opening. If a leak occurs, it is necessary to know how to determine. Note that only when the engine reaches the normal temperature, the data stream will increase from a small value. When idling or engine cold, the EVAP will not open.
Canister Load	1	3.2	0.7	

2.2.7.10 Action Test Table

By reading the "Action Test Table" on the scan tool, you can check switches, sensors, actuators working state without removing any parts. Before the control system diagnosis, carrying out action test is a prerequisite, so that the diagnose time could be shortened.

Note

Data under normal conditions is listed in the following table for reference only. Do not determine whether a part is faulty solely based on these reference values. Under normal circumstances you can compare the vehicle that needs to be repaired with a normal working vehicle in the same state to determine the current vehicle diagnostic data is normal or not.

1. Run the engine to reach normal working temperature.
2. Turn the ignition switch to "OFF" position.
3. Connect scan tool.
4. Turn the ignition switch to "ON" position.
5. Select "engine"/"action test".
6. Refer to the following table to test.

Scan Tool Display Item	Test Component	Control Range	Diagnosis Description
Fault Indicator	Enable the engine fault indicator.	ON/OFF	When the engine is running (or) the ignition switch is turned on, with the signal accepted, the engine control module will request the fault indicator to light through the CAN bus. The fault indicator will be on or off in 3-5s.

Scan Tool Display Item	Test Component	Control Range	Diagnosis Description
Fuel Pump Relay	Enable the fuel pump relay.	ON/OFF	<p>Note</p> <p>This test can only be carried out when the vehicle speed is equal to zero and vehicle speed sensor has no fault.</p> <p>This function can control the fuel pump relay. Fuel pump relay will be on or off within 3-5s.</p>
Canister Control Valve	Enable the Canister solenoid valve.	ON/OFF	When the command is "ON" the solenoid valve will be on or off within 3-5s.
Fan 1	Enable the Low-Speed cooling fan.	ON/OFF	<p>Note</p> <p>Carry out this test only when the engine coolant temperature is below 100°C (212 °F) and Air-Conditioning is not switched on.</p> <p>This function controls the Low-Speed cooling fan relay. When the instruction is received, the cooling fan will be on at high speed for 5s.</p>
Fan 2	Enable High-Speed cooling fan	ON/OFF	<p>Note</p> <p>Carry out this test only when the engine coolant temperature is below 100°C (212 °F) and Air-Conditioning is not switched on.</p> <p>This function controls the High-Speed cooling fan relay. When the instruction is received, the cooling fan will be on at high speed for 5s.</p>
Air-Conditioning Clutch	Enable the Air-Conditioning compressor clutch.	ON/OFF	<p>Note</p> <p>Carry out this test only when the ignition switch is at "ON" position and the engine is not running.</p> <p>This function controls Air-Conditioning compressor relay. When the instruction is "ON", the Air-Conditioning compressor relay will be on or off in 3-5s.</p>
Fuel Injection Disable	Disable the fuel injection.	ON/OFF	<p>Note</p> <p>This function will not close the two fuel injectors at the same time. perform the test only when the vehicle speed is zero, the speed sensor without fault and oxygen sensor signal indicating a lean Air-Fuel ratio.</p> <p>Disable fuel injectors and test fuel injectors sealing state.</p>

Scan Tool Display Item	Test Component	Control Range	Diagnosis Description
Ignition Delay	Delay the ignition advance angle.	---	---
Idle Speed Control	Control engine speed to the required speed.	<ul style="list-style-type: none"> • 600 rpm • 700 rpm • 800 rpm • 900 rpm • 1,000 rpm • 2,000 rpm 	Control engine speed to the required speed.
Stepper Motor Actuator Test	Test idle control valve to open a few steps.	---	<p>Note</p> <p>Carry out this test only when the engine is not running and the ignition switch is at "ON" position.</p>

2.2.7.11 DTC Code Index

DTC Code	Description	Diagnostic Procedures
P000A	Intake VVT Slow Response	Refer to 2.2.7.13 DTC P000A P0012 .
P0010	VVT Intake Control Solenoid Valve Circuit Open	Refer to 2.2.7.12 DTC P0010 P2088 P2089 .
P0012	VVT Not At the Default Location During Intake Process	Refer to 2.2.7.13 DTC P000A P0012 .
P0016	Unreasonable Camshaft and Crankshaft Relative Installation Position	Refer to 2.2.7.14 DTC P0016 .
P0030	Pre-Catalytic Heated Oxygen Sensor Heating Control Circuit Open	Refer to 2.2.7.15 DTC P0030 P0031 P0032 P0053 .
P0031	Pre-Catalytic Heated Oxygen Sensor Heating Control Circuit Short to Ground	
P0032	Pre-Catalytic Heated Oxygen Sensor Heating Control Circuit Short to Power Supply	
P0036	Post-Catalytic Heated Oxygen Sensor Heating Control Circuit Open	Refer to 2.2.7.16 DTC P0036 P0037 P0038 P0054 .
P0037	Post-Catalytic Heated Oxygen Sensor Heating Control Circuit Short to Ground	
P0038	Post-Catalytic Heated Oxygen Sensor Heating Control Circuit Short to Power Supply	

DTC Code	Description	Diagnostic Procedures
P0053	Pre-Catalytic Heated Oxygen Sensor Internal Heating Resistance Unreasonable	Refer to 2.2.7.15 DTC P0030 P0031 P0032 P0053 .
P0054	Post-Catalytic Heated Oxygen Sensor Internal Heating Resistance Unreasonable	Refer to 2.2.7.16 DTC P0036 P0037 P0038 P0054 .
P0105	Intake Air Pressure Sensor Signal No Change (Frozen)	Refer to 2.2.7.17 DTC P0105 P0106 P0107 P0108 .
P0106	Intake Air Pressure Sensor Unreasonable	
P0107	Intake Air Pressure Sensor Circuit Short to Ground	
P0108	Intake Air Pressure Sensor Circuit Short to Power Supply	
P0112	Intake Air Temperature Sensor Circuit Voltage Too Low	Refer to 2.2.7.18 DTC P0112 P0113 .
P0113	Intake Air Temperature Sensor Circuit Voltage Too High	
P0117	Engine Coolant Temperature Sensor Circuit Voltage Too Low	Refer to 2.2.7.19 DTC P0117 P0118 .
P0118	Engine Coolant Temperature Sensor Circuit Voltage Too High	
P0122	Throttle Position Sensor Circuit Voltage Lower Than Minimum	Refer to 2.2.7.20 DTC P0122 P0123 .
P0123	Throttle Position Sensor Circuit Voltage Higher Than Maximum	
P0130	Pre-Catalytic Heated Oxygen Sensor Signal Unreasonable	Refer to 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .
P0131	Pre-Catalytic Heated Oxygen Sensor Circuit Voltage Too Low	
P0132	Pre-Catalytic Heated Oxygen Sensor Circuit Voltage Too High	
P0133	Pre-Catalytic Heated Oxygen Sensor Aging	
P0134	Pre-Catalytic Heated Oxygen Sensor Circuit Malfunction	
P0136	Oxygen Sensor Signal Unreasonable	
P0137	Post-Catalytic Heated Oxygen Sensor Circuit Voltage Too Low	Refer to 2.2.7.22 DTC P0136 P0137 P0138 P0140 P2270 P2271 .
P0138	Post-Catalytic Heated Oxygen Sensor Circuit Voltage Too High	

DTC Code	Description	Diagnostic Procedures
P0140	Post-Catalytic Heated Oxygen Sensor Signal Malfunction	
P0170	Post-Catalytic Air-Fuel Ratio Closed-loop Control self learn Unreasonable	
P0171	Post-Catalytic Air-Fuel Ratio Closed-loop Control self learn Too Lean	Refer to 2.2.7.23 DTC P0170 P0171 P0172 P2177 P2178 P2187 P2188 .
P0172	Post-Catalytic Air-Fuel Ratio Closed-loop Control self learn Too Rich	
P0201	Cylinder No.1 Fuel Injection Control Circuit Open	Refer to 2.2.7.24 DTC P0201 P0261 P0262 .
P0202	Cylinder No.2 Fuel Injection Control Circuit Open	Refer to 2.2.7.25 DTC P0202 P0264 P0265 .
P0203	Cylinder No.3 Fuel Injection Control Circuit Open	Refer to 2.2.7.26 DTC P0203 P0267 P0268 .
P0204	Cylinder No.4 Fuel Injection Control Circuit Open	Refer to 2.2.7.27 DTC P0204 P0270 P0271 .
P0261	Cylinder No.1 Fuel Injection Control Circuit Short to Ground	Refer to 2.2.7.24 DTC P0201 P0261 P0262 .
P0262	Cylinder No.1 Fuel Injection Control Circuit Short to Power Supply	
P0264	Cylinder No.2 Fuel Injection Control Circuit Short to Ground	Refer to 2.2.7.25 DTC P0202 P0264 P0265 .
P0265	Cylinder No.2 Fuel Injection Control Circuit Short to Power Supply	
P0267	Cylinder No.3 Fuel Injection Control Circuit Short to Ground	Refer to 2.2.7.26 DTC P0203 P0267 P0268 .
P0268	Cylinder No.3 Fuel Injection Control Circuit Short to Power Supply	
P0270	Cylinder No.4 Fuel Injection Control Circuit Short to Ground	Refer to 2.2.7.27 DTC P0204 P0270 P0271 .
P0271	Cylinder No.4 Fuel Injection Control Circuit Short to Power Supply	
P0300	Multi-Cylinder Misfire	
P0301	Cylinder No.1 Misfire	
P0302	Cylinder No.2 Misfire	Refer to 2.2.7.28 DTC P0300-P0304 .
P0303	Cylinder No.3 Misfire	
P0304	Cylinder No.4 Misfire	

DTC Code	Description	Diagnostic Procedures
P0321	Speed Reference Point Fault	Refer to 2.2.7.29 DTC P0321 P0322.
P0322	No CKP sensor Pulse Signal (Open or Short Circuit)	
P0327	Knock Sensor Signal Circuit Voltage Too Low	Refer to 2.2.7.30 DTC P0327 P0328.
P0328	Knock Sensor Signal Circuit Voltage Too High	
P0340	Improper Camshaft Position Sensor Installation Location	Refer to 2.2.7.31 DTC P0340-P0343.
P0341	Camshaft Position Sensor Poor Connection	
P0342	Camshaft Position Sensor Circuit Short to Ground	
P0343	Camshaft Position Sensor Circuit Short to Power Supply	
P0420	Three-way Catalytic Converter Oxygen Storage Capacity Aging (Emission Over Limit)	Refer to 2.2.7.32 DTC P0420.
P0444	Canister Control Valve Control Circuit Open	Refer to 2.2.7.33 DTC P0444 P0458 P0459.
P0458	Canister Control Valve Control Circuit Voltage Too Low	
P0459	Canister Control Valve Control Circuit Voltage Too High	
P0480	Cooling Fan Relay Control Circuit Open (Low Speed)	Refer to 2.2.7.34 DTC P0480 P0481 P0691 P0692 P0693 P0694.
P0481	Cooling Fan Relay Control Circuit Malfunction (High Speed)	
P0501	Vehicle Speed Sensor Signal Unreasonable	Refer to 2.2.7.35 DTC P0501.
P0506	Idle Control Speed Lower Than Target Idle Speed	Refer to 2.2.7.36 DTC P0506-P0509 P0511.
P0507	Idle Control Speed Higher Than Target Idle Speed	
P0508	Stepper Motor Driver Pin Circuit Short to Ground	
P0509	Stepper Motor Driver Pin Circuit Short to Power Supply	
P0511	Stepper Motor Driver Pin Circuit Open	
P0560	System Battery Voltage Signal Unreasonable	Refer to 2.2.7.37 DTC P0560 P0562 P0563.

DTC Code	Description	Diagnostic Procedures
P0562	System Battery Voltage Too Low	
P0563	System Battery Voltage Too High	
P0602	Electronic Control Unit Code Fault	Refer to 2.2.7.38 DTC P0602 .
P0627	Pump Relay Control Circuit Open	Refer to 2.2.7.39 DTC P0627 P0628 P0629 .
P0628	Pump Relay Control Circuit Short to Ground	
P0629	Pump Relay Control Circuit Short to Power Supply	
P0645	A/C Compressor Relay Control Circuit Open	Refer to 2.2.7.40 DTC P0645-P0647 .
P0646	A/C Compressor Relay Control Circuit Short to Ground	
P0647	A/C Compressor Relay Control Circuit Short to Power Supply	
P0650	MIL Lamp Driver Circuit Malfunction	Refer to 2.2.7.41 DTC P0650 .
P0691	Cooling Fan Relay Control Circuit Short to Ground (Low Speed)	Refer to 2.2.7.34 DTC P0480 P0481 P0691 P0692 P0693 P0694 .
P0692	Cooling Fan Relay Control Circuit Short to Power Supply (Low Speed)	
P0693	Cooling Fan Control Circuit Short to Ground (High Speed)	
P0694	Cooling Fan Control Circuit Short to Power Supply (High Speed)	
P1523	Airbag to ECU Signal Interrupted or Incorrect	Refer to 2.2.7.43 DTC P1523 U0001 U0121 U0140 U0151 .
P1610	Anti-theft Malfunction	Refer to 2.2.7.42 DTC P1610-P1614 .
P1611	Anti-theft Malfunction	
P1612	Anti-theft Malfunction	
P1613	Anti-theft Malfunction	
P1614	Anti-theft Malfunction	
P2088	VVT Intake Control Solenoid Valve Circuit Short to Ground	Refer to 2.2.7.12 DTC P0010 P2088 P2089 .
P2089	VVT Intake Control Solenoid Valve Circuit Short to Power Supply	Refer to 2.2.7.12 DTC P0010 P2088 P2089 .
P2177	Air-Fuel Ratio Closed-loop Control self learn Higher Than Maximum Limit	Refer to 2.2.7.23 DTC P0170 P0171 P0172 P2177 P2178 P2187 P2188 .
P2178	Air-Fuel Ratio Closed-loop Control self learn Lower Than Minimum Limit	

DTC Code	Description	Diagnostic Procedures
P2187	Air-Fuel Ratio Closed-loop Control self learn Higher Than Maximum Limit (Low-Load Zone)	Refer to 2.2.7.23 DTC P0170 P0171 P0172 P2177 P2178 P2187 P2188 .
P2188	Air-Fuel Ratio Closed-loop Control self learn Lower Than Minimum Limit (Low-Load Zone)	
P2195	Pre-Catalytic Oxygen Sensor Aging (Too Lean)	Refer to 2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196 .
P2196	Pre-Catalytic Oxygen Sensor Aging (Too Rich)	
P2270	Post-Catalytic Oxygen Sensor Aging (Too Lean)	Refer to 2.2.7.22 DTC P0136 P0137 P0138 P0140 P2270 P2271 .
P2271	Post-Catalytic Oxygen Sensor Aging (Too Rich)	
U0001	CAN High-Speed Communication Bus Malfunction	Refer to 2.2.7.43 DTC P1523 U0001 U0121 U0140 U0151 .
U0121	Communication With ABS Controller Interrupted	
U0140	Communication With BCM Interrupted	
U0151	Communication With airbag control module Interrupted	

2.2.7.12 DTC P0010 P2088 P2089 اولین سامانه دیجیتال

1. DTC Descriptor:

DTC	P0010	VVT Intake Control Solenoid Valve Circuit Open
DTC	P2088	VVT Intake Control Solenoid Valve Circuit Short to Ground
DTC	P2088	VVT Intake Control Solenoid Valve Circuit Short to Power Supply


The intake camshaft position actuator is connected to the intake camshaft and operated by hydraulic pressure. The hydraulic pressure is provided by the engine oil pump in order to change the intake camshaft to the crankshaft relative position (CKP) angle. The intake VVT solenoid valve power supply is provided by The Main Relay. ECM modulates the pulse-width to control signal ground, thus controlling the camshaft position actuator engine oil flow. Engine oil pressure moves the camshaft position actuator slide valve at the front of the camshaft. When the safety slide valve is operated, the engine oil is imported into the camshaft position actuator, so that camshaft rotates. The intake camshaft cam actuator can change the camshaft working angle up to 50°.

ECM controls the solenoid valve internal ground by ECM harness connector EN01 terminal No.2. There is a feedback circuit within ECM. ECM monitors the feedback signals to determine whether there is an open control circuit, or a short to ground circuit or a short to power supply circuit. If ECM detects the control circuit voltage is within a predetermined range, when being disconnected, this DTC code is set.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0010 P2088 P2089	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Solenoid Valve Circuit 2. Solenoid Valve 3. ECM

3. Schematic:




4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Measure VVT solenoid valve assembly resistance.
--------	---



- (a) Disconnect VVT solenoid valve wiring harness connector EN10.
- (b) Measure VVT solenoid valve resistance between the two terminals.

Standard Resistance: 9.4-10.6 Ω (68 °F) when 20°C


- (c) Connect VVT solenoid valve wiring harness connector.

No

Replace VVT solenoid valve assembly. Go to step 6

Yes

Step 2 Measure VVT solenoid valve working power supply voltage.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect VVT solenoid valve wiring harness connector EN10.
- (c) Turn the ignition switch to "ON" position.
- (d) Use multimeter to measure EN10 harness connector terminal No.1.

Standard Voltage: 11-14 V


- (e) Reconnect VVT solenoid valve wiring harness connector EN10.

No

Check open circuit between EN10 solenoid valve wiring harness connector terminal No.1 and the main relay terminal No.3 or short to ground.

Yes

Step 3 Check VVT solenoid valve control circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect VVT solenoid valve wiring harness connector EN10.
- (c) Disconnect ECM harness connector EN01.
- (d) Use multimeter to measure the resistance between VVT solenoid valve wiring harness connector EN10 terminal No. 2 and ECM harness connector EN01 terminal No.2. For the Standard Value. Refer to the table below.
- (e) Use multimeter to measure the resistance between VVT solenoid valve wiring harness connector EN10 terminal No. 2 and the ground. For the Standard Value. Refer to the table below.
- (f) Turn the ignition switch to "ON" position, (Note: At this time EN01 and EN10 connectors must be disconnected.) Use multimeter to measure the voltage between the VVT solenoid valve wiring harness connector EN10 No.2 terminal and the ground. For the Standard Value. Refer to the table below.

Test Connection	Standard Value
Resistance Between EN10 (2) and EN01 (2)	Less than 1 Ω
Resistance Between EN10 (2) and Ground	10 kΩ or higher
Voltage Between EN10 (2) and Ground	0 V

All normal?

No Repair or replace wiring harness connectors.

Yes

Step 4 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 5 Replace ECM.

Next

Step 6 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up engine for at least 5 min.

- (e) Road test the vehicle for at least 10 min.
- (f) Read DTC control system code again to confirm that there is no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 7	Diagnostic completed.
--------	-----------------------

5. Repair Instructions:

Replace VVT solenoid valve. Refer to [2.2.8.4 VVT Solenoid Valve Replacement and Filter Cleaning](#).

2.2.7.13 DTC P000A P0012

1. DTC Descriptor:

DTC	P000A	Intake VVT Slow Response
DTC	P0012	VVT is not at the default location during air intake process.

The intake camshaft position actuator is connected to the intake camshaft and operated by hydraulic pressure. The hydraulic pressure is provided by the engine oil pump in order to change the intake camshaft to the crankshaft relative position (CKP) angle. The intake VVT solenoid valve power supply is provided by The Main Relay. ECM modulates the pulse-width to control signal ground, thus controlling the camshaft position actuator engine oil flow. Engine oil pressure moves the camshaft position actuator slide valve at the front of the camshaft. When the safety slide valve is operated, the engine oil is imported into the camshaft position actuator, so that camshaft rotates. The intake camshaft cam actuator can change the camshaft working angle up to 50°.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P000A	VVT actual angle and target angle difference is too great.	<ol style="list-style-type: none"> 1. VVT actual angle and target angle difference is too great. 2. Camshaft completed self learn. 3. Engine oil temperature is between -40°C (-40 °F) and 120°C (248 °F). 4. Engine coolant temperature is between 0°C (32 °F) and 105°C (221 °F). 5. Engine speed is between 600 rpm to 6,000 rpm. 6. No VVT circuit fault. 	<ol style="list-style-type: none"> 1. Valve Timing Chain 2. VVT Solenoid Valve 3. Solenoid Valve Filter 4. VVT Actuator Assembly 5. ECM

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0012	VVT actual angle is not at the default location.	<ol style="list-style-type: none"> VVT actual angle and target angle difference is greater than or equal to 20°. Camshaft completed self learn. The engine running time is less than or equal to 1.5 s. The engine oil temperature is between -40°C (-40 °F) and 120°C (248 °F) . The engine coolant temperature is between 0°C (32 °F) and 105°C (221 °F) . Engine speed is between 600 rpm to 6,000 rpm. No VVT circuit fault. 	

3. Schematic:

Refer to [2.2.7.12 DTC P0010 P2088 P2089](#).

4. Diagnostic Steps:


Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Check control system whether there are DTC codes other than DTC P0010, P2088, P2089, P000A, P0012.
--------	--

- Connect scan tool to datalink connector.
- Turn the ignition switch to "ON" position.
- Press the scan tool power button.
- Select the following menu items: Engine/Read DTC codes.
- Read DTC codes.

DTC Codes Shown	To Step
DTC P0010, P2088, P2089	Yes
DTC Other Than DTC P0010, P2088, P2089	No




Yes

Step 2	Check the following items.
--------	----------------------------


- Engine oil viscosity and clean circuits are normal.

- (b) Check engine oil level. The engine oil level should be within the range.
- (c) Check if engine oil needs to be replaced or contains additives or engine oil viscosity is not correct.


All normal?



Replace the engine oil and oil filter, when necessary, clean the engine lubrication system.




Step 3 Check VVT solenoid valve resistance.




- (a) Disconnect VVT solenoid valve wiring harness connector EN10.
- (b) Measure VVT solenoid valve resistance between the two terminals.

Standard Resistance: 9.4-10.6 Ω (68 °F) when 20°C




Replace VVT solenoid valve. Refer to [2.2.8.4 VVT Solenoid Valve Replacement and Filter Cleaning](#). Go to step 8




Note
 Connecting two wires directly is strictly prohibited in the testing process, as it might cause an explosion, fire and other dangers.

Step 4 Check VVT solenoid valve operation.



- (a) Connect the battery positive terminal with the VVT solenoid valve terminal No.1 and the negative terminal with the VVT solenoid valve terminal No.2.
- (b) Check the spool operation.


Spool activated?



Replacement VVT solenoid valve. Refer to [2.2.8.4 VVT Solenoid Valve Replacement and Filter Cleaning](#)

Yes

Step 5 Check VVT solenoid valve filter.



- (a) Remove VVT solenoid valve filter.
- (b) Check whether filter is blocked.
- (c) Check whether filter is damaged.
- (d) Re-install VVT solenoid valve filter.


Does VVT solenoid valve filter work properly?

No

Clean VVT solenoid valve filter, if necessary, replace the VVT solenoid valve filter.

Yes

Step 6 Check whether timing system is normal.



- (a) Remove the cylinder head cover.
- (b) Align point D, rotate crankshaft pulley, so that timing mark on the pulley aligned with the marked "0" on the timing chain cover.
- (c) Check point C, make sure the camshaft timing gear timing mark as shown in the graphic aligned with horizontal position.
- (d) Check points A, B point, make sure the distance between intake and exhaust camshaft gear timing marks A and B is 8 timing chain section.
- (e) Re-install the cylinder head cover.

Are timing marks shown as in above graphics?

No

Adjust the valve timing.

Yes

Step 7 Replace VVT actuator assembly.

Next

Step 8	Check control system DTC code.
--------	--------------------------------

- (a) Connect scan tool to datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Press scan tool power button.
- (d) Select the following menu items: Engine/Read DTC codes.
- (e) Read DTC codes.

Are there DTC codes?

No

Intermittent Fault. Refer to [2.2.7.4 Fault Symptom Table](#)

Yes

Step 9	Diagnostic completed.
--------	-----------------------

5. Repair Instructions:

The intake VVT actuator assembly is only replaced as as assembly. Do not repair its disassembled components. For VVT actuator replacement, refer to [2.6.8.12 Camshaft Replacement](#).

2.2.7.14 DTC P0016

1. DTC Descriptor:

DTC	P0016	Unreasonable Camshaft and Crankshaft Relative Installation Position
-----	-------	---

Engine Control Module (ECM) uses crankshaft position sensor (CKP) and camshaft position sensor (CMP) pulse signals to monitor the correlation between crankshaft position and camshaft position. Crankshaft variable reluctance rotor has 60 teeth, of which two missing teeth were used as a reference gap. Each tooth spaces 6° evenly, except the reference gap with a 12° interval. Camshaft signal plate has 4 teeth, 2 narrow teeth and 2 wide ones. Each tooth trailing edge evenly spaces at 90°.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0016	The difference between crankshaft and camshaft synchronization learn value and reference value	1. When camshaft and crankshaft angle difference is greater than 20°, the DTC code is set. When the angle is greater than 25°, the camshaft and the crankshaft adaptive is activated. 2. The camshaft and crankshaft angle difference is greater than the negative 25°.	1. Timing Chain Tensioner 2. Timing Chain 3. Crank Sprocket 4. Exhaust Sprocket 5. VVT Actuator 6. ECM

3. Schematic:

Refer to [2.2.7.29 DTC P0321 P0322](#).

4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Check valve timing system.
--------	----------------------------

- (a) Check whether camshaft, crankshaft and timing chain is correct.
- (b) Check whether timing chain tensioning force is normal.

No

Go to step 4

Yes

Step 2	Check ECM power supply circuit.
--------	---------------------------------

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No

Repair the faulty part.

Yes

Step 3	Replace ECM.
--------	--------------

Next

Go to step 5

Note

Use of Lubrication system cleaner is not recommended. Such cleaning agents contain strong solvent and may have side effects on seals and other engine components.

Step 4	Adjust and repair the mechanical timing system.
--------	---

- (a) Read the vehicle service records and identify whether recent services included the timing chain, camshaft or crankshaft, and whether engine oil change intervals are too long.
- (b) If the engine oil is contaminated or contains impurities, the reasons should be identified. Remove timing chain, camshaft position actuators and the sprocket. Refer to [2.6.8.10 Timing Chain Replacement](#). Remove VVT solenoid valve that filters the engine oil provided to the intake camshaft actuator. Refer to [2.2.8.4 VVT Solenoid Valve Replacement and Filter Cleaning](#). Check filters and oil channel whether there are impurities. Clean filters and replace the filter if necessary.
- (c) If the engine oil pressure is too low, identify causes and carry out necessary repairs.

Next

Step 5	Use scan tool to confirm whether the DTC code is stored again.
--------	--

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.

- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 5 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

Next

Step 6	Diagnostic completed.
--------	-----------------------

2.2.7.15 DTC P0030 P0031 P0032 P0053

1. DTC Descriptor:

DTC	P0030	Pre-Catalytic oxygen sensor heating control circuit open
DTC	P0031	Pre-Catalytic oxygen sensor heating control circuit short to ground
DTC	P0032	Pre-Catalytic oxygen sensor heating control circuit short to power supply


The Pre-Catalytic heated oxygen sensor (HO₂S) is used for fuel control. The sensor compares the oxygen content in ambient air with the oxygen content in exhaust flow. Each heated oxygen sensor has an internal heating element for sensor heating. ECM controls the heated oxygen sensor heating control circuit. This makes the system enter into the closed-loop control mode earlier, so that ECM can calculate Air-Fuel ratio earlier. ECM commands heater control module switched on or off, so that heated oxygen sensor works within the specified working temperature range. Engine control module detects the temperature by Measure the heater current.

The Pre-Catalytic heated oxygen sensor heating coil voltage is provided by The Main Relay, which is controlled by ECM. When the ignition switch is turned to "ON" position, harness connector EN02 terminal No.1 voltage is provided by the battery. ECM controls heater working time through ECM harness connector EN01 terminal No.6.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0030 P0031 P0032	Hardware Circuit Checks	<ol style="list-style-type: none"> 1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply. 	<ol style="list-style-type: none"> 1. Sensor Circuit
P0053	Resistance is greater than the set value.	<ol style="list-style-type: none"> 1. The current Pre-Catalytic oxygen sensor internal resistance is greater than 1500 Ω. 2. The current exhaust gas temperature is between 200°C (392 °F) and 550°C (1,022 °F). 	<ol style="list-style-type: none"> 2. Sensor 3. ECM

3. Schematic:



4. Diagnostic Steps:

Note اولین سامانه دیجیتال خودرو در ایران

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.


Step 1	Initial inspection.
--------	---------------------

Check the existence of following factors that will affect the heated oxygen sensor working status:

- (a) Exhaust system leaks or blockage.
- (b) Water entering into the heated oxygen sensor connector.
- (c) After engine working in high temperatures, whether exhaust pipes are too hot.

Next

Step 2	Check the Pre-Catalytic oxygen sensor heater resistance.
--------	--



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect oxygen sensor wiring harness connector.
- (c) Measure heater resistance between the Pre-Catalytic oxygen sensor terminal No.1 and terminal No.2.
Standard Resistance: 9 Ω(68 °F) at 20°C
- (d) Connect the Pre-Catalytic oxygen sensor wiring harness connector.


Is resistance the specified value?

No

Replace the Pre-Catalytic oxygen sensor.
Refer to [2.4.7.2 Pre-Catalytic Oxygen Sensor Replacement](#)

Yes

Step 3 Check the terminal No.2 to ground voltage.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the Pre-Catalytic oxygen sensor wiring harness connector.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure the Pre-Catalytic oxygen sensor wiring harness connector EN02 terminal No.1 to ground voltage.
Standard Voltage Value: Voltage between the EN02 terminal No.1 and the ground is 11-14 V.
- (e) Connect the Pre-Catalytic oxygen sensor wiring harness connector.

Is voltage the specified values?


No

Pre-Catalytic Oxygen Sensor Power Supply Circuit Fault


Yes

Step 4 Check the Pre-Catalytic oxygen sensor terminal heating control signal continuity.

Pre-catalytic Oxygen Sensor Harness Connector EN02



ECM Harness Connector EN01



FE02-5011b

- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the Pre-Catalytic oxygen sensor wiring harness connector EN02.
- (c) Disconnect ECM harness connector EN01.
- (d) Test continuity between the Pre-Catalytic oxygen sensor wiring harness connector EN02 terminal No.2 and ECM harness connector EN01 terminal No.6.

Standard Resistance: Less than 1 Ω

- (e) Connect ECM harness connector EN01.
- (f) Connect the Pre-Catalytic oxygen sensor wiring harness connector EN02.

Is resistance the specified value?

No ECM control circuit malfunction

Yes

Step 5 Check ECM working circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuits is normal.

No Repair the faulty part.

Yes

Step 6 Replace ECM. Refer to [2.2.8.8 Engine Control Module Replacement](#).

Next

Step 7 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 5 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 8 Diagnostic completed.

5. Repair Instructions:

Replace the Pre-Catalytic oxygen sensor. Refer to [2.4.7.2 Pre-Catalytic Oxygen Sensor Replacement](#).

2.2.7.16 DTC P0036 P0037 P0038 P0054

1. DTC Descriptor:

DTC	P0036	Post-Catalytic Oxygen Sensor Heating Control Circuit Open
DTC	P0037	Post-Catalytic Oxygen Sensor Heating Control Circuit Short to Ground
DTC	P0038	Post-Catalytic Oxygen Sensor Heating Control Circuit Short to Power Supply
DTC	P0054	Post-Catalytic Oxygen Sensor Heating Resistance Unreasonable


The Post-Catalytic heated oxygen sensor (HO₂S) is used for monitoring three-way catalytic converter working status. The sensor compares the oxygen content in ambient air with the oxygen content in exhaust flow. Each heated oxygen sensor has an internal heating element for sensor heating. ECM controls the heated oxygen sensor heating control circuit. This makes the system enter into the closed-loop control mode earlier, so that ECM can calculate Air-Fuel ratio earlier. ECM commands heater control module switched on or off, so that heated oxygen sensor works within the specified working temperature range. Engine control module detects the temperature by Measure the heater current.

The Post-Catalytic heated oxygen sensor heating coil voltage is provided by The Main Relay, which is controlled by ECM. When the ignition switch is turned to "ON" position, the Post-Catalytic oxygen sensor harness connector EN03 terminal No.1 voltage is provided by the battery. ECM controls heater working time through ECM harness connector EN01 terminal No.4.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0036 P0037 P0038	Hardware Circuit Checks	<ol style="list-style-type: none"> 1. Circuit Open 2. Circuit Short to Ground 3. Circuit Short to Power Supply 	<ol style="list-style-type: none"> 1. Sensor Circuit 2. Sensor 3. ECM
P0054	The current resistance is greater than the set value.	<ol style="list-style-type: none"> 1. The oxygen sensor current internal resistance is greater than 1700 Ω. 2. The current exhaust gas temperature is between 200°C (392 °F) and 550°C (1,022 °F). 	

3. Schematic:



4. Diagnostic Steps:

Note اولین سامانه دیجیتال خودرو در ایران

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.


Step 1	Initial Inspection
--------	--------------------

Check the existence of following factors that will affect the oxygen sensor working status:

- (a) Exhaust system leaks or blockage.
- (b) Water entering into heated oxygen sensor connector.
- (c) After engine worked in high temperatures, check whether exhaust pipes are too hot.

Next

Step 2	Check the Post-Catalytic oxygen sensor heater resistance.
--------	---



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the post-catalytic oxygen sensor wiring harness connector.
- (c) Measure the Post-Catalytic oxygen sensor heater resistance. Standard Resistance: Between connector No.1 and No.2, 9 Ω (68 °F) at 20°C
- (d) Connect the post-catalytic oxygen sensor wiring harness connector.


Is the resistance the specified value?

No

Replace oxygen sensor. Refer to [2.4.7.1 Post-Catalytic Oxygen Sensor Replacement](#)

Yes

Step 3 Check the terminal No.2 to ground voltage.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the post-catalytic oxygen sensor wiring harness connector.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure the Post-Catalytic oxygen sensor harness connector EN03 terminal No.1 to ground voltage. Standard Voltage: 11-14 V
- (e) Connect the post-catalytic oxygen sensor wiring harness connector EN03.

Is voltage the specified values?


No

The Post-Catalytic oxygen sensor heater power supply circuit malfunction.


Yes

Step 4 Check the Post-Catalytic oxygen sensor heater control terminal continuity.

Post-catalytic Oxygen Sensor Harness Connector EN03



ECM Harness Connector EN01



FE02-5015b

- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the post-catalytic oxygen sensor wiring harness connector EN03.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure the continuity between the post-catalytic oxygen sensor wiring harness connector EN03 terminal No.2 and ECM harness connector EN01 terminal No.4.

Standard Resistance: Less than 1 Ω

- (e) Connect ECM harness connector EN01.
- (f) Connect the post-catalytic oxygen sensor wiring harness connector EN03.

Is resistance the specified value?

No ECM control circuit malfunction

Yes

Step 5 Check ECM working circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 6 Replace ECM. Refer to [2.2.8.8 Engine Control Module Replacement](#).

Next

Step 7 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 5 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 8	Diagnostic completed.
--------	-----------------------

5. Repair Instructions:

Replace the post-catalytic oxygen sensor. Refer to [2.4.7.1 Post-Catalytic Oxygen Sensor Replacement](#).

2.2.7.17 DTC P0105 P0106 P0107 P0108

1. DTC Descriptor:

DTC	P0105	Intake Air Pressure Sensor Signal No Change (Frozen)
DTC	P0106	Intake Air Pressure Sensor Unreasonable
DTC	P0107	Intake Air Pressure Sensor Circuit Short to Ground
DTC	P0108	Intake Air Pressure Sensor Circuit Short to Power Supply

Intake Air Pressure Sensor responds to the pressure changes within the intake manifold. Pressure varies according to engine load. The sensor circuit consists of the following:

- 5V Reference Voltage Circuit
- Low Reference Voltage Circuit
- Sensor Signal Circuit


ECM provides EN16 5 V reference voltage through ECM harness connector EN01 terminal No.19 to the sensor harness connector EN16 terminal No.3. At the same time ECM provides a low reference voltage through EN01 terminal No.40 to the sensor harness connector EN16 terminal No.1. The sensor provides a signal through EN16 terminal No.4 to ECM harness connector EN01 terminal No.59, and the signal is related to the intake manifold pressure change. When the intake manifold absolute pressure is low, ECM detected signal voltage will be low, such as at idle or during deceleration. When the intake manifold absolute pressure is high, ECM detected signal voltage will be high, such as when the ignition switch is turned on and the engine is turned off, or when the throttle fully open. Sensors are also used to determine the atmospheric pressure such as When the ignition switch is turned on and the engine is turned off. As long as the engine running with the throttle fully open, atmospheric pressure readings will also be updated. ECM monitors sensor signals in order to determine whether the voltage is beyond the normal range.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0105	Signal Inspection: The pressure does not decrease after starting.	1. The pressure drop is less than 2 kPa after starting. 2. Engine speed is greater than 800 rpm.	1. Sensor Circuit 2. Sensor
P0106	Signal Unreasonable	Pressure Sensor Displayed Pressure.	3. ECM
P0107	Circuit Inspection, Over the Maximum Limit	Pressure sensor voltage is less than 0.1 V.	

P0108	Circuit Inspection, Lower Than the Maximum Limit	Pressure sensor voltage is greater than 4.9 V.
-------	--	--

3. Schematic:



4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

Check the existence of the following conditions:


- (a) Sensor Housing Damage, Broken Vacuum Tubes.
- (b) Sensor Seal Damage.
- (c) Sensor Loose or Not Properly Installed.
- (d) Sensor Tube blockage.

Next

Note

It is not allowed to connect intake manifold absolute pressure sensor 5 V reference voltage circuit and other components of the vehicle, as this will damage the sensors and ECM.

Step 2 Measure intake manifold absolute pressure sensor 5 V reference voltage.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake manifold absolute pressure sensor wiring harness connector EN16.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure intake manifold absolute pressure sensor wiring harness connector EN16 terminal No.3 to a reliable ground voltage.

Standard Voltage: 4.5V-5.5V

- (e) Connect intake manifold absolute pressure sensor wiring harness connector EN16.


Is voltage the specified value?

No

Go to step 6

Yes

Step 3 Measure sensor signal circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake manifold absolute pressure sensor wiring harness connector EN16.
- (c) Turn the ignition switch to "ON" position.
- (d) Between EN16 terminal No.3 and No.4, connect a 5A fuse wire. Use scan tool to read "the actual intake manifold absolute pressure sensor voltage" parameter.

Standard Parameter: 4.5V-5.5V

- (e) Connect intake manifold absolute pressure sensor wiring harness connector EN16.

Is data normal?


No

Go to step 7

Yes

Step 4 Measure intake manifold absolute pressure sensor ground circuit.

Intake Air Pressure Temperature Sensor Harness Connector EN16



FE02-5019b

- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake manifold absolute pressure sensor wiring harness connector EN16.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure resistance between intake manifold absolute pressure sensor wiring harness connector EN16 terminal No. 1 and a reliable ground.

Standard Value: Less than 3 Ω

- (e) Connect intake manifold absolute pressure sensor wiring harness connector EN16.

Is resistance normal?

No Go to step 8


Yes

Step 5 Replace intake manifold absolute pressure sensor.


Next Go to step 10

Step 6 Check sensor 5 V reference voltage circuit.

Intake Air Pressure Temperature Sensor Harness Connector EN16



ECM Harness Connector EN01




FE02-5020b

- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake manifold absolute pressure sensor wiring harness connector EN16.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure the resistance between intake manifold absolute pressure sensor harness connector EN16 terminal No.3 and ECM harness connector terminal No.19. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure the resistance between intake manifold absolute pressure sensor wiring harness connector EN16 terminal No. 3 and a reliable ground. Check whether there is a circuit short to ground . If there is no short circuit, repair the faulty part.
- (f) Measure the voltage value between intake manifold absolute pressure sensor wiring harness connector EN16 terminal No. 3 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN16 (3) and EN01 (19)	Less than 1 Ω
Resistance Between EN16 (3) and A Reliable Ground	10 kΩ or higher
Voltage Between EN16 (3) and A Reliable Ground	0 V

Next Go to step 9

Step 7 Check sensor signal circuit.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake manifold absolute pressure sensor wiring harness connector EN16.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between intake manifold absolute pressure sensor harness connector EN16 terminal No.4 and ECM harness connector terminal No.59. Check whether the circuit is open. If there is no open circuit, repair faulty part.
- (e) Measure resistance between intake manifold absolute pressure sensor harness connector EN16 terminal No.4 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair faulty part.
- (f) Measure voltage between intake manifold absolute pressure sensor harness connector EN16 terminal No.4 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair faulty part.

Test Items	Standard Value
Resistance Between EN16 (4) and EN01 (59)	Less than 1 Ω
Resistance Between EN16 (4) and A Reliable Ground	10 kΩ or higher
Voltage Between EN16 (4) and A Reliable Ground	0 V

Normal ➤ Go to step 9

Step 8 Check sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake manifold absolute pressure sensor wiring harness connector EN16.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between intake manifold absolute pressure sensor harness connector EN16 terminal No.1 and ECM harness connector terminal No.40. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure voltage between intake manifold absolute pressure sensor harness connector EN16 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN16 (1) and EN01 (40)	Less than 1 Ω
Voltage Between EN16 (1) and A Reliable Ground	0 V

Execute next step as per normal.

Next

Step 9 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 10 Replace ECM.

Next

Step 11 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Read control system DTC code again to confirm that the system has no DTC code.

No Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 12	Diagnostic completed.
---------	-----------------------

5. Repair Instructions:

Replace the MAP sensor. Refer to [2.2.8.7 Intake Air Pressure and Temperature Sensor Replacement](#).

Refer to [2.2.8.8 Engine Control Module Replacement](#) Replace ECM.

2.2.7.18 DTC P0112 P0113

1. DTC Descriptor:

DTC	P0112	Intake Air Temperature Sensor Signal Voltage Too Low
DTC	P0113	Intake Air Temperature Sensor Signal Voltage Too High

The sensor is an integrated part of the engine intake pressure sensor for Measure the temperature of air entering the engine. ECM provides 5 V reference voltage through ECM harness connector EN01 terminal No.25 to the intake air pressure and temperature sensor wiring harness connector EN16 terminal No.2. At the same time it provides ECM internal low reference voltage through EN01 terminal No.40 to intake air pressure and temperature sensor EN16 terminal No.1. When the intake air pressure and temperature sensors is cold, the thermistor value used to measure temperature is high. When the air temperature rises, the resistance decreases. When the resistance is higher, ECM will detect the signal circuit with a higher voltage. With the decrease of resistance, ECM detected intake air temperature signal circuit voltage also decreases.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0112 P0113	1. More Than the Upper Limit 2. Less than the Lower Limit	1. Short to ground. Intake air temperature is higher than 138°C (280.4 °F). 2. Short to power supply. Intake air temperature is less than -38.3°C (-36.9 °F). 3. Startup time more than 240 s. 4. Engine idle.	1. Sensor Circuit 2. Sensor 3. ECM

3. Schematic:

Refer to [2.2.7.17 DTC P0105 P0106 P0107 P0108](#) in schematics.

4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

Check the existence of the following conditions:

- (a) Sensor Housing Damage
- (b) Sensor Loose or Not Properly Installed


(c) Sensor Wiring Harness Connector Loose

Next

Note

It is not allowed to connect intake manifold absolute pressure sensor 5 V reference voltage circuit and other components of the vehicle, as this will damage the sensors and ECM.

Step 2 Measure intake air temperature sensor resistance.




- (a) Turn the ignition switch to "OFF" position.
 - (b) Disconnect intake air pressure and temperature sensor wiring harness connector EN16.
 - (c) Measure intake air temperature sensor resistance. Standard Resistance (Refer to the specific parameters [2.2.1.2 Temperature Sensor Temperature and Resistance Correlation](#)): 20°C (68 °F) 2,400 Ω
 - (d) Connect intake air pressure and temperature sensor wiring harness connector EN16.
- Is resistance the specified value?

No → Replace intake air pressure and temperature sensor. Go to step 9

Yes

Step 3 Measure intake air temperature sensor signal.




- (a) Turn the ignition switch to "OFF" position.
 - (b) Disconnect intake air pressure and temperature sensor wiring harness connector EN16.
 - (c) Turn the ignition switch to "ON" position.
 - (d) Measure voltage between intake air pressure and temperature sensor wiring harness connector EN16 terminal No.2 and a reliable ground. Standard Voltage: 4.7-5.5 V
 - (e) Connect intake air pressure and temperature sensors connector EN16.
- Is voltage normal?

No → Go to step 5

Yes

Step 4 Measure intake air temperature sensor to ground circuit.

Intake Air Pressure Temperature
Harness Connector EN16



FE02-5026b

- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake air pressure and temperature sensor wiring harness connector EN16.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure resistance between intake air pressure and temperature sensor wiring harness connector EN16 terminal No.1 and a reliable ground.

Standard Resistance: Less than 3 Ω


- (e) Connect intake air pressure and temperature sensors wiring harness connector EN16.

Is resistance normal?


No	Go to step 6
Yes	Go to step 7

Step 5 Check intake air temperature sensor signal circuit.

Intake Air Pressure Temperature
Harness Connector EN16



ECM Harness Connector EN01




FE02-5027b

- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake air pressure and temperature sensor wiring harness connector EN16.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between intake air pressure and temperature sensor wiring harness connector EN16 terminal No.2 and ECM harness connector terminal No.25. Check whether the circuit is open.
- (e) Measure resistance between intake air pressure and temperature sensor wiring harness connector EN16 terminal No.2 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure voltage between intake air pressure and temperature sensor wiring harness connector EN16 terminal No.2 and a reliable ground. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN16 (2) and EN01 (25)	Less than 1 Ω
Resistance Between EN16 (2) and a Reliable Ground	10 kΩ or higher
Voltage Between EN16 (2) and a Reliable Ground	0 V

Next	Go to step 7
------	--------------

Step 6 Check intake air temperature sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect intake air pressure and temperature sensor wiring harness connector EN16.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between intake air pressure and temperature sensor wiring harness connector EN16 terminal No.1 and ECM harness connector terminal No.40. Check whether the circuit is open. If there is no open circuit,repair the faulty part.
- (e) Measure voltage between intake air pressure and temperature sensor wiring harness connector EN16 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit,repair the faulty part.

Test Items	Standard Value
Resistance Between EN16 (1) and EN01 (40)	Less than 1 Ω
Voltage Between EN16 (1) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 7 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 8 Replace ECM.

Next

Step 9 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Read control system DTC code again to confirm that the system has no DTC code.

No Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 10	Diagnostic completed.
---------	-----------------------

5. Repair Instructions:

Replace intake air pressure and temperature sensor. Refer to [2.2.8.7 Intake Air Pressure and Temperature Sensor Replacement](#).

2.2.7.19 DTC P0117 P0118

1. DTC Descriptor:

DTC	P0117	Engine Coolant Temperature Sensor Circuit Voltage Too Low
-----	-------	---


DTC	P0118	Engine Coolant Temperature Sensor Circuit Voltage Too High
-----	-------	--

ECT sensor is a variable resistor with negative temperature coefficient and is used to measure engine coolant temperature. ECM provides 5V voltage through ECM harness connector EN01 terminal No.41 ECT sensor harness connector EN23 terminal A. It also provides a low reference voltage through EN01 terminal No.40 to the ECT sensor connector EN23 terminal C. ECM will always record the length of time the ignition switch off. When starting if it reaches the set ignition switch off time, the engine control module will compare the engine coolant temperature and intake air temperature in order to determine whether the temperature difference is within the normal working range.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0117	1. More Than the Upper Limit	1. Short to Ground. The engine coolant temperature is higher than 140°C (284 °F).	1. Sensor Circuit
P0118	2. Lower Than the Lower Limit	2. Short to power supply. The engine coolant temperature is lower than -37.5°C (-35.5 °F).	2. Sensor 3. ECM

3. Schematic:



4. Diagnostic Steps:

Warning!

Refer to "Cooling System Servicing Warning" in "Warnings and Notices".

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Note

It is not recommended at any time to use flammable anti-freezer, such as alcohol. Combustible anti-freezer can cause serious fires.


Step 1	Initial Inspection
--------	--------------------

- (a) Check the engine coolant temperature sensor whether there is evidence of corrosion, as well as the engine coolant leaking through the sensor.
- (b) Check the cooling system whether the engine coolant level is correct.

Next

Step 2	Measure engine coolant temperature sensor resistance.
--------	---

Engine Coolant Temperature



FE02-5030b

- Turn the ignition switch to "OFF" position.
- Disconnect the engine coolant temperature sensor wiring harness connector EN23.
- Measure engine coolant temperature sensor resistance. Standard Resistance (Refer to the specific parameters [2.2.1.2 Temperature Sensor Temperature and Resistance Correlation](#)): 2400 Ω (68 °F) at 20°C
- Connect the engine coolant temperature sensor wiring harness connector EN23.

Is resistance the specified value?


No

Replace the engine coolant temperature sensor. Go to step 9

Yes

Step 3 Measure engine coolant temperature sensor signal circuit.

Engine Coolant Temperature Sensor Harness Connector EN23



FE02-5031b

- Turn the ignition switch to "OFF" position.
- Disconnect the engine coolant temperature sensor wiring harness connector EN23.
- Turn the ignition switch to "ON" position.
- Measure voltage between engine coolant temperature sensor EN23 terminal A and a reliable ground. Standard Voltage: 4.7-5.5 V
- Connect the engine coolant temperature sensor wiring harness connector EN23.

Is voltage normal?


No

Go to step 5

Yes

Step 4 Measure engine coolant temperature sensor ground circuit.

Engine Coolant Temperature Sensor Harness Connector EN23



FE02-5032b

- Turn the ignition switch to "OFF" position.
- Disconnect the engine coolant temperature sensor wiring harness connector EN23.
- Turn the ignition switch to "ON" position.
- Measure resistance between engine coolant temperature sensor wiring harness connector EN23 terminal No.C and a reliable ground. Standard Resistance: Less than 3 Ω
- Connect the engine coolant temperature sensor wiring harness connector EN23.

Is resistance normal?


No

Go to step 6

Yes

Go to step 7

Step 5 Check the engine coolant temperature sensor signal circuit.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the engine coolant temperature sensor wiring harness connector EN23.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between engine coolant temperature sensor wiring harness connector EN23 terminal A and ECM harness connector terminal No.41. Check whether the circuit is open.
- (e) Measure resistance between engine coolant temperature sensor wiring harness connector EN23 terminal A and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure voltage between engine coolant temperature sensor wiring harness connector EN23 terminal A and a reliable ground. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN23 (A) and EN01 (41)	Less than 1 Ω
Resistance Between EN23 (A) and a Reliable Ground	10 kΩ or higher
Voltage Between EN23 (A) and a Reliable Ground	0 V

Next

Go to step 7

Step 6 Check the engine coolant temperature sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the engine coolant temperature sensor wiring harness connector EN23.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between engine coolant temperature sensor wiring harness connector EN23 terminal C and ECM harness connector terminal No.40. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure voltage between engine coolant temperature sensor wiring harness connector EN23 terminal C and a reliable ground. Check whether there is a short circuit. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN23 (C) and EN01 (40)	Less than 1 Ω
Voltage Between EN23 (C) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 7 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No → Repair the faulty part.

Yes

Step 8 Replace ECM.

Next

Step 9 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Read control system DTC code again to confirm that the system has no DTC code.

No → Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 10	Diagnostic completed.
---------	-----------------------

5. Repair Instructions:

Replace the engine coolant temperature sensor. Refer to [2.2.8.6 Engine Coolant Temperature Sensor Replacement](#).

2.2.7.20 DTC P0122 P0123

1. DTC Descriptor:

DTC	P0122	Throttle Position Sensor Circuit Voltage Lower Than Minimum
DTC	P0123	Throttle Position Sensor Circuit Voltage Higher Than Maximum


The actual throttle position will be compared with throttle position determined by the engine load. Engine Control Module (ECM) detects the engine load by intake manifold absolute pressure sensor (MAP) signal. After further comparison, ECM determines whether there is a sensor fault and set the corresponding DTC codes.

- ECM provides 5 V reference voltage through ECM harness connector EN01 terminal No.39 to TPS sensor harness connector EN27 terminal No.1.
- TPS provides sensor signal voltage through EN27 terminal No.3 to ECM harness connector EN01 terminal No.26.
- ECM provides low reference voltage through ECM harness connector EN01 terminals No.14 and No.18 to TPS sensor harness connector EN27 terminal No.2.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0122 P0123	1. Higher Than Throttle Position and Angle Signals Maximum Limit 2. Lower Than Throttle Position and Angle Signals Minimum Limit	1. Throttle Position angle signal is greater than 99%. 2. Throttle Position angle signal is less than 1.2%. 3. Engine speed is greater than 800 rpm.	1. Sensor Circuit 2. Sensor 3. ECM

3. Schematic:



4. Diagnostic Steps:

Note


Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

- (a) Check whether there is a loose sensor wiring harness connector.
- (b) Check whether a damages sensor.

Next

Step 2	Measure throttle position sensor resistance.
--------	--



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect throttle position sensor wiring harness connector EN27.
- (c) Measure throttle position sensor resistance.

Test Items	Standard Resistance Value
Terminal 1 and Terminal 2	3,000 Ω
Terminal 2 and Terminal 3	Changes between 1,300 Ω and 2,900 Ω

- (d) Connect throttle position sensor wiring harness connector EN27.


Is resistance the specified value?

No

Replace throttle position sensor. Go to step 11

Yes

Step 3 Measure throttle position sensor 5 V reference voltage.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect throttle position sensor wiring harness connector EN27.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between throttle position sensor EN27 terminal No.2 and a reliable ground.

Standard Voltage: 4.5-5.5 V

- (e) Connect throttle position sensor wiring harness connector EN27.


Is voltage the specified value?

No

Go to step 6

Yes

Step 4 Measure throttle position sensor signal circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect throttle position sensor wiring harness connector EN27.
- (c) Turn the ignition switch to "ON" position.
- (d) Connect a 5A fuse between EN27 terminal No.2 and No.3. Use scan tool to read "the actual throttle position sensor voltage" parameter.


Standard Voltage: 4.5-5.5 V

- (e) Connect throttle position sensor wiring harness connector EN27.

Is data normal?

No

Step 5 Measure throttle position sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect throttle position sensor wiring harness connector EN27.
- (c) Measure resistance between throttle position sensor wiring harness connector EN27 terminal No.1 and a reliable ground.


Standard Resistance: Less than 1 Ω

- (d) Connect throttle position sensor wiring harness connector EN27.

No

Yes

Step 6 Check throttle position sensor 5 V reference voltage circuit.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect throttle position sensor wiring harness connector EN27.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between throttle position sensor wiring harness connector EN27 terminal No.2 and ECM harness connector terminal No.18. check whether there is open circuit. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between throttle position sensor wiring harness connector EN27 terminal No.2 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between throttle position sensor wiring harness connector EN27 terminal No.2 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN27 (2) and EN01 (18)	Less than 1 Ω
Resistance Between EN27 (2) and a Reliable Ground	10 kΩ or higher
Voltage Between EN27 (2) and a Reliable Ground	0 V

Normal Go to step 9

Step 7 | Check throttle position sensor signal circuit. اولین سامانه دیجیتال خودرو (مسئولیت محدود)




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect throttle position sensor wiring harness connector EN27.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between throttle position sensor wiring harness connector EN27 terminal No.3 and ECM harness connector terminal No.26. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between throttle position sensor wiring harness connector EN27 terminal No.3 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between throttle position sensor wiring harness connector EN27 terminal No.3 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN27 (3) and EN01 (26)	Less than 1 Ω
Resistance Between EN27 (3) and a Reliable Ground	10 kΩ or higher
Voltage Between EN27 (3) and a Reliable Ground	0 V

Normal

Go to step 9

Step 8 Check throttle position sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect throttle position sensor wiring harness connector EN27.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between throttle position sensor wiring harness connector EN27 terminal No.1 and ECM harness connector terminal No.39. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure voltage between throttle position sensor wiring harness connector EN27 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN27 (3) and EN01 (39)	Less than 1 Ω
Voltage Between EN27 (3) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 9 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 10 Replace ECM.

Next

Step 11 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Read control system DTC code again to confirm that the system has no DTC code.

No Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 12	Diagnostic completed.
---------	-----------------------

5. Repair Instructions:

Replace throttle position sensor. Refer to [2.2.8.3 Throttle Position Sensor Replacement](#).

2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196

1. DTC Descriptor:

DTC	P0130	Pre-Catalytic Oxygen Sensor Signal Unreasonable
DTC	P0131	Pre-Catalytic Oxygen Sensor Circuit Voltage Too Low
DTC	P0132	Pre-Catalytic Oxygen Sensor Circuit Voltage Too High
DTC	P0133	Pre-Catalytic Oxygen Sensor Aging
DTC	P0134	Pre-Catalytic Oxygen Sensor Malfunction
DTC	P2195	Pre-Catalytic Oxygen Sensor Aging (Too Lean)
DTC	P2196	Pre-Catalytic Oxygen Sensor Aging (Too Rich)

After the vehicle is started, the control module works in the open-loop mode and ignores pre-catalytic oxygen sensor signal voltage when calculating air-fuel ratio. The control module provides approximately 450mV reference voltage to the pre-catalytic oxygen sensor. When the engine starts running, the pre-catalytic oxygen sensor will be heated and begin to generate a 0-0.1 V voltage. This voltage fluctuates. Once the control module detects that the pre-catalytic oxygen sensor voltage exceeds a threshold voltage, it will immediately enter into the closed-loop mode. Control module determines the Air-Fuel ratio using the received pre-catalytic oxygen sensor voltage signal. If the pre-catalytic oxygen sensor voltage increases to over the reference voltage (tend to 1 V), it indicates that the air fuel mixture is too rich. If the pre-catalytic oxygen sensor voltage decreases to below the reference voltage (tend to 0 mV), it indicates that the air fuel mixture is too lean.


ECM provides a signal through ECM harness connector EN01 terminal No.45 to pre-catalytic oxygen sensor wiring harness connector EN02 terminal No.4; a low internal reference voltage through ECM harness connector EN01 terminal No.39 to Pre-Catalytic oxygen sensor wiring harness connector EN02 terminal No.3.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0130	<ol style="list-style-type: none"> Pre-Catalytic Oxygen Sensor Voltage Too Low In an Extended Period of Time Short to Ground When Cold Pre-Catalytic Oxygen Sensor Voltage Leakage 	<ol style="list-style-type: none"> Pre-Catalytic oxygen sensor output voltage is between 0.06-0.40 V. Pre-Catalytic oxygen sensor output voltage is less than 0.06 V. Pre-Catalytic oxygen sensor output voltage is greater than 0.611 V and less than 1.5 V and Post-Catalytic oxygen sensor output voltage is 0.099 V. 	<ol style="list-style-type: none"> Sensor Circuit Sensor ECM

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0131 P0132	1. Pre-Catalytic Sensor Voltage Too High 2. Pre-Catalytic Sensor Voltage Too Low	1. Pre-Catalytic oxygen sensor output voltage is greater than 1.5 V. 2. Pre-Catalytic oxygen sensor output voltage is less than 0.06 V. 3. Battery voltage is greater than 10.98 V. 4. Engine speed is greater than 25 rpm. 5. Exhaust temperature is less than the upper limit 800°C (1,472 °F). 6. Exhaust is hot enough.	
P0134	1. Signal circuit open. 2. Pre-Catalytic Oxygen Sensor High Resistance At High Temperature	1. Sensor voltage is between 0.401 V and 0.601 V. 2. Sensor resistance is greater than 20,000 Ω. 3. Oxygen sensor is hot enough, lasting for 100 s.	
P0133 P2195 P2196	1. Post-Catalytic oxygen sensor control integral value is over maximum limit. 2. Post-Catalytic oxygen sensor control integral value is lower than minimum limit. 3. Filtered Pre-Catalytic oxygen sensor signal is greater than specified value.	1. Post-Catalytic oxygen sensor control integral value is greater than 1.0 s. 2. Post-Catalytic oxygen sensor control integral value is less than -1.0 s. 3. Diagnostic function is switched on. 4. Filtered pre-catalytic oxygen sensor signal cycle is more than 3.3 s. 5. Effective cycle count value is greater than 20. 6. Target excess air coefficient is equal to 1. 7. No pressure sensor malfunction. 8. No coolant temperature sensor malfunction. 9. No intake air temperature sensor malfunction. 10. No diagnosis preventing conditions. 11. Speed is between 1,600 rpm and 2,600 rpm. 12. Load is between 25 and 50. 13. Exhaust temperature model value is greater than 500. 14. No pre-catalytic oxygen sensor malfunction. 15. No three-way catalytic converter malfunction.	1. Sensor Circuit 2. Sensor 3. Mixture Too Rich 4. Mixture Too Lean 5. ECM

3. Schematic:



FE02-5008b

4. Diagnostic Steps:

Step 1	Connect scan tool.
Next	
Step 2	Start engine and turn on the scan tool.
Next	
Step 3	Maintain engine speed at 2,500 rpm for more than 2 min to warm up the engine, until the engine coolant temperature reaches 80°C (176 °F).
Next	
Step 4	Select on scan tool: Engine/Read data stream/group 1 oxygen sensor voltage 1 (Pre-Catalytic oxygen sensors).
Next	
Step 5	Observe the oxygen sensor output voltage, the data should fluctuate within 0.1-0.8 V.

Yes

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

No

Step 6 Test the oxygen sensor signal.

- (a) If the voltage data is consistently below 0.45 V (mixture too lean), then carry out inspection steps as following:
 - Spray proper amount of propane gas into the intake port.
 - Inspect whether the pre-catalytic oxygen sensor voltage data has a significant change, in which case the signal voltage will increase rapidly.
- (b) If the voltage data is consistently higher than 0.45 V (mixture too rich), then carry out inspection steps as following:
 - Put gear into Neutral.
 - Apply hand brake.
 - Press the accelerator pedal so the engine speed suddenly increases to 4,000 rpm and then quickly release the accelerator pedal.
 - Repeat the previous steps more than 3 times.
 - Inspect whether the pre-catalytic oxygen sensor voltage data has a significant change, in which case the signal voltage will decrease rapidly.

During the above test, the pre-catalytic oxygen sensor signal voltage should change significantly.

Is voltage changed significantly?

Yes

Inspect the cause for engine air-fuel ratio too lean/too rich. Refer to [2.2.7.4 Fault Symptom Table](#).

No

Step 7 Check and confirm no other control system DTC codes.

- (a) Connect scan tool to a datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Press the scan tool power button.
- (d) Select the following menu items: Engine/Read DTC codes.
- (e) Read DTC codes.

Results:

DTC Codes Shown	To Step
DTC codes other than P0030, P0031, P0032, P0053	No
P0030, P0031, P0032, P0053	Yes


No

Refer to [2.2.7.11 DTC Code Index](#)

Yes

Step 8 Measure pre-catalytic oxygen sensor signal circuit.

Pre-catalytic Oxygen Sensor
Harness Connector EN02



FE02-5043b

- Turn the ignition switch to "OFF" position.
- Disconnect oxygen sensor wiring harness connector EN02.
- Turn the ignition switch to "ON" position.
- Measure voltage between Pre-Catalytic oxygen sensor wiring harness connector EN02 terminal No.4 and a reliable ground.

Standard Voltage: 0.35-0.5 V

- Connect the pre-catalytic oxygen sensor wiring harness connector EN02.

Is voltage the specified value?


No

Go to step 11

Yes

Step 9 Measure the pre-catalytic oxygen sensor ground circuit.

Pre-catalytic Oxygen Sensor
Harness Connector EN02



FE02-5044b

- Turn the ignition switch to "OFF" position.
- Disconnect oxygen sensor wiring harness connector EN02.
- Turn the ignition switch to "ON" position.
- Measure resistance between pre-catalytic oxygen sensor connector EN02 terminal No.3 and a reliable ground.

Standard Resistance: Less than 1 Ω

- Connect pre-catalytic oxygen sensor wiring harness connector EN02.

Is resistance the specified value?

No

Go to step 12


Yes

Step 10 Replace the pre-catalytic oxygen sensor. Refer to [2.4.7.2 Pre-Catalytic Oxygen Sensor Replacement](#).

Next

Go to step 15

Step 11 Check the pre-catalytic oxygen sensor signal circuit.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect oxygen sensor wiring harness connector EN02.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between pre-catalytic oxygen sensor wiring harness connector EN02 terminal No.4 and ECM harness connector terminal No.45. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between pre-catalytic oxygen sensor wiring harness connector EN02 terminal No.4 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between Pre-Catalytic oxygen sensor wiring harness connector EN02 terminal No.4 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN02 (4) and EN01 (45)	Less than 1 Ω
Resistance Between EN02 (4) and a Reliable Ground	10 kΩ or higher
Voltage Between EN02 (4) and a Reliable Ground	0 V

Normal Go to step 15

Step 12 Check the pre-catalytic oxygen sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect oxygen sensor wiring harness connector EN02.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between the oxygen sensor wiring harness connector EN02 terminal No.3 and ECM harness connector terminal No.39. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between pre-catalytic oxygen sensor wiring harness connector EN02 terminal No.3 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between pre-catalytic oxygen sensor wiring harness connector EN02 terminal No.3 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN02 (3) and EN01 (39)	Less than 1 Ω
Resistance Between EN02 (3) and a Reliable Ground	10 kΩ or higher
Voltage Between EN02 (3) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 13 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No → Repair the faulty part.

Yes

Step 14 Replace ECM.

Next

Step 15 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 16 Diagnostic completed.

5. Repair Instructions:

Replace the pre-catalytic oxygen sensor. Refer to [2.4.7.2 Pre-Catalytic Oxygen Sensor Replacement](#).

2.2.7.22 DTC P0136 P0137 P0138 P0140 P2270 P2271

1. DTC Descriptor:

DTC	P0136	Post-Catalytic Oxygen Sensor Unreasonable
DTC	P0137	Post-Catalytic Oxygen Sensor Circuit Voltage Too Low
DTC	P0138	Post-Catalytic Oxygen Sensor Circuit Voltage Too High
DTC	P0140	Post-Catalytic Oxygen Sensor Circuit Malfunction
DTC	P2270	Post-Catalytic Oxygen Sensor Aging (Too Lean)
DTC	P2271	Post-Catalytic Oxygen Sensor Aging (Too Rich)

After the vehicle is started, the control module works in the open-loop mode and ignores heated oxygen sensor signal voltage when calculating air-fuel ratio. The control module provides approximately 450mV reference voltage to the heated oxygen sensor. When the engine starts running, the heated oxygen sensor will be heated and begin to generate a 0-0.1V voltage. This voltage fluctuates. Once the control module detects that the heated oxygen sensor voltage exceeds a threshold voltage, it will immediately enter into the closed-loop mode. Control module determines the air-fuel ratio using the received heated oxygen sensor voltage signal. If the heated oxygen sensor voltage increases to over the reference voltage (tend to 1V), it indicates that the air fuel mixture is too rich. If the heated oxygen sensor voltage decreases to below the reference voltage (tend to 0mV), it indicates that the air fuel mixture is too lean.


- ECM provides a signal through ECM harness connector EN01 terminal No.29 to post-catalytic oxygen sensor wiring harness connector EN03 terminal No.4.
- ECM provides a low reference voltage through ECM harness connector EN01 terminal No.39 to pre-catalytic oxygen sensor wiring harness connector EN03 terminal No.3.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0136 P0137	Short to Ground When Cold	1. Post-Catalytic oxygen sensor voltage is less than 0.06 V. 2. Post-Catalytic oxygen sensor reaches the normal working temperature.	1. Sensor Circuit 2. Sensor 3. Mixture Too Rich 4. Mixture Too Lean

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0138	Post-Catalytic Oxygen Sensor Voltage Too High	<ol style="list-style-type: none"> 1. Post-Catalytic oxygen voltage signal is greater than 1.5 V. 2. Battery voltage is greater than 10.98 V. 3. Engine speed is greater than 25 rpm. 4. Target excess air coefficient is equal to 1. 5. Three-way catalytic converter temperature is higher than 320°C (608 °F). 6. Battery voltage is greater than 10.98 V. 7. Post-Catalytic oxygen sensor reaches the normal working temperature. 	<ol style="list-style-type: none"> 5. Three-way Catalytic Converter 6. ECM
P0140	<ol style="list-style-type: none"> 1. Oxygen Sensor Signal Circuit Open 2. Oxygen Sensor With High Resistance at High Temperature 	<ol style="list-style-type: none"> 1. Post-Catalytic oxygen sensor voltage is between 0.42 V and 0.5 V. 2. Post-Catalytic oxygen sensor resistance is greater than 40,000 Ω. 3. Post-Catalytic oxygen sensor reaches the normal working temperature. 	<ol style="list-style-type: none"> 1. Sensor Circuit 2. Sensor 3. Mixture Too Rich 4. Mixture Too Lean
P2270 P2271	<ol style="list-style-type: none"> 1. Post-Catalytic oxygen sensor voltage is continuously low. 2. Post-Catalytic oxygen sensor voltage is continuously high. 	<ol style="list-style-type: none"> 1. Post-Catalytic oxygen sensor voltage is less than 0.6 V. 2. Post-Catalytic oxygen sensor voltage is greater than 0.6 V. 3. Post-Catalytic oxygen sensor reaches the normal working temperature. 	<ol style="list-style-type: none"> 5. Three-way Catalytic Converter 6. ECM

3. Schematic



4. Diagnostic Steps:

Step 1	Connect scan tool.
Next	
Step 2	Start engine and turn on the scan tool.
Next	
Step 3	Maintain the engine speed at 2,500 rpm for more than 2 min to warm up the engine, until the engine coolant temperature reaches 80°C (176 °F).
Next	
Step 4	Select on scan tool: Engine/Read data flow/Group 1 Oxygen sensor voltage 2 (Post-Catalytic oxygen sensors).
Next	
Step 5	Observe oxygen sensor output voltage, the data should be within 0.6-0.7V unchanged.

Yes

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

No

Step 6 Test the oxygen sensor signal.

- (a) If the voltage data is consistently below 0.45 V (mixture too lean), carry out steps as following:
- Spray proper amount of propane gas into the intake.
 - Check whether the Post-Catalytic oxygen sensor voltage data has a significant change, as it will cause signal voltage rise rapidly.
- (b) If the voltage data is consistently above 0.45 V (mixture too rich), carry out steps as following:
- Put gear into Neutral.
 - Apply hand brake.
 - Press the accelerator pedal so that the engine speed suddenly increases to 4,000 rpm and then quickly release the accelerator pedal.
 - Repeat the previous step more than 3 times.
 - Check whether the Post-Catalytic oxygen sensor voltage data has a significant change, as it will cause signal voltage decrease rapidly.

During the test, the oxygen sensor signal voltage should have significant changes.

Does voltage have a significant change?

Yes

Check the cause for engine Air-Fuel ratio too lean/too rich. Refer to [2.2.7.4 Fault Symptom Table](#).

No

Step 7 Check whether there are other control system DTC codes.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Press the scan tool power button.
- (d) Select the following menu items: Engine/Read DTC codes.
- (e) Read DTC codes.

Results:

DTC Codes Shown	To Step
DTC code other than P0136, P0137, P0138, P0140, P2270, P2271DTC, P0136, P0137, P0138, P0140, P2270, P2271	No

DTC Codes Shown	To Step
P0136, P0137, P0138, P0140, P2270, P2271DTC, P0136, P0137, P0138, P0140, P2270, P2271	Yes

No

Refer to [2.2.7.11 DTC Code Index](#)

Yes


Step 8 Inspect the exhaust system seal.

- (a) Check the three-way catalytic converter appearance (signs of excessive heat, gasket missing, etc.).
- (b) Check whether the exhaust pipe is intact and whether gasket is intact.

No

Replace the damaged parts. Go to step 16

Step 9 Measure oxygen sensor signal circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the oxygen sensor wiring harness connector EN03.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between oxygen sensor wiring harness connector EN03 terminal No.4 and a reliable ground.
Standard Voltage: 0.35-0.5 V
- (e) Connect the oxygen sensor wiring harness connector EN03.
Is voltage the specified value?


No

Go to step 12

Yes

Step 10 Measure the post-catalytic oxygen sensor ground circuit.

Post-Catalytic Oxygen Sensor
Harness Connector EN03



FE02-5048b

- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the oxygen sensor wiring harness connector EN03.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure resistance between Post-Catalytic oxygen sensor connector EN03 terminal No.3 and a reliable ground.

Standard Resistance: Less than 1 Ω

- (e) Connect the post-catalytic oxygen sensor wiring harness connector EN03.

Is resistance the specified value?

No

Go to step 13

Yes


Step 11 Replace the post-catalytic oxygen sensor.

Next


Go to step 16

Step 12 Check the post-catalytic oxygen sensor signal circuit.

Post-Catalytic Oxygen Sensor
Harness Connector EN03



ECM Harness Connector EN01



FE02-5049b


- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the post-catalytic oxygen sensor wiring harness connector EN03.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between post-catalytic oxygen sensor wiring harness connector EN03 terminal No.4 and ECM harness connector terminal No.29. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between post-catalytic oxygen sensor wiring harness connector EN03 terminal No.4 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between post-catalytic oxygen sensor wiring harness connector EN03 terminal No.4 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN03 (4) and EN01 (29)	Less than 1 Ω
Resistance Between EN03 (4) and a Reliable Ground	10 kΩ or higher
Voltage Between EN03 (4) and a Reliable Ground	0 V

Normal

Go to step 16

Step 13 Check oxygen sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the oxygen sensor wiring harness connector EN03.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between post-catalytic oxygen sensor wiring harness connector EN03 terminal No.3 and ECM harness connector terminal No.39. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between post-catalytic oxygen sensor wiring harness connector EN03 terminal No.3 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between post-catalytic oxygen sensor wiring harness connector EN03 terminal No.3 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN03 (3) and EN01 (39)	Less than 1 Ω
Resistance Between EN03 (3) and a Reliable Ground	10 kΩ or higher
Voltage Between EN03 (3) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 14 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No → Repair the faulty part.

Yes

Step 15 Replace ECM.

Next

Step 16 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.

- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 17	Diagnostic completed.
---------	-----------------------

5. Repair Instructions:

Replace post-catalytic oxygen sensor. Refer to [2.4.7.1 Post-Catalytic Oxygen Sensor Replacement](#).

2.2.7.23 DTC P0170 P0171 P0172 P2177 P2178 P2187 P2188

1. DTC Descriptor:

DTC	P0170	Close-Loop Control Down Stream Air-Fuel Ratio Self Learn Unreasonable
DTC	P0171	Close-Loop Control Down Stream Air-Fuel Ratio Self Learn Too Lean
DTC	P0172	Close-Loop Control Down Stream Air-Fuel Ratio Self Learn Too Rich
DTC	P2177	Close-Loop Control Down Stream Air-Fuel Ratio Self Learn Value Higher Than Maximum
DTC	P2178	Close-Loop Control Down Stream Air-Fuel Ratio Self Learn Value Lower Than Minimum
DTC	P2187	Close-Loop Control Down Stream Air-Fuel Ratio Self Learn Value Higher Than Maximum (Low-Load Zone)
DTC	P2188	Close-Loop Control Down Stream Air-Fuel Ratio Self Learn Value Lower Than Minimum (Low-Load Zone)

Engine Control Module (ECM) controls the close-loop Air-Fuel ratio Measure system that achieves optimal combination of performance, fuel economy and emissions control. In the close-loop mode, the engine control module monitors heated oxygen sensor (HO₂S) signal voltage and adjusts fuel supply according to the signal. Changes in fuel supply will change the value of long-term and short-term fuel supply adjustment. Short-term fuel supply adjustment will respond to heated oxygen sensor signal voltage and rapidly change. These changes will fine tune the fuel supply. Long-term fuel supply adjustment will respond to the trend in short-term fuel supply adjustment. Long-term fuel adjustment adjusts the fuel supply in order to return to the center of the short-term fuel adjustment value and controls the short-term fuel adjustment. The ideal fuel adjustment value is around 0%. A positive value indicates that engine control module is increasing fuel supply to compensate the lean Air-Fuel mixture. A negative value indicates that engine control module is decreasing fuel supply to compensate the rich Air-Fuel mixture.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0170 P0171 P0172 P2177 P2178 P2187 P2188	1. Fuel Adjustment Value Higher Than Maximum Limit 2. Fuel Adjustment Value Lower Than Minimum Limit 3. Fuel Adjustment Value Higher Than Maximum Limit (Low-Load Zone) 4. Fuel Adjustment Value Lower Than Minimum Limit (Low-Load Zone)	1. Excessive air coefficient is higher than the standard value 1.23. 2. Excessive air coefficient is higher than the standard value 0.77. 3. With engine speed at 1,640-3,200 rpm, throttle opens 20% -60%. 4. With engine speed at 1,640-3,200 rpm, throttle opens 20% -60%.	1. Fuel Injectors 2. Canister 3. MAP 4. TPS 5. Pre-Catalytic Oxygen Sensor

3. Schematic:

Refer to [2.2.6.1 Schematic](#).

4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Check there are no other control system DTC codes.
--------	--

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Press the scan tool power button.
- (d) Select the following menu items: Engine/Read DTC codes.
- (e) Read DTC codes.

Are there DTC codes other than P0170, P0171, P0172, P2177, P2178, P2187, P2188?

Yes Refer to [2.2.7.11 DTC Code Index](#)

No

Step 2	Read the intake manifold absolute pressure sensor data.
--------	---

- (a) Turn the ignition switch to "OFF" position and connect scan tool.
- (b) Start the vehicle.
- (c) Read the intake manifold absolute pressure sensor data.
- (d) Read the scan tool for atmospheric pressure value, and compare it with [table 2.2.1.3 Altitude and Atmospheric Pressure Correlation](#).

Is scan tool atmospheric pressure reading normal?

No

Refer to [2.2.7.17 DTC P0105 P0106 P0107 P0108](#)

Yes

Step 3	Read the throttle position sensor data.
--------	---

- (a) Start the vehicle.
 - (b) Warm up the engine with normal idle speed and throttle opening is less than 10%.
 - (c) Use scan tool to read throttle position sensor data.
- Is throttle position sensor data normal?

No

Refer to [2.2.7.20 DTC P0122 P0123](#)

Yes

Step 4	Read the pre-catalytic oxygen sensor data.
--------	--

- (a) Start the vehicle.
 - (b) Warm up the engine with normal idle speed.
 - (c) Read the pre-catalytic oxygen sensor data.
- Pre-Catalytic oxygen sensor standard value: 0.2-0.8 V

Is pre-catalytic oxygen sensor data is normal?

No

Refer to [2.2.7.21 DTC P0130 P0131 P0132 P0133 P0134 P2195 P2196](#)

Yes

Step 5	Observe the long-term fuel adjustment parameter.
--------	--

- (a) Start the vehicle.
 - (b) Warm up the engine.
 - (c) Observe the long-term fuel adjustment parameter.
- Is the long-term fuel adjustment parameter normal?

Yes

System normal.

No

Step 6	Check engine and its components.
--------	----------------------------------

- (a) Turn the ignition switch to "OFF" position.
- (b) Check the vacuum hose crack, kink or connections.
- (c) Check the intake manifold, throttle body and fuel injector vacuum leakage.
- (d) Check the crankshaft ventilation system leakage.
- (e) Check fuel contamination.
- (f) Check the fuel system working at air-fuel ratio too lean.
- (g) Check injector nozzle spray fuel too lean.
- (h) Check the fuel system working at air-fuel ratio too rich.
- (i) Check injector spray fuel too rich.
- (j) Check intake manifold collapse or obstruction.

- (k) Check whether there is excessive fuel in the crankcase.
 - (l) Check evaporative emission control systems working condition.
 - (m) Check other fault lights in I/P working condition.
- Is engine System normal?

Yes System normal

No

Step 7 Repair engine and its components.

Next

Step 8 System normal.

5. Repair Instructions:

Replace fuel injectors. Refer to [2.2.8.2 Fuel Injector Replacement](#).

Replace Canister solenoid valve. Refer to [2.4.7.3 Canister Solenoid Valve Replacement](#).

2.2.7.24 DTC P0201 P0261 P0262

1. DTC Descriptor:


DTC	P0201	Cylinder No.1 Fuel Injection Control Circuit Open
DTC	P0261	Cylinder No.1 Fuel Injector Control Circuit Short to Ground
DTC	P0262	Cylinder No.1 Fuel Injector Control Circuit Short to Power Supply

Fuel injector operating voltage is provided by The Main Relay which is controlled by ECM. Battery voltage passes through the main relay terminal No.3 to all fuel injector wiring harness connectors terminal No.1. ECM controls fuel injector ground circuit by ECM harness connector EN01 terminal No.50. ECM monitors all fuel injector driver circuit status, if ECM detects driving circuit corresponding voltage is incorrect, ECM will set up a fuel injector control circuit fault DTC code.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0201 P0261 P0262	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Sensor Circuit 2. Sensor 3. ECM

3. Schematic:



4. Diagnostic Steps:

Note


Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

- (a) Check the fuel injector wiring harness connector for damage, poor connection, aging or signs of loosening.

Next

Step 2	Measure the resistance of fuel injector assembly.
--------	---




- (a) Disconnect the fuel injector wiring harness connector EN11.
- (b) Measure resistance between the two fuel injector terminals.
Standard Resistance: 20°C (68 °F) 11.5-12.5 Ω
- (c) Connect the fuel injector wiring harness connector EN11.

No Replace fuel injector assembly. Refer to [2.2.8.2 Fuel Injector Replacement](#)

Yes

Step 3 Measure fuel injectors working power supply.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.1 fuel injector wiring harness connector EN11.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between cylinder No.1 fuel injector wiring harness connector EN11 No.1 terminal and a reliable ground.
Standard Voltage :11-14 V
- (e) Connect cylinder No.1 fuel injector wiring harness connector EN11.

Is voltage normal?
No Go to step 5

Yes

Step 4 Check the fuel injector control circuit.




- (a) Turn the ignition switch to "OFF" position.
 - (b) Disconnect cylinder No.1 fuel injector wiring harness connector EN11.
 - (c) Connect test lamp made from light-emitting diodes to the fuel injector wiring harness connector EN11 terminal No.1 and No.2.
 - (d) Start the engine.
 - (e) Check whether the test lamp is flashing as per normal.
- Is test lamp flashing as per normal?

No Go to step 6

Yes Go to step 7

Step 5 Check and repair cylinder No.1 fuel injector power supply circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the fuel injector wiring harness connector EN11.
- (c) Remove the engine main relay.
- (d) Measure resistance between cylinder No.1 fuel injector wiring harness connector EN11 terminal No.1 and engine main relay terminal No.3.
- (e) Measure resistance between cylinder No.1 fuel injector wiring harness connector EN11 terminal No.1 and a reliable ground.


Test Items	Standard Value
EN11 (1) and Main Relay Terminal No.3	Less than 1 Ω
EN11 (1) and a Reliable Ground	10 kΩ or higher

- (f) Install the engine main relay.
- (g) Connect cylinder No.1 fuel injector wiring harness connector EN11.

Exclude the fuel injector power supply circuit fault.

Next Go to step 9

Step 6 Check cylinder No.1 fuel injector control circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.1 fuel injector wiring harness connector EN11.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between cylinder No.1 fuel injector wiring harness connector EN11 terminal No.1 and ECM harness connector terminal No.50. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between cylinder No.1 fuel injector wiring harness connector EN11 terminal No.1 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between cylinder No.1 fuel injector wiring harness connector EN11 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN11 (1) and EN01 (50)	Less than 1 Ω
Resistance Between EN11 (1) and a Reliable Ground	10 kΩ or higher

Voltage Between EN11 (1) and a Reliable Ground	0 V
--	-----

Execute next step as per normal.

Next

Step 7 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No

Repair the faulty part.

Yes

Step 8 Replace ECM.

Next

Step 9 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 10 Diagnostic completed.

5. Repair Instructions:

Replace the fuel injector. Refer to [2.2.8.2 Fuel Injector Replacement](#).

2.2.7.25 DTC P0202 P0264 P0265

1. DTC Descriptor:


DTC	P0202	Cylinder No.2 Fuel Injector Control Circuit Open
DTC	P0264	Cylinder No.2 Fuel Injector Control Circuit Short to Ground
DTC	P0265	Cylinder No.2 Fuel Injector Control Circuit Short to Power Supply

Fuel injector operating voltage is provided by The Main Relay which is controlled by ECM. Battery voltage passes through the main relay terminal No.3 to all fuel injector wiring harness connectors terminal No.1. ECM controls fuel injector ground circuit by ECM harness connector EN01 terminal No.63. ECM monitors all fuel injector driver circuit status, if ECM detects driving circuit corresponding voltage is incorrect, ECM will set up a fuel injector control circuit fault DTC code.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0202 P0264 P0265	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Sensor Circuit 2. Sensor 3. ECM

3. Schematic:



4. Diagnostic Steps:

Note


Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

- (a) Check the fuel injector wiring harness connector for damage, poor connection, aging or signs of loosening.

Next

Step 2 Measure the resistance of fuel injector assembly.




- (a) Disconnect the fuel injector wiring harness connector EN12.
- (b) Measure resistance between the two fuel injector terminals. Standard Resistance: 20°C (68 °F) 11.5-12.5 Ω
- (c) Connect the fuel injector wiring harness connector EN12.

No

Replace fuel injector assembly. Refer to [2.2.8.2 Fuel Injector Replacement](#)

Yes

Step 3 Measure fuel injectors working power supply.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.1 fuel injector wiring harness connector EN12.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between cylinder No.2 fuel injector wiring harness connector EN12 No.1 terminal and a reliable ground. Standard Voltage: 11-14 V
- (e) Connect cylinder No.2 fuel injector wiring harness connector EN12.

Is voltage normal?


No

Go to step 5

Yes

Step 4 Check the fuel injector control circuit.

Cylinder No.2 Fuel Injector Harness Connector EN12



FE02-5060b


- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.1 fuel injector wiring harness connector EN12.
- (c) Connect test lamp made from light-emitting diodes to the fuel injector wiring harness connector EN12 terminal No.1 and No.2.
- (d) Start the engine.
- (e) Check whether the test lamp is flashing as per normal. Is test lamp flashing as per normal?

No Go to step 6

Yes Go to step 7

Step 5 Check and repair cylinder No.2 fuel injector power supply circuit.

Cylinder No.2 Fuel Injector Harness Connector EN12



FE02-5061b


- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the fuel injector wiring harness connector EN12.
- (c) Remove the engine main relay.
- (d) Measure resistance between cylinder No.2 fuel injector wiring harness connector EN12 terminal No.1 and engine main relay terminal No.3.
- (e) Measure resistance between cylinder No.2 fuel injector wiring harness connector EN12 terminal No.1 and a reliable ground.

Test Items	Standard Value
EN12 (1) and Main Relay Terminal No.3	Less than 1 Ω
EN12 (1) and a Reliable Ground	10 kΩ or higher

- (f) Install the engine main relay.
 - (g) Connect cylinder No.2 fuel injector wiring harness connector EN12.
- Exclude the fuel injector power supply circuit fault.

Next Go to step 9

Step 6 Check cylinder No.2 fuel injector control circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.2 fuel injector wiring harness connector EN12.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between cylinder No.2 fuel injector wiring harness connector EN12 terminal No.1 and ECM harness connector terminal No.63. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between cylinder No.2 fuel injector wiring harness connector EN12 terminal No.1 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between cylinder No.2 fuel injector wiring harness connector EN12 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN12 (1) and EN01 (63)	Less than 1 Ω
Resistance Between EN12 (1) and a Reliable Ground	10 kΩ or higher
Voltage Between EN12 (1) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 7 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 8 Replace ECM.

Next

Step 9 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 10 Diagnostic completed.

5. Repair Instructions:

Replace the fuel injector. Refer to [2.2.8.2 Fuel Injector Replacement](#).

2.2.7.26 DTC P0203 P0267 P0268

1. DTC Descriptor:


DTC	P0203	Cylinder No.3 Fuel Injection Control Circuit Open
DTC	P0267	Cylinder No.3 Fuel Injector Control Circuit Short to Ground
DTC	P0268	Cylinder No.3 Fuel Injector Control Circuit Short to Power Supply

Fuel injector operating voltage is provided by the main relay which is controlled by ECM. Battery voltage passes through the main relay terminal No.3 to all fuel injector wiring harness connectors terminal No.1. ECM controls fuel injector ground circuit by ECM harness connector EN01 terminal No.49. ECM monitors all fuel injector driver circuit status, if ECM detects driving circuit corresponding voltage is incorrect, ECM will set up a fuel injector control circuit fault DTC code.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0203 P0267 P0268	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Sensor Circuit 2. Sensor 3. ECM

3. Schematic



4. Diagnostic Steps:

Note اولین سامانه دیجیتال خودرو در ایران


Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

- (a) Check the fuel injector wiring harness connector for damage, poor connection, aging or signs of loosening.

Next

Step 2	Measure the resistance of fuel injector assembly.
--------	---




- (a) Disconnect the fuel injector wiring harness connector EN13.
- (b) Measure resistance between the two fuel injector terminals.
Standard Resistance: 20°C (68 °F) 11.5-12.5 Ω
- (c) Connect the fuel injector wiring harness connector EN13.

No

Replace fuel injector assembly. Refer to [2.2.8.2 Fuel Injector Replacement](#)

Yes

Step 3 Measure fuel injectors working power supply.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.3 fuel injector wiring harness connector EN13.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between cylinder No.3 fuel injector wiring harness connector EN13 No.1 terminal and a reliable ground.
Standard Voltage: 11-14 V
- (e) Connect cylinder No.3 fuel injector wiring harness connector EN13.


Voltage normal?

No

Go to step 5

Yes

Step 4 Check the fuel injector control circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.3 fuel injector wiring harness connector EN13.
- (c) Connect test lamp made from light-emitting diodes to the fuel injector wiring harness connector EN13 terminal No.1 and No.2.
- (d) Start the engine.
- (e) Check whether the test lamp is flashing as per normal.
Is test lamp flashing as per normal?


No

Go to step 6

Yes

Go to step 7

Step 5 Check and repair cylinder No.3 fuel injector power supply circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the fuel injector wiring harness connector EN13.
- (c) Remove the engine main relay.
- (d) Measure resistance between cylinder No.3 fuel injector wiring harness connector EN13 terminal No.1 and engine main relay terminal No.3.
- (e) Measure resistance between cylinder No.3 fuel injector wiring harness connector EN13 terminal No.1 and a reliable ground.


Test Items	Standard Value
EN13 (1) and Main Relay Terminal No.3	Less than 1 Ω
EN13 (1) and a Reliable Ground	10 kΩ or higher

- (f) Install the engine main relay.
- (g) Connect cylinder No.3 fuel injector wiring harness connector EN13.

Exclude the fuel injector power supply circuit fault.

Next Go to step 9

Step 6 Check 3-cylinder fuel injector control circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.3 fuel injector wiring harness connector EN13.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between cylinder No.3 fuel injector wiring harness connector EN13 terminal No.1 and ECM harness connector terminal No.49. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between cylinder No.3 fuel injector wiring harness connector EN13 terminal No.1 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between cylinder No.3 fuel injector wiring harness connector EN13 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN13 (1) and EN01 (49)	Less than 1 Ω
Resistance Between EN13 (1) and a Reliable Ground	10 kΩ or higher

Voltage Between EN13 (1) and a Reliable Ground	0 V
--	-----

Execute next step as per normal.

Next

Step 7	Check ECM power supply circuit.
--------	---------------------------------

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No

Repair the faulty part.

Yes

Step 8	Replace ECM.
--------	--------------

Next

Step 9	Use scan tool to confirm whether the DTC code is stored again.
--------	--

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 10	Diagnostic completed.
---------	-----------------------

5. Repair Instructions:

Replace the fuel injector. Refer to [2.2.8.2 Fuel Injector Replacement](#).

2.2.7.27 DTC P0204 P0270 P0271

1. DTC Descriptor:


DTC	P0204	Cylinder No.4 Fuel Injection Control Circuit Open
DTC	P0270	Cylinder No.4 Fuel Injector Control Circuit Short to Ground
DTC	P0271	Cylinder No.4 Fuel Injector Control Circuit Short to Power Supply

Fuel injector operating voltage is provided by The Main Relay which is controlled by ECM. Battery voltage passes through the main relay terminal No.3 to all fuel injector wiring harness connectors terminal No.1. ECM controls fuel injector ground circuit by ECM harness connector EN01 terminal No.64. ECM monitors all fuel injector driver circuit status, if ECM detects driving circuit corresponding voltage is incorrect, ECM will set up a fuel injector control circuit fault DTC code.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0204 P0270 P0271	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Sensor Circuit 2. Sensor 3. ECM

3. Schematic:



4. Diagnostic Steps:

Note


Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

- (a) Check the fuel injector wiring harness connector for damage, poor connection, aging or signs of loosening.

Next

Step 2 Measure the resistance of fuel injector assembly.




- (a) Disconnect the fuel injector wiring harness connector EN14.
- (b) Measure resistance between the two fuel injector terminals. Standard Resistance: 20°C (68 °F) 11.5-12.5 Ω
- (c) Connect the fuel injector wiring harness connector EN14.

No

Replace fuel injector assembly. Refer to [2.2.8.2 Fuel Injector Replacement](#)

Yes

Step 3 Measure fuel injectors working power supply.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.4 fuel injector wiring harness connector EN14.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between cylinder No.4 fuel injector wiring harness connector EN14 No.1 terminal and a reliable ground. Standard Voltage: 11-14 V
- (e) Connect cylinder No.4 fuel injector wiring harness connector EN14.

Is voltage normal?


No

Go to step 5

Yes

Step 4 Check the fuel injector control circuit.

Cylinder No.4 Fuel Injector Harness Connector EN14



FE02-5072b



- (a) Turn the ignition switch to "OFF" position.
 - (b) Disconnect cylinder No.1 fuel injector wiring harness connector EN14.
 - (c) Connect test lamp made from light-emitting diodes to the fuel injector wiring harness connector EN14 terminal No.1 and No.2.
 - (d) Start the engine.
 - (e) Check whether the test lamp is flashing as per normal.
- Is test lamp flashing as per normal?

No Go to step 6

Yes Go to step 7

Step 5 Check and repair cylinder No.4 fuel injector power supply circuit.

Cylinder No.4 Fuel Injector Harness Connector EN14



FE02-5073b


- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the fuel injector wiring harness connector EN14.
- (c) Remove the engine main relay.
- (d) Measure resistance between cylinder No.4 fuel injector wiring harness connector EN14 terminal No.1 and engine main relay terminal No.3.
- (e) Measure resistance between cylinder No.4 fuel injector wiring harness connector EN14 terminal No.1 and a reliable ground

Test Items	Standard Value
EN14 (1) and Main Relay Terminal No.3	Less than 1 Ω
EN14 (1) and a Reliable Ground	10 kΩ or higher

- (f) Install the engine main relay.
 - (g) Connect cylinder No.4 fuel injector wiring harness connector EN14.
- Exclude the fuel injector power supply circuit fault.

Next Go to step 9

Step 6 Check cylinder No.4 fuel injector control circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect cylinder No.4 fuel injector wiring harness connector EN14.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between cylinder No.4 fuel injector wiring harness connector EN14 terminal No.1 and ECM harness connector terminal No.64. Check whether the circuit is open. If there is no open circuit, repair the faulty part.
- (e) Measure resistance between cylinder No.4 fuel injector wiring harness connector EN14 terminal No.1 and a reliable ground. Check whether the circuit is short to ground. If there is no short circuit, repair the faulty part.
- (f) Measure voltage between cylinder No.4 fuel injector wiring harness connector EN14 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply. If there is no short circuit, repair the faulty part.

Test Items	Standard Value
Resistance Between EN14 (1) and EN01 (64)	Less than 1 Ω
Resistance Between EN14 (1) and a Reliable Ground	10 kΩ or higher
Voltage Between EN14 (1) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 7	Check ECM power supply circuit.
--------	---------------------------------

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No → Repair the faulty part.

Yes

Step 8	Replace ECM.
--------	--------------

Next

Step 9	Use scan tool to confirm whether the DTC code is stored again.
--------	--

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 10 Diagnostic completed.

5. Repair Instructions:

Replace the fuel injector. Refer to [2.2.8.2 Fuel Injector Replacement](#).

2.2.7.28 DTC P0300-P0304

1. DTC Descriptor:

DTC	P0300	Multi-Cylinder Misfire
DTC	P0301	Cylinder No.1 Misfire
DTC	P0302	Cylinder No.2 Misfire
DTC	P0303	Cylinder No.3 Misfire
DTC	P0304	Cylinder No.4 Misfire


The engine control module (ECM) uses information from the crankshaft position (CKP) sensor and the camshaft position (CMP) sensors to determine when an engine misfire is occurring. By monitoring variations in the crankshaft rotation speed for each cylinder ECM is able to detect individual misfire events. When a misfire happens, unburnt mixture will be discharged into the exhaust system and burnt in the exhaust system. A misfire rate that is high enough can cause 3-way catalytic converter damage. The malfunction indicator lamp (MIL) will flash ON and OFF when the conditions for catalytic converter damage are present. A DTC will be set.

2. DTC Code Set Up and Removal Conditions:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0300 P0301 P0302 P0303 P0304	<ol style="list-style-type: none"> 1. A Misfire Rate Sufficient to Cause Damage to Catalytic Converters 2. A Misfire Rate Sufficient to Cause the Emission Deterioration 3. Doubtful Error 	<ol style="list-style-type: none"> 1. Each Cylinder Catalytic Converter Damage Related Misfire Counters. 2. Catalytic Converter Damage Misfire Rate More Than 4.5% -20%. 3. Four Emissions Related All Cylinder Misfire Counts In One Driving Cycle. 4. Misfire Rate Causing Emission Deterioration More Than 3.0%. 5. After Starting Each Cylinder Emission Related Misfire Counts During a Count Cycle. 6. Undetected Bad Circuit. 7. Fuel Control Inactivated. 8. Torque Intervention Inactivated. 9. Engine speed is greater than 600 rpm and less than 5,000 rpm. 10. Intake air temperature is greater than -30°C (-22 °F). 	<ol style="list-style-type: none"> 1. Connector Loose or Poor Connection 2. Vacuum Tube Hose Broken or Loose 3. Ignition System 4. Fuel Injectors 5. Fuel Pressure 6. Intake Air Pressure Sensor 7. Engine Coolant Temperature Sensor 8. Cylinder Compression Pressure 9. Valve Clearance and Timing 10. Evaporative Emission Control System 11. Purged Crankcase Ventilation System 12. Intake System 13. Poor Exhaust System Ventilation 14. ECM


3. Schematic:

Ignition System



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Fuel Injector



FE02-5076b

4. Diagnostic Steps:

Note

- If the control system stores DTC other than misfire, diagnose these DTC first and eliminate the faults.
- If the vehicle does not have a misfire when sent to a service station, road test the vehicle, so that the misfire will occur again. Use scan tool to record ECM data when misfire is occurring, in order to facilitate analyzing the cause of the fault.
- If after a long period road test, ECM does not store any misfire associated DTC codes, then the fault may be due to the following reasons:
 - Overfill fuel tank and fuel enters into the evaporative emission control system, so that the mixture is too rich and causes misfire.
 - Use improper fuel caused poor combustion and misfire.
 - Contaminated spark plug causes the ignition failure and misfire.
 - Carry out basic checks at fault locations identified by DTC codes.
- Road test the vehicle after repair to confirm no DTC is stored.

Step 1	Initial inspection.
--------	---------------------

- (a) Check the wiring harness connector for damage, poor connection, aging or signs of loosening.

- (b) Check the vacuum tube for damaged, loose, leakage and so on.

Next

Step 2 Check for other DTC codes.

- (a) Connect scan tool to the datalink connector.
 (b) Turn the ignition switch to "ON" position.
 (c) Press the scan tool power button.
 (d) Select the following menu items: Engine/Read DTC codes.
 (e) Read DTC codes.

Results:

DTC Codes Shown	To Step
DTC Codes Other Than DTC P0300-P0304	No
DTC P0300-P0304	Yes

No

Refer to [2.2.7.11 DTC Code Index](#)

Yes

Step 3 Check valves and air intake system.

- (a) Check vacuum solenoid valve Canister connection is correct or not and leakage.
 (b) Check the vacuum brake booster vacuum tube connection is correct or not and leakage.
 (c) Check the intake tube pressure sensor connection is correct or not and leakage.
 (d) Check purged crankcase ventilation valve, ventilation pipe connection is correct or not and leakage.
 (e) Check whether there is intake leakage.

Is there above mentioned fault?

Yes

Fault location. Go to step 17

No

Step 4 Check the Spark Plug.

- (a) Remove the spark plug from the misfire cylinder.
 (b) Check whether the spark plug gap is too large or too small.
 Standard Gap: 0.8-0.9 mm (0.031-0.035 in)
 (c) Check the existence of spark plug electrode erosion, damage.
 (d) Check whether the spark plug and the electrode part skirt is wet or not and check the existence of a serious gasoline leakage.
 (e) Reinstall the spark plug.

Is there above mentioned fault?

Yes

Replace the spark plug. Refer to [2.10.8.4 Spark Plug Replacement](#). Go to step 8

No

Note

Prior to the implementation of this program, the following conditions must be met:

1. Disconnect all fuel injector connectors.
2. Engine running time must not be longer than 5 s.

Step 5	Check whether the spark plug arcing is normal.
--------	--

- (a) Test the spark.
 - (b) Remove misfire cylinder ignition wires.
 - (c) Disconnect all fuel injector cylinder connectors.
 - (d) Install the ignition wires to the spark plug.
 - (e) Run the engine (the engine running time no longer than 5 s) and check the arcing.
 - (f) Reconnect all cylinder fuel injector connectors.
 - (g) Install the ignition wires.
- Is spark plug arcing normal?

No

Go to step 9

Yes

Step 6	Check the misfire cylinder compression pressure.
--------	--

- (a) For detailed steps. Refer to [2.6.7 Diagnostic Information and Procedures](#).
- Is cylinder compression pressure normal?

Yes

Go to step 10

No

Step 7	Check the cause of cylinder compression pressure too low. Refer to the "Engine Mechanical System" in the 2.6.7 Diagnostic Information and Procedures .
--------	--

Step 8	Check fuel and misfire cylinder fuel injectors.
--------	---

- (a) Check whether there is fuel injectors leakage and stagnate.
 - (b) Check fuel quality.
- Is there above mentioned fault?

Yes

Repair the faulty part. Go to step 17

No

Note

Prior to the implementation of this test, the following conditions must be met:

1. Disconnect all fuel injector connectors.

2. Run the engine for no longer than 5s.


Step 9 Use a properly working spark plug and check whether there is misfire cylinder arcing.

- (a) Replace the installed spark plug with a spark plug that works properly.
 - (b) Test spark plug.
 - (c) Remove misfire cylinder ignition wires.
 - (d) Disconnect all fuel injector cylinder connectors.
 - (e) Install the ignition wires to the spark plug.
 - (f) Run the engine (the engine running time no longer than 5 s) and check the arcing.
 - (g) Reconnect all cylinder fuel injector connectors.
 - (h) Install the ignition wires.
- Is spark plug arcing normal?

No → Check the ignition coil and ignition wire. Go to step 17

Yes → Replace the spark plug. Refer to [2.10.8.4 Spark Plug Replacement](#). Go to step 17

Step 10 Check ECM connector terminal voltage of the misfire cylinder fuel injector.



- (a) Turn the ignition switch to the "ON" position.
- (b) Connect ECM harness EN01.
- (c) Measure ECM harness connector EN01 terminal voltage according to the following table.

Connector Terminal	Standard Value
EN01 (49)	9-14 V
EN01 (50)	
EN01 (63)	
EN01 (64)	

Is voltage the specified value?

No → Check the fuel injector circuit. Refer to [2.2.7.24 DTC P0201 P0261 P0262](#)

Yes

Step 11 Check the misfire cylinder valve gap.

- (a) Refer to the "Engine Mechanical System" in the [2.6.8.20 Valve Clearance Adjustments](#). Is valve clearance normal?

No → Adjust the valve clearance. Go to step 17

Yes

Step 12 Check valve timing system.

- (a) Refer to the "Engine Mechanical System" in the [2.6.8.9 Timing Chain Cover Replacement](#), Is valve timing normal?

No

Adjust the valve timing. Go to step 17

Yes

Step 13 Check the fuel pressure.

- (a) Refer to "Fuel System" in the [2.3.7.7 Fuel Pressure Testing Procedure](#), Is fuel pressure normal?

No

Check fuel system: fuel pump, fuel filter, fuel pipe circuit and fuel pressure regulator. Go to step 17

Yes

Step 14 Check whether the data in the data stream table is normal.

- (a) Check intake air pressure sensor data.
 (b) Check engine coolant temperature sensor data.
 (c) Check throttle position sensor.
 Are these components normal?

No

Replace the damaged components. Go to step 17

Yes

Step 15 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
 (b) Check whether ECM ground circuit is normal.

No

Repair the faulty part.

Yes

Step 16 Replace ECM.

Next

Step 17 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
 (b) Turn the ignition switch to "ON" position.
 (c) Clear DTC code.
 (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
 (e) Road test the vehicle for at least 10 min.
 (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 18 Diagnostic completed.

5. Repair Instructions:

Replace the spark plug. Refer to [2.10.8.4 Spark Plug Replacement](#).

2.2.7.29 DTC P0321 P0322

1. DTC Descriptor:

DTC	P0321	Speed Reference Point Fault
DTC	P0322	No CKP Sensor Pulse Signal (Open or Short Circuit)


CKP sensor signal provides ECM with current crankshaft speed and position. CKP sensor produces an alternating voltage with changing amplitude and frequency. Frequency depends on the crankshaft speed and the AC output voltage depends on the CKP. CKP sensor works with a fixed 58X variable reluctance rotor on the crankshaft. ECM calculates the ignition timing, injection timing and controls knock ignition according to CKP sensor and camshaft position sensor input signal. CKP sensor is also used to detect misfire and tachometer display. ECM uses CAN network to send the engine speed signal to the instrument panel.

CKP sensor signal passes through the CKP sensor harness connector EN26 terminal No.1 and No.2 to ECM harness connector EN01 terminal No.47 and 46.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0321	Hardware Circuit Checks	<ol style="list-style-type: none"> Frequently add teeth to adjust. Frequently reduce teeth to adjust. Speed sensor signal exists but there is no reference. Frequently lose the reference. 	<ol style="list-style-type: none"> The count of adding a tooth is greater than 250 times. The count of reducing a tooth is greater than 250 times. The count of no record of the teeth missing is more than 6 times. The count of losing the missing teeth is greater than 2000 times.
P0322	Hardware Circuit Checks	No speed sensor signal is monitored after a certain number of phases.	<ol style="list-style-type: none"> Phase signal transition count is greater than 18 times. A low engine speed.

3. Schematic:



4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

- (a) Check the sensor wiring harness connector EN26 whether there is loose or poor connection and so on.
- (b) Check whether the sensor is installed correctly.
- (c) Check whether the sensor gap is normal.

No ➤ Fault location. Go to step 10

Yes

Step 2	Read the engine data (engine speed) on the scan tool.
--------	---

- (a) Connect scan tool to datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Select "Engine"/"Reading Data"/"Engine Speed."
- (d) Start the engine.
- (e) With the engine running, read the engine data on the scan tool.

Standard Value: Normal data. Refer to [2.2.7.9 Data Stream List](#)


- (f) If the engine does not start, check the data with the engine running.
- (g) If the engine speed is shown as "0", it indicates the circuit between the crankshaft position sensor and ECM wiring harness open or short.

Yes Go to step 4

No

Step 3 Intermittent Fault. Refer to [2.2.7.4 Fault Symptom Table](#).

Step 4 Check the sensor.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the crankshaft position sensor wiring harness connector EN26.
- (c) Measure crankshaft position sensor resistance.
Standard Resistance: 774-946 Ω at 23°C (73.4 °F)
- (d) Connect the crankshaft position sensor wiring harness connector EN26.

Is resistance normal?

No Replace the crankshaft position sensor. Refer to [2.10.8.2 Crankshaft Position Sensor Replacement](#). Go to step 10

Yes

Step 5 Check sensor terminal No.1 circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the crankshaft position sensor wiring harness connector EN26.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between crankshaft position sensor wiring harness connector EN26 terminal No.1 and ECM harness connector EN01 terminal No.47. Check whether the circuit is open.
- (e) Measure resistance between crankshaft position sensor wiring harness connector EN26 terminal No.1 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure resistance between crankshaft position sensor wiring harness connector EN26 terminal No.1 and power supply. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN26 (1) and EN01 (47)	Less than 1 Ω
Resistance Between EN26 (1) and a Reliable Ground	10 kΩ or higher
Voltage Between EN26 (1) and a Reliable Ground	0 V


Are the values specified values?

No

Repair the faulty part. Go to step 10

Yes

Step 6 Check sensor terminal No.2 circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect the crankshaft position sensor wiring harness connector EN26.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between crankshaft position sensor wiring harness connector EN26 terminal No.2 and ECM harness connector EN01 terminal No.46. Check whether the circuit is open.
- (e) Measure resistance between crankshaft position sensor wiring harness connector EN26 terminal No.2 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure resistance between crankshaft position sensor wiring harness connector EN26 terminal No.2 and power supply. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN26 (2) and EN01 (46)	Less than 1 Ω
Resistance Between EN26 (2) and a Reliable Ground	10 kΩ or higher
Voltage Between EN26 (2) and a Reliable Ground	0 V

Are the values the specified values?

Yes
 No
 Repair the faulty part. Go to step 10

Yes

Step 7 Check sensor signal plate.

- (a) Check whether the sensor signal plate is damaged, missing and so on.
- (b) Check whether the sensor signal plate is installed correctly.

Yes
 No
 Repair the faulty part. Go to step 10

Yes

Step 8 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

Yes
 No
 Repair the faulty part.

Yes

Step 9 Replace ECM.

Next

Step 10 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 11 Diagnostic completed.

5. Repair Instructions:

Replace crankshaft position sensor. Refer to [2.10.8.2 Crankshaft Position Sensor Replacement](#).

2.2.7.30 DTC P0327 P0328

1. DTC Descriptor:

DTC	P0327	Knock sensor signal circuit voltage is too low
DTC	P0328	Knock sensor signal circuit voltage is too high

KS sensor to ECM feedback signal helps ECM control the ignition timing to achieve the optimal operation and the ignition system to achieve the best performance, as well as to prevent damage to the engine by a potential knock. KS sensor is located below the intake manifold on the cylinder. KS sensor voltage changes with the AC signal generated by the vibration with running engine. Engine control module adjusts spark timing according to KS sensor signal amplitude and frequency.


ECM receives signals from KS sensor harness connector EN08 terminal No.1 and 2 through ECM harness connector EN01 terminal No.30 and 31.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
----------	------------------------	---	-----------------

<p>P0327</p>	<p>Signal Range Too Low</p>	<ol style="list-style-type: none"> Knock identification reference voltage is 0.35-0.60 V. It occurs for more than 30 times successively. Engine coolant temperature is greater than 40°C (104 °F). Engine speed is greater than 2,600 rpm. Cylinder No.1 can be identified. 	<ol style="list-style-type: none"> Sensor Circuit Sensor
<p>P0328</p>	<p>Signal Range Too Low</p>	<ol style="list-style-type: none"> Knock identification reference voltage is 36-150 V. It occurs more than 30 times successively. Knock control circuit has no malfunction. Jolt-limited feature is not activated. Engine load is greater than 39.8%. 	<ol style="list-style-type: none"> ECM

3. Schematic:



4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------

- (a) Check whether there is KS sensor physical damage.
- (b) Check whether KS sensor is installed correctly. Torque is set too tight or too loose will trigger DTC codes.
- (c) Check KS sensor installation surface whether there are glitches, casting flash and foreign matter.
- (d) Knock sensor must be kept away from hoses, brackets and engine wires.

Are above mentioned parts normal?

No

Repair the faulty part. Go to step 9

Yes

Step 2	Read the engine data (engine speed) on the scan tool.
--------	---

- (a) Connect scan tool to datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Select "Engine"/"Read Data"/"Knock Sensor Signal 1".
- (d) Start and run the engine at normal working temperature.
- (e) Road test the vehicle and read the engine speed data on the scan tool.

Is data normal?

Standard Value: Normal data. Refer to [2.2.7.9 Data Stream List](#)


No

Go to step 4

Yes

Step 3	Intermittent Fault. Refer to 2.2.7.4 Fault Symptom Table .
--------	--

Step 4	Check the knock sensor.
--------	-------------------------




- (a) Turn the ignition switch to "OFF" position.
 - (b) Disconnect Knock Sensor harness connector EN08.
 - (c) Measure knock sensor resistance.
Standard Resistance: 49 kΩ at 20°C (68 °F)
 - (d) Connect Knock Sensor harness connector EN08.
- Is resistance normal?

No

Replace the knock sensor. Refer to [2.10.8.5 Knock Sensor Replacement](#). Go to step 9

Yes

Step 5 Check sensor terminal No.1 circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect Knock Sensor harness connector EN08.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between knock sensor harness connector EN08 terminal No.1 and ECM harness connector EN01 terminal No.30. Check whether the circuit is open.
- (e) Measure resistance between knock sensor harness connector EN08 terminal No.1 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure voltage between knock sensor harness connector EN08 terminal No.1 and power supply. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN08 (1) and EN01 (30)	Less than 1 Ω
Resistance Between EN08 (1) and a Reliable Ground	10 kΩ or higher
Voltage Between EN08 (1) and a Reliable Ground	0 V


Are the values specified values?

No

Repair the faulty part. Go to step 9

Yes

Step 6 Check sensor terminal No.2 circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect Knock sensor harness connector EN08.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between knock sensor harness connector EN08 terminal No.2 and ECM harness connector EN01 terminal No.31. Check whether the circuit is open.
- (e) Measure resistance between knock sensor harness connector EN08 terminal No.2 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure voltage between knock sensor harness connector EN08 terminal No.2 and power supply. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN08 (2) and EN01 (31)	Less than 1 Ω
Resistance Between EN08 (2) and a Reliable Ground	10 kΩ or higher
Voltage Between EN08 (2) and a Reliable Ground	0 V

Are the values specified values?

No Repair the faulty part. Go to step 9

Yes

Step 7 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 8 Replace ECM.

Next

Step 9 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 10	Diagnostic completed.
---------	-----------------------

5. Repair Instructions:

Replaced the knock sensor. Refer to [2.10.8.5 Knock Sensor Replacement](#).

2.2.7.31 DTC P0340-P0343

1. DTC Descriptor:

DTC	P0340	Camshaft Position Sensor Incorrectly Installed
DTC	P0341	Camshaft Position Sensor Poor Connection
DTC	P0342	Camshaft Position Sensor Circuit Short to Ground
DTC	P0343	Camshaft Position Sensor Circuit Short to Power Supply

CMP links the crankshaft position to the camshaft position, so that ECM calculates cylinder No.1 compression TDC and determines at what time to which cylinder spray fuel.

Camshaft position sensor circuit includes the following:

- Reference Voltage: ECM provides a reference voltage to CMP sensor harness connector EN15 terminal No.1 via ECM harness connector EN01 terminal No.39.
- Signal Circuit: ECM receives signal voltage from CMP sensor harness connector EN15 terminal No.2 via ECM harness connector EN01 terminal No.42.

ECM Low Reference Voltage Circuit: ECM provides a low reference voltage to CMP sensor harness connector EN15 terminal No. 3 via ECM harness connector EN01 terminal No.14 and 18.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0340	Poor Connection	1. Phase signal register value is equal to 255, or equal to 0. 2. Phase signal transition count is greater than 4.	1. Sensor Circuit 2. Sensor 3. ECM
P0341	Poor Connection	Phase signal register value is greater than 0 and less than 255 at the same time does not equal 170 and 85.	
P0342	Short to Ground	Phase signal register value is equal to 0.	
P0343	Short to Power Supply	Phase signal register value is equal to 255.	

3. Schematic:

Refer to [2.2.7.29 DTC P0321 P0322](#).

4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Initial Inspection
--------	--------------------


- (a) Check the sensor wiring harness connector EN15 whether there is loose or poor connection and so on.
 - (b) Check whether the sensor is installed correctly.
 - (c) Check whether the sensor gap is normal.
- Are above mentioned parts normal?

No

Repair the faulty part. Go to step 12

Yes

Step 2	Measure sensor 5 V reference voltage.
--------	---------------------------------------



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect camshaft position sensor wiring harness connector EN15.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between camshaft position sensor wiring harness connector EN15 terminal No.3 and a reliable ground. Standard Voltage: 4.5-5.5 V
- (e) Connect camshaft position sensor wiring harness connector EN15.


Is the value specified value?

No

Go to step 6

Yes

Step 3	Measure the sensor signal circuit.
--------	------------------------------------




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect camshaft position sensor wiring harness connector EN15.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between camshaft position sensor wiring harness connector EN15 terminal No.2 and a reliable ground.
Standard Voltage: 4.5-5.5 V
- (e) Connect camshaft position sensor wiring harness connector EN15.

Is the value specified value?

No Go to step 7

Yes

Step 4 Test ECM internal low reference circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect camshaft position sensor wiring harness connector EN15.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between camshaft position sensor wiring harness connector EN15 terminal No.1 and a reliable ground.
Standard Resistance: Less than 3 Ω
- (e) Connect camshaft position sensor wiring harness connector EN15.

Is the value specified value?


No Go to step 8

Yes

Step 5 Replace the camshaft position sensor. Refer to [2.10.8.1 Camshaft Position Sensor Replacement](#).

Next Go to step 12

Step 6 Check the sensor 5 V reference voltage circuit.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect camshaft position sensor wiring harness connector EN15.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between camshaft position sensor harness connector EN015 terminal No.3 and ECM harness connector EN01 terminal No.18. Check whether the circuit is open.
- (e) Measure resistance between camshaft position sensor harness connector EN015 terminal No.3 and a reliable ground. Check whether there is short to ground circuit.
- (f) Measure voltage between camshaft position sensor harness connector EN015 terminal No.3 and power supply. Check whether there is short to power supply circuit.

Test Items	Standard Value
Resistance Between EN15 (3) and EN01 (18)	Less than 1 Ω
Resistance Between EN15 (3) and a Reliable Ground	10 kΩ or higher
Voltage Between EN15 (3) and a Reliable Ground	0 V

Execute next step as per normal.

Next Repair the faulty part. Go to step 12

Step 7	Check sensor signal circuit.
--------	------------------------------



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect camshaft position sensor wiring harness connector EN15.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between camshaft position sensor harness connector EN015 terminal No.2 and ECM harness connector EN01 terminal No.42. Check whether the circuit is open.
- (e) Measure resistance between camshaft position sensor harness connector EN015 terminal No.2 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure resistance between camshaft position sensor harness connector EN015 terminal No.2 and power supply. Check whether the circuit is short to power supply.


Test Items	Standard Value
Resistance Between EN15 (2) and EN01 (42)	Less than 1 Ω
Resistance Between EN15 (2) and a Reliable Ground	10 kΩ or higher
Voltage Between EN15 (2) and a Reliable Ground	0 V

Are the values specified values?

No Repair the faulty part. Go to step 12

Yes

Step 8 Check ECM internal low reference circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect camshaft position sensor wiring harness connector EN15.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between camshaft position sensor wiring harness connector EN15 terminal No.1 and ECM harness connector EN01 terminal No.39. Check whether the circuit is open.
- (e) Measure voltage between camshaft position sensor wiring harness connector EN15 terminal No.1 and a reliable ground. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN15 (1) and EN01 (39)	Less than 1 Ω
Voltage Between EN15 (1) and a Reliable Ground	0 V

Execute next step as per normal.

Next

Step 9 Check whether camshaft signal plate is normal.

No Repair the faulty part. Go to step 12

Yes

Step 10 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 11 Replace ECM.

Next

Step 12 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 13 Diagnostic completed.

5. Repair Instructions:

Replace the CMP sensor. Refer to [2.10.8.1 Camshaft Position Sensor Replacement](#).

2.2.7.32 DTC P0420

1. DTC Descriptor:

DTC	P0420	Three-way Catalytic Converter Oxygen Storage Capacity Aging (Emission Over the Limit)
-----	-------	---

ECM uses two oxygen sensors (Pre-Catalytic oxygen sensor and Post-Catalytic oxygen sensor) installed before and after the three-way catalytic converters to monitor the conversion efficiency of the three-way catalytic converter (TWC). ECM uses Pre-Catalytic oxygen sensor for Air-Fuel ratio close-loop control and monitors oxygen content in the exhaust gas not purified by TWC. The Post-Catalytic oxygen sensor sends voltage signal to ECM indicating the oxygen content in the exhaust gas purified by the TWC. ECM compares signals from the two sensors to determine whether the TWC is currently under normal working condition. If the calculated TWC conversion efficiency is too low, the fault lamp will be lit and the DTC code will be set.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0420	Exceed the Maximum Limit	<ol style="list-style-type: none"> After adjustment, the post-catalytic oxygen sensor signal is greater than the average amplitude, which is 0.48 V. Catalytic converter monitoring activation time is greater than 70 s. 	<ol style="list-style-type: none"> Pre-Catalytic Oxygen Sensor Post-Catalytic Oxygen Sensor Three-way Catalytic Converter Exhaust Leakage

3. Schematic:

Refer to [2.2.6.1 Schematic](#)

4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1 Check whether there are control system DTC codes other than DTC P0420.

- Connect scan tool to the datalink connector.
- Turn the ignition switch to "ON" position.
- Press the scan tool power button.
- Select the following menu items: Engine/Read DTC codes.
- Read DTC codes.

DTC Codes Shown	To Step
DTC P0420	Yes
DTC Code Other Than DTC P0420	No

No Refer to [2.2.7.11 DTC Code Index](#)

Yes

Step 2 Start the engine and turn on the scan tool.


Next

Step 3 Keep the engine speed at 2,500 rpm for more than 2 min to warm up the engine, until the engine coolant temperature reaches 80°C (176 °F).

Next

Step 4 Select on the scan tool: Engine/Read data/Group 1 oxygen sensor voltage 1 (Pre-Catalytic oxygen sensor), Group 1 oxygen sensor voltage 2 (Post-Catalytic oxygen sensor)

Next



Step 5 Observe Pre-Catalytic oxygen sensor and Post-Catalytic oxygen sensor output voltages.

Whether Pre-Catalytic oxygen sensor and Post-Catalytic oxygen sensor signal voltage is matching "Normal TWC" in the figure?

Yes

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

No

Warning!

Propane gas is a flammable gas. It is strictly prohibited to operate propane gas near a fire, otherwise it will cause a fire.

Step 6 Test the oxygen sensor signal.

- (a) If the voltage data is consistently below 0.45 V (mixture too lean), carry out the steps as following:
- Spray proper amount of propane gas into the intake.
 - Inspect whether the sensor voltage data changes significantly, as the signal voltage will increase rapidly.

Pre-Catalytic Oxygen Sensor Signal Voltage	Post-Catalytic Oxygen Sensor Signal Voltage	To Step
Obvious Change	No Change	A
No Change	Obvious Change	B
Obvious Change	No Change	C
No Change	No Change	D

B

Replace the pre-catalytic oxygen sensor. Refer to [2.4.7.2 Pre-Catalytic Oxygen Sensor Replacement](#). Go to step 11

C

Go to step 9

D

Check the cause for engine air-fuel ratio too lean/too rich. Refer to [2.2.7.4 Fault Symptom Table](#)

A

Step 7 Check whether there is exhaust leakage.

Yes

Repair the faulty part. Go to step 11

No

Step 8 Replace the three-way catalytic converter. Refer to [2.7.6.2 Three-way Catalytic Converter Replacement](#).

Next

Go to step 11

Step 9 Check whether there is exhaust leakage.

Yes

Repair the faulty part. Go to step 11

No

Step 10 Replace the post-catalytic oxygen sensor. Refer to [2.4.7.1 Post-Catalytic Oxygen Sensor Replacement](#).

Next

Step 11 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 12 Diagnostic completed.

2.2.7.33 DTC P0444 P0458 P0459

1. DTC Descriptor:

DTC	P0444	Canister Control Valve Control Circuit Open
DTC	P0458	Canister Control Valve Control Circuit Voltage Too Low
DTC	P0459	Canister Control Valve Control Circuit Voltage Too High


EVAP solenoid valve absorbs fuel vapor from the evaporative emission canister to the intake manifold. EVAP solenoid valve is controlled by the pulse width modulation (PWM). The circuit consists of:

- Operating Voltage: Battery voltage passes through ECM controlled main relay terminal No.3 to reach EVAP solenoid harness connector EN24 terminal No.1.
- ECM control circuit: EVAP solenoid valve wiring harness connector EN24 terminal No.2 is connected to ECM harness connector EN01 terminal No.37. ECM has an internal driver circuit to control the solenoid valve ground. Driver circuit is equipped with a ECM feedback circuit. ECM monitors the feedback voltage to determine whether the control circuit is open, short to ground or short to power supply.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0444 P0458 P0459	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Canister Solenoid Valve Circuit 2. Solenoid Valve 3. ECM

3. Schematic:



4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1	Test the Canister solenoid valve with a scan tool.
--------	--

- (a) Connect scan tool to the "Data Link Connector".
- (b) Disconnect the Canister solenoid valve to the Canister vacuum tubes.
- (c) Start engine and turn on the scan tool.


- (d) Select the following menu: "Engine"/"Action Test"/"Canister Solenoid Valve".
- (e) Use scan tool to enable the use of "Canister Control Valve". Place a finger over the vacuum port solenoid valve and check whether there is suction.

Yes

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

No

Step 2 Measure canister solenoid valve resistance.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect canister solenoid valve harness connector EN24.
- (c) Measure resistance between the canister solenoid valve two terminals.

Standard Resistance: 25 Ω at 20°C (68 °F)


- (d) Connect canister solenoid valve harness connector EN24. Is the value specified value?

No

Replace the canister solenoid valve. Refer to [2.4.7.3 Canister Solenoid Valve Replacement](#). Go to step 7

Yes

Step 3 Measure canister solenoid valve working power supply.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect canister solenoid valve harness connector EN24.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between canister solenoid valve wiring harness connector EN24 terminal No.1 and a reliable ground.

Standard Voltage: 11-14 V


- (e) Connect canister solenoid valve harness connector EN24. Is the value specified value?

No

Check whether there is an open circuit or a circuit short to ground between solenoid valve wiring harness connector EN10 terminal No. 1 and main relay terminal No.3. Repair the faulty part. Go to step 7

Yes

Step 4 Check canister solenoid valve control circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect canister solenoid valve harness connector EN24.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between canister solenoid valve wiring harness connector EN24 terminal No.2 and ECM harness connector EN01 terminal No.37. Check whether the circuit is open.
- (e) Measure resistance between canister solenoid valve wiring harness connector EN24 terminal No.2 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure voltage between canister solenoid valve wiring harness connector EN24 terminal No.2 and a reliable ground. Check whether the circuit is short to power supply.

Test Items	Standard Value
Resistance Between EN24 (2) and EN01 (37)	Less than 1 Ω
Resistance Between EN24 (2) and a Reliable Ground	10 kΩ or higher
Voltage Between EN24 (2) and a Reliable Ground	0 V

Are the values specified values?

No Repair or replace the wiring harness connectors. Go to step 7

Yes

Step 5 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes

Step 6 Replace ECM.

Next

Step 7 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 8 Diagnostic completed.

5. Repair Instructions:

Replace EVAP solenoid valve. Refer to [2.4.7.3 Canister Solenoid Valve Replacement](#).

2.2.7.34 DTC P0480 P0481 P0691 P0692 P0693 P0694

1. DTC Descriptor:

DTC	P0480	Cooling Fan Relay Control Circuit Open (Low Speed)
DTC	P0482	Cooling Fan Relay Control Circuit Malfunction (High Speed)
DTC	P0691	Cooling Fan Relay Control Circuit Short to Ground (Low Speed)
DTC	P0692	Cooling Fan Relay Control Circuit Short to Power Supply (Low Speed)
DTC	P0693	Cooling Fan Relay Control Circuit Short to Ground (High Speed)
DTC	P0694	Cooling Fan Relay Control Circuit Short to Power Supply (High Speed)

High or low speed cooling fan relay coil power is provided by ECM controlled main relay. ECM controls the relay via ECM harness connector EN01 terminal No.52 and 62. ECM has an internal driver circuit that controls the relay coil ground. Drive circuit is equipped with a feedback circuit to ECM. ECM monitors the feedback voltage control circuit to determine whether the control circuit is open, short to ground or short to ground.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0480	Hardware Circuit Checks	Circuit Open.	1. Relay Circuit 2. Relay 3. ECM
P0481	Hardware Circuit Checks	Circuit Open.	
P0691	Hardware Circuit Checks	Circuit Short to Ground.	
P0692	Hardware Circuit Checks	Circuit Short to Power Supply.	
P0693	Hardware Circuit Checks	Circuit Short to Ground.	
P0694	Hardware Circuit Checks	Circuit Short to Power Supply.	

3. Schematic:

Refer to [2.8.6.1 Schematic](#).

4. Diagnostic Steps:

Refer to [2.8.7.2 Cooling Fan Circuit Diagnosis](#).

5. Repair Instructions:

Replace the cooling fan. Refer to [2.8.8.3 Cooling Fan Replacement](#).

2.2.7.35 DTC P0501

1. DTC Descriptor:

DTC	P0501	Unreasonable Vehicle Speed Sensor Signal
-----	-------	--


The vehicle speed signal is used to monitor the vehicle speed. The vehicle speed signal is one of the fuel control reference signals during an urgent deceleration. The vehicle speed sensor working voltage is provided by The Main Relay which is controlled by ECM via ECM harness connector EN01 terminal No.57. The vehicle speed sensor signal is sent to the instrument panel used for the vehicle speed display.

2. Conditions For Setting DTC and The Fault Location:


DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0501	Low Limit for Stopping Fuel Supply	<ol style="list-style-type: none"> The vehicle speed is less than 5 km/h. Stopping Fuel Supply Enabled. Engine coolant temperature is higher than 64.5°C. (148.1 °F) . Engine speed is greater than 1,520 rpm and less than 4,000 rpm. 	<ol style="list-style-type: none"> Vehicle Speed Sensor Circuit Vehicle Speed Sensor ECM

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



3. Schematic:



4. Diagnostic Steps:


Step 1	Road test the vehicle. Is the vehicle speed meter display working properly?
--------	---

- (a) If the instrument panel displays the vehicle speed as per normal, the vehicle speed sensor is working correctly.
- (b) If the instrument panel displays the vehicle speed abnormally, the vehicle speed sensor or the circuit may be faulty.

No ➤ Go to step 3

Yes

Step 2	Check the vehicle speed signal circuit.
--------	---



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect speed sensor wiring harness connector EN21.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between the vehicle speed sensor harness connector EN21 terminal No.3 and ECM harness connector EN01 terminal No.57. Check whether the circuit is open.
- (e) Measure resistance between the vehicle speed sensor harness connector EN21 terminal No.3 and a reliable ground. Check whether the circuit is short to ground.
- (f) Measure voltage between the vehicle speed sensor harness connector EN21 terminal No.3 and power supply. Check whether the circuit is short to power supply.


Test Items	Standard Value
Resistance Between EN21 (2) and EN01 (57)	Less than 1 Ω
Resistance Between EN21 (2) and a Reliable Ground	10 kΩ or higher
Voltage Between EN21 (2) and a Reliable Ground	0 V

Are the values specified values?

No Repair or replace the wiring harness connector. Go to step 8

Yes Go to step 6

Step 3 Check the vehicle speed sensor power supply circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect speed sensor wiring harness connector EN21.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between vehicle speed sensor harness connector EN21 terminal No.1 and a reliable ground.

Standard Voltage: 11-14 V


- (e) Connect vehicle speed sensor harness connector EN21.

Is the value specified value?

No Check whether there is a short circuit between the vehicle speed sensor terminal No.3 and the main relay terminal No.87. Repair the faulty part.

Yes

Step 4 Check the vehicle speed sensor ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect speed sensor wiring harness connector EN21.
- (c) Measure resistance between vehicle speed sensor harness connector EN21 terminal No.2 and a reliable ground. Check whether the circuit is short to ground.

Standard Resistance: Less than 1 Ω

Is the value specified value?

No

Check whether there is an open circuit between the vehicle speed sensor terminal No.2 and a reliable ground. Repair the faulty part.

Yes

Step 5 Replace the vehicle speed sensor.

Next

Go to step 8

Step 6 Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No

Repair the faulty part.

Yes

Step 7 Replace ECM.

Next

Step 8 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 9 Diagnostic completed.

2.2.7.36 DTC P0506-P0509 P0511

1. DTC Descriptor:

DTC	P0506	Controlled Idle Speed Lower Than Target Idle Speed
DTC	P0507	Controlled Idle Speed Higher Than Target Idle Speed
DTC	P0508	Stepper Motor Driver Pin Short to Ground
DTC	P0509	Stepper Motor Driver Pin Short to Power Supply
DTC	P0511	Stepper Motor Driver Pin Circuit Open

ECM controls the engine idle speed by regulating the IAC valve core shaft position. IAC valve's two internal coils are driven by the stepper motors. idle air control valve's move is controlled by 4 circuits. ECM's driver controls idle air control valve two wires polarity via these circuits. ECM commands the IAC valve stepper motor rotate clockwise or counterclockwise. IAC valve motor is connected to the idle air control spool shaft through the driver screw. ECM sends electrical pulses to the IAC valve coils to allow the core shaft stretch into or contract out of the throttle body channel. Through the core shaft, air flow increases, so the engine speed increases. When the pivotal stretches, the air flow decreases, therefore the engine speed is reduced. If the engine control module detects the engine speed is not in the expected range, the DTC codes will be set.


ECM harness connector EN01 terminals No. 21,22,35,36 are connected to IAC valve harness connector EN17 terminals B, A, C, D.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0506	Idle actuator stays at a small opening position.	<ol style="list-style-type: none"> Static target idle speed and the actual idle speed difference is less than 200 rpm. Idle speed integral part is equal to the minimum. Canister solenoid valve opening is less than 100%. The engine is at idle speed. The vehicle speed is equal to 0. Engine coolant temperature is higher than 80.3°C (176.5 °F) . Intake air temperature is higher than 20.3°C (68.5 °F). 	<ol style="list-style-type: none"> Idle Air Control Valve Circuit Idle Speed Control Valve Intake System ECM

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0507	Idle actuator stays at a big opening position.	<ol style="list-style-type: none"> 1. Static target idle speed and the actual idle speed difference is less than 100 rpm. 2. Idle speed integral part is equal to the maximum. 3. Canister solenoid valve opening is less than 100%. 4. The engine is at idle speed. 5. The vehicle speed is equal to 0. 6. Engine coolant temperature is higher than 80.3°C (176.5 °F) . 7. Intake air temperature is higher than 20.3°C (68.5 °F). 	
P0508	Hardware Circuit Checks	One stepper motor pin is short to ground.	
P0509		One stepper motor pin is short to battery positive cable.	
P0511		One stepper motor pin is in an open circuit.	

3. Schematic:



4. Diagnostic Steps:

Note

Before carrying out this diagnosis step, observe the data list on scan tool and analyze the accuracy of the data, as these will help with quick diagnosis.

Step 1 Use scan tool to carry out idle air control valve action test.

- (a) Connect scan tool to the datalink connector.
- (b) Start engine and turn on the scan tool.
- (c) Select the following: the "Engine"/"Action Test"/"Idle Speed Control".
- (d) Use scan tool "Function Test" command to enable IAC valve opening. Increase the speed up to 1,800 rpm and decrease to 800 rpm, and then increase to 1,800 rpm.

Whether the engine speed follows the instructions rise and fall steadily?

Yes

Intermittent Fault. Refer to [2.2.7.4 Fault Symptom Table](#)

No

Step 2 Check the following items.

- (a) Throttle body damage or blockage.
- (b) Is idle air control channel blocked?
- (c) Is there too much residue on the throttle?
- (d) Is there too much residue on the throttle?
- (e) Is there too much residue on the idle air control core shaft?
- (f) Is intake blocked?


Any above mentioned fault?

Yes

Repair the faulty parts. Go to step 10

No

Step 3 Check idle speed control valve.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect idle speed control valve wiring harness connector EN17.
- (c) Measure idle speed control valve resistance.

Tester Connection	Standard Value
AD, BC	40-50 Ω
AC, BD	10 kΩ or higher

- (d) Connect idle speed control valve wiring harness connector EN17.


Voltage normal?

No

Replace idle speed control valve. Refer to [2.2.8.1 Idle Air Control Valve Replacement](#).
Go to step 10

Yes

Step 4 Check idle speed control Valve terminal A circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect idle speed control valve wiring harness connector EN17.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between idle speed control valve wiring harness connector EN17 terminal A and ECM harness connector EN01 terminal No.22. The standard value parameter is in the table below.
- (e) Measure resistance between idle speed control valve wiring harness connector EN17 terminal A and a reliable ground. The standard value parameter is in the table below.
- (f) Measure voltage between idle speed control valve wiring harness connector EN17 terminal A and a reliable ground. The standard value parameter is in the table below.

Test Items	Standard Value
Resistance Between EN17 (A) and EN01 (22)	Less than 1 Ω
Resistance Between EN17 (A) and a Reliable Ground	10 kΩ or higher
Voltage Between EN17 (A) and a Reliable Ground	0 V


Are the values specified values?

No

Repair or replace the wiring harness connector. Go to step 10

Yes

Step 5 Check idle speed control valve terminal B circuit.




- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect idle speed control valve wiring harness connector EN17.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between idle speed control valve wiring harness connector EN17 terminal B and ECM harness connector EN01 terminal No.21. The standard value parameter is in the table below.
- (e) Measure resistance between idle speed control valve wiring harness connector EN17 terminal B and a reliable ground. The standard value parameter is in the table below.
- (f) Measure voltage between idle speed control valve wiring harness connector EN17 terminal B and a reliable ground. The standard value parameter is in the table below.

Test Items	Standard Value
Resistance Between EN17 (B) and EN01 (21)	Less than 1 Ω
Resistance Between EN17 (B) and a Reliable Ground	10 kΩ or higher
Voltage Between EN17 (B) and a Reliable Ground	0 V

Are the values specified values?

No Repair or replace the wiring harness connector. Go to step 10

Yes **Step 6** Check idle speed control valve terminal C circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect idle speed control valve wiring harness connector EN17.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between idle speed control valve wiring harness connector EN17 terminal C and ECM harness connector EN01 terminal No.35. The standard value parameter is in the table below.
- (e) Measure resistance between idle speed control valve wiring harness connector EN17 terminal C and a reliable ground. The standard value parameter is in the table below.
- (f) Measure voltage between idle speed control valve wiring harness connector EN17 terminal C and a reliable ground. The standard value parameter is in the table below.

Test Items	Standard Value
Resistance Between EN17 (C) and EN01 (35)	Less than 1 Ω
Resistance Between EN17 (C) and a Reliable Ground	10 kΩ or higher
Voltage Between EN17 (C) and a Reliable Ground	0 V


Are the values specified values?

No

Repair or replace the wiring harness connector. Go to step 10

Yes

Step 7 Check idle speed control valve terminal D circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect idle speed control valve wiring harness connector EN17.
- (c) Disconnect ECM harness connector EN01.
- (d) Measure resistance between idle speed control valve wiring harness connector EN17 terminal D and ECM harness connector EN01 terminal No.36. The standard value parameter is in the table below.
- (e) Measure resistance between idle speed control valve wiring harness connector EN17 terminal D and a reliable ground. The standard value parameter is in the table below.
- (f) Measure voltage between idle speed control valve wiring harness connector EN17 terminal D and a reliable ground. The standard value parameter is in the table below.

Test Items	Standard Value
Resistance Between EN17 (D) and EN01 (36)	Less than 1 Ω
Resistance Between EN17 (D) and a Reliable Ground	10 kΩ or higher
Voltage Between EN17 (D) and a Reliable Ground	0 V

Are the values specified values?

No Repair or replace the wiring harness connector. Go to step 10

Yes **Step 8** Check ECM power supply circuit.

- (a) Check whether ECM power supply circuit is normal.
- (b) Check whether ECM ground circuit is normal.

No Repair the faulty part.

Yes **Step 9** Replace ECM.

Next **Step 10** Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.

(f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 11 Diagnostic completed.

5. Repair Instructions:

Replace idle speed control valve. Refer to [2.2.8.1 Idle Air Control Valve Replacement](#).

2.2.7.37 DTC P0560 P0562 P0563

1. DTC Descriptor:

DTC	P0560	System Battery Voltage Signal Unreasonable
DTC	P0562	System Battery Voltage Too Low
DTC	P05673	System Battery Voltage Too High

ECM power supply circuit consists of the following:


- Battery power passes through ECM KAPWR fuse 10 A to ECM harness connector EN01 terminal No.16.
- When the ignition switch is turned to "ON" position, battery power passes through the ignition switch wiring harness connector IP23 terminal No.6, to ECM fuse 10 A and finally to ECM harness connector EN01 terminal No.17.
- When ECM detects that ECM harness connector EN01 terminal No.17 has battery voltage, ECM controls EN01 terminal No.32 connected to internal ground. Because EN01 terminal No.32 is connected to the main relay terminal No.1, the main relay pulls in.

After the main relay pulls in, the battery power passes through the main relay terminal No.3 to ECM harness connector EN01 terminals No.8 and 51.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0560	System check	Battery voltage is lower than 2.5 V.	1. ECM Power Supply Circuit 2. Generator 3. ECM
P0562	Lower Than the Lower Limit	1. Battery voltage is lower than 10.02 V. 2. Start time is longer than 180 s.	
P0563	Battery Voltage ADC Value	1. Battery voltage is higher than 17.02 V. 2. Vehicle speed is greater than 25 km/h. 3. Start time is longer than 180 s.	


3. Schematic:



FE02-5107b

4. Diagnostic Steps:

Step 1	Check ECM fuses EF04 and EF18.
--------	--------------------------------



FE02-5109b

- (a) Turn the ignition switch to "OFF" position.
- (b) Remove fuses EF04, EF18 from the I/P fuse block.
- (c) Use multimeter to measure whether there is conduction between the two terminals.


Conducted?

No

Check whether there are short circuits.
Replace the fuses.


Yes

Step 2	Check I/P fuse block ECM fuse IF12.
--------	-------------------------------------




- (a) Turn the ignition switch to "OFF" position.
- (b) Remove IF12 from the I/P fuse block.
- (c) Use multimeter to measure whether there is conduction between the two terminals.


Conducted?



Check whether there are short circuits.
Replace the fuses.




Step 3 Check ECM power supply voltage.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect ECM harness connector EN01.
- (c) Turn the ignition switch to "ON" position.
- (d) Measure voltage between ECM harness connector EN01 terminal No.16 and a reliable ground.
- (e) Measure voltage between ECM harness connector EN01 terminal No.17 and a reliable ground.

Standard Voltage: 11-14 V


Voltage normal?



Go to step 5




Step 4 Check ECM ground circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect ECM harness connector EN01.
- (c) Measure resistance between ECM harness connector EN01 terminal No.5 and a reliable ground.
- (d) Measure resistance between ECM harness connector EN01 terminal No.43 and a reliable ground.
- (e) Measure resistance between ECM harness connector EN01 terminal No.48 and a reliable ground.

Standard Resistance: Less than 1 Ω

Resistance normal?



ECM ground circuit is faulty. Repair the faulty part.

Yes

Step 5 Check charging system.


- (a) Check the battery voltage.
Standard Voltage: 11-14 V
- (b) Check the generator charging voltage.
Standard Resistance: 11.5-14.5 V

Normal?

No Repair the faulty part.

Yes Go to step 8

Step 6 Check EF04 fuse to ECM circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect ECM harness connector EN01.
- (c) Measure continuity between ECM harness connector EN01 terminal No.16 and the fuse No.EF04.
- (d) Measure resistance between ECM harness connector EN01 terminal No.16 and A reliable ground.

Standard Value:


Test Items	Specified Value
Continuity Between EN01 (16) and EF04	Conducted
Resistance Between EN01 (16) and a Reliable Ground	10 kΩ or higher

Normal?

No The wiring harness is faulty. Repair or replace the wiring harness.

Yes

Step 7 Check circuit between fuse IF12 and ECM.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect ECM harness connector EN01.
- (c) Measure continuity between ECM harness connector EN01 terminal No.17 and fuse IF12.
- (d) Measure resistance between ECM harness connector EN01 terminal No.17 and A reliable ground.

Standard Value:

Test Items	specified value
Continuity Between EN01 (17) and IF12	turn
Resistance Between EN01 (17) and a Reliable Ground	10 kΩ or higher

Normal?

No

The wiring harness is faulty. Repair or replace the wiring harness.

Yes

Step 8 Use scan tool to confirm whether the DTC code is stored again.

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Clear DTC code.
- (d) Start and run the engine at idle speed to warm up the engine for at least 5 min.
- (e) Road test the vehicle for at least 10 min.
- (f) Read control system DTC code again to confirm that the system has no DTC code.

No

Intermittent Fault. Refer to [2.2.7.3 Intermittent Fault Check](#)

Yes

Step 9 Replace ECM.

2.2.7.38 DTC P0602

1. DTC Descriptor:

DTC	P0602	Electronic Control Module DTC Codes Error

ECM Internal Process Errors

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0602	ECM Internal Monitoring	---	ECM

4. Diagnostic Steps:

Step 1	Check whether there is control system DTC code other than DTC P0602.
--------	--

- (a) Connect scan tool to the datalink connector.
- (b) Turn the ignition switch to "ON" position.
- (c) Press the scan tool power button.
- (d) Select the following menu items: Engine/Read DTC codes.
- (e) Read DTC codes.

Results:

DTC Codes Shown	To Step
DTC P0602	Yes
DTC Codes Other Than DTC P0602	No

No Refer to [2.2.7.11 DTC Code Index](#)

Yes

Step 2	Replace ECM.
--------	--------------

2.2.7.39 DTC P0627 P0628 P0629

1. DTC Descriptor:

DTC	P0627	Fuel Pump Relay Control Circuit Open
DTC	P0628	Fuel Pump Relay Control Circuit Short to Ground
DTC	P0629	Fuel Pump Relay Control Circuit Short to Power Supply


Fuel pump relay coil power is provided by the main relay under the control of ECM. ECM controls pump relay terminal No.1 to the internal ground by ECM harness connector EN01 terminal No.61 and so the fuel pump relay pulls in. ECM has an internal driver circuit that controls relay coil ground. The driver circuit is equipped with a feedback circuit to ECM. ECM monitors the feedback voltage control circuit to determine whether there is an open circuit, a circuit short to ground or power supply.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0627	Hardware Circuit Checks	Circuit Open.	1. Relay Circuit
P0628		Circuit Short to Ground.	2. Relay 3. ECM

P0629	Circuit Short to Power Supply.
-------	--------------------------------

3. Schematic:



4. Diagnostic Steps:

Check fuel pump relay circuit. Refer to [2.3.7.3 Fuel Pump Inoperative](#).

2.2.7.40 DTC P0645-P0647

1. DTC Descriptor:

DTC	P0645	A/C Compressor Relay Control Circuit Open
DTC	P0646	A/C Compressor Relay Control Circuit Short to Ground
DTC	P0647	A/C Compressor Relay Control Circuit Short to Power Supply

The Air-Conditioning compressor relay working voltage is provided by the main relay controlled by ECM. ECM controls air-conditioning compressor relay internal ground by ECM harness connector EN01 terminal No.60, so relay pulls in. ECM has a driver circuit that controls relay coil ground. The driver circuit is equipped with a feedback circuit to ECM. ECM monitors the feedback voltage control circuit to determine whether there is an open circuit or a circuit short to ground or power supply.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0645 P0646 P0647	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Air-Conditioning Relay 2. ECM

3. Schematic:

Refer to [8.2.6.2 Air-conditioning System Circuit Schematic](#).

4. Diagnostic Steps:

Refer to [8.2.7.6 Air-conditioning Clutch Inoperative](#).

2.2.7.41 DTC P0650

1. DTC Descriptor:

DTC	P0650	MIL Lamp Driver Malfunction

CAN network is used in vehicles. Fault lamps are controlled via the instrument panel circuit. When ECM DTC code is set to light fault lamps, ECM sends a "Light the fault lamp" signal through the CAN network the instrument panel. The instrument panel internal circuit light the fault lamp indicating engine fault after receiving the instruction from ECM.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P0650	Hardware Circuit Checks	1. Circuit Open. 2. Circuit Short to Ground. 3. Circuit Short to Power Supply.	1. Instrument Panel 2. CAN Bus

3. Diagnostic Steps:

Refer to [2.2.7.44 Engine Fault Lamp \(MIL\)/Check Vehicle Lamp Malfunction](#).

2.2.7.42 DTC P1610-P1614

1. DTC Descriptor:

DTC	P1610	Anti-theft Malfunction
DTC	P1611	Anti-theft Malfunction
DTC	P1612	Anti-theft Malfunction
DTC	P1613	Anti-theft Malfunction


DTC	P1614	Anti-theft Malfunction
-----	-------	------------------------

ECM communicates with the anti-theft control module via ECM harness connector EN01 terminal No.15 W-LIN and terminal No.23 R-LIN-line. For working details. Refer to.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P1610	Security keys and security codes are not programmed.	Turn the ignition switch to "ON".	1. Ignition Key 2. Ignition Key Coil 3. ECM 4. Chip Anti-theft Module 5. Data circuit (W-LIN circuit, R-LIN-line)
P1611	Security Code Error		
P1612	Security Request Not Accepted		
P1613	Security Code Request Services Not Accepted		
P1614	Anti-theft Transceiver Fails to Respond, Damaged or Malfunction		

3. Schematic:



4. Diagnostic Steps:

Refer to [2.5.7.12 Engine Anti-theft Warning Lamp Flashing, Vehicle Can Not Start.](#)

5. Repair Instructions:

Repair the anti-theft system. Refer to [2.5.7 Diagnostic Information and Procedures](#).

2.2.7.43 DTC P1523 U0001 U0121 U0140 U0151

1. DTC Descriptor:


DTC	P1523	airbag control module to ECU Signals Interrupted or Incorrect
DTC	U0001	CAN High-Speed Line Fault
DTC	U0121	Communications with ABS Controller Interrupted
DTC	U0140	Communications with BCM Controller Interrupted
DTC	U0151	Communications with airbag control module Controller Interrupted

In this vehicle, anti-lock brake system control module, airbag control module, body control module, engine control module and the instrument cluster are connected to the CAN bus, consisting a linear connection. The terminal resistors are set within the BCM and ECM.

2. Conditions For Setting DTC and The Fault Location:

DTC Code	DTC Detection Strategy	Conditions For Setting The DTC (Control Strategy)	Fault Locations
P1523 U0001 U0121 U0140 U0151	Hardware Circuit Checks	Communication signal loss, signal logic error.	1. Airbag control module, BCM (Body Control Module), ECM (Engine Control Module) 2. CAN Bus

3. Schematic:



FE02-5116b

4. Diagnostic Steps:

Refer to [11.17.7.6 CAN Bus Signal Diagnostic](#).

2.2.7.44 Engine Fault Lamp (MIL)/Check Vehicle Lamp Malfunction

Description:

CAN network is used in vehicles. Fault lamps are controlled via the instrument panel circuit. When ECM DTC code is set to light fault lamps, ECM sends a "Light the fault lamp" signal through the CAN network the instrument panel. The instrument panel internal circuit light the fault lamp indicating engine fault after receiving the instruction from ECM.

Diagnostic Steps:

Step 1	Check other fault lamps in the instrument cluster.
--------	--

- (a) Turn the ignition switch to "ON" position.
- Other fault lamps normal?

Yes Go to step 3

No

Step 2	Repair instrument cluster circuits.
--------	-------------------------------------

- (a) Repair instrument cluster power supply circuit. Refer to [11.7.6.7 DTC U129C U129D](#).

- (b) Repair instrument cluster ground circuit. Refer to [11.7.6.7 DTC U129C U129D](#).

Fault solved?

Yes System normal

No

Step 3 Check the instrument DTC codes.

- (a) Connect scan tool.
- (b) Turn the ignition switch to "ON" position.
- (c) Scan instrument DTC.

Is there DTC U1430?

Yes Go to step 5

No

Step 4 Test the fault indicator lamp.

- (a) Connect scan tool.
- (b) Turn the ignition switch to "ON" position.
- (c) Select on the scan tool "Fault indicator lamp test" menu within the "Function Test".

Is the fault indicator lamp lit?

Yes Go to step 6

No

Step 5 Replace the instrument cluster.

- (a) Turn off the ignition switch and remove the ignition key.
- (b) Disconnect the battery negative cable.
- (c) Replace the instrument cluster. Refer to [11.7.7.1 Instrument Cluster Replacement](#).

Fault solved?

Yes System normal

No

Step 6 Repair the instrument cluster and ECM network communication.

- (a) Repair the instrument cluster and ECM network communication. Refer to [11.17.7.4 CAN Bus Integrity Diagnosis](#).

Fault solved?

Yes System normal

No

Step 7	Repair ECM power supply circuit.
--------	----------------------------------

- (a) Repair ECM power supply circuit. Refer to [2.2.7.37 DTC P0560 P0562 P0563](#).

Fault solved?

Yes System normal

No

Step 8	Replace ECM.
--------	--------------

- (a) Connect scan tool.
- (b) Turn the ignition switch to "ON" position.
- (c) Scan ECM DTC codes, identify ECM fault. If necessary, Replace ECM. Refer to [2.2.8.8 Engine Control Module Replacement](#).
- (d) Clear DTC code.

Next

Step 9	System normal.
--------	----------------


2.2.7.45 Crankshaft rotates, but the engine can not start.

Note

Before carry out this step, make sure the engine oil is comply with the manufacturer requirements, the fuel tank has sufficient fuel and battery has enough power for starting engine. Observe the scan tool data list, analyze the accuracy of the data, as these will facilitate diagnostic.

Diagnostic Steps:

Step 1	Check fuel pump fuse.
--------	-----------------------



- (a) Check whether the fuel pump fuse is faulty.
- (b) Repair fuel pump fuse power circuit.
- (c) If necessary, replace the faulty fuel pump fuse.

Fault solved?

Yes System normal

No

Step 2 Scan ECM for DTC codes.

- (a) Connect scan tool.
 - (b) Turn the ignition switch to "ON" position.
 - (c) Scan ECM for DTC codes.
 - (d) Check DTC P0627 and any fuel system related DTC codes and repair the faulty part. Refer to [2.2.7.11 DTC Code Index](#).
 - (e) Clear ECM DTC codes.
- Start the engine, fault solved?

Yes

System normal

No

Step 3 Check fuel pump relay.

- (a) Connect scan tool.
 - (b) Turn the ignition switch to "ON" position.
 - (c) Select scan tool "Fuel Pump Relay" in the "Action Test" to drive the fuel pump relay.
- Is fuel pump relay working properly?

Yes

Go to step 6

No

Step 4 Replace the fuel pump relay.


- (a) Refer to "Fuel System" in the [2.3.7.3 Fuel Pump Inoperative](#).
 - (b) Replace the fuel pump relay.
 - (c) Inspect fuel pump relay circuits and repair the faulty part.
- Start the engine, fault solved?

Yes

System normal

No

Step 5 Check the fuel pump circuit.



- (a) Turn the ignition switch to "OFF" position.
- (b) Disconnect fuel pump harness connector SO29.
- (c) Connect scan tool.
- (d) Turn the ignition switch to "ON" position.
- (e) Select scan tool "Fuel Pump Relay" in the "Action Test" to drive the fuel pump relay.
- (f) Connect SO29 terminal 3 and 4 with a test lamp.


Is test lamp lit properly?

Yes

Go to step 8

No

Step 6 Repair the fuel pump circuit.



- (a) Turn the ignition switch to "ON" position.
- (b) Check the fuel pump working circuits. Repair the fuel pump relay open circuit fault between SO29 terminal No.3 and No. 5.

Start the engine, fault solved?

Yes

System normal

No

Step 7 Check the fuel pressure.

- (a) Turn the ignition switch to "OFF" position.
- (b) Install fuel pressure gage and connect scan tool.
- (c) Turn the ignition switch to "ON" position.
- (d) On the scan tool, select scan tool "Fuel Pump Relay" in the "Action Test" to drive the fuel pump relay.

Standard Fuel Pressure Value: 400 kPa

Is fuel pressure normal?

Yes

Go to step 9

No

Step 8 Replace the fuel pump.

- (a) Turn off the ignition switch and remove the ignition key.

- (b) Replace fuel pump assembly. Refer to [2.3.8.3 Fuel Pump Assembly Replacement](#).

Start the engine, fault solved?

Yes

System normal

No

Step 9 Inspect (repair) fuel injectors.

- (a) Inspect (repair) fuel injectors. Refer to the DTC code [2.2.7.24 DTC P0201 P0261 P0262](#) in the repair procedures. If necessary, replace the faulty fuel injectors.

Start the engine, fault solved?

Yes

System normal

No

Step 10 Check the ignition coil.

- (a) Turn the ignition switch to "OFF" position.
 (b) Remove the cylinder ignition wire. Connect a new wire connect the spark plug to a reliable ground.
 (c) Remove the fuel pump fuse.
 (d) Start the engine.

Is spark plug ignition normal?

Yes

Go to step 13

No

Step 11 Replace the ignition coil.

- (a) Turn off the ignition switch and remove the ignition key.
 (b) Replace the ignition coil. Refer to [2.10.8.3 Ignition Coil Replacement](#).

Start the engine, fault solved?

Yes

System normal

No

Step 12 Check crankshaft position sensor and circuit.

- (a) Check crankshaft position sensor. Refer to [2.2.7.29 DTC P0321 P0322](#).
 (b) Measure the crankshaft position sensor resistance with a multimeter.
 Standard Resistance: 870 Ω
 (c) Inspect the sensor circuit. Repair the faulty part. If necessary, replace the crankshaft position sensor. Refer to [2.10.8.2 Crankshaft Position Sensor Replacement](#).

Start the engine, fault solved?

Yes

System normal

No

Step 13 Test the cylinder pressure.

- (a) Test the cylinder pressure. Refer to the "Engine Mechanical System" in the.

Standard Cylinder Pressure: 800 kPa

All cylinders compression pressure equal to or higher than the specified value?

Yes

Go to step 16

No

Step 14 Timing Chain Inspection.

- (a) Turn off the ignition switch and remove the ignition key.
 (b) For timing chain inspection. Refer to "Engine Mechanical System" in the [2.6.8.11 Timing Chain Inspection](#).

Is timing chain positioned properly?

Yes

Go to step 16

No

Step 15 Install the timing chain.

- (a) Turn off the ignition switch and remove the ignition key.
 (b) Reinstall the timing chain. Refer to "Engine Mechanical System" in the [2.6.8.10 Timing Chain Replacement](#).

Start the engine, fault solved?

Yes

System normal

No

Step 16 Check mechanical parts inside the engine.

- (a) Remove the engine.
 (b) Check the mechanical parts inside the engine. If necessary, repair the damaged parts inside the engine.
 (c) identify the damaged parts repair has been completed.

Next

Step 17 Diagnostic completed.

2.2.7.46 Idle Speed Reading Procedure

Must carry out this procedure if any of the following occurs:

- Disconnect battery cables.

- Engine control module is disconnected or replaced.
- The fuse between the ignition voltage IGN1 or battery positive voltage and the engine control module is removed.
- The idle air control valve has been removed or replaced.
- idle air control system malfunction.

Read in procedure:

Step 1	Run the engine until the engine coolant temperature exceeds 90°C(194 °F).
Next	
Step 2	Run the engine at idle speed for 5min.
Next	
Step 3	Turn off the ignition switch.
Next	
Step 4	Read in procedure completed. Restart the engine and confirm that the engine idle speed is normal.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



2.2.8 Removal and Installation



2.2.8.1 Idle Air Control Valve Replacement

Removal Procedure:


Note

Refer to "Battery Disconnection Warning" in the "Warnings and Notices".

1. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
2. Disconnect idle speed control valve wiring harness connector.




3. Remove the idle speed control valve retaining bolts from the throttle body.



4. Remove the idle speed control valve from the throttle body.


Note

Do not drop the idle speed control valve O-ring.



Installation Procedure:

1. Clean carbon residue in the throttle body idle speed control valve air bypass.




2. Install and tighten idle speed control valve retaining bolts.

Note

Check the idle speed control valve O-ring is installed in good conditions.

Torque: 2.5 Nm (Metric) 1.85 lb-ft (US English)




3. Connect the idle speed control valve wiring harness connector.
4. Connect the battery negative cable.

2.2.8.2 Fuel Injector Replacement


Removal Procedure:

Warning!

Refer to "Battery Disconnection Warning" in the "Warnings and Notices".




1. Release fuel system pressure. Refer to [2.3.8.1 Fuel Pressure Release Procedure](#).
2. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
3. Remove the hood. Refer to [2.6.8.1 Plastic Engine Shield Replacement](#).
4. Disconnect the crankcase ventilation tube.




5. Disconnect the fuel injector wiring harness connector.

Note


Pull up the connector gray part of the self-locking device, and then press down to Disconnect the connector.



6. Remove the fuel pipe from the fuel rail.




7. Remove the fuel rail retaining bolts.




8. Remove the fuel rail and fuel injector assembly.

Note


Plug four fuel injector holes immediately after removal to prevent debris falling into the cylinder causing engine damage.



- Remove fuel injectors retaining clips.



- Pull fuel injectors out of the fuel rail.




Installation Procedure:


- Apply a small amount of engine oil to lubricate the fuel injector O-ring.
- Install the fuel injectors to the fuel rail.

Note


The fuel injector terminals should face outside.




3. Install fuel injector retaining clips to ensure that the fuel injector wiring harness connector and the fuel rail mounting hole are in the same direction.



4. Install the fuel rail.




5. Install the fuel rail retaining bolts.
Torque: 9 Nm (Metric) 6.66 lb-ft (US English)




6. Connect the fuel pipe.

Note


The fuel pipe must be inserted into the fuel rail after the second boss and then tightened with the clips.



7. Connect the fuel injector wiring harness connector.



8. Restore the self-locking device.



9. Install the crankcase ventilation tube.
10. Connect the battery negative cable.

Note

Start the engine. Check fuel and fuel injectors for fuel leaks and vacuum leaks.

11. Install the engine hood.


2.2.8.3 Throttle Position Sensor Replacement


Removal Procedure:

Note

Refer to "Battery Disconnection Warning" in the "Warnings and Important Notices".

1. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
2. Remove the throttle body assembly. Refer to [2.6.8.5 Throttle Body Assembly Replacement](#).
3. Remove the throttle position sensor retaining bolts.





Installation Procedure:

1. Install and tighten the throttle position sensor retaining bolts.

Note

During the installation procedure align the throttle shaft groove with the sensor boss.

2. Install the throttle body assembly.
3. Connect the battery negative cable.


2.2.8.4 VVT Solenoid Valve Replacement and Filter Cleaning


Removal Procedure:

Warning!

Refer to "Battery Disconnection Warning" in the "Warnings and Important Notices".

1. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
2. Remove the hood. Refer to [2.6.8.1 Plastic Engine Shield Replacement](#).
3. Disconnect VVT solenoid valve wiring harness connector.






4. Remove VVT solenoid valve retaining bolts and remove the VVT solenoid valve.

Installation Procedure:

Note


After replacing the VVT solenoid valve, you must carry out the "Clean Solenoid Valve Filter" procedure, other it cause electromagnetic valve damage.


1. Make sure the new VVT solenoid valve seals are intact. Apply a small amount of engine oil on the seal.




2. Install the VVT solenoid valve and fasten the retaining bolts.

Torque: 8 Nm (Metric) 6 lb-ft (US English)






3. Connect the VVT solenoid valve wiring harness connector.




Clean the solenoid valve filter:


1. Remove the generator. Refer to [2.11.8.3 Generator Replacement](#).
2. Remove the VVT solenoid valve filter sealing bolts.



3. Remove the VVT solenoid valve filter with a plier.



4. Clean the filter and make sure the solenoid valve is not damaged or deformed, otherwise it must be replaced.
5. Install the VVT solenoid valve filter.




6. Install the solenoid valve filter and tighten the bolts.
Torque: 16.5 Nm (Metric) 12.2 lb-ft (US English)
7. Install the generator.
8. Connect the battery negative cable.

2.2.8.5 VVT Solenoid Valve Cleaning

Note

- A. Inoperative near at high temperatures or near a fire to avoid cleaning agents being ignited or exploded.
- B. The length of wire should be more than 3m. It is recommended to install the wire relay.
- C. During the cleaning process, do not scratch the O-ring, scratch or knock the surface of the valve or drop the valve..
- D. After repair, reinstall the valve VVT and tightening the bolt to 10 Nm.
- E. Replace repeatedly cleaned VVT valve.




1. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
2. Remove VVT solenoid valve. Refer to [2.2.8.4 VVT Solenoid Valve Replacement and Filter Cleaning](#).
3. Clean the VVT solenoid valve hole, return hole, the chamber.

Note

During the cleaning process, keep the VVT solenoid valve and wiring harness connector upright, otherwise the cleaning agent will easily enter the VVT solenoid valve and cause internal damage.



4. Use an air gun to clean the VVT valve hole and oil chamber. Clean up the cleaning agent residue.



5. Switch on and off the VVT solenoid valve. Clean the valve with an air gun and repeat 2-3 times.

Note

Each time switch the valve on no longer than the 2 s, otherwise the VVT solenoid valve may be damaged.


2.2.8.6 Engine Coolant Temperature Sensor Replacement

Removal Procedure:

Warning!


Refer to "Cooling System Service Warning" in "Warnings and Notices".

1. Release cooling system pressure.
2. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
3. Disconnect the engine coolant temperature sensor wiring harness connector.
4. Remove the engine coolant temperature sensor.



Installation Procedure:




1. Apply sealant on the engine coolant temperature sensor thread.
2. Install the engine coolant temperature sensor.
3. Tighten the engine coolant temperature sensor.
Torque: 15 Nm (Metric) 11 lb-ft (US English)
4. Connect engine coolant temperature sensor wiring harness connector.
5. Fill the engine coolant.
6. Connect the battery negative cable.



2.2.8.7 Intake Air Pressure and Temperature Sensor Replacement

Removal Procedure:

1. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
2. Disconnect intake air pressure and temperature sensor wiring harness connector.
3. Remove the intake manifold assembly. Refer to [2.6.8.6 Intake Manifold Assembly Replacement](#).



4. Remove the sensor retaining bolts.


5. Pull out the intake air pressure and temperature sensor.

Installation Procedure:

1. Clean the intake air pressure and temperature sensor installation position and apply new seals.


Note

The seal is single used only. After removal, a new seal must be installed.




2. Install the sensor retaining bolt.

Torque: 9 Nm (Metric) 6.66 lb-ft (US English)



3. Install the intake manifold assembly.
4. Connect the intake air pressure and temperature sensors wiring harness connector.
5. Connect the battery negative cable.




2.2.8.8 Engine Control Module Replacement

Removal Procedure:

Warning!

Refer to "Battery Disconnection Warning" in "Warnings and Notices"

1. Disconnect the battery negative cable. Refer to [2.11.8.1 Battery Disconnection](#).
2. Remove the glove box. Refer to [12.8.3.2 Glove Box Replacement](#).
3. Disconnect the engine control module wiring harness connector.
4. Remove the engine control module retaining bolts.



Installation Procedure:

1. Install the engine control module retaining bolts.
Torque: 9 Nm (Metric) 6.66 lb-ft (US English)
2. Connect the engine control module wiring harness connector.
3. Install the glove box.
4. Connect the battery negative cable.

