

General Information

FL-3

General Information

Specifications

Fuel Delivery System

Items	Specification	
Fuel Tank	Capacity	50 lit. (13.2 U.S gal., 52.8 U.S.qt., 44.0 Imp.qt.)
Fuel Filter	Type	Paper type
Fuel Pressure Regulator	Regulated Fuel Pressure	345 ~ 355kpa (3.5 ~ 3.6 kgf / cm ² , 50.0 ~ 51.5 psi)
Fuel Pump	Type	Electrical, in-tank type
	Driven by	Electric motor
Fuel Return System	Type	Returnless

Sensors

Manifold Absolute Pressure Sensor (MAPS)

▷ Type: Piezo-resistive pressure sensor type

▷ Specification

Pressure (kPa)	Output Voltage (V)
20.0	0.79
46.7	1.84
101.32	4.0

Intake Air Temperature Sensor (IATS)

▷ Type: Thermistor type

▷ Specification

Temperature [°C(°F)]	Resistance (kΩ)
-40(-40)	40.93 ~ 48.35
-30(-22)	23.43 ~ 27.34
-20(-4)	13.89 ~ 16.03
-10(14)	8.50 ~ 9.71
0(32)	5.38 ~ 6.09
10(50)	3.48 ~ 3.90
20(68)	2.31 ~ 2.57
25(77)	1.90 ~ 2.10
30(86)	1.56 ~ 1.74
40(104)	1.08 ~ 1.21
60(140)	0.54 ~ 0.62
80(176)	0.29 ~ 0.34

Engine Coolant Temperature Sensor (ECTS)

▷ Type: Thermistor type

▷ Specification

Temperature [°C(°F)]	Resistance (kΩ)
-40(-40)	48.14
-20(-4)	14.13 ~ 16.83
0(32)	5.79
20(68)	2.31 ~ 2.59
40(104)	1.15
60(140)	0.59
80(176)	0.32

Throttle Position Sensor (TPS)

▷ Type: Variable resistor type

▷ Specification

Throttle Angle	Output Voltage (V)
C.T	0.25 ~ 0.9
W.O.T	Min. 4.0V

Items	Specification
Sensor Resistance (kΩ)	1.6 ~ 2.4 [20°C(68°F)]

FL-4**Fuel System***Heated Oxygen Sensor (HO2S)*▷ Type: Zirconia (ZrO₂) type

▷ Specification

A/F Ratio (λ)	Output Voltage (V)
Rich	0.6 ~ 1.0
Lean	0 ~ 0.4

Item	Specification
Heater Resistance (Ω)	Approx. 9.0 [20°C (68°F)]

Camshaft Position Sensor (CMPS)

▷ Type: Hall effect type

Crankshaft Position Sensor (CKPS)

▷ Type: Magnetic field sensitive Type

Item	Specification
Coil Resistance (Ω)	774 ~ 946 [20°C (68°F)]

Knock Sensor (KS)

▷ Type: Piezo-electricity type

▷ Specification

Item	Specification
Capacitance (pF)	950 ~ 1,350
Resistance (MΩ)	4.87



General Information

FL-5

Actuators

Injector

▷ Number: 4

▷ Specification

Item	Specification
Coil Resistance (Ω)	13.8 ~ 15.2 [20°C (68°F)]

Idle Speed Control Actuator (ISCA)

▷ Type: Double coil type

▷ Specification

Item	Specification
Closing Coil Resistance (Ω)	14.6 ~ 16.2 [20°C (68°F)]
Opening Coil Resistance (Ω)	11.1 ~ 12.7 [20°C (68°F)]

Duty (%)	Air Flow Rate (m ³ /h)
15	0.5 ~ 1.4
35	4.6 ~ 8.0
70	25.0 ~ 32.0
96	33.0 ~ 40.0

Purge Control Solenoid Valve (PCSV)

▷ Specification

Item	Specification
Coil Resistance (Ω)	16.0 [20°C (68°F)]

CVVT Oil Control Valve (OCV)

▷ Specification

Item	Specification
Coil Resistance (Ω)	6.9 ~ 7.9 [20°C (68°F)]

Ignition Coil

▷ Type: Stick type

▷ Specification

Item	Specification
Primary Coil Resistance (Ω)	0.75 Ω \pm 15% [20°C (68°F)]
Secondary Coil Resistance (k Ω)	7.0 k Ω \pm 15% [20°C (68°F)]



FL-6

Fuel System

Service Standard

Items	Specification		
Ignition Timing	BTDC $0^{\circ} \pm 10^{\circ}$		
Idle Speed	A/CON OFF	Neutral,N,P-range	660 \pm 100 rpm
		D-range	660 \pm 100 rpm
	A/CON ON	Neutral,N,P-range	660 \pm 100 rpm
		D-range	660 \pm 100 rpm

Tightening Torques

Engine Control System

Item	kgf.m	N.m	lb-ft
ECM installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Manifold absolute pressure sensor installation bolt	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Engine coolant temperature sensor installation	3.0 ~ 4.0	29.4 ~ 39.2	21.7 ~ 28.9
Throttle position sensor installation screw	0.15 ~ 0.25	1.5 ~ 2.5	1.1 ~ 1.8
Crankshaft position sensor installation bolt	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Camshaft position sensor installation bolt	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Knock sensor installation bolt	1.9 ~ 2.5	18.6 ~ 24.5	13.7 ~ 18.1
Heated oxygen sensor (Bank 1 / Sensor 1) installation	4.0 ~ 5.0	39.2 ~ 49.1	28.9 ~ 36.2
Heated oxygen sensor (Bank 1 / Sensor 2) installation	4.0 ~ 5.0	39.2 ~ 49.1	28.9 ~ 36.2
Idle speed control actuator installation bolt	0.6 ~ 0.8	5.9 ~ 7.8	4.3 ~ 5.8
CVVT Oil control valve installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Ignition coil installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Throttle body installation bolt/nut	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7




Fuel Delivery System

Item	kgf.m	N.m	lb-ft
Fuel tank installation bolt	4.5 ~ 6.0	44.1 ~ 58.8	32.5 ~ 43.4
Fuel tank installation nut	4.0 ~ 5.5	39.2 ~ 53.9	28.9 ~ 39.8
Fuel pump installation bolt	0.2 ~ 0.3	2.0 ~ 2.9	1.4 ~ 2.2
Filler-neck assembly installation bolt	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Filler-neck assembly installation screw	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Delivery pipe installation bolt	2.0 ~ 2.5	19.6 ~ 24.5	14.5 ~ 18.1

General Information

FL-7

Special Service Tools



Tool(Number and name)	Illustration	Application
09353-24100 Fuel Pressure Gauge	 <p style="text-align: right;">EFDA003A</p>	Measuring the fuel line pressure
09353-38000 Fuel Pressure Gauge Adapter	 <p style="text-align: right;">BF1A025D</p>	Connection between the delivery pipe and fuel feed line
09353-24000 Fuel Pressure Gauge Connector	 <p style="text-align: right;">EFDA003C</p>	Connection between Fuel Pressure Gauge (09353-24100) and Fuel Pressure Gauge Adapter (09353-38000)

FL-8

Fuel System

Basic Troubleshooting

Basic Troubleshooting Guide

1	Bring Vehicle to Workshop
2	Analyze Customer's Problem <ul style="list-style-type: none"> Ask the customer about the conditions and environment relative to the issue (Use CUSTOMER PROBLEM ANALYSIS SHEET).
3	Verify Symptom, and then Check DTC and Freeze Frame Data <ul style="list-style-type: none"> Connect Hi-Scan (Pro) to Diagnostic Link Connector (DLC). Record the DTC and freeze frame data. <p> NOTE</p> <p>To erase DTC and freeze frame data, refer to Step 5.</p>
4	Confirm the Inspection Procedure for the System or Part <ul style="list-style-type: none"> Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked.
5	Erase the DTC and Freeze Frame Data <p> WARNING</p> <p>NEVER erase DTC and freeze frame data before completing Step 2 MIL/DTC in "CUSTOMER PROBLEM ANALYSIS SHEET".</p>
6	Inspect Vehicle Visually <ul style="list-style-type: none"> Go to Step 11, if you recognize the problem.
7	Recreate (Simulate) Symptoms of the DTC <ul style="list-style-type: none"> Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC.
8	Confirm Symptoms of Problem <ul style="list-style-type: none"> If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11.
9	Recreate (Simulate) Symptom <ul style="list-style-type: none"> Try to recreate or simulate the condition of the malfunction as described by the customer.
10	Check the DTC <ul style="list-style-type: none"> If DTC(s) does(do) not occur, refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE. If DTC(s) occur(s), go to Step 11.
11	Perform troubleshooting procedure for DTC
12	Adjust or repair the vehicle
13	Confirmation test
14	END

LW8F1001

General Information

FL-9

Customer Problem Analysis Sheet

1. VEHICLE INFORMATION

VIN No.		Transmission	<input type="checkbox"/> M/T <input type="checkbox"/> A/T <input type="checkbox"/> CVT <input type="checkbox"/> etc.
Production date		Driving type	<input type="checkbox"/> 2WD (FF) <input type="checkbox"/> 2WD (FR) <input type="checkbox"/> 4WD
Odometer Reading	_____ km/mile	CPF (Diesel Engine)	<input type="checkbox"/> With CPF <input type="checkbox"/> Without CPF

2. SYMPTOMS

<input type="checkbox"/> Unable to start	<input type="checkbox"/> Engine does not turn over <input type="checkbox"/> Incomplete combustion <input type="checkbox"/> Initial combustion does not occur
<input type="checkbox"/> Difficult to start	<input type="checkbox"/> Engine turns over slowly <input type="checkbox"/> Other _____
<input type="checkbox"/> Poor idling	<input type="checkbox"/> Rough idling <input type="checkbox"/> Incorrect idling <input type="checkbox"/> Unstable idling (High: _____ rpm, Low: _____ rpm) <input type="checkbox"/> Other _____
<input type="checkbox"/> Engine stall	<input type="checkbox"/> Soon after starting <input type="checkbox"/> After accelerator pedal depressed <input type="checkbox"/> After accelerator pedal released <input type="checkbox"/> During A/C ON <input type="checkbox"/> Shifting from N to D-range <input type="checkbox"/> Other _____
<input type="checkbox"/> Others	<input type="checkbox"/> Poor driving (Surge) <input type="checkbox"/> Knocking <input type="checkbox"/> Poor fuel economy <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> Other _____

3. ENVIRONMENT

Problem frequency	<input type="checkbox"/> Constant <input type="checkbox"/> Sometimes (_____) <input type="checkbox"/> Once only <input type="checkbox"/> Other _____
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Other _____
Outdoor temperature	Approx. _____ °C/°F
Place	<input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner City <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Other _____
Engine temperature	<input type="checkbox"/> Cold <input type="checkbox"/> Warming up <input type="checkbox"/> After warming up <input type="checkbox"/> Any temperature
Engine operation	<input type="checkbox"/> Starting <input type="checkbox"/> Just after starting (_____ min) <input type="checkbox"/> Idling <input type="checkbox"/> Racing <input type="checkbox"/> Driving <input type="checkbox"/> Constant speed <input type="checkbox"/> Acceleration <input type="checkbox"/> Deceleration <input type="checkbox"/> A/C switch ON/OFF <input type="checkbox"/> Other _____

4. MIL/DTC

MIL (Malfunction Indicator Lamp)	<input type="checkbox"/> Remains ON <input type="checkbox"/> Sometimes lights up <input type="checkbox"/> Does not light
DTC	Normal check (Pre-check) <input type="checkbox"/> Normal <input type="checkbox"/> DTC (_____) <input type="checkbox"/> Freeze Frame Data
	Check mode <input type="checkbox"/> Normal <input type="checkbox"/> DTC (_____) <input type="checkbox"/> Freeze Frame Data

5. ECM/PCM INFORMATION

ECM/PCM Part No.	
ROM ID	

SDF28233L

FL-10

Fuel System

Basic Inspection Procedure

Measuring Condition of Electronic Parts' Resistance

The measured resistance at high temperature after vehicle running may be high or low. So all resistance must be measured at ambient temperature (20°C, 68°F), unless stated otherwise.


NOTICE

The measured resistance in except for ambient temperature (20°C, 68°F) is reference value.

Intermittent Problem Inspection Procedure

Sometimes the most difficult case in troubleshooting is when a problem symptom occurs but does not occur again during testing. An example would be if a problem appears only when the vehicle is cold but has not appeared when warm. In this case, the technician should thoroughly make out a "Customer Problem Analysis Sheet" and recreate (simulate) the environment and condition which occurred when the vehicle was having the issue.

1. Clear Diagnostic Trouble Code (DTC).
2. Inspect connector connection, and check terminal for poor connections, loose wires, bent, broken or corroded pins, and then verify that the connectors are always securely fastened.



BFG321A

3. Slightly shake the connector and wiring harness vertically and horizontally.
4. Repair or replace the component that has a problem.
5. Verify that the problem has disappeared with the road test.

● Simulating Vibration

- a. Sensors and Actuators

: Slightly vibrate sensors, actuators or relays with finger.

⚠WARNING

Strong vibration may break sensors, actuators or relays

- b. Connectors and Harness

: Lightly shake the connector and wiring harness vertically and then horizontally.

● Simulating Heat

- a. Heat components suspected of causing the malfunction with a hair dryer or other heat source.

⚠WARNING

• **DO NOT heat components to the point where they may be damaged.**

• **DO NOT heat the ECM directly.**

● Simulating Water Sprinkling

- a. Sprinkle water onto vehicle to simulate a rainy day or a high humidity condition.

⚠WARNING

DO NOT sprinkle water directly into the engine compartment or electronic components.

● Simulating Electrical Load

- a. Turn on all electrical systems to simulate excessive electrical loads (Radios, fans, lights, rear window defogger, etc.).


General Information

FL-11

Connector Inspection Procedure


1. Handling of Connector

- a. Never pull on the wiring harness when disconnecting connectors.




BFGE015F

- b. When removing the connector with a lock, press or pull locking lever.




BFGE015G

- c. Listen for a click when locking connectors. This sound indicates that they are securely locked.



BFGE015H

- d. When a tester is used to check for continuity, or to measure voltage, always insert tester probe from wire harness side.




BFGE015I

FL-12

Fuel System

- e. Check waterproof connector terminals from the connector side. Waterproof connectors cannot be accessed from harness side.



BFG015J


NOTICE

- Use a fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.

2. Checking Point for Connector

- a. While the connector is connected:
Hold the connector, check connecting condition and locking efficiency.
- b. When the connector is disconnected:
Check missed terminal, crimped terminal or broken core wire by slightly pulling the wire harness.
Visually check for rust, contamination, deformation and bend.
- c. Check terminal tightening condition:
Insert a spare male terminal into a female terminal, and then check terminal tightening conditions.

- d. Pull lightly on individual wires to ensure that each wire is secured in the terminal.



BFG015K

3. Repair Method of Connector Terminal

- a. Clean the contact points using air gun and/or shop rag.

NOTICE

Never use sand paper when polishing the contact points, otherwise the contact point may be damaged.

- b. In case of abnormal contact pressure, replace the female terminal.

Wire Harness Inspection Procedure

1. Before removing the wire harness, check the wire harness position and crimping in order to restore it correctly.
2. Check whether the wire harness is twisted, pulled or loosened.
3. Check whether the temperature of the wire harness is abnormally high.
4. Check whether the wire harness is rotating, moving or vibrating against the sharp edge of a part.
5. Check the connection between the wire harness and any installed part.
6. If the covering of wire harness is damaged; secure, repair or replace the harness.

General Information

FL-13

Electrical Circuit Inspection Procedure


● Check Open Circuit

1. Procedures for Open Circuit

- Continuity Check
- Voltage Check

If an open circuit occurs (as seen in [FIG. 1]), it can be found by performing Step 2 (Continuity Check Method) or Step 3 (Voltage Check Method) as shown below.

FIG 1



BFGE501A

2. Continuity Check Method

UNNOTICE

When measuring for resistance, lightly shake the wire harness above and below or side to side.

Specification (Resistance)


1Ω or less → Normal Circuit

1MΩ or Higher → Open Circuit

- Disconnect connectors (A), (C) and measure resistance between connector (A) and (C) as shown in [FIG. 2].

In [FIG.2.] the measured resistance of line 1 and 2 is higher than 1MΩ and below 1 Ω respectively. Specifically the open circuit is line 1 (Line 2 is normal). To find exact break point, check sub line of line 1 as described in next step.

FIG 2




BFGE501B

- Disconnect connector (B), and measure for resistance between connector (C) and (B1) and between (B2) and (A) as shown in [FIG. 3].

In this case the measured resistance between connector (C) and (B1) is higher than 1MΩ and the open circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).

FIG 3



BFGE501C

3. Voltage Check Method

- With each connector still connected, measure the voltage between the chassis ground and terminal 1 of each connectors (A), (B) and (C) as shown in [FIG. 4].

FL-14


Fuel System

The measured voltage of each connector is 5V, 5V and 0V respectively. So the open circuit is between connector (C) and (B).

a. Disconnect connectors (A), (C) and measure for resistance between connector (A) and Chassis Ground as shown in [FIG. 6].


The measured resistance of line 1 and 2 in this example is below 1 Ω and higher than 1MΩ respectively. Specifically the short to ground circuit is line 1 (Line 2 is normal). To find exact broken point, check the sub line of line 1 as described in the following step.

FIG 4



BFIGE501D

FIG 6



BFIGE501F

● Check Short Circuit

1. Test Method for Short to Ground Circuit


- Continuity Check with Chassis Ground

If short to ground circuit occurs as shown in [FIG. 5], the broken point can be found by performing Step 2 (Continuity Check Method with Chassis Ground) as shown below.

b. Disconnect connector (B), and measure the resistance between connector (A) and chassis ground, and between (B1) and chassis ground as shown in [FIG. 7].

The measured resistance between connector (B1) and chassis ground is 1Ω or less. The short to ground circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).

FIG 5



BFIGE501E

2. Continuity Check Method (with Chassis Ground)

NOTICE


Lightly shake the wire harness above and below, or side to side when measuring the resistance.

Specification (Resistance)

1Ω or less → Short to Ground Circuit

1MΩ or Higher → Normal Circuit

FIG 7



BFIGE501G

General Information

FL-15

Symptom Troubleshooting Guide Chart

Main symptom	Diagnostic procedure	Also check for
Unable to start (Engine does not turn over)	<ol style="list-style-type: none"> 1. Test the battery 2. Test the starter 3. Inhibitor switch (A/T) or clutch start switch (M/T) 	
Unable to start (Incomplete combustion)	<ol style="list-style-type: none"> 1. Test the battery 2. Check the fuel pressure 3. Check the ignition circuit 4. Troubleshooting the immobilizer system (In case of immobilizer lamp flashing) 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Slipped or broken timing belt • Contaminated fuel
Difficult to start	<ol style="list-style-type: none"> 1. Test the battery 2. Check the fuel pressure 3. Check the ECT sensor and circuit (Check DTC) 4. Check the ignition circuit 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark
Poor idling (Rough, unstable or incorrect Idle)	<ol style="list-style-type: none"> 1. Check the fuel pressure 2. Check the Injector 3. Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM) 4. Check the idle speed control circuit (Check DTC) 5. Inspect and test the Throttle Body 6. Check the ECT sensor and circuit (Check DTC) 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark
Engine stall	<ol style="list-style-type: none"> 1. Test the Battery 2. Check the fuel pressure 3. Check the idle speed control circuit (Check DTC) 4. Check the ignition circuit 5. Check the CKPS Circuit (Check DTC) 	<ul style="list-style-type: none"> • DTC • Intake air leaks • Contaminated fuel • Weak ignition spark
Poor driving (Surge)	<ol style="list-style-type: none"> 1. Check the fuel pressure 2. Inspect and test Throttle Body 3. Check the ignition circuit 4. Check the ECT Sensor and Circuit (Check DTC) 5. Test the exhaust system for a possible restriction 6. Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM) 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark
Knocking	<ol style="list-style-type: none"> 1. Check the fuel pressure 2. Inspect the engine coolant 3. Inspect the radiator and the electric cooling fan 4. Check the spark plugs 	<ul style="list-style-type: none"> • DTC • Contaminated fuel
Poor fuel economy	<ol style="list-style-type: none"> 1. Check customer's driving habits <ul style="list-style-type: none"> · A/C on full time or the defroster mode on? · Are tires at correct pressure? · Is excessively heavy load being carried? · Is acceleration too much, too often? 2. Check the fuel pressure 3. Check the injector 4. Test the exhaust system for a possible restriction 5. Check the ECT sensor and circuit 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark

FL-16

Fuel System

Main symptom	Diagnostic procedure	Also check for
Hard to refuel (Overflow during refueling)	<ol style="list-style-type: none"> 1. Test the canister close valve 2. Inspect the fuel filler hose/pipe <ul style="list-style-type: none"> · Pinched, kinked or blocked? · Filler hose is torn 3. Inspect the fuel tank vapor vent hose between the EVAP. canister and air filter 4. Check the EVAP. canister 	<ul style="list-style-type: none"> • Malfunctioning gas station filling nozzle (If this problem occurs at a specific gas station during refueling)

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System

FL-17

Engine Control System

Description

If the Gasoline Engine Control system components (sensors, ECM, injector, etc.) fail, interruption to the fuel supply or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered.

1. Engine is hard to start or does not start at all.
2. Unstable idle.
3. Poor driveability

If any of the above conditions are noted, first perform a routine diagnosis that includes basic engine checks (ignition system malfunction, incorrect engine adjustment, etc.). Then, inspect the Gasoline Engine Control system components with the HI-SCAN (Pro).

NOTICE

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the ECM.
- The control harnesses between the ECM and heated oxygen sensor are shielded with the shielded ground wires to the body in order to prevent the influence of ignition noises and radio interference. When the shielded wire is faulty, the control harness must be replaced.
- When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the ECM.

Malfunction Indicator Lamp (MIL)

[EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL.

- Catalyst
- Fuel system
- Mass Air Flow Sensor (MAFS)
- Intake Air Temperature Sensor (IATS)
- Engine Coolant Temperature Sensor (ECTS)
- Throttle Position Sensor (TPS)
- Upstream Oxygen Sensor
- Upstream Oxygen Sensor Heater
- Downstream Oxygen Sensor
- Downstream Oxygen Sensor Heater
- Injector
- Misfire
- Crankshaft Position Sensor (CKPS)
- Camshaft Position Sensor (CMPS)
- Evaporative Emission Control System
- Vehicle Speed Sensor (VSS)
- Idle Speed Control Actuator (ISCA)
- Power Supply
- ECM/ PCM
- MT/AT Encoding
- Acceleration Sensor
- MIL-on Request Signal
- Power Stage

NOTICE

Refer to "Inspection Chart For Diagnostic Trouble Codes (DTC)" for more information.

FL-18

Fuel System

[NON-EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- Heated oxygen sensor (HO2S)
- Mass Air Flow sensor (MAFS)
- Throttle position sensor (TPS)
- Engine coolant temperature sensor (ECTS)
- Idle speed control actuator (ISCA)
- Injectors
- ECM

NOTICE

Refer to "Inspection Chart For Diagnostic Trouble Codes (DTC)" for more information.

[INSPECTION]

1. After turning ON the ignition key, ensure that the light illuminates for about 5 seconds and then goes out.
2. If the light does not illuminate, check for an open circuit in the harness, a blown fuse or a blown bulb.


Self-Diagnosis

The ECM monitors the input/output signals (some signals at all times and the others under specified conditions). When the ECM detects an irregularity, it records the diagnostic trouble code, and outputs the signal to the Data Link connector. The diagnosis results can be read with the MIL or HI-SCAN (Pro). Diagnostic Trouble Codes (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble codes will, however, be erased when the battery terminal or ECM connector is disconnected, or by the HI-SCAN (Pro).

NOTICE

If a sensor connector is disconnected with the ignition switch turned on, the diagnostic trouble code (DTC) is recorded. In this case, disconnect the battery negative terminal (-) for 15 seconds or more, and the diagnosis memory will be erased.

The relation between DTC and driving pattern in EOBD system



LGIF601Q

Engine Control System

FL-19

1. When the same malfunction is detected and maintained during two sequential driving cycles, the MIL will automatically illuminate.
2. The MIL will go off automatically if no fault is detected after 3 sequential driving cycles.
3. A Diagnostic Trouble Code(DTC) is recorded in ECM memory when a malfunction is detected after two sequential driving cycles. The MIL will illuminate when the malfunction is detected on the second driving cycle.

If a misfire is detected, a DTC will be recorded, and the MIL will illuminate, immediately after a fault is first detected.

4. A Diagnostic Trouble Code(DTC) will automatically erase from ECM memory if the same malfunction is not detected for 40 driving cycles.

NOTICE

- A "warm-up cycle" means sufficient vehicle operation such that the coolant temperature has risen by at least 40 degrees Fahrenheit from engine starting and reaches a minimum temperature of 160 degrees Fahrenheit.
- A "driving cycle" consists of engine startup, vehicle operation beyond the beginning of closed loop operation.




دیجیتال خودرو سامانه (مسئولیت محدود) شرکت دیجیتال خودرو سامانه

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FL-20

Fuel System

Components Location



STDFL9100L

Engine Control System

FL-21

1. Engine Control Module (ECM)
2. Manifold Absolute Pressure Sensor (MAPS)
3. Intake Air Temperature Sensor (IATS)
4. Engine Coolant Temperature Sensor (ECTS)
5. Throttle Position Sensor (TPS)
6. Crankshaft Position Sensor (CKPS)
7. Camshaft Position Sensor (CMPS)
8. Knock Sensor (KS)
9. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]
10. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]
11. A/C Pressure Transducer (APT)
12. Injector
13. Idle Speed Control Actuator (ISCA)
14. Purge Control Solenoid Valve (PCSV)
15. CVVT Oil Control Valve (OCV)
16. Ignition Coil
17. Main Relay
18. Fuel Pump Relay
19. Data Link Connector (DLC)
20. Multi-Purpose Check Connector

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




FL-22

Fuel System


- 1. Engine Control Module (ECM)
- 20. Multi-Purpose Check Connector




- 2. Manifold Absolute Pressure Sensor (MAPS)
- 3. Intake Air Temperature Sensor (IATS)




- 4. Engine Coolant Temperature Sensor (ECTS)




- 5. Throttle Position Sensor (TPS)



- 6. Crankshaft Position Sensor (CKPS)




- 7. Camshaft Position Sensor (CMPS)




Engine Control System

FL-23


8. Knock Sensor (KS)




9. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]




10. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]




11. A/C Pressure Transducer (APT)



12. Injector
16. Ignition Coil




13. Idle Speed Control Actuator (ISCA)




FL-24

Fuel System


14. Purge Control Solenoid Valve (PCSV)



15. CVVT Oil Control Valve (OCV)



17. Main Relay
18. Fuel Pump Relay




Engine Control System

FL-25

Engine Control Module (ECM)

ECM Terminal And Input/Output signal

ECM Harness Connector (A/T)



STDFL9106L

ECM Terminal Function (A/T)

Connector [CGGA-K]

Pin No.	Description	Connected to
1	Power Ground	Chassis Ground
2	Power Ground	Chassis Ground
3	Power Ground	Chassis Ground
4	Battery voltage supply after main relay	Main Relay
5	Battery voltage supply after main relay	Main Relay
6	Battery voltage supply after main relay	Main Relay
7		
8	Sensor ground	Manifold Absolute Pressure Sensor (MAPS)
9	Sensor ground	Heated Oxygen Sensor (Sensor 2)
10	Manifold Absolute Pressure Sensor signal input	Manifold Absolute Pressure Sensor (MAPS)
11	-	
12	-	
13	Heated Oxygen Sensor (Sensor 2) signal input	Heated Oxygen Sensor (Sensor 2)
14	-	
15	-	
16	-	
17	Alternator load signal input	Alternator
18	-	
19	-	
20	Vehicle speed signal input	ABS/ESP Control Module [Euro-III/IV With ABS/ESP] Vehicle Speed Sensor (VSS) [Except Euro-III/IV]
21	-	

FL-26

Fuel System

Pin No.	Description	Connected to
22	Electric Load signal input	Defrost
23	A/C Switch "ON" signal input	A/C Switch
24	For Autotransaxle Control	
25	For Autotransaxle Control	
26	For Autotransaxle Control	
27	For Autotransaxle Control	
28	For Autotransaxle Control	
29	-	
30	Sensor ground	A/C Pressure Transducer (APT)
31	Sensor ground	Heated Oxygen Sensor (Sensor 1)
32	Intake Air Temperature Sensor signal input	Intake Air Temperature Sensor (IATS)
33	-	
34	-	
35	Heated Oxygen Sensor (Sensor 1) signal input	Heated Oxygen Sensor (Sensor 1)
36	-	
37	-	
38	Sensor ground	Camshaft Position Sensor (CMPS)
39	-	
40	-	
41	Camshaft Position Sensor signal input	Camshaft Position Sensor (CMPS)
42	-	
43	-	
44	Power Steering Switch signal input	Power Steering Switch
45	-	
46	A/C thermal switch signal input	A/C Thermal Switch
47	For Autotransaxle Control	
48	For Autotransaxle Control	
49	For Autotransaxle Control	
50	For Autotransaxle Control	
51	Sensor ground	Throttle Position Sensor (TPS)
52	-	
53	-	
54	-	
55	-	

Engine Control System

FL-27

Pin No.	Description	Connected to
56	-	
57	For Autotransaxle Control	
58	-	
59	-	
60	For Autotransaxle Control	
61	For Autotransaxle Control	
62	For Autotransaxle Control	
63	-	
64	For Autotransaxle Control	
65	For Autotransaxle Control	
66	For Autotransaxle Control	
67	For Autotransaxle Control	
68	For Autotransaxle Control	
69	-	
70	For Autotransaxle Control	
71	For Autotransaxle Control	
72	For Autotransaxle Control	
73	Sensor ground	Engine Coolant Temperature Sensor (ECTS)
74	-	
75	Throttle Position Sensor signal input	Throttle Position Sensor (TPS)
76	-	
77	Engine Coolant Temperature Sensor signal input	Engine Coolant Temperature Sensor (ECTS)
78	-	
79	A/C Pressure Transducer signal input	A/C Pressure Transducer (APT)
80	For Autotransaxle Control	
81	For Autotransaxle Control	
82	For Autotransaxle Control	
83	For Autotransaxle Control	
84	For Autotransaxle Control	
85	-	
86	For Autotransaxle Control	
87	For Autotransaxle Control	
88	For Autotransaxle Control	
89	For Autotransaxle Control	

FL-28

Fuel System

Pin No.	Description	Connected to
90	For Autotransaxle Control	
91	For Autotransaxle Control	
92	For Autotransaxle Control	
93	For Autotransaxle Control	
94	For Autotransaxle Control	

Connector [CGGA-A]

Pin No.	Description	Connected to
1	Ignition Coil (Cylinder #2) control output	Ignition Coil (Cylinder #2)
2	Ignition Coil (Cylinder #4) control output	Ignition Coil (Cylinder #4)
3	-	
4	-	
5	-	
6	Idle Speed Control Actuator [OPEN] control output	Idle Speed Control Actuator (ISCA)
7	-	
8	Purge Control Solenoid Valve control output	Purge Control Solenoid Valve (PCSV)
9	Main Relay control output	Main Relay
10	-	
11	Battery voltage supply after ignition switch	Ignition Switch
12	CAN [HIGH]	Other control module, Data Link Connector (DLC), Multi-Purpose Check Connector
13	-	
14	-	
15	Knock Sensor signal input	Knock Sensor (KS)
16	Ignition Coil (Cylinder #3) control output	Ignition Coil (Cylinder #3)
17	Ignition Coil (Cylinder #1) control output	Ignition Coil (Cylinder #1)
18	-	
19	-	
20	-	
21	Cooling Fan Relay [Low] control output	Cooling Fan Relay [Low]
22	Idle Speed Control Actuator [CLOSE] control output	Idle Speed Control Actuator (ISCA)
23	Cooling Fan Relay [High] control output	Cooling Fan Relay [High]
24	Fuel consumption signal output	Trip Computer
25	Engine speed signal output	Tachometer (Cluster)
26	-	

Engine Control System

FL-29

Pin No.	Description	Connected to
27	CAN [LOW]	Other control module, Data Link Connector (DLC), Multi-Purpose Check Connector
28	-	
29	-	
30	Sensor ground	Knock Sensor (KS)
31	-	
32	Immobilizer lamp control output	Immobilizer Lamp
33	Heated Oxygen Sensor (Sensor 2) Heater control output	Heated Oxygen Sensor (Sensor 2)
34	Heated Oxygen Sensor (Sensor 1) Heater control output	Heated Oxygen Sensor (Sensor 1)
35	Fuel Pump Relay control output [With Immobilizer]	Fuel Pump Relay
36	Injector (Cylinder #3) control output	Injector (Cylinder #3)
37	Fuel Pump Relay control output [Without Immobilizer]	Fuel Pump Relay
38	A/C Compressor Relay control output	A/C Compressor Relay
39	-	
40	Crankshaft Position Sensor [A] signal input	Crankshaft Position Sensor (CKPS)
41	-	
42	-	
43	Sensor power (+5V)	Manifold Absolute Pressure Sensor (MAPS)
44	Immobilizer communication line	Immobilizer Control Module
45	Wheel Speed Sensor [A] signal input	Wheel Speed Sensor (WSS) [Euro-III/IV Without ABS/ESP]
46	-	
47	-	
48	Injector (Cylinder #4) control output	Injector (Cylinder #4)
49	CVVT Oil Control Valve control output	CVVT Oil Control Valve (OCV)
50	Injector (Cylinder #1) control output	Injector (Cylinder #1)
51	Malfunction Indicator Lamp (MIL) control output	Cluster (Malfunction Indicator Lamp)
52	Injector (Cylinder #2) control output	Injector (Cylinder #2)
53	-	
54	-	
55	Crankshaft Position Sensor [B] signal input	Crankshaft Position Sensor (CKPS)
56	Battery Power (B+)	Battery
57	Sensor power (+5V)	A/C Pressure Transducer (APT)
58	Sensor power (+5V)	Throttle Position Sensor (TPS)

FL-30

Fuel System

Pin No.	Description	Connected to
59	-	
60	Wheel Speed Sensor [B] signal input	Wheel Speed Sensor (WSS) [Euro-III/IV Without ABS/ESP]

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System

FL-31

ECM Terminal Input/Output Signal (A/T)

Connector [CGGA-K]

Pin No	Description	Condition	Type	Level	Test Result
1	Power Ground	Idle	DC	Max. 50mV	0V
2	Power Ground	Idle	DC	Max. 50mV	3.6mV
3	Power Ground	Idle	DC	Max. 50mV	3.6mV
4	Battery voltage supply after main relay	IG OFF	DC	Max. 1.0V	200mV
		IG ON		Battery Voltage	12.9V
5	Battery voltage supply after main relay	IG OFF	DC	Max. 1.0V	200mV
		IG ON		Battery Voltage	12.9V
6	Battery voltage supply after main relay	IG OFF	DC	Max. 1.0V	200mV
		IG ON		Battery Voltage	12.9V
7	-				
8	Sensor ground	Idle	DC	Max. 50mV	16mV
9	Sensor ground	Idle	DC	Max. 50mV	6.2mV
10	Manifold Absolute Pressure Sensor signal input	IG ON	DC	3.9 ~ 4.1V	4.09V
		Idle		0.8 ~ 1.6V	1.44V
11	-				
12	-				
13	Heated Oxygen Sensor (Sensor 2) signal input	Racing	Analog	Rich: 0.6 ~ 1.0V	860mV
				Lean: Max. 0.4V	10mV
14	-				
15	-				
16	-				
17	Alternator load signal input	Idle	Pulse	Hi: Battery Voltage	13.2V
				Lo: Max. 1.5V	1.34V
18	-				
19	-				
20	Vehicle speed signal input	Idle	Pulse	Hi: Min. 4.5V	12.2V
				Lo: Max. 1.0V	0V
					Freq: 72.2Hz
		Vehicle Run (30km/h)		Hi: Min. 4.5V	12.2V
				Lo: Max. 1.0V	0V
					Freq: 212Hz
21	-				
22	Electric Load signal input				

FL-32

Fuel System

Pin No	Description	Condition	Type	Level	Test Result
23	A/C Switch "ON" signal input	S/W OFF	DC	Max. 1.0V	20mV
		S/W ON		Battery Voltage	12.48V
24	For Autotransaxle Control				
25	For Autotransaxle Control				
26	For Autotransaxle Control				
27	For Autotransaxle Control				
28	For Autotransaxle Control				
29	-				
30	Sensor ground	Idle	DC	Max. 50mV	6.2mV
31	Sensor ground	Idle	DC	Max. 50mV	6.8mV
32	Intake Air Temperature Sensor signal input	Idle	DC	0 ~ 5.0V	1.89V
33	-				
34	-				
35	Heated Oxygen Sensor (Sensor 1) signal input	Racing	Analog	Rich: 0.6 ~ 1.0V	884mV
				Lean: Max. 0.4V	8mV
36	-				
37	-				
38	Sensor ground	Idle	DC	Max. 50mV	12mV
39	-				
40	-				
41	Camshaft Position Sensor signal input	Idle	Pulse	Hi: Battery Voltage	13.72V
				Lo: Max. 0.5V	200mV
42	-				
43	-				
44	Power Steering Switch signal input				
45	-				
46	A/C thermal switch signal input	A/C S/W OFF	DC	Max.1.0V	200mV
		A/C S/W ON		Battery Voltage	12.6V
47	For Autotransaxle Control				
48	For Autotransaxle Control				
49	For Autotransaxle Control				
50	For Autotransaxle Control				
51	Sensor ground	Idle	DC	Max. 50mV	11.2mV
52	-				

Engine Control System

FL-33

Pin No	Description	Condition	Type	Level	Test Result
53	-				
54	-				
55	-				
56	-				
57	For Autotransaxle Control				
58	-				
59	-				
60	For Autotransaxle Control				
61	For Autotransaxle Control				
62	For Autotransaxle Control				
63	-				
64	For Autotransaxle Control				
65	For Autotransaxle Control				
66	For Autotransaxle Control				
67	For Autotransaxle Control				
68	For Autotransaxle Control				
69	-				
70	For Autotransaxle Control				
71	For Autotransaxle Control				
72	For Autotransaxle Control				
73	Sensor ground	Idle	DC	Max. 50mV	16.8mV
74	-				
75	Throttle Position Sensor signal input	C.T	Analog	0.25 ~ 0.9V	0.34V
		W.O.T		Min. 4.0V	4.43V
76	-				
77	Engine Coolant Temperature Sensor signal input	Idle	Analog	0.5 ~ 4.5V	1.43V
78	-				
79	A/C Pressure Transducer signal input	A/C ON	Analog	Max. 4.8V	1.88V
80	For Autotransaxle Control				
81	For Autotransaxle Control				
82	For Autotransaxle Control				
83	For Autotransaxle Control				
84	For Autotransaxle Control				
85	-				

FL-34

Fuel System

Pin No	Description	Condition	Type	Level	Test Result
86	For Autotransaxle Control				
87	For Autotransaxle Control				
88	For Autotransaxle Control				
89	For Autotransaxle Control				
90	For Autotransaxle Control				
91	For Autotransaxle Control				
92	For Autotransaxle Control				
93	For Autotransaxle Control				
94	For Autotransaxle Control				

Connector [CGGA-A]

Pin No.	Description	Condition	Type	Level	Test Result
1	Ignition Coil (Cylinder #2) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	372V
				ON Voltage: Max. 2.0V	1.1V
2	Ignition Coil (Cylinder #4) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	372V
				ON Voltage: Max. 2.0V	1.1V
3	-				
4	-				
5	-				
6	Idle Speed Control Actuator [OPEN] control output	Idle	Pulse	Hi: Battery Voltage	13.8V
				Lo: Max. 1.0V	20mV
7	-				
8	Purge Control Solenoid Valve control output	Active Inactive	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	120mV
9	Main Relay control output	Relay OFF	DC	Battery Voltage	12.78V
		Relay ON		Max. 1.0V	860mV
10	-				
11	Battery voltage supply after ignition switch	IG OFF	DC	Max. 1.0V	3.2mV
		IG ON		Battery Voltage	12.68V
12	CAN [HIGH]	RECESSIVE	Pulse	2.0 ~ 3.0V	2.5V
		DOMINANT		2.75 ~ 4.5V	3.58V
13	-				
14	-				

Engine Control System

FL-35

Pin No.	Description	Condition	Type	Level	Test Result
15	Knock Sensor signal input	Knocking	Variable Frequency		
		Normal			
16	Ignition Coil (Cylinder #3) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	366V
				ON Voltage: Max. 2.0V	1.1V
17	Ignition Coil (Cylinder #1) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	352V
				ON Voltage: Max. 2.0V	1.1V
18	-				
19	-				
20	-				
21	Cooling Fan Relay [Low] control output	Relay OFF	DC	Battery Voltage	14.12V
		Relay ON		Max. 1.0V	61.6mV
22	Idle Speed Control Actuator [CLOSE] control output	Idle	Pulse	Hi: Battery Voltage	13.8V
				Lo: Max. 1.0V	200mV
23	Cooling Fan Relay [High] control output	Relay OFF	DC	Battery Voltage	14.01V
		Relay ON		Max. 1.0V	52.6mV
24	Fuel consumption signal output	Idle	Pulse	Hi: Battery Voltage	13.8V
				Lo: Max. 0.5V	200mV
25	Engine speed signal output	Idle	Pulse	Hi: Battery Voltage	14.0V
				Lo: Max. 0.5V	20mV
				Freq.: 20 ~ 60Hz	22Hz
26	-				
27	CAN [LOW]	RECESSIVE	Pulse	2.0 ~ 3.0V	2.5V
		DOMINANT		0.5 ~ 2.25V	1.5V
28	-				
29	-				
30	Sensor ground	Idle	DC	Max. 50mV	
31	-				
32	Immobilizer lamp control output	Lamp OFF	DC	Battery Voltage	12.6V
		Lamp ON		Max. 1.0V	20mV
33	Heated Oxygen Sensor (Sensor 2) Heater control output	Engine Run	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	220mV
34	Heated Oxygen Sensor (Sensor 1) Heater control output	Engine Run	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	220mV

FL-36

Fuel System

Pin No.	Description	Condition	Type	Level	Test Result
35	Fuel Pump Relay control output [With Immobilizer]	Relay OFF	DC	Battery Voltage	12.8V
		Relay ON		Max. 1.0V	400mV
36	Injector (Cylinder #3) control output	Idle	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	40mV
				Vpeak: Max. 80V	73.6V
37	Fuel Pump Relay control output [Without Immobilizer]	Relay OFF	DC	Battery Voltage	12.8V
		Relay ON		Max. 1.0V	400mV
38	A/C Compressor Relay control output	Relay OFF	DC	Battery Voltage	14.1V
		Relay ON		Max. 1.0V	400mV
39	-				
40	Crankshaft Position Sensor [A] signal input	Idle		Vp_p: Min. 1.0V	6.48V
41	-				
42	-				
43	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	3.6mV
		IG ON		4.8 ~ 5.2V	5.02V
44	Immobilizer communication line	When communicating after IG ON	Pulse	Hi: Min. 8.5V	12.51V
				Lo: Max. 3.5V	1.17V
45	Wheel Speed Sensor [A] signal input	Vehicle Run	SINE Wave	Vp_p: Min. 0.2V	
46	-				
47	-				
48	Injector (Cylinder #4) control output	Idle	Pulse	Hi: Battery Voltage	13.6V
				Lo: Max. 1.0V	336mV
				Vpeak: Max. 80V	69.7V
49	CVVT Oil Control Valve control output	Idle	Pulse	Hi: Battery Voltage	14.9V
				Lo: Max. 1.0V	36.2mV
50	Injector (Cylinder #1) control output	Idle	Pulse	Hi: Battery Voltage	13.6V
				Lo: Max. 1.0V	336mV
				Vpeak: Max. 80V	69.7V

Engine Control System

FL-37

Pin No.	Description	Condition	Type	Level	Test Result
51	Malfunction Indicator Lamp (MIL) control output	Lamp OFF	DC	Battery Voltage	11.51V
		Lamp ON		Max. 1.0V	663mV
52	Injector (Cylinder #2) control output	Idle	Pulse	Hi: Battery Voltage	13.6V
				Lo: Max. 1.0V	336mV
				Vpeak: Max. 80V	69.7V
53	-				
54	-				
55	Crankshaft Position Sensor [B] signal input	Idle	SINE Wave	Vp_p: Min. 1.0V	6.48V
56	Battery Power (B+)	Always	DC	Battery Voltage	12.23V
57	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	3.6mV
		IG ON		4.9 ~ 5.1V	5.02V
58	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	3.6mV
		IG ON		4.9 ~ 5.1V	5.02V
59	-				
60	Wheel Speed Sensor [B] signal input	Vehicle Run	SINE Wave	Vp_p: Min. 0.2V	


شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FL-38

Fuel System

ECM Harness Connector (M/T)



STDFL9107L

ECM Terminal Function (M/T)

Connector [CGGM-K]

Pin No.	Description	Connected to
1	Ignition Coil (Cylinder #1) control output	Ignition Coil (Cylinder #1)
2	Power Ground	Chassis Ground
3	Ignition Coil (Cylinder #3) control output	Ignition Coil (Cylinder #3)
4	-	
5	-	
6	Battery voltage supply after main relay	Main Relay
7	Ignition Coil (Cylinder #4) control output	Ignition Coil (Cylinder #4)
8	A/C thermal switch signal input	A/C Thermal Switch
9	-	
10	Power Steering Switch signal input	Power Steering Switch
11	Knock Sensor signal input	Knock Sensor (KS)
12	Sensor ground	Throttle Position Sensor (TPS)
13	-	
14	-	
15	Sensor ground	Manifold Absolute Pressure Sensor (MAPS)
16	Sensor ground	Heated Oxygen Sensor (Sensor 2)
17	Sensor ground	Camshaft Position Sensor (CMPS)
18	Immobilizer communication line	Immobilizer Control Module
19	Manifold Absolute Pressure Sensor signal input	Manifold Absolute Pressure Sensor (MAPS)
20	-	
21	-	
22	Main Relay control output	Main Relay
23	Cooling Fan Relay [High] control output	Cooling Fan Relay [High]
24	Injector (Cylinder #3) control output	Injector (Cylinder #3)
25	Idle Speed Control Actuator [CLOSE] control output	Idle Speed Control Actuator (ISCA)

Engine Control System

FL-39

Pin No.	Description	Connected to
26	-	
27	-	
28	Cooling Fan Relay [Low] control output	Cooling Fan Relay [Low]
29	Ignition Coil (Cylinder #2) control output	Ignition Coil (Cylinder #2)
30	A/C Switch "ON" signal input	A/C Switch
31	Electric Load signal input	Defrost
32	Sensor ground	Knock Sensor (KS)
33	Sensor ground	A/C Pressure Transducer (APT)
34	-	
35	Sensor ground	Engine Coolant Temperature Sensor (ECTS)
36	Heated Oxygen Sensor (Sensor 2) signal input	Heated Oxygen Sensor (Sensor 2)
37	-	
38	Sensor ground	Heated Oxygen Sensor (Sensor 1)
39	Throttle Position Sensor signal input	Throttle Position Sensor (TPS)
40	A/C Pressure Transducer signal input	A/C Pressure Transducer (APT)
41	-	
42	-	
43	Intake Air Temperature Sensor signal input	Intake Air Temperature Sensor (IATS)
44	-	
45	A/C Compressor Relay control output	A/C Compressor Relay
46	Fuel Pump Relay control output [Without Immobilizer]	Fuel Pump Relay
47	Injector (Cylinder #2) control output	Injector (Cylinder #2)
48	Immobilizer lamp control output	Immobilizer Lamp
49	Fuel Pump Relay control output [With Immobilizer]	
50	-	
51	Power Ground	Chassis Ground
52	-	
53	-	
54	Heated Oxygen Sensor (Sensor 1) signal input	Heated Oxygen Sensor (Sensor 1)
55	-	
56	-	
57	-	
58	Wheel Speed Sensor [A] signal input	Wheel Speed Sensor (WSS) [Euro-III/IV Without ABS/ESP]
59	Sensor power (+5V)	A/C Pressure Transducer (APT)

FL-40

Fuel System

Pin No.	Description	Connected to
60	Sensor power (+5V)	Throttle Position Sensor (TPS)
61	-	
62	CAN [LOW]	Other control module, Data Link Connector (DLC), Multi-Purpose Check Connector
63	Camshaft Position Sensor signal input	Camshaft Position Sensor (CMPS)
64	Vehicle speed signal input	ABS/ESP Control Module [Euro-III/IV With ABS/ESP] Vehicle Speed Sensor (VSS) [Except Euro-III/IV]
65	-	
66	Alternator load signal input	Alternator
67	Engine speed signal output	Tachometer (Cluster)
68	Injector (Cylinder #4) control output	Injector (Cylinder #4)
69	Purge Control Solenoid Valve control output	Purge Control Solenoid Valve (PCSV)
70	Malfunction Indicator Lamp (MIL) control output	Cluster (Malfunction Indicator Lamp)
71	Heated Oxygen Sensor (Sensor 2) Heater control output	Heated Oxygen Sensor (Sensor 2)
72	Heated Oxygen Sensor (Sensor 1) Heater control output	Heated Oxygen Sensor (Sensor 1)
73	Power Ground	Chassis Ground
74	-	
75	-	
76	-	
77	Engine Coolant Temperature Sensor signal input	Engine Coolant Temperature Sensor (ECTS)
78	-	
79	Wheel Speed Sensor [B] signal input	Wheel Speed Sensor (WSS) [Euro-III/IV Without ABS/ESP]
80	-	
81	Sensor power (+5V)	Manifold Absolute Pressure Sensor (MAPS)
82	Battery Power (B+)	Battery
83	Battery voltage supply after ignition switch	Ignition Switch
84	CAN [HIGH]	Other control module, Data Link Connector (DLC), Multi-Purpose Check Connector
85	-	
86	Crankshaft Position Sensor [B] signal input	Crankshaft Position Sensor (CKPS)
87	Crankshaft Position Sensor [A] signal input	Crankshaft Position Sensor (CKPS)
88	Fuel consumption signal output	Trip Computer
89	-	

Engine Control System

FL-41

Pin No.	Description	Connected to
90	Idle Speed Control Actuator [OPEN] control output	Idle Speed Control Actuator (ISCA)
91	Injector (Cylinder #1) control output	Injector (Cylinder #1)
92	CVVT Oil Control Valve control output	CVVT Oil Control Valve (OCV)
93	-	
94	-	

ECM Terminal Input/Output Signal (M/T)

CONNECTOR [CGGM-K]

Pin No.	Description	Condition	Type	Level	Test Result
1	Ignition Coil (Cylinder #1) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	352V
				ON Voltage: Max. 2.0V	1.1V
2	Power Ground	Idle	DC	Max. 50mV	0mV
3	Ignition Coil (Cylinder #3) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	366V
				ON Voltage: Max. 2.0V	1.1V
4	-				
5	-				
6	Battery voltage supply after main relay	IG OFF	DC	Max. 1.0V	200mV
		IG ON		Battery Voltage	12.9V
7	Ignition Coil (Cylinder #4) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	372V
				ON Voltage: Max. 2.0V	1.1V
8	A/C thermal switch signal input	A/C S/W OFF	DC	Max. 0.5V	200mV
		A/C S/W ON		Battery Voltage	12.6V
9	-				
10	Power Steering Switch signal input				
11	Knock Sensor signal input	Knocking	Variable Frequency		
		Normal			
12	Sensor ground	Idle	DC	Max. 50mV	11.2mV
13	-				
14	-				
15	Sensor ground	Idle	DC	Max. 50mV	16mV
16	Sensor ground	Idle	DC	Max. 50mV	6.2mV
17	Sensor ground	Idle	DC	Max. 50mV	12mV

FL-42

Fuel System

Pin No.	Description	Condition	Type	Level	Test Result
18	Immobilizer communication line	When communicating after IG ON	Pulse	Hi: Min. 8.5V	12.51V
				Lo: Max. 3.5V	1.17V
19	Manifold Absolute Pressure Sensor signal input	IG ON	DC	3.9 ~ 4.1V	4.09V
		Idle		0.8 ~ 1.6V	1.44V
20	-				
21	-				
22	Main Relay control output	Relay OFF	DC	Battery Voltage	12.78V
		Relay ON		Max. 1.0V	860mV
23	Cooling Fan Relay [High] control output	Relay OFF	DC	Battery Voltage	14.01V
		Relay ON		Max. 1.0V	52.6mV
24	Injector (Cylinder #3) control output	Idle	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	40mV
				Vpeak: Max. 80V	73.6V
25	Idle Speed Control Actuator [CLOSE] control output	Idle	Pulse	Hi: Battery Voltage	13.8V
				Lo: Max. 1.0V	200mV
26	-				
27	-				
28	Cooling Fan Relay [Low] control output	Relay OFF	DC	Battery Voltage	14.12V
		Relay ON		Max. 1.0V	61.6mV
29	Ignition Coil (Cylinder #2) control output	Idle	Pulse	1st Voltage: 300 ~ 400V	372V
				ON Voltage: Max. 2.0V	1.1V
30	A/C Switch "ON" signal input	A/C S/W OFF	DC	Max. 1.0V	20mV
		A/C S/W ON		Battery Voltage	12.48V
31	Electric Load signal input				
32	Sensor ground	Idle	DC	Max. 50mV	
33	Sensor ground	Idle	DC	Max. 50mV	6.2mV
34	-				
35	Sensor ground	Idle	DC	Max. 50mV	16.8mV
36	Heated Oxygen Sensor (Sensor 2) signal input	Racing	Analog	Rich: 0.6 ~ 1.0V	860mV
				Lean: Max. 0.4V	10mV

Engine Control System

FL-43

Pin No.	Description	Condition	Type	Level	Test Result
37	-				
38	Sensor ground	Idle	DC	Max. 50mV	6.8mV
39	Throttle Position Sensor signal input	C.T	Analog	0.2 ~ 0.7V	0.34V
		W.O.T		Min. 4.0V	4.43V
40	A/C Pressure Transducer signal input	A/C ON	Analog	Max. 4.8V	1.88V
41	-				
42	-				
43	Intake Air Temperature Sensor signal input	Idle	DC	0.2 ~ 4.8V	1.89V
44	-				
45	A/C Compressor Relay control output	Relay OFF	DC	Battery Voltage	14.1V
		Relay ON		Max. 1.0V	400mV
46	Fuel Pump Relay control output [Without Immobilizer]	Relay OFF	DC	Battery Voltage	12.8V
		Relay ON		Max. 1.0V	400mV
47	Injector (Cylinder #2) control output	Idle	Pulse	Hi: Battery Voltage	13.6V
				Lo: Max. 1.0V	336mV
				Vpeak: Max. 80V	69.7V
48	Immobilizer lamp control output	Lamp OFF	DC	Battery Voltage	12.6V
		Lamp ON		Max. 1.0V	20mV
49	Fuel Pump Relay control output [With Immobilizer]	Relay OFF	DC	Battery Voltage	12.8V
		Relay ON		Max. 1.0V	400mV
50	-				
51	Power Ground	Idle	DC	Max. 50mV	3.6mV
52	-				
53	-				
54	Heated Oxygen Sensor (Sensor 1) signal input	Racing	Analog	Rich: 0.6 ~ 1.0V	884mV
				Lean: Max. 0.4V	8mV
55	-				
56	-				
57	-				
58	Wheel Speed Sensor [A] signal input	Vehicle Run	SINE Wave	Vp_p: Min. 0.2V	

FL-44

Fuel System

Pin No.	Description	Condition	Type	Level	Test Result
59	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	3.6mV
		IG ON		4.9 ~ 5.1V	5.02V
60	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	3.6mV
		IG ON		4.9 ~ 5.1V	5.02V
61	-				
62	CAN [LOW]	RECESSIVE	Pulse	2.0 ~ 3.0V	2.5V
		DOMINANT		0.5 ~ 2.25V	1.5V
63	Camshaft Position Sensor signal input	Idle	Pulse	Hi: Battery Voltage	13.72V
				Lo: Max. 0.5V	200mV
64	Vehicle speed signal input	Idle	Pulse	Hi: Min. 4.5V	12.2V
				Lo: Max. 1.0V	0V
					Freq.: 72.2Hz
		Vehicle Run (30km)		Hi: Min. 4.5V	12.2V
				Lo: Max. 1.0V	0V
					Freq.: 212Hz
65	-				
66	Alternator load signal input	Idle	Pulse	Hi: Battery Voltage	13.2V
				Lo: Max. 1.5V	1.34V
67	Engine speed signal output	Idle	Pulse	Hi: Battery Voltage	14.0V
				Lo: Max. 0.5V	20mV
				Freq.: 20 ~ 26Hz	22Hz
68	Injector (Cylinder #4) control output	Idle	Pulse	Hi: Battery Voltage	13.6V
				Lo: Max. 1.0V	336mV
				Vpeak: Max. 80V	69.7V
69	Purge Control Solenoid Valve control output	Active/Inactive	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	120mV
70	Malfunction Indicator Lamp (MIL) control output	Lamp OFF	DC	Battery Voltage	11.51V
		Lamp ON		Max. 1.0V	663mV
71	Heated Oxygen Sensor (Sensor 2) Heater control output	Engine Run	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	220mV
72	Heated Oxygen Sensor (Sensor 1) Heater control output	Engine Run	Pulse	Hi: Battery Voltage	14.2V
				Lo: Max. 1.0V	220mV
73	Power Ground	Idle	DC	Max. 50mV	3.6mV
74	-				

Engine Control System

FL-45


Pin No.	Description	Condition	Type	Level	Test Result
75	-				
76	-				
77	Engine Coolant Temperature Sensor signal input	Idle	Analog	0.5 ~ 4.5V	1.43V
78	-				
79	Wheel Speed Sensor [B] signal input	Vehicle Run	SINE Wave	Vp_p: Min. 0.2V	
80	-				
81	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	3.6mV
		IG ON		4.8 ~ 5.2V	5.02V
82	Battery Power (B+)	Always	DC	Battery Voltage	12.23V
83	Battery voltage supply after ignition switch	IG OFF	DC	Max. 1.0V	3.2mV
		IG ON		Battery Voltage	12.68V
84	CAN [HIGH]	RECESSIVE	Pulse	2.0 ~ 3.0V	2.5V
		DOMINANT		2.75 ~ 4.5V	3.58V
85	-				
86	Crankshaft Position Sensor [B] signal input	Idle	SINE Wave	Vp_p: Min. 1.0V	6.48V
87	Crankshaft Position Sensor [A] signal input	Idle	SINE Wave	Vp_p: Min. 1.0V	6.48V
88	Fuel consumption signal output	Idle	Pulse	Hi: Battery Voltage	1.3.8V
				Lo: Max. 0.5V	20mV
89	-				
90	Idle Speed Control Actuator [OPEN] control output	Idle	Pulse	Hi: Battery Voltage	13.8V
				Lo: Max. 1.0V	20mV
91	Injector (Cylinder #1) control output	Idle	Pulse	Hi: Battery Voltage	13.6V
				Lo: Max. 1.0V	336mV
				Vpeak: Max. 80V	69.7V
92	CVVT Oil Control Valve control output	Idle	Pulse	Hi: Battery Voltage	14.9V
				Lo: Max. 1.0V	36.2mV
93	-				
94	-				

FL-46

Fuel System

Circuit Diagram


[A/T]



STDFL9108L

Engine Control System


FL-47



STDFL9109L

FL-48

Fuel System




دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (وابستگی محدود)
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

STDFL9110L

Engine Control System

FL-49




STDFL9111L

FL-50

Fuel System


[M/T]



SPBF19112L

Engine Control System


FL-51



STDFL9113L

FL-52


Fuel System



STDFL9114L

Engine Control System

FL-53



STDFL9115L

FL-54


Fuel System

Removal

⚠CAUTION

- In the case of the vehicle equipped with immobilizer, perform "Key Teaching" procedure together (Refer to "Immobilizer" in BE group).

1. Turn ignition switch OFF and disconnect the negative (-) battery cable.
2. Disconnect the ECM connector (A).



SHDFL6134L

3. Remove the air cleaner & ECM assembly.
(Refer to "Engine and Transaxle assembly" in EM group).
4. Remove the installation bolts (A), and then remove the ECM from the air cleaner assembly.

Installation

⚠CAUTION

- In the case of the vehicle equipped with immobilizer, perform "Key Teaching" procedure together (Refer to "Immobilizer" in BE group).

Installation is reverse of removal.

ECM installation bolt: 9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)

ECM Problem Inspection Procedure

1. TEST ECM GROUND CIRCUIT: Measure resistance between ECM and chassis ground using the backside of ECM harness connector as ECM side check point. If the problem is found, repair it.

Specification: below 1Ω

2. TEST ECM CONNECTOR: Disconnect the ECM connector and visually check the ground terminals on ECM side and harness side for bent pins or poor contact pressure. If the problem is found, repair it.
3. If problem is not found in Step 1 and 2, the ECM could be faulty. If so, replace the ECM with a new one, and then check the vehicle again. If the vehicle operates normally then the problem was likely with the ECM.
4. RE-TEST THE ORIGINAL ECM : Install the original ECM (may be broken) into a known-good vehicle and check the vehicle. If the problem occurs again, replace the original ECM with a new one. If problem does not occur, this is intermittent problem (Refer to Intermittent Problem Procedure in Basic Inspection Procedure)

Engine Control System

FL-55

Manifold Absolute Pressure Sensor (MAPS)

Description

Manifold Absolute Pressure Sensor (MAPS) is a speed-density type sensor and is installed on the surge tank. It senses absolute pressure of the surge tank and transfers the analog signal proportional to the pressure to the ECM. By using this signal, the ECM calculates the intake air quantity and engine speed.


The MAPS consists of a piezo-electric element and a hybrid IC amplifying the element output signal. The element is silicon diaphragm type and adapts pressure sensitive variable resistor effect of semi-conductor. Because 100% vacuum and the manifold pressure apply to both sides of the sensor respectively, this sensor can output analog signal by using the silicon variation proportional to pressure change.



SMGF19111L

Specification

Pressure (kPa)	Output Voltage (V)
20.0	0.79
46.66	1.84
101.32	4.0



SHDFL8129C


FL-56

Fuel System

Circuit Diagram [A/T]


[CIRCUIT DIAGRAM]

[CONNECTION INFORMATION]



Terminal	Connected to	Function
1	ECM CGGA-K (10)	MAPS Signal
2	ECM CGGA-A (43)	Sensor Power (+5V)
3	ECM CGGA-K (32)	IATS Signal
4	ECM CGGA-K (8)	Sensor Ground

[HARNESS CONNECTOR]



STDFL9117L


Engine Control System

FL-57

[M/T]


[CIRCUIT DIAGRAM]

[CONNECTION INFORMATION]




Terminal	Connected to	Function
1	ECM CGGM-K (19)	MAPS Signal
2	ECM CGGM-K (81)	Sensor Power (+5V)
3	ECM CGGM-K (43)	IATS Signal
4	ECM CGGM-K (15)	Sensor Ground

[HARNESS CONNECTOR]



CGG25
MAPS



CGGM-K
ECM

Inspection

1. Connect a scan tool on Data Link Connector (DLC).
2. Check MAPS output voltage at idle and IG ON.

Condition	Output Voltage (V)
IG ON	3.9 ~ 4.1
Idle	0.8 ~ 1.6

STDFL9118L

FL-58


Fuel System

Intake Air Temperature Sensor (IATS)

Description

Intake Air Temperature Sensor (IATS) is included inside Manifold Absolute Pressure Sensor and detects the intake air temperature.


To calculate precise air quantity, correction of the air temperature is needed because air density varies according to the temperature. So the ECM uses not only MAPS signal but also IATS signal. This sensor has a Negative Temperature Coefficient (NTC) and its resistance is in inverse proportion to the temperature.



SMGF19111L

Specification

Temperature [$^{\circ}\text{C}$ ($^{\circ}\text{F}$)]	Resistance ($\text{k}\Omega$)
-40 (-40)	40.93 ~ 48.35
-30 (-22)	23.43 ~ 27.34
-20 (-4)	13.89 ~ 16.03
-10 (14)	8.50 ~ 9.71
0 (32)	5.38 ~ 6.09
10 (50)	3.48 ~ 3.90
20 (68)	2.31 ~ 2.57
25 (77)	1.90 ~ 2.10
30 (86)	1.56 ~ 1.74
40 (104)	1.08 ~ 1.21
60 (140)	0.54 ~ 0.62
80 (176)	0.29 ~ 0.34



SHDFL8132C


Engine Control System

FL-59

Circuit Diagram [A/T]



[CIRCUIT DIAGRAM]

[CONNECTION INFORMATION]



Terminal	Connected to	Function
1	ECM CGGA-K (10)	MAPS Signal
2	ECM CGGA-A (43)	Sensor Power (+5V)
3	ECM CGGA-K (32)	IATS Signal
4	ECM CGGA-K (8)	Sensor Ground

[HARNESS CONNECTOR]



STDFL9117L


FL-60

Fuel System

[M/T]


[CIRCUIT DIAGRAM]

[CONNECTION INFORMATION]




Terminal	Connected to	Function
1	ECM CGGM-K (19)	MAPS Signal
2	ECM CGGM-K (81)	Sensor Power (+5V)
3	ECM CGGM-K (43)	IATS Signal
4	ECM CGGM-K (15)	Sensor Ground

[HARNESS CONNECTOR]



CGG25
MAPS



CGGM-K
ECM

Inspection

1. Turn ignition switch OFF.
2. Disconnect IATS connector.
3. Measure resistance between IATS terminals 3 and 4.
4. Check that the resistance is within the specification.

Specification: Refer to "Specification"

STDFL9118L

Engine Control System

FL-61


Engine Coolant Temperature Sensor (ECTS)

Description

Engine Coolant Temperature Sensor (ECTS) is located in the engine coolant passage of the cylinder head for detecting the engine coolant temperature. The ECTS uses a thermistor whose resistance changes with the temperature.

The electrical resistance of the ECTS decreases as the temperature increases, and increases as the temperature decreases. The reference +5V is supplied to the ECTS via a resistor in the ECM. That is, the resistor in the ECM and the thermistor in the ECTS are connected in series. When the resistance value of the thermistor in the ECTS changes according to the engine coolant temperature, the output voltage also changes.

During cold engine operation, the ECM increases the fuel injection duration and controls the ignition timing using the information of engine coolant temperature to avoid engine stalling and improve drivability.



EGRF241A


Specification

Temperature [$^{\circ}\text{C}$ ($^{\circ}\text{F}$)]	Resistance ($\text{k}\Omega$)
-40(-40)	48.14
-20(-4)	14.13 ~ 16.83
0(32)	5.79
20(68)	2.31 ~ 2.59
40(104)	1.15
60(140)	0.59
80(176)	0.32

FL-62


Fuel System

Circuit Diagram [A/T]



STDFL9119L

[M/T]



STDFL9120L

Engine Control System

FL-63

Inspection

1. Turn ignition switch OFF.
2. Disconnect ECTS connector.
3. Remove the ECTS.
4. After immersing the thermistor of the sensor into engine coolant, measure resistance between ECTS terminals 1 and 3.
5. Check that the resistance is within the specification.

Specification: Refer to "Specification"

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FL-64

Fuel System


Throttle Position Sensor (TPS)

Description

The Throttle Position Sensor (TPS) is mounted on the throttle body and detects the opening angle of the throttle plate. The TPS has a variable resistor (potentiometer) which is changed according to the throttle angle.

During acceleration, the TPS resistance between the reference +5V and the signal terminal decreases and output voltage increases; during deceleration, the TPS resistance increases and TPS output voltage decreases. The TPS output voltage will vary from 0.25~0.9V at closed throttle to minimum 4.0V at wide-open throttle.

The ECM determines operating conditions such as idle (closed throttle), part load, acceleration / deceleration, and wide-open throttle by using the TPS signal. Also the ECM uses the Manifold Absolute Pressure Sensor (MAPS) signal along with the TPS signal to adjust fuel injection duration and ignition timing.



SPBF19121L

Specification


Throttle Angle	Output Voltage(V)
C.T	0.25 ~ 0.9
W.O.T	Min. 4.0

Item	Specification
Sensor Resistance(k Ω)	1.6 ~ 2.4 [20 $^{\circ}$ C (68 $^{\circ}$ F)]

Engine Control System


FL-65

Circuit Diagram [A/T]



STDFL9122L

[M/T]



STDFL9123L

FL-66

Fuel System

Inspection

1. Connect a scan tool on the Data Link Connector (DLC).
2. Start engine and check output voltages of TPS at C.T and W.O.T.

Specification: Refer to "Specification"

3. Turn ignition switch OFF and disconnect the scan tool from the DLC.
4. Disconnect TPS connector and measure resistance between TPS terminals 2 and 3.

Specification: Refer to "Specification"

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System


FL-67

Crankshaft Position Sensor (CKPS)

Description

Crankshaft Position Sensor (CKPS) detects the crankshaft position and is one of the most important sensors of the engine control system. If there is no CKPS signal input, the engine may stop because of CKPS signal missing. This sensor is installed on the cylinder block or the transaxle housing and generates alternating current by magnetic flux field which is made by the sensor and the target wheel when engine runs.

The target wheel consists of 58 slots and 2 missing slots on 360 degrees CA (Crank Angle).




SHDFL8138C

Specification

Item	Specification
Coil Resistance(Ω)	774 ~ 946 [20°C (68°F)]


Waveform



SPBF19520L

FL-68

Fuel System



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


SPBF19521L

Engine Control System

FL-69

Circuit Diagram


[A/T]



شرکت دیجیتال خودرو (مسئولیت محدود)

STDFL9124L

[M/T]



STDFL9125L

FL-70

Fuel System

Inspection

1. Check signal waveform of CKPS and CMPS using a scan tool.

Specification: Refer to "Waveform"

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System

FL-71


Camshaft Position Sensor (CMPS)

Description

Camshaft Position Sensor (CMPS) is a hall sensor and detects the camshaft position by using a hall element.


It is related with Crankshaft Position Sensor (CKPS) and detects the piston position of each cylinder which the CKPS can't detect.

The CMPS is installed on engine head cover and uses a target wheel installed on the camshaft. This sensor has a hall-effect IC which output voltage changes when magnetic field is made on the IC with current flow.



KFCF1022


Waveform



SPBF19520L

FL-72

Fuel System



دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


SPBF19521L

Engine Control System

FL-73


Circuit Diagram

[A/T]



STDFL9126L

[M/T] اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



STDFL9127L

FL-74

Fuel System

Inspection

1. Check signal waveform of CKPS and CMPS using a scan tool.

Specification: Refer to "Waveform"

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System


FL-75

Knock Sensor (KS)

Description

Knocking is a phenomenon characterized by undesirable vibration and noise and can cause engine damage. Knock Sensor (KS) is installed on the cylinder block and senses engine knocking.

When knocking occurs, the vibration from the cylinder block is applied as pressure to the piezoelectric element. At this time, this sensor transfers the voltage signal higher than the specified value to the ECM and the ECM retards the ignition timing. If the knocking disappears after retarding the ignition timing, the ECM will advance the ignition timing. This sequential control can improve engine power, torque and fuel economy.



SHDFL8144C

Specification

Item	Specification
Capacitance(pF)	950 ~ 1,350
Resistance ($M\Omega$)	4.87




FL-76

Fuel System

Circuit Diagram [A/T]

[CIRCUIT DIAGRAM]




[CONNECTION INFORMATION]

Terminal	Connected to	Function
1	ECM CGGA-A (30)	Sensor Ground
2	ECM CGGA-A (15)	Knock Sensor Signal


[HARNESS CONNECTOR]



CGG23
KNOCK SENSOR



CGGA-K



ECM


CGGA-A

شرکت دیجیتال خودرو (مسئولیت محدود)

STDFL9128L

[M/T] اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

[CIRCUIT DIAGRAM]




[CONNECTION INFORMATION]

Terminal	Connected to	Function
1	ECM CGGM-K (32)	Sensor Ground
2	ECM CGGM-K (11)	Knock Sensor Signal

[HARNESS CONNECTOR]



CGG23
KNOCK SENSOR



CGGM-K
ECM

STDFL9129L

Engine Control System

FL-77


Heated Oxygen Sensor (HO2S)

Description

Heated Oxygen Sensor (HO2S) consists of zirconium and alumina and is installed on upstream and downstream of the Manifold Catalytic Converter (MCC).

After it compares oxygen consistency of the atmosphere with the exhaust gas, it transfers the corresponding voltage signal to the ECM. When A/F ratio is rich or lean, it generates approximately +1V or 0V respectively.

In order that this sensor normally operates, the temperature of the sensor tip must be higher than predetermined temperature. So it has a heater which is controlled by the ECM duty signal. When the exhaust gas temperature is lower than the specified value, the heater warms the sensor tip.



SHDFL8147C

Specification


A/F Ratio (λ)	Output Voltage(V)
Rich	0.6 ~ 1.0
Lean	0 ~ 0.4

Item	Specification
Heater Resistance(Ω)	Approx. 9.0 [20°C (68°F)]

FL-78

Fuel System

Waveform




SPBF19510L

Engine Control System

FL-79

Circuit Diagram [A/T]

[CIRCUIT DIAGRAM]



[CONNECTION INFORMATION]


HO2S [B1/S1] (CGG16)

Terminal	Connected to	Function
1	ECM CGGA-K (35)	HO2S [B1/S1] Signal
2	ECM CGGA-K (31)	Sensor Ground
3	Main Relay	Battery Power (B+)
4	ECM CGGA-A (34)	Heater Control

HO2S [B1/S2] (CGG31)

Terminal	Connected to	Function
1	ECM CGGA-K (9)	Sensor Ground
2	ECM CGGA-K (13)	HO2S [B1/S2] Signal
3	ECM CGGA-A (33)	Heater Control
4	Main Relay	Battery Power (B+)

[HARNESS CONNECTOR]




STDFL9130L

FL-80

Fuel System

[M/T]



شرکت دیجیتال خودرو سازانه (مسئول محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

STDFL9131L

Inspection

1. Check signal waveform of HO2S using a scan tool.

Specification: Refer to "Waveform"

2. Disconnect the HO2S connector.
3. Measure resistance between HO2S heater terminals 3 and 4.
4. Check that the resistance is within the specification.

Specification: Refer to "Specification"


Engine Control System

FL-81

Injector

Description

Based on information from various sensors, the ECM can calculate the fuel amount to be injected. The fuel injector is a solenoid-operated valve and the fuel injection amount is controlled by length of injection time. The ECM controls each injector by grounding the control circuit. When the ECM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the ECM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should momentarily peak.



Specification

Item	Specification
Coil Resistance (Ω)	13.8 ~ 15.2 [20°C (68°F)]



دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئول محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


KFCF1026

FL-82

Fuel System

Circuit Diagram [A/T]

[CIRCUIT DIAGRAM]



[CONNECTION INFORMATION]

INJECTOR #1 (CGG24-1)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGA-A (50)	Injector #1 Control

INJECTOR #2 (CGG24-2)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGA-A (52)	Injector #2 Control

INJECTOR #3 (CGG24-3)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGA-A (36)	Injector #3 Control


INJECTOR #4 (CGG24-4)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGA-A (48)	Injector #4 Control


[HARNES CONNECTOR]



CGG24-1,2,3,4
INJECTOR #1,2,3,4



CGGA-K



CGGA-A

ECM


STDFL9132L

Engine Control System

FL-83

[M/T]

[CIRCUIT DIAGRAM]



[CONNECTION INFORMATION]

INJECTOR #1 (CGG24-1)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGM-K (91)	Injector #1 Control

INJECTOR #2 (CGG24-2)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGM-K (47)	Injector #2 Control

INJECTOR #3 (CGG24-3)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGM-K (24)	Injector #3 Control


INJECTOR #4 (CGG24-4)

Terminal	Connected to	Function
1	Main Relay	Battery Power (B+)
2	ECM CGGM-K (68)	Injector #4 Control

[HARNESS CONNECTOR]



CGG24-1,2,3,4
INJECTOR #1,2,3,4



CGGM-K
ECM

STDFL9133L

Inspection

1. Turn ignition switch OFF.
2. Disconnect injector connector.
3. Measure resistance between injector terminals 1 and 2.
4. Check that the resistance is within the specification.

Specification: Refer to "Specification"

FL-84

Fuel System

Idle Speed Control Actuator (ISCA)

Description

The Idle Speed Control Actuator (ISCA) is installed on the throttle body and controls the intake airflow that is bypassed around the throttle plate to keep constant engine speed when the throttle valve is closed.



The function of the ISCA is to maintain idle speed according to various engine loads and conditions, and also to provide additional air during starting.

The ISCA consists of an opening coil, a closing coil, and a permanent magnet. Based on information from various sensors, the ECM controls both coils by grounding their control circuits. According to the control signals from the ECM, the valve rotor rotates to control the by-pass airflow into the engine.

Specification

Item	Specification
Opening Coil Resistance (Ω)	14.6 ~ 16.2 [20°C(68°F)]
Closing Coil Resistance (Ω)	11.1 ~ 12.7 [20°C(68°F)]

Duty (%)	Air Flow Rate (m ³ /h)
15	0.5 ~ 1.4
35	4.6 ~ 8.0
70	25.0 ~ 32.0
96	33.0 ~ 40.0




SPBF19134L

Engine Control System


FL-85

Circuit Diagram [A/T]



STDFL9135L

[M/T]



STDFL9136L

FL-86

Fuel System

Inspection

1. Turn ignition switch OFF.
2. Disconnect ISCA connector.
3. Measure resistance between ISCA terminals 2 and 1 [Opening Coil].
4. Measure resistance between ISCA terminals 2 and 3 [Closing Coil].
5. Check that the resistance is within the specification.

Specification: Refer to "Specification"

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System


FL-87

Purge Control Solenoid Valve (PCSV)

Description

Purge Control Solenoid Valve (PCSV) is a solenoid valve and is installed on the surge tank and controls the passage between the canister and the intake manifold.

The evaporative gases gathered in the canister are delivered to the intake manifold when the PCSV is open by ECM control signal.



STDFL9146D

Specification

Item	Specification
Coil Resistance (Ω)	16.0 [20°C (68°F)]

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FL-88


Fuel System

Circuit Diagram [A/T]



STDFL9137L

[M/T]



STDFL9138L

Inspection

1. Turn ignition switch OFF.
2. Disconnect PCSV connector.

3. Measure resistance between PCSV terminals 1 and 2.
4. Check that the resistance is within the specification.

Specification: Refer to "Specification"

Engine Control System

FL-89

CVT Oil Control Valve (OCV)

Description

The Continuously Variable Valve Timing (CVVT) system controls the amount of valve overlap by varying the amount of oil flow into an assembly mounted on the intake camshaft through ECM control of an oil control valve.

As oil is directed into the chambers of the CVVT assembly, the cam phase is changed to suit various performance and emissions requirements.

1. When camshaft rotates engine rotation-wise:
Intake-Advance / Exhaust-Retard
2. When camshaft rotates counter engine rotation-wise:
Intake- Retard / Exhaust- Advance



SHDFL8159C

Specification


Item	Specification
Coil Resistance (Ω)	6.9 ~ 7.9 [20°C (68°F)]



FL-90


Fuel System

Circuit Diagram [A/T]



STDFL9139L

[M/T]



STDFL9140L

Engine Control System

FL-91

Inspection

1. Turn ignition switch OFF.
2. Disconnect OCV connector.
3. Measure resistance between OCV terminals 1 and 2.
4. Check that the resistance is within the specification.

Specification: Refer to "Specification"

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




FL-92

Fuel System

Fuel Delivery System

Component Location



STDFL9150L

- | | |
|--------------------------------------|--|
| 1. Fuel Tank | 6. Canister |
| 2. Fuel Pump (Including Fuel Filter) | 7. Vapor Hose (Canister → Intake Manifold) |
| 3. Fuel Pressure Regulator | 8. Vapor Hose (Canister ↔ Fuel Tank) |
| 4. Fuel Filler Pipe | 9. Vapor Hose (Canister ↔ Atmosphere) |
| 5. Leveling Pipe | |


Fuel Delivery System

FL-93

Fuel Pressure Test


1. PREPARING

1. Remove the rear seat cushion (Refer to "SEAT" in BD group).
2. Open the service cover (A).



2. RELEASE THE INTERNAL PRESSURE

1. Disconnect the fuel pump connector (A).
2. Start the engine and wait until fuel in fuel line is exhausted.
3. After the engine stalls, turn the ignition switch to OFF position and disconnect the negative (-) terminal from the battery.



NOTE

Be sure to reduce the fuel pressure before disconnecting the fuel feed hose, otherwise fuel will spill out.


3. INSTALL THE SPECIAL SERVICE TOOL (SST) FOR MEASURING THE FUEL PRESSURE

1. Disconnect the fuel feed hose from the delivery pipe.

CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

2. Install the Fuel Pressure Gauge Adapter (09353-38000) between the delivery pipe and the fuel feed hose.
3. Connect the Fuel Pressure Gauge Connector (09353-24000) to the Fuel Pressure Gauge Adapter (09353-38000).
4. Connect the Fuel Pressure Gauge and Hose (09353-24100) to Fuel Pressure Gauge Connector (09353-24000).
5. Connect the fuel feed hose to the Fuel Pressure Gauge Adapter (09353-38000).



STDFL9151L

FL-94

Fuel System

4. INSPECT FUEL LEAKAGE ON CONNECTION

1. Connect the battery negative (-) terminal.
2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.

5. FUEL PRESSURE TEST

1. Disconnect the negative (-) terminal from the battery.
2. Connect the fuel pump connector.
3. Connect the battery negative (-) terminal.
4. Start the engine and measure the fuel pressure at idle.

Standard Value: 345 ~ 355 kpa (3.5 ~ 3.6 kgf/cm², 50.0 ~ 51.5 psi)

- If the measured fuel pressure differs from the standard value, perform the necessary repairs using the table below.

Condition	Probable Cause	Suspected Area
Fuel Pressure too low	Clogged fuel filter	Fuel filter
	Fuel leak on the fuel-pressure regulator that is assembled on fuel pump because of poor sealing of the fuel-pressure regulator.	Fuel Pressure Regulator
Fuel Pressure too High	Sticking fuel pressure regulator	Fuel Pressure Regulator

5. Stop the engine and check for a change in the fuel pressure gauge reading.

After engine stops, the gage reading should hold for about 5 minutes

- Observing the declination of the fuel pressure when the gage reading drops and perform the necessary repairs using the table below.

Condition	Probable Cause	Supected Area
Fuel pressure drops slowly after engine is stopped	Injector leak	Injector
Fuel pressure drops immediately after engine is stopped	The check valve within the fuel pump is open	Fuel Pump


STDFL9152L

Fuel Delivery System

FL-95

6. RELEASE THE INTERNAL PRESSURE

1. Disconnect the fuel pump connector (A).
2. Start the engine and wait until fuel in fuel line is exhausted.
3. After the engine stalls, turn the ignition switch to OFF position and disconnect the negative (-) terminal from the battery.



NOTE

Be sure to reduce the fuel pressure before disconnecting the fuel feed hose, otherwise fuel will spill out.

7. REMOVE THE SPECIAL SERVICE TOOL (SST) AND CONNECT THE FUEL LINE

1. Disconnect the Fuel Pressure Gage and Hose (09353-24100) from the Fuel Pressure Gage Connector (09353-24000).
2. Disconnect the Fuel Pressure Gage Connector (09353-24000) from the Fuel Pressure Gage Adapter (09353-38000).
3. Disconnect the fuel feed hose from the Fuel Pressure Gage Adapter (09353-38000).
4. Disconnect the Fuel Pressure Gage Adapter (09353-38000) from the delivery pipe.

CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

5. Connect the fuel feed hose to the delivery pipe.

8. INSPECT FUEL LEAKAGE ON CONNECTION

1. Connect the battery negative (-) terminal.
2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.
3. If the vehicle is normal, connect the fuel pump connector.

STDFL9153L

FL-96


Fuel System

Fuel Tank

Removal


1. Preparation

- 1) Remove the rear seat cushion (Refer to "Seat" in BD group).
- 2) Open the service cover (A).



STDFL9159D


- 3) Disconnect the fuel pump connector (A).



STDFL9154L


- 4) Start the engine and wait until fuel in fuel line is exhausted.
- 5) After engine stalls, turn the ignition switch to OFF position.

2. Disconnect the fuel feed quick-connector (A) and the vapor tube quick-connector (B).



STDFL9156L


3. Lift the vehicle and support the fuel tank with a jack.
4. Remove the center muffler (Refer to "Intake And Exhaust System" in EM group).
5. Disconnect the fuel filler hose (A), the leveling hose (B) and the vapor hose (C).



STDFL9157L


Fuel Delivery System

FL-97



STDFL9158L

6. Remove the fuel tank mounting bolts (A) and nuts (B), and then remove the fuel tank (C).



SHDFL8170C

Installation

Installation is reverse of removal.

Fuel tank installation bolt: 44.1 ~ 58.8 N.m (4.5 ~ 6.0 kgf.m, 32.5 ~ 43.4 lb-ft)

Fuel tank installation nut: 39.2 ~ 53.9 N.m (4.0 ~ 5.5 kgf.m, 28.9 ~ 39.8 lb-ft)

FL-98


Fuel System

Fuel Pump

Removal


1. Preparation

- 1) Remove the rear seat cushion (Refer to "Seat" in BD group).
- 2) Open the service cover (A).



STDFL9159D


- 3) Disconnect the fuel pump connector (A).



STDFL9154L


- 4) Start the engine and wait until fuel in fuel line is exhausted.
- 5) After engine stalls, turn the ignition switch to OFF position.

2. Disconnect the fuel feed tube quick-connector (A), the vapor hose (B) and the vapor tube quick-connector (C).



STDFL9160L

3. Remove the fuel pump installation bolts (D) and remove the fuel pump assembly.



SHDFL8172C

Installation

Installation is reverse of removal.

Fuel pump installation bolt: 2.0 ~ 2.9 N.m (0.2 ~ 0.3 kgf.m, 1.4 ~ 2.2 lb-ft)

⚠ CAUTION

When installing the fuel pump module, be careful not to get the seal-ring entangled.


Fuel Delivery System

FL-99

Fuel Filter


Replacement

1. Remove the fuel pump (Refer to "Fuel Pump" in this group).
2. Disconnect the electric pump wiring connector (A) and the fuel sender wiring connector (B).



SHDFL8173C


3. Disconnect the electric pump wiring connector (A) from the pump.



SHDFL8174C


4. Remove the fuel sender (B) with sliding it downward after releasing the latch (C).

5. Remove the fuel pressure regulator & hose assembly (A) after releasing the cap (B).



SHDFL8175C

6. Remove the reservoir cup (A) after releasing the three fixing hooks (B).




SHDFL8176C

FL-100


Fuel System

- Remove the fuel feed tube (A) from the fuel filter after releasing the two fixing hooks.




SHDFL8177C


- Remove the plate assembly (B) after removing the cushion pipe fixing clip (C).
- Extract the fuel filter (A) upward after releasing the two fixing hooks (B)



SHDFL8178C



SHDFL8179C



SHDFL8183C




Fuel Delivery System

FL-101

Filler-Neck Assembly


Removal

1. Disconnect the fuel filler hose (A), the leveling hose (B) and the vapor hose (C).



STDFL9161L


2. Open the fuel filler door and unfasten the filler-neck assembly mounting screws (A).



SCMFL6655D

3. Remove the rear-LH wheel, tire, and the inner wheel house.

4. Remove the bracket mounting bolt (A) and remove the filler-neck assembly.



SHDFL8181C

Installation

1. Installation is reverse of removal.

Filler-neck assembly installation bolt:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)

Filler-neck assembly installation screw:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)