

SQRE4T15C ENGINE MECHANICAL

| | | | |
|--|--------------|--------------|-------|
| GENERAL INFORMATION | 06-3 | Inspection | 06-35 |
| Overview | 06-3 | Installation | 06-36 |
| Description | 06-3 | | |
| Operation | 06-3 | | |
| Specifications | 06-4 | | |
| Tools | 06-9 | | |
| DIAGNOSIS & TESTING | 06-15 | | |
| Problem Symptoms Table | 06-15 | | |
| Inspection | 06-16 | | |
| ON-VEHICLE SERVICE | 06-19 | | |
| Accessory Pulley | 06-19 | | |
| Removal | 06-19 | | |
| Inspection | 06-20 | | |
| Installation | 06-20 | | |
| Idler Pulley Assembly | 06-21 | | |
| Removal | 06-21 | | |
| Inspection | 06-21 | | |
| Installation | 06-21 | | |
| Tensioner Assembly | 06-22 | | |
| Removal | 06-22 | | |
| Inspection | 06-22 | | |
| Installation | 06-22 | | |
| Cylinder Head Cover | 06-23 | | |
| Removal | 06-23 | | |
| Installation | 06-24 | | |
| Crankshaft Front Oil Seal | 06-25 | | |
| Removal | 06-25 | | |
| Installation | 06-26 | | |
| Flywheel (CVT) | 06-27 | | |
| Removal | 06-27 | | |
| Inspection | 06-27 | | |
| Installation | 06-28 | | |
| Flywheel (6MT) | 06-29 | | |
| Removal | 06-29 | | |
| Inspection | 06-29 | | |
| Installation | 06-29 | | |
| Crankshaft Rear Oil Seal | 06-31 | | |
| Removal | 06-31 | | |
| Installation | 06-31 | | |
| Engine Timing Chain | 06-32 | | |
| Description | 06-32 | | |
| Removal | 06-32 | | |
| Camshaft & Rocker Arm | 06-39 | | |
| Description | 06-39 | | |
| Removal | 06-40 | | |
| Inspection | 06-41 | | |
| Installation | 06-42 | | |
| Cylinder Head | 06-44 | | |
| Description | 06-44 | | |
| Removal | 06-45 | | |
| Disassembly | 06-47 | | |
| Inspection | 06-49 | | |
| Assembly | 06-51 | | |
| Installation | 06-53 | | |
| Engine Mounting Assembly | 06-54 | | |
| (For CVT models) | 06-54 | | |
| (For MT models) | 06-55 | | |
| Removal & Installation - Rear Mounting Assembly (for CVT Models) | 06-56 | | |
| Installation | 06-56 | | |
| Removal & Installation - Rear Mounting Assembly (for MT Models) | 06-57 | | |
| Installation | 06-57 | | |
| CYLINDER BLOCK UNIT REPAIR | 06-68 | | |
| Engine Block | 06-68 | | |
| Disassembly | 06-70 | | |
| Inspection | 06-75 | | |
| Selection of Main Bearing Shell | 06-81 | | |
| Selection of Connecting Rod Bearing Shell | 06-82 | | |
| Assembly | 06-83 | | |

06

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION

Overview

Description


SQRE4T15C engine has the following features:

- DVVT
- Water cooled vertical
- In-line DOHC with 4 cylinders
- Four valves per cylinder
- Aluminum cylinder head
- Cast iron cylinder block
- Supercharged intercooled

Operation

- SQRE4T15C engine uses a design of vertical, four cylinders, water-cooled, four-stroke, single-cylinder four-valve, DOHC, supercharged water-cooled, VVT and multi-point electronic control gasoline sequential injection. Engine uses independent ignition.
- SQRE4T15C engine adopts a cast iron cylinder block. Aluminum oil pan is fixed to aluminum frame with bolts. The aluminum cylinder head is secured to the block with bolts. The camshaft is installed on cylinder head. The power output from crankshaft drives camshaft to rotate by crankshaft sprocket through timing chain, so that camshaft can interact with valve lifter to open and close valve. Piston assembly is an aluminum piston with cast iron connecting rod. This engine has features of reliable structure and excellent performance.

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Specifications

Engine Specifications

| Item | Specifications | |
|---|--|-------------------|
| Type | Vertical, in-line with four cylinders, four strokes, DOHC and supercharged intercooled | |
| Model | SQRE4T15C | |
| Valve Number Per Cylinder | 4 | |
| Cylinder Diameter (mm) | 77 | |
| Piston Stroke (mm) | 80.5 | |
| Working Volume (ml) | 1498 | |
| Compression Ratio | 9.5:1 | |
| Ignition Type | Independent | |
| Ignition Sequence | 1 - 3 - 4 - 2 | |
| Rated Power (kW) | 115 | |
| Rated Power Speed (r/min) | 5500 | |
| Max. Net Power | 108 | |
| Max. Net Power Speed (r/min) | 5500 | |
| Max. Torque (N·m) | 230 | |
| Max. Torque Speed (r/min) | 1750-4000 | |
| Min. Fuel Consumption Rate (g/kW·h) | 275 | |
| Fuel Octane Number (Not Less Than) | Unleaded gasoline, octane number 92 | |
| Oil Grade | SM 5W-30 (for summer) SM 5W-40 (for winter) SM 10W-40 (for summer) | |
| Oil Capacity (L) | 4.7 ± 0.2 | |
| Starting Type | Electrical starting | |
| Cooling Type | Forced circulation type antifreeze cooling | |
| Lubrication Type | Compound type (pressure, splash lubrication) | |
| Cylinder Compression Pressure (bar) (180 - 250) r/min | 7 - 10 | |
| Oil Pressure (bar) | Idling speed (700 ± 50 r/min) | Not less than 0.7 |
| | High speed (2000 r/min) | Not less than 2.5 |

Engine Mechanical Specifications

| Item | | Specifications |
|----------------|--|--|
| Camshaft | Cam height | Intake cam (mm) 37.07 - 37.31 |
| | | Exhaust cam (mm) 36.94 - 37.18 |
| | Camshaft diameter (same for intake and exhaust sides) (mm) | 1st journal 33.934 - 33.95. |
| | | 2nd - 5th journal 23.947 - 23.96 |
| | Camshaft axial clearance | Intake cam (mm) 0.15 - 0.2 |
| | | Exhaust cam (mm) 0.15 - 0.2 |
| Cylinder Head | Lower surface flatness (mm) | |
| | Overall height (mm) | |
| | Surface grinding limit | |
| Valve | Valve head margin thickness | Intake valve (mm) 0.68 - 1.1 |
| | | Exhaust valve (mm) 0.48 - 0.9 |
| | Valve stem diameter | Intake valve (mm) 5.98 ± 0.008 |
| | | Exhaust valve (mm) 5.96 ± 0.008 |
| | Valve face sealing width | Intake valve (mm) 1.154 |
| | | Exhaust valve (mm) 1.307 |
| | Clearance between valve stem and guide | Intake valve (mm) 0.012 - 0.043 |
| | | Exhaust valve (mm) 0.032 - 0.063 |
| | Seal with cone angle | Intake valve 90° |
| | | Exhaust valve 90° |
| | Height | Intake valve (mm) 107.75 - 108.25 |
| | | Exhaust valve (mm) 106.07 - 106.57 |
| Valve Spring | Free height (mm) | |
| | Operating preload (N)/operating height (mm) | |
| Valve Guide | Inner diameter (mm) | |
| | Depression depth (mm) | |
| Piston | Piston skirt diameter (mm) | |
| | Piston pin hole diameter (mm) | |
| Piston Ring | Piston ring side clearance (mm) | First ring 0.02 - 0.065 |
| | | Second ring 0.02 - 0.06 |
| | Piston ring end gap (mm) | First ring 0.2 - 0.3 |
| | | Second ring 0.3 - 0.5 |
| Piston Pin | Diameter (mm) | |
| | Length (mm) | |
| Crankshaft | Crankshaft main journal | Diameter (mm) Standard value 50 limit value: 49.979 |
| | | Coaxially (mm) 0.05 |
| | | Cylindricity (mm) 0.007 |
| | | Roundness (mm) 0.004 |
| | Connecting rod journal | Diameter (mm) Standard value: 50 Limit value: 49.984 |
| | | Parallelism to main journal (mm) 0.008 |
| Cylinder Block | Overall height (mm) | |
| | Bore roundness/straightness (mm) | |
| | Upper surface flatness (mm) | |
| | Surface grinding limit | |
| Connecting Rod | Connecting rod big end hole axial clearance (mm) | |
| | Connecting rod bearing shell radial clearance (mm) | |

Engine Torque Specifications

| Description | Torque (N·m) |
|---|--|
| Ignition Coil Fixing Bolt | 8 ± 1 |
| Flywheel Fixing Bolt | 1st step: 35 ± 5 2nd step: 45° ± 5° |
| Idler Pulley Fixing Bolt | 40 ± 5 |
| Tensioner Fixing Bolt | 40 ± 5 |
| Cylinder Head Cover Fixing Bolt | 1st step: 3 ± 2 2nd step: 8 ± 3 |
| Crankshaft Pulley Fixing Bolt | 1st step: 100 ± 10 2nd step: 120° ± 10° |
| Crankshaft Timing Hole Fixing Bolt | 40 ± 5 |
| Hydraulic Tensioner Fixing Bolt | 9 ± 3 |
| Movable Guide Rail Fixing Bolt | 9 ± 3 |
| Fixing Guide Rail Fixing Bolt | 9 ± 3 |
| Upper Guide Rail Fixing Bolt | 9 ± 3 |
| Phaser Fixing Bolt | 105 ± 5 |
| Camshaft Bearing Cap Fixing Bolt | 1st step: 9.5 ± 1.5 2nd step: 9.5 ± 1.5 |
| Cylinder Head Fixing Bolt | 1st step: 40 ± 5 2nd step: 90° ± 5° 90° ± 5° |
| Variable Timing Control Solenoid Valve | 6 ± 2 |
| Camshaft Position Sensor Fixing Bolt | 8 ± 3 |
| Lifting Eye Fixing Bolt | 20 ± 5 |
| Coupling Bolt Between Rear Mounting Upper Body and Lower Body | 105 ± 10 |
| Coupling Bolt Between Rear Mounting Upper Body and Transmission | 80 ± 5 |
| Coupling Bolt Between Rear Mounting Lower Body and Sub Frame | 150 ± 10 |
| Coupling Bolt And Nut Between Left Mounting Cushion and Bracket | 80 ± 5 |
| Coupling Bolt Between Left Mounting Cushion Assembly and Body | 70 ± 5 |
| Coupling Bolt Between Left Mounting Bracket and Transmission | 60 ± 5 |
| Coupling Bolt Between Right Mounting Cushion and Engine | 80 ± 5 |
| Coupling Bolt Between Right Mounting Cushion and Body | 70 ± 5 |
| Knock Sensor Fixing Bolt | 20 ± 5 |
| Cooling Pipe Assembly I Fixing Bolt | 20 ± 5 |
| Oil Pump Movable Guide Rail Fixing Bolt | 12 ± 2 |
| Oil Deflector Fixing Bolt | 8 ± 3 |
| Crankshaft Frame Fixing Bolt | 27 ± 3 |
| Crankshaft Main Bearing Fixing Bolt (Frame) | 1st step: 45 ± 5 180° ± 10° |
| Connecting Rod Bearing Cap Fixing Bolt | 1st step: 15 ± 3 2nd step: 60° ± 2° |

Lubrication Areas During Engine Assembly

| Lubrication Area | Note |
|---|-------------------------------------|
| Valve Guide Bottom Hole | Same type as engine lubrication oil |
| Intake Valve Retainer Bottom Hole | Same type as engine lubrication oil |
| Exhaust Valve Retainer Bottom Hole | Same type as engine lubrication oil |
| Cylinder Head OCV Valve Hole | Same type as engine lubrication oil |
| Check Valve | Same type as engine lubrication oil |
| Valve Stem Part | Same type as engine lubrication oil |
| Valve Oil Seal Lip | Same type as engine lubrication oil |
| Valve Lifter Outer Circumcircle | Same type as engine lubrication oil |
| Camshaft Journal and Bearing Seat Hole | Same type as engine lubrication oil |
| Cam Surface | Same type as engine lubrication oil |
| Camshaft Phaser Assembly Front End Control Valve | Same type as engine lubrication oil |
| Rocker Arm Roller | Same type as engine lubrication oil |
| Timing System | Same type as engine lubrication oil |
| Cylinder Bore | Same type as engine lubrication oil |
| Main Bearing Cap Bolt | Same type as engine lubrication oil |
| Connecting Rod Bearing and Connecting Rod Bearing Journal | Same type as engine lubrication oil |
| Main Bearing Shell and Crankshaft Main Journal | Same type as engine lubrication oil |
| Piston Pin Cylindrical Surface | Same type as engine lubrication oil |
| Crankshaft Front and Rear Oil Seal Journal and Oil Seal Lip | Same type as engine lubrication oil |
| Piston Ring Groove | Same type as engine lubrication oil |
| Cylinder Bore Inner Wall | Same type as engine lubrication oil |
| Crankshaft Front and Rear Oil Seal Cylindrical Surface | Same type as engine lubrication oil |
| Collector O-ring | Same type as engine lubrication oil |
| Oil Pump Inlet | Same type as engine lubrication oil |
| Oil Filter Module Inlet on Cylinder Block | Same type as engine lubrication oil |
| Oil Filter O-ring | Same type as engine lubrication oil |
| Oil Dipstick Tube O-ring | Same type as engine lubrication oil |

Areas with seal gum applied during engine assembly

| Area with Seal Gum Applied | Seal Gum |
|--|------------------|
| Coolant Temperature Sensor | Loctite 243 |
| Bowl plug | Loctite 11747 |
| "T" Position Between Timing Chain Cover and Cylinder Block | Loctite 5900H |
| Timing Chain Cover | Loctite 5900H |
| Upper Guide Rail Bolt | Loctite 243 |
| Cylinder Bowl Plug | Loctite 577 |
| Cylinder Block Frame Assembly | Loctite 518/5182 |
| Deflector Mounting Bolt Thread | Loctite 243 |
| Collector Mounting Bolt Thread | Loctite 243 |
| Oil pump Mounting Bolt Thread | Loctite 243 |
| Oil Pan Mounting Surface Frame | Loctite 5900H |
| Oil Pressure Switch Thread | Loctite 577 |

06






Non-reusable Part

| Non-reusable Part | |
|---|---------|
| Valve Oil Seal | Replace |
| Cylinder Head Bolt and Washer | Replace |
| Cylinder Head Gasket | Replace |
| Crankshaft Rear Oil Seal | Replace |
| Crankshaft Front Oil Seal | Replace |
| Connecting Rod Bearing Cap Fixing Bolt | Replace |
| Flywheel Fixing Bolt (MT + CVT) | Replace |
| Main Bearing Cap Fixing Bolt (Frame) | Replace |
| Rubber O-ring (Mounting Surface Between Frame and Cylinder Block) | Replace |


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Tools

General Tools


| | |
|------------------------------------|---|
| Piston Installer |  RCH0039006 |
| Dial Indicator and Magnetic Holder |  RCH0023006 |
| External Micrometer |  RCH0064006 |
| Vernier Caliper |  RCH0019006 |
| Inner Diameter Micrometer |  RCH0069006 |

Precision Straightedge




RCH0063006

Feeler Gauge



RCH0060006


Piston Ring Remover



RCH0066006


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Cylinder Gauge






RCH0065006

Digital Multimeter




RCH0002006

| | |
|-----------------------------|---|
| Flexional Magnetic Rod |  RCH0042006 |
| Engine Hoist |  RCH0043006 |
| Engine Equalizer |  RCH0026006 |
| Transmission Carrier |  RCH000506 |
| Fuel System Pressure Tester |  RCH0048006 |


06

Cylinder Pressure Gauge




RCH0044006

Engine Service Platform



RCH0057006


Angle Gauge



RCH0091006


Special Tools

Crankshaft Front Oil Seal Guide Tool








RCH0049006





Crankshaft Front Oil Seal Installer



RCH0067006

| | |
|------------------------------------|---|
| Valve Spring Compression Adapter |  RCH0050006 |
| Valve Spring Compressor |  RCH0028006 |
| Crankshaft Rear Oil Seal Installer |  RCH0031006 |
| Valve Oil Seal Installer |  RCH0034006 |
| Valve Oil Seal Guide Sleeve |  RCH0035006 |

06

| | |
|------------------------------------|---|
| Valve Oil Seal Remover |  RCH0037006 |
| Valve Cotter Installer |  RCH0029006 |
| Crankshaft Rear Oil Seal Installer |  RCH0070006 |
| Camshaft Timing Tool |  RCH0033006 |
| Crankshaft Timing Tool |  RCH0027006 |

DIAGNOSIS & TESTING

Problem Symptoms Table

Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

06

| Symptom | Suspected Area |
|---------------------------------|---|
| Valve mechanism noise | Engine oil (oil level high or low, oil lean or rich) |
| | Cam |
| | Valve spring seat (excessive runout) |
| | Valve (excessive clearance between valve and guide) |
| Connecting rod noise | Engine oil (low pressure) |
| | Engine oil (become lean) |
| | Connecting rod bearing cap (becomes loosen) |
| | Connecting rod (misaligned) |
| | Connecting rod bearing shell (excessive radial clearance) |
| | Connecting rod journal (out-of roundness) |
| Main bearing noise | Engine oil (low pressure) |
| | Engine oil becomes lean |
| | Main bearing shell (excessive clearance) |
| | Crankshaft axial clearance (excessive) |
| | Crankshaft journal (out-of roundness or worn) |
| | Flywheel or clutch (loose) |
| Oil loss or spark plug blockage | Piston ring (worn, scratched or damaged) |
| | Piston ring groove (carbon deposited) |
| | Valve oil seal (worn or damaged) |
| | Valve (excessive clearance between valve and guide) |
| | Spark plug (dirty, burnt or incorrect gap) |
| Engine power loss | Electric fuel pump assembly |
| | Ignition coil |
| | Incorrect valve timing |
| | Cylinder head (leakage) |
| | Valve (burnt, deformed or excessive gap) |
| | Low cylinder pressure |
| | Fuel System (dirty) |
| | Exhaust system (blocked) |
| | Cylinder gasket (leakage) |
| | Cylinder liner (cracks) |
| Water in engine | Wading driving |
| | Oil filter module (inner leakage) |

Inspection

1. Check the coolant.
2. Check the engine oil.
3. Check the battery.
4. Check the air filter element.
 - (a) Remove the air filter element.
 - (b) Visually check that there is no dirt, blockage or damage in the air filter element.

Hint:

- If there is any dirt or blockage in air filter element, clean it with compressed air.
- If any dirt or blockage remains, even after cleaning air filter element with compressed air, replace it.

5. Check the spark plug.
6. Test the cylinder compression pressure.

06

- Cylinder pressure is the main index to judge engine operation and also can be used to definitely judge whether some system of engine operates well or not. Therefore, it is necessary to perform cylinder pressure measurement when servicing engine.
- Ensure battery is fully charged and engine starter is in good operating condition. Otherwise, indicated compression pressure used for diagnosis may be invalid.


Caution:

- Recommended compression pressure is only used as a guide for diagnosing engine malfunction.
- Never determine cause of low pressure by disassembling engine unless there are some malfunctions.

Measurement procedures:

Caution:

- Use a cylinder pressure gauge with accurate reading and reset it to zero, or it will influence accuracy of reading.
- (a) Turn off all electrical equipment and the ignition switch.
- (b) Remove the engine trim cover.
- (c) Remove the ignition coil.
 - Disconnect the ignition coil connector (1).




- Remove 8 fixing bolts (arrow) from ignition coils and remove 4 ignition coils.

Tightening torque

$8 \pm 1 \text{ N}\cdot\text{m}$


(d) Disconnect all injector connectors (arrow).



EM0002002

(e) Remove spark plugs in each cylinder.

(f) Slowly screw the cylinder pressure gauge connector vertically into the spark plug mounting hole. Do not tighten it excessively to prevent difficult removal.



EM0003002

(g) With transmission in P/N position (for CVT models) or neutral position (for 6 MT models), depress accelerator pedal fully, then start engine and keep it racing for 3 to 5 seconds; record the measured pressure value.

(h) Press the bleeder button of cylinder pressure gauge to reset it to zero. Use same method to repeat this test three times and then calculate average value.
Cylinder pressure value is within 7 - 10 bar (180 - 250 r/min).

Caution:

- DO NOT screw the cylinder pressure gauge excessively to prevent difficult removal.
- During measurement, do not turn ignition switch to "START" for more than 10 seconds. Otherwise, engine may be damaged.
- Ensure battery is fully charged when cranking engine. Correct cylinder pressure can be measured only when engine is running at 180 - 250 r/min.
- Use same method to measure pressure of other cylinders.

Cylinder pressure value judgment:

Correct cylinder pressure


Standard cylinder pressure value is 7 - 10 bar (180 - 250 r/min). The value will drop slightly with usage of engine, but lowest value cannot be below 9 bar and pressure difference between each cylinder should not be above 3 bar.

If engine cylinder pressure is lower than standard value, it indicates that cylinder pressure is insufficient. Add a small amount of engine oil to cylinder through spark plug hole and perform measurement again.


If pressure increases after adding oil, piston ring or cylinder bore may be worn or damaged.

If pressure remains low, the valve may be stuck or damaged, or there may be air leakage in cylinder head gasket.

06



و در ایران



و در ایران

(i) Install the spark plug.

Caution:

- Be sure to check spark plugs, and apply a proper amount of lubricant to spark plug mounting threads before installing spark plugs. During installation, do not put spark plugs directly through mounting holes, as high dropping may cause the side electrode to deform, thus reducing the gap. Spark jump may affect the engine operation. Mounting torque: $20 \pm 3 \text{ N}\cdot\text{m}$.

(j) Connect all injector connectors.

(k) Install the ignition coils ([See page 20-7](#)).

7. Test cylinder head gasket for leakage.

Cylinder head gasket leakage may be present between adjacent cylinder and water jacket or from an oil passage to the external of engine.

- Possible trouble symptoms caused by cylinder head gasket leakage between adjacent cylinders are as follows:

Engine power loss.

Engine stall.

Low fuel economy.

- Possible trouble symptoms caused by cylinder head gasket leakage between cylinder and adjacent water jacket are as follows:

Engine overheats.

Coolant loss.

Excessive steam (white smoke) emitted from exhaust system.

Coolant foaming.

06

دیجیتال خودرو سامانه

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ON-VEHICLE SERVICE

Accessory Pulley

Description



06

EM0004001

| | |
|--------------------------|---------------------------|
| 1 - Alternator Assembly | 2 - Idler Pulley Assembly |
| 3 - Tensioner Assembly | 4 - Compressor Assembly |
| 5 - Accessory Drive Belt | 6 - Water Pump Pulley |
| 7 - Crankshaft Pulley | |

Removal

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover.
4. Remove the accessory drive belt.
 - (a) Insert tip of ratchet rod into tensioner pin hole (arrow) and pull it downward in direction of arrow as shown in illustration, then remove accessory drive belt assembly (1).

Caution:


- Prevent hand from contacting belt tensioner when raising it upward.



EM0005002

Inspection

1. Visually check accessory drive belt for excessive wear and cords for wear, etc. If any of these defects is found, replace accessory drive belt.



06

Hint:

- If accessory drive belt has chunks missing from ribs, it should be replaced.
- After installing accessory drive belt, check that it fits properly in the ribbed grooves. Check that belt has not slipped out of grooves on bottom of the crankshaft pulley by hand.

Installation

Warning/Caution/Hint

Caution:

- Before installation, remove the dirt from accessory drive belt.
- Rotate crankshaft after installation, make sure that accessory drive belt is installed in place and does not contact with other separate parts.

1. Installation is in the reverse order of removal.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Idler Pulley Assembly

Removal

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover.
4. Remove the accessory drive belt (See page 06-19).
5. Remove the idler pulley assembly.
 - (a) Remove fixing bolt (arrow) from idler pulley assembly.

Tightening torque

40 + 5 N·m



- (b) Remove the idler gear assembly.

Inspection

1. Rotate idler pulley by hands and check if rotation is smooth and if abnormal noise occurs.
2. Wiggle idler pulley in axial and radial directions to check bearing for looseness.
3. Check if there is damage on idler pulley assembly operating surface.

Installation

Warning/Caution/Hint

Caution:

- After installation, turn crankshaft to run accessory drive belt by several turns, and check if crankshaft turns smoothly and belt runs well. If it cannot turn smoothly, reinstall accessory drive belt.
- Make sure to correctly install accessory drive belt, and it does not interfere with other components.

1. Installation is in the reverse order of removal.

Tensioner Assembly

Removal

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover.
4. Remove the accessory drive belt (See page 06-19).
5. Remove the tensioner assembly.

(a) Remove the tensioner assembly fixing bolt (arrow).

Tightening torque

40 + 5 N·m



(b) Remove the tensioner assembly.

Inspection

1. Rotate tensioner pulley assembly by hands and check if rotation is smooth and if abnormal noise occurs.
2. Wiggle tensioner pulley assembly in axial and radial directions to check for looseness.
3. Check if there is damage on tensioner pulley operating surface.

Installation

Warning/Caution/Hint

Caution:

- After installation, turn crankshaft to run accessory drive belt by several turns, and check if crankshaft turns smoothly and belt runs well. If it cannot turn smoothly, reinstall accessory drive belt.
- Make sure to correctly install accessory drive belt, and it does not interfere with other components.

1. Installation is in the reverse order of removal.

Cylinder Head Cover

Removal



Warning/Caution/Hint

Caution:

- Blow dirt and debris away from surface of cylinder head cover with compressed air.
- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

- Turn off all electrical equipment and ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Remove the engine trim cover.
- Remove the ignition coils (See page 20-7).
- Drain the coolant.
- Remove the turbocharger outlet pipe set.
- Remove the discharge steel pipe.
- Remove the cylinder head cover.
 - Disconnect joint (arrow) between crankshaft ventilation hose and cylinder head cover.


06



- Move away the two-channel pipe clamp (arrow) from cylinder head cover.




(d) Remove 15 cylinder head cover fixing bolts in order shown in illustration.



(e) Remove the cylinder head cover assembly.
(f) Remove the fuel filler cap (1) and cylinder head cover gasket (2) from cylinder head cover assembly.

06



Installation

Warning/Caution/Hint

Caution:

- Remove oil dirt and sealant on cylinder head cover and cylinder head before installation.
- Check if gasket is damaged or loses elasticity. If so, replace gasket.

1. Install the cylinder head cover assembly.

(a) As shown in figure, apply sealant to "T" position between timing chain cover and cylinder block.

Seal gum

Loctite 5900H

Hint:


- Note that the sealant surface should not be too thick, to prevent excess sealant into the engine when the valve chamber cover is pressed.
- Install the cylinder head cover assembly and wait for 15 minutes to apply seal gum.

Seal gum diameter

2.5 - 5 mm

(b) Install cylinder head cover and manually install bolt by 1 to 2 threads.


(c) Tighten 15 cylinder head cover fixing bolts in order shown in illustration.



Tightening torque

1st step: 3 + 2 N·m

2nd step: 10.5 - 12.5 N·m



2. Other installation procedures are in the reverse order of removal.

Crankshaft Front Oil Seal

Removal

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover.
4. Remove the accessory drive belt (See page 06-19).
5. Remove the crankshaft front oil seal assembly.

(a) Remove 1 fixing bolt (arrow) from crankshaft pulley.

Tightening torque

1st step: $100 \pm 10 \text{ N}\cdot\text{m}$

2nd step: $120^\circ \pm 10^\circ$

Hint:


- Use a rigid iron rod with proper right-angle bending, and insert the bent part into clearance on lower part of alternator bracket, use another right-angle iron rod as a fulcrum while inserting it into the crankcase pulley groove to lock crankshaft pulley and remove bolts at the same time.

(b) Remove the crankshaft pulley.

(c) Using a flat tip screwdriver wrapped with gum tape, pry out the crankshaft front oil seal (arrow).

Hint:

Be careful not to scratch junction surface, when removing crankshaft front oil seal.



06



Installation

Warning/Caution/Hint

Caution:

- Apply a coat of engine oil to the crankshaft front oil seal guide tool before installing a new oil seal.
- Remove dirt on junction surface and apply a coat of engine oil to junction surface and oil seal lip (except the oil seal with surface applied wax) before assembly.
- Be sure to prevent the lip of crankshaft front oil seal from being scratched during installation. If it is damaged, replace it immediately.


1. Install the crankshaft front oil seal.

(a) Install new oil seal (2) to crankshaft (3), then install new oil seal evenly and fully into oil seal retainer with a crankshaft front oil seal installer (1).

Caution:

- Oil seal surface should be lower than timing chain cover oil seal hole end surface by 0 ~ 1 mm.
- Ensure that oil seal lip has no damage during assembly.
- Never allow tilting it by more than 5°, oil seal external rubber breakage or flanges during oil seal press fitting.

(b) Other installation procedures are in the reverse order of removal.



EM0015002



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


Flywheel (CVT)

Removal

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.
- 1. Turn off all electrical equipment and the ENGINE START STOP switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the automatically transmission assembly.
- 4. Remove the flywheel assembly.
 - (a) Install flywheel holding tool (1) to lock flywheel.



EM0016002

(b) Remove 6 fixing bolts (arrow) from flywheel assembly, and then remove flywheel assembly.



Non-reusable Part

Tightening torque

1st step: $35 \pm 5 \text{ N}\cdot\text{m}$;

2nd step: $45^\circ \pm 5^\circ$



Warning:

- Pay attention to personal safety during operation.
- DO NOT remove all fixing bolts without any auxiliary measures.

Caution:

- Flywheel fixing bolts must be disposed after removal. Never reuse them.

Inspection

1. Check if crankshaft position signal gear is distorted or deformed. If damaged, replace flywheel. Clean signal gear before installation.
2. Check if starter driven gear ring is worn. If excessively worn, replace flywheel.

Installation

Warning/Caution/Hint

Warning:

- Never reuse flywheel fixing bolts after removal.

Caution:


- Six bolt holes on the flywheel have asymmetrical positions. During installation, pay attention to that flywheel fixing bolts are aligned with crankshaft bolt holes.

- It is necessary to reset before flywheel installation.


Reset steps:

- Using a flat tip screwdriver (1), insert it into flange groove, rotate it clockwise until both the two locking levers are pushed into flange groove (2).

Meanwhile, ensure that the two locking levers can be pushed downward and locked.



- The condition of reset flywheel is as shown in illustration.



- Install the flywheel.

Caution:

- Lightly push flywheel after alignment during assembly. Do not tap flywheel with a hammer.
- Replace flywheel fixing bolts with new ones.

- When installing flywheel assembly, pretighten fixing bolts (arrow), and install flywheel holding tool (1), then tighten each flywheel bolt diagonally in order.

Tightening torque

1st step: 35 ± 5 N·m;

2nd step: $45^\circ \pm 5^\circ$




Flywheel (6MT)

Removal

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.
- 1. Turn off all electrical equipment and the ENGINE START STOP switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the transmission assembly.
- 4. Remove the flywheel assembly.
 - (a) Install flywheel holding tool (1) to lock flywheel.



06

(b) Remove 6 fixing bolts (arrow) from flywheel assembly, and then remove flywheel assembly.

Tightening torque

1st step: $35 \pm 5 \text{ N}\cdot\text{m}$;

2nd step: $30^\circ \pm 5^\circ$



Non-reusable Part

Warning:

- Pay attention to personal safety during operation.
- DO NOT remove all fixing bolts without any auxiliary measures.

Caution:

- Flywheel fixing bolts must be disposed after removal. Never reuse them.

Inspection

1. Check if crankshaft position signal gear is distorted or deformed. If damaged, replace flywheel. Clean signal gear before installation.
2. Check if starter driven gear is worn. If excessively worn, replace flywheel.
3. Check whether there are grooves, cracks, color changes and other phenomena on the surface of flywheel. If damaged, replace flywheel.

Installation

Warning/Caution/Hint

Warning:

- Never reuse flywheel fixing bolts after removal.

Caution:

- Six bolt holes on the flywheel have asymmetrical positions. During installation, pay attention to that flywheel fixing bolts are aligned with crankshaft bolt holes.


1. Install the flywheel.

Caution:

- Lightly push flywheel after alignment during assembly. Do not tap flywheel with a hammer.

- It is necessary to replace flywheel fixing bolts with new ones.

- When installing flywheel assembly, pretighten fixing bolts (arrow), and install flywheel holding tool (1), then tighten each flywheel bolt diagonally in order.



06

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Crankshaft Rear Oil Seal

Removal

Warning/Caution/Hint


Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the transmission assembly.
4. Remove the flywheel assembly.
5. Remove the crankshaft rear oil seal.
 - (a) Using a screwdriver with the tip wrapped with screwdriver tape, remove crankshaft rear oil seal (arrow).

Caution:

- Be careful not to scratch cylinder block when removing oil seal.



EM0020002

06

Installation

Warning/Caution/Hint

Caution:

- Be sure to clean dirt around oil seal retainer and on inside wall before installation.
- Check oil seal for damage before installation. If there is any damage, replace it.
- Be sure to prevent the lip of crankshaft rear oil seal from being scratched during installation.
- Be careful not to damage oil seal retainer during installation.


1. Install the crankshaft rear oil seal.

- (a) Apply engine lubricant to crankshaft oil seal outer retainer and lip.

Hint:

Oil seal with surface applied with wax cannot be applied.

- (b) Install guide tool (1) to crankshaft.



EM0021002


- (c) Install new oil seal (2) to crankshaft rear oil seal guide tool, then install new oil seal evenly and fully into oil seal retainer with a crankshaft rear oil seal installer (3).

Caution:

- Oil seal surface should be lower than cylinder block mounting hole rear end surface by 0 ~ 1 mm.
- Ensure that oil seal lip has no damage during assembly.
- Never allow tilting it by more than 5°, oil seal external rubber breakage or flanges during oil seal press fitting.

Engine Timing Chain

Description



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

EM0022001

| | |
|-----------------------------|-----------------------------|
| 1 - Intake Phaser Assembly | 2 - Exhaust Phaser Assembly |
| 3 - Upper Fixing Guide Rail | 4 - Engine Timing Chain |
| 5 - Fixing Guide Rail | 6 - Crankshaft Assembly |
| 7 - Oil Pump Drive Chain | 8 - Movable Guide Rail |
| 9 - Tensioner Assembly | 10 - Timing Chain Cover |

Removal

Warning/Caution/Hint

Caution:

- Blow dirt and debris away from surface of cylinder head cover with compressed air.
- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

- Turn off all electrical equipment and the ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Remove the engine trim cover.
- Remove the ignition coils ([See page 20-7](#)).
- Remove the cylinder head cover ([See page 06-23](#)).
- Remove the accessory drive belt ([See page 06-19](#)).
- Remove the idler gear assembly ([See page 06-21](#)).
- Remove the tensioner assembly ([See page 07-27](#)).
- Remove the crankshaft pulley ([See page 06-25](#)).

10. Remove the water pump pulley.
11. Use an engine equalizer to hang engine assembly.

Hint:

Use an engine equalizer to hang lifting eye of engine when supporting the engine oil pan with jack. Avoid engine tilting to right side for easy removal of engine right mounting cushion assembly.


12. Remove the engine right mounting cushion assembly.

13. Install the timing tool.

- (a) Remove starter assembly.
- (b) Remove crankshaft timing tool installation hole fixing bolt (arrow) from engine block.

Tightening torque

40 + 5 N·m




06


- (c) Install crankshaft timing positioning pin to cylinder block through thread hole on intake side of cylinder block, and insert front end of positioning pin into positioning hole of crankshaft balancer (each cylinder piston should be in the same plane).

Caution:

- It takes patience to perform this operation and pay more attention to avoid damage to crankshaft.



- (d) Place camshaft timing positioning special tool on the back of cylinder head upper plane, rotate intake and exhaust camshafts separately in order to clamp the special tool into slots on rear end of both camshafts.




14. Remove the engine timing chain cover.

- (a) Remove 4 fixing bolts (1) between engine timing chain cover and oil pan assembly.

Tightening torque

20 + 5 N·m



(b) Remove fixing bolts (arrow) from timing chain cover.

Tightening torque

M8x45 (6 bolts) 20 + 5 N·m

M8x40-10.9 (4 bolts) 30 + 5 N·m

M10x45 (5 bolts) 40 + 5 N·m

M10x80 (1 bolt) 40 + 5 N·m

(c) Remove the timing chain cover.

Caution:

- Remove oil and seal gum with a special tool.


- Carefully observe timing chain cover for cracks or oil leakage. If exists, replace timing chain assembly.

15. Remove the timing chain.

(a) Push movable guide rail to keep tensioner plunger at maximum compression position, and insert plunger snap pin (1) to stick tensioner plunger.

Caution:

- Since tensioner plunger has large elastic force, never remove tensioner assembly fixing bolts when plunger snap pin is not installed, to prevent plunger from popping out suddenly and cause accidental injuries.



(b) Remove 2 fixing bolts (arrow) from tensioner assembly, and then remove tensioner assembly.


Tightening torque

9 + 3 N·m

(c) Remove movable guide rail fixing bolt (1), and remove movable guide rail assembly.

Tightening torque

12 + 2 N·m



(d) Remove 2 fixing guide rail fixing bolts (2), and then remove fixing guide rail assembly.


Tightening torque

9 + 3 N·m

(e) Remove 2 upper guide rail fixing bolts (arrow), and then remove upper guide rail assembly.

Tightening torque

9 + 3 N·m



(f) Remove the engine timing chain assembly.

Caution:

- Mark front side and back side of chain with a marking pen after removing chain, so as to keep same direction during installation. Long time movement in one direction of timing chain will cause wear difference between two sides of chain, so it is necessary to remove and install the chain in same direction.

06

Inspection


1. Check the timing chain.

- Carefully check if timing chain is seriously worn or cracked. If exists, replace timing chain assembly.
- Use a force of 147 N to pull the chain. Take 15 links from chain for measurement with vernier caliper. Max. elongation ratio: 120.84 mm.

Hint:


Take 3 positions for measurement. If the average value is larger than max. elongation ratio, replace timing chain assembly.

If it is not as specified, replace timing chain cover assembly.




2. Check tensioner

- Press and release piston manually to confirm that spring should flex freely without any stick condition. If so, replace tensioner assembly.
- Block holding pin hole (two) (arrow) by hand and blow air to piston hole. There should be no air leakage. If exists, replace tensioner assembly.



(c) Remove oil pan, piston, spring. Block holding pin (arrow) hole by hand. Blow air to housing with mouth (1), there should be no air flowing out while there should be air flowing out during suction. Otherwise, replace hydraulic tensioner.



3. Check movable guide rail

(a) Measure depth of movable guide rail with a vernier caliper.
Hint:
 If wear limit is beyond 2 mm, replace movable guide rail assembly.

06

Installation

Warning/Caution/Hint

Caution:

- Apply seal gum to edge of engine timing chain cover, and apply seal gum to inside of timing chain cover mounting bolt hole.

Seal gum

Loctite 5900H


1. Install the timing chain.

(a) Use a proper wrench to hold intake camshaft and loosen fixing bolt from intake phaser assembly.

Tightening torque

105 + 5 N·m

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



(b) Loosening method for exhaust phaser fixing bolt is the same as that of intake phaser fixing bolt.

Hint:

It is only necessary to loosen intake and exhaust phaser fixing bolts without removing phaser.

(c) Apply seal gum to 2 upper guide rail by 2-3 teeth and screw them onto 1st bearing cap.

Hint:

Do not fully tighten bolts.

Seal gum

Loctite 5900H

(d) Install the timing chain assembly.


Caution:

- Ensure to install according to marks on timing chain correctly.
- Ensure to hang timing chain to intake and exhaust phasers and crankshaft sprocket. Make sure that timing chain and upper guide rail are in level.

(e) Install fixing guide rail and tighten 2 bolts (2).

Tightening torque

9 + 3 N·m



06

(f) Install movable guide rail and tighten fixing bolt (1).

Tightening torque

12 + 2 N·m

Caution:


- Check if movable guide rail can rotate smoothly around the bolt after tightening movable guide rail fixing bolt, if not, remove and check bolt and movable guide rail assembly.

(g) Install the tensioner assembly.

(1) Install tensioner assembly, and tighten 2 fixing bolts (arrow).

Tightening torque

9 + 3 N·m



EM0031002

(2) Push movable guide rail to chock against tensioner plunger, then remove hold-down pin (1).


Caution:

- Make sure to keep tensioner assembly clean during installation. Otherwise, poor lubrication will cause abnormal engine noise and damage to timing chain and guide rail.
- Check if chain is in tension status.
- Check if chain is pressed in the fixing guide rail and movable guide rail, and engages normally with crankshaft sprocket, intake and exhaust phasers.
- Check that contact areas between chain and upper guide rail are in level without any looseness.

(h) Tighten 2 upper guide rail fixing bolts (arrow).

Tightening torque

9 + 3 N·m



EM0032002

(i) Tighten intake and exhaust phaser assembly fixing bolts.

Tightening torque

105 + 5 N·m

Warning:

- Tighten exhaust phaser fixing bolt first, and then tighten intake phaser fixing bolt. Failure to tighten in order may cause "tooth missing" phenomenon in timing chain.

(j) Remove crankshaft timing tool and camshaft timing tool, then rotate crankshaft clockwise 2 turns at least, to check if timing system can operate normally.

Caution:


- Never rotate crankshaft counterclockwise.

2. Install the timing chain cover.

(a) Apply seal gum to edge of engine timing chain cover, and apply seal gum to inside of timing chain cover mounting bolt hole.

Seal gum

Loctite 5900H



(b) Install timing chain cover and tighten timing chain cover fixing bolts (arrow).


Tightening torque

M8x45 (6 bolts) 20 + 5 N·m

M8x40-10.9 (4 bolts) 30 + 5 N·m

M10x45 (5 bolts) 40 + 5 N·m

M10x80 (1 bolt) 40 + 5 N·m



(c) Install 4 fixing bolts (1) between timing chain cover and oil pan.

Tightening torque

20 + 5 N·m

Caution:

- Before installing timing chain cover, it is necessary to apply seal gum on oil pan. Note that seal gum should be applied to inner side of mounting bolt hole.

Seal gum

Loctite 5900H


Seal gum diameter

1.5 - 3mm

3. Other installation procedures are in the reverse order of removal.

Camshaft & Rocker Arm

Description



EM0034001

| | |
|---|--|
| 1 - 1st Bearing Cap | 2 - 1st Bearing Cap Fixing Bolt |
| 3 - Exhaust Camshaft Bearing Cap | 4 - Exhaust Camshaft Bearing Cap Fixing Bolt |
| 5 - Intake Camshaft Bearing Cap Fixing Bolt | 6 - Intake Camshaft Bearing Cap |
| 7 - Rocker Arm | 8 - Hydraulic Lifter |
| 9 - Intake Camshaft Assembly | 10 - Intake Phaser Assembly |
| 11 - Intake Phaser Fixing Bolt | 12 - Exhaust Phaser Fixing Bolt |
| 13 - Exhaust Phaser Assembly | 14 - Exhaust Camshaft Assembly |

Removal

Warning/Caution/Hint

Caution:

- Blow dirt and debris away from surface of cylinder head cover with compressed air.
- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and ENGINE START STOP switch.

2. Disconnect the negative battery cable.

3. Remove the engine trim cover.

4. Remove the ignition coils (See page 20-7).

5. Remove the cylinder head cover assembly (See page 06-23).

6. Remove the accessory drive belt (See page 06-19).

7. Remove the tensioner assembly (See page 07-27).

06

8. Remove the idler gear assembly (See page 06-21).

9. Remove the water pump pulley.

10. Remove the timing chain cover.


11. Remove the timing chain assembly.

12. Remove intake and exhaust phaser assemblies.

(a) Use a proper wrench to hold intake camshaft, and remove fixing bolt from intake phaser assembly in direction of arrow.

Tightening torque

105 + 5 N·m



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

(b) Removal method for exhaust phaser assembly is the same as that of intake phaser assembly.

13. Remove intake and exhaust camshafts.

(a) Remove intake and exhaust camshaft bearing cap fixing bolts in order shown in illustration.


Hint:

During removal, loosen fixing bolts in order shown in illustration first, and then remove bolts thoroughly in order.

Tightening torque

1st step: 9.5 ± 1.5 N·m

2nd step: 9.5 ± 1.5 N·m




(b) Remove intake and exhaust camshaft bearing caps.


(c) Remove intake and exhaust camshaft assemblies.

14. Remove rocker arm and hydraulic lifter.

(a) Remove rocker arm and hydraulic lifter set (1) in direction of arrow.



(b) Remove elastic clip (1) and separate rocker arm and hydraulic lifter in direction of arrow as shown in illustration.



06

Inspection

1. Check camshaft

(a) Check the appearance.

- Check if there are scratches on camshaft surface. If there are scratches, replace camshaft.
- Check if there are leaking holes and cracks on camshaft bearing caps. If there are leaking holes or cracks, replace camshaft.

(b) Check the camshaft journal diameter.

Measure camshaft journal diameter with a micrometer.

| Measurement Item | Specification (mm) |
|---|--------------------|
| 1st journal diameter (same for intake and exhaust sides) (mm) | 33.934 - 33.95 |
| 2nd - 5th journals (same for intake and exhaust sides) | 23.947 - 23.96 |


If camshaft journal diameter is not within specified range, replace intake/exhaust camshaft assembly.

(c) Check the cam height.


Measure highest point of cam with a micrometer.

| Measurement Item | Specification (mm) |
|-----------------------------------|------------------------|
| Cam flange height (highest point) | Intake: 37.07 - 37.31 |
| | Exhaust: 36.94 - 37.18 |

If cam height is not within specified range, replace intake/exhaust camshaft assembly.



EM0038002




EM0039002

(d) Check the camshaft axial clearance.

- Reinstall intake and exhaust camshaft assemblies.
- Keep dial indicator plunger contact with front end of camshaft, and reset dial indicator to zero.
- Push camshaft forward and backward lightly (do not rotate camshaft), then read value on dial indicator.

| Measurement Item | Specification (mm) |
|----------------------------------|--------------------|
| Intake Camshaft Axial Clearance | 0.15 - 0.20 |
| Exhaust Camshaft Axial Clearance | 0.15 - 0.20 |



EM0040002

If camshaft axial clearance is not within specified range, replace intake/exhaust camshaft assembly.

06 2. Check the hydraulic lifter.

- (a) Check if end surface and cylindrical operating surface of hydraulic lifter are normal.
- (b) Check if hydraulic lifter slides smoothly in cylinder head guide hole.
- (c) Check each hydraulic lifter for weakness. If exists, remove and soak it for 24 hours, then press the hydraulic lifter plunger. If the plunger can be pressed significantly, it indicates that the lifter "becomes soft". Replace hydraulic lifter.

Installation

Warning/Caution/Hint

Caution:

- Adjust timing and adjust 4 pistons to same level before installing camshaft.
- When installing intake and exhaust phaser assemblies, tighten bolts on exhaust side first, and then tighten bolts on intake side.

1. Install the camshaft.

- (a) Clean intake and exhaust camshafts and camshaft bearing caps.
- (b) Apply engine oil to camshaft cam surface. Apply a proper amount of engine oil to camshaft bearing hole.
- (c) Install intake, exhaust camshaft assemblies and intake and exhaust camshaft bearing caps.

Caution:


- Install them according to marks on bearing cap.

I

Intake Camshaft Bearing Cap

E

Exhaust Camshaft Bearing Cap




EM0041002

- (d) Install intake and exhaust camshaft fixing bolts by hand.

(e) Tighten intake and exhaust camshaft bearing cap fixing bolts in order shown in illustration.

Tightening torque

1st step: $9.5 \pm 1.5 \text{ N}\cdot\text{m}$
2nd step: $9.5 \pm 1.5 \text{ N}\cdot\text{m}$



2. Other installation procedures are in the reverse order of removal.

06

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Cylinder Head

Description

06




★ : Non-reusable Part

EM0043001

| | |
|-------------------------------|--------------------------------------|
| 1 - Valve Cotter | 2 - Valve Spring Upper Seat |
| 3 - Valve Spring | 4 - Valve Oil Seal |
| 5 - Valve Spring Lower Seat | 6 - Valve Guide |
| 7 - Cylinder Head Fixing Bolt | 8 - Cylinder Head Fixing Bolt Washer |
| 9 - Cylinder Head | 10 - Stud |
| 11 - Cylinder Head Gasket | 12 - Intake Valve |
| 13 - Exhaust Valve | ★ - Non-reusable Parts |


Removal

1. Release the fuel system pressure.
2. Turn off all electrical equipment and ENGINE START STOP switch.
3. Disconnect the negative battery cable.
4. Drain the engine oil.
5. Drain the coolant.
6. Disconnect the wire harness connector.
 - (a) Disconnect the intake variable timing control valve connector (arrow).



06


- (b) Disconnect the exhaust variable timing control valve connector (arrow).




- (c) Remove the engine wire harness ground wire fixing bolt (arrow).

Tightening torque


$7 \pm 1 \text{ N}\cdot\text{m}$



- (d) Disconnect the intake camshaft position sensor connector (arrow).



(e) Disconnect the exhaust camshaft position sensor connector (arrow).



06

7. Remove the air filter assembly.
8. Remove the battery assembly.
9. Remove the battery tray.
10. Remove the ignition coils ([See page 20-7](#)).
11. Remove the spark plugs.
12. Remove the fuel rail injector assembly.
13. Remove the engine discharge steel pipe assembly.
14. Remove the intake manifold assembly.
15. Remove the thermostat seat.
16. Remove the turbocharger assembly.
17. Remove the accessory drive belt ([See page 06-19](#)).
18. Remove the idler gear assembly ([See page 06-21](#)).
19. Remove the tensioner assembly ([See page 07-27](#)).
20. Remove the water pump pulley.
21. Remove the cylinder head cover assembly ([See page 06-23](#)).
22. Use an engine equalizer to hang engine assembly.

Hint:

Use an engine equalizer to hang engine assembly. Meanwhile, support engine oil pan with a jack. Avoid engine tilting to right side.

23. Remove the engine timing chain.
24. Remove camshaft and rocker arm.
25. Remove the engine equalizer.
26. Remove the cylinder head assembly.

(a) Remove 10 cylinder head assembly fixing bolts in order shown in illustration.

Tightening torque


1st step: $40 \pm 5 \text{ N}\cdot\text{m}$

2nd step: $90^\circ \pm 5^\circ$

3rd step: $90^\circ \pm 5^\circ$

Caution:

- When engine is in high temperature, removal and installation may cause deformation to cylinder head, so perform removal and installation at normal temperature.
- Remove the cylinder head cover fixing bolts in order. Otherwise, it may cause deformation to cylinder head.
- Mark disposed signs on removed bolt and washer. Never reuse them.



(b) Carefully take off the cylinder head and cylinder head gasket.

Caution:

- DO NOT reuse the removed cylinder head gasket, and it is necessary to replace it with new one. Be careful not to lose cylinder head mounting dowel pin during removal.



EM0050002


Disassembly

- Disassemble the cylinder head.

- Remove intake variable timing control valve fixing bolt (arrow), and remove intake variable timing control valve assembly.

Tightening torque

$6 + 2 \text{ N}\cdot\text{m}$




EM0051002

- Remove exhaust variable timing control valve fixing bolt (arrow), and remove exhaust variable timing control valve assembly.

Tightening torque

$6 + 2 \text{ N}\cdot\text{m}$




EM0052002

- Remove intake camshaft position sensor fixing bolt (arrow), and remove sensor assembly.

Tightening torque

$8 + 3 \text{ N}\cdot\text{m}$




EM0053002

(d) Remove exhaust camshaft position sensor fixing bolt (arrow), and remove sensor assembly.

Tightening torque


8 + 3 N·m




(e) Remove 2 fixing bolts (arrow) from rear lifting eyes.

Tightening torque

20 + 5 N·m



(f) Using a valve spring compressor (1), compress valve spring. to a position so that valve cotter can be removed.




(g) Using a magnetic rod (2), remove valve cotter.

Caution:

- Due to the valve cotter is small, please operate carefully when operating it, so as to avoid loss.




(h) Remove valve spring upper seat (1), valve spring (2) and intake and exhaust valve (3) from cylinder head.



EM0056002

(i) Using a valve oil seal remover (1), remove the valve oil seal (2).



EM0057002

(j) Using a magnetic rod, remove valve spring lower seat.

شرکت دیجیتال خودرو سامانه (مسنوبیت محدود)

Inspection

1. Check the cylinder head assembly.

(a) Check the appearance.


- Check if there are scratches on camshaft bearing journals.
- Remove carbon deposits inside valve guides with cleaner.
- Make sure valve stem can move and rotate freely in its mounting hole.

(b) Check the cylinder head flatness.

Using a precision straightedge and feeler gauge, check cylinder head flatness.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|------------------------|--------------------|------------------|
| Cylinder Head Flatness | 0.04 | 0.04 |

If cylinder head flatness is not within specified range, replace cylinder head assembly.




EM0059002

(c) Check the cylinder head height.
Using a precision straightedge, measure cylinder head height.

| Measurement Item | Specification (mm) |
|----------------------|--------------------|
| Cylinder Head Height | 141.05 |

If cylinder head height is not within specified range, replace cylinder head assembly.




EM0060002

06 2. Check the valve spring.

Using a vernier caliper, measure free length of valve spring and length of valve spring under the pre-pressure of 229 - 251 N.

| Measurement Item | Specification (mm) |
|---|--------------------|
| Valve Spring Free Length | 47.8 |
| Valve Spring Length Under Pre-pressure of 229 - 251 N | 41 |

If valve spring length is not within specified range, replace valve spring.




EM0061002

3. Check the valve.

(a) Clean the valve.

- Using a scraper, remove carbon deposited on valve head.
- Using a wire brush, clean the valve thoroughly.




EM0062002

(b) Check the valve height.
Using a micrometer, measure the valve height.

| Measurement Item | Specification (mm) |
|----------------------|--------------------|
| Intake Valve Height | 107.75 - 108.25 |
| Exhaust Valve Height | 106.07 - 106.57 |

If valve height is less than specified value, replace valve.




EM0063002

(c) Check the valve head.

- Measure margin thickness (a) of valve head.
- Measure width (b) of valve face.


| Measurement Item | Specification (mm) |
|-------------------------------------|--------------------|
| Intake Valve Head Margin Thickness | 0.68 - 1.1 |
| Exhaust Valve Head Margin Thickness | 0.48 - 0.9 |
| Intake Valve Face Width | 1.154 |
| Exhaust Valve Face Width | 1.307 |



If valve head margin thickness and face width are not within specified range, replace valve.

(d) Check the valve stem diameter.
Using a micrometer, measure the valve stem diameter.

| Measurement Item | Specification (mm) |
|-----------------------------|--------------------|
| Intake Valve Stem Diameter | 5.98 ± 0.008 |
| Exhaust Valve Stem Diameter | 5.96 ± 0.008 |




If valve stem diameter is not within specified range, check clearance between valve stem and valve guide.

(e) Check clearance between valve stem and valve guide.
Using a caliper gauge, measure inner diameter of valve guide.

| Measurement Item | Specification (mm) |
|----------------------------|--------------------|
| Valve Guide Inner Diameter | 6.0 - 6.015 |

- Clearance between valve stem and valve guide = Valve guide inner diameter - Valve stem diameter



| Measurement Item | Specification (mm) |
|---|--------------------|
| Clearance Between Intake Valve and Valve Guide | 0.012 - 0.043 |
| Clearance Between Exhaust Valve and Valve Guide | 0.032 - 0.063 |

If clearance between valve and valve guide is not within specified range, replace valve or valve guide.

Assembly

Warning/Caution/Hint

Caution:

- Soak valve oil seal in oil for several minutes before installing valve oil seal.
- Check if valve spring lower seat is installed properly before installing valve spring.

Hint:


Clean all components to be assembled thoroughly before assembly.

1. Assemble the cylinder head.

(a) Install valve (1) into cylinder head.

Hint:

- Distinguish intake valves and exhaust valves during installation. Diameter of intake valve head is larger than that of exhaust valve head.
- Apply engine oil to valve stem end, when assembling valve.



06

(b) Install new valve spring lower seat (2) if necessary.

Caution:

- Bottom plane of valve spring lower seat should contact with cylinder head with flange facing upward.

(c) Install the valve oil seal.

Hint:

Apply engine oil to valve oil seal lip, when assembling valve oil seal.

(1) Install valve oil seal guide sleeve (3) to valve.


(2) Install valve oil seal (4) to valve oil seal guide sleeve.

(3) Press valve oil seal installer (5) lightly by hand to install valve oil seal (4) in place.


Caution:

- Check valve spring lower seat and valve oil seal for wrong installation, neglected installation and over installation.

(d) Install valve cotter (1) to valve cotter installer (2).



(e) Install valve spring (1) and valve spring upper seat (2). Using a valve spring compressor, compress valve spring to a position so that valve cotter can be installed. Using a valve cotter installer, install valve cotter (3) in place.



(f) Tap tip of valve stem lightly with a rubber hammer to make sure valve cotter is installed in place after assembly.

06

Installation


Warning/Caution/Hint

Caution:

- DO NOT damage or lose dowel pin on cylinder block.
- Remove residual seal gum and oil on cylinder head and cylinder block.
- Replace the cylinder head gasket.
- Check that cylinder head gasket is neat and clean without any chips and scratches, and the side stamped with part number faces upward.
- Install cylinder head gasket to flat surface of cylinder block with a dowel pin.
- Clean junction surface between cylinder head and combustion chamber, and remove any accumulated oil at bottom of cylinder block thread hole.
- During installation, piston should not be located at the top dead center, in order to prevent it from being impacted by opening valve, when installing the camshaft.
- Replace cylinder head fixing bolt and washer, and make scraping marks on removed bolt.
- Install the cylinder head bolt washer with chamfering surface facing upward and flat side facing cylinder head.

1. Tighten cylinder head fixing bolts in order from (1) to (10) shown in illustration:

(a) Tighten bolts in place by hands.



(b) Tighten cylinder head fixing bolts according to following procedures:

- (1) 1st step: Tighten bolts to $40 \pm 5 \text{ N}\cdot\text{m}$ in order from (1) to (10) shown in illustration.
- (2) 2nd step: Rotate bolts clockwise by $90 \pm 5^\circ$ in tightening order.
- (3) 3rd step: Rotate bolts clockwise by $90 \pm 5^\circ$ in tightening order again.

Caution:

- Check cylinder head fixing bolts before installation. If damaged, replace them immediately.


- Be sure to tighten cylinder head bolts strictly according to operating procedures above, to achieve the technology standard for vehicle usage.

2. Other installation procedures are in the reverse order of removal.

Engine Mounting Assembly

(For CVT models)


06



EM0262001

| | |
|-------------------------------------|------------------------------|
| 1 - Left Mounting Cushion Assembly | 2 - Left Mounting Bracket |
| 3 - Right Mounting Cushion Assembly | 4 - Rear Mounting Upper Body |
| 5 - Rear Mounting Lower Body | |

(For MT models)



EM0301001

1 - Left Mounting Cushion Assembly

2 - Left Mounting Bracket

3 - Right Mounting Cushion Assembly

4 - Rear Mounting Upper Body

5 - Rear Mounting Lower Body

Removal & Installation - Rear Mounting Assembly (For CVT Models)

Warning/Caution/Hint

Caution:


- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Raise the vehicle to a proper position.
4. Remove the rear mounting upper body.
 - (a) Remove coupling bolt (1) between rear mounting upper body and lower body.

Tightening torque

$105 \pm 10 \text{ N}\cdot\text{m}$


06



- (b) Remove 3 coupling connector bolts (arrow) between rear mounting upper body and transmission.

Tightening torque

$80 \pm 5 \text{ N}\cdot\text{m}$




- (c) Remove the rear mounting upper body.

5. Remove the rear mounting lower body.

- (a) Remove coupling bolt (arrow) between rear mounting lower body and sub frame.

Tightening torque

$150 \pm 10 \text{ N}\cdot\text{m}$



- (b) Remove the rear mounting lower body body.

Installation

1. Installation is in the reverse order of removal.


Caution:

- Pre-tighten 2 or 3 threads manually first during assembly of bolts and nuts, then pre-tighten and tighten it to specified torque with a tool.

Removal & Installation - Rear Mounting Assembly (For MT Models)**Warning/Caution/Hint****Caution:**


- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Raise the vehicle to a proper position.
4. Remove the rear mounting upper body.
 - (a) Remove coupling bolt (1) between rear mounting upper body and lower body.

Tightening torque $105 \pm 10 \text{ N}\cdot\text{m}$ 


06

- (b) Remove 3 coupling connector bolts (arrow) between rear mounting upper body between and transmission.

Tightening torque $80 \pm 5 \text{ N}\cdot\text{m}$ 

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

- (c) Remove the rear mounting upper body.
5. Remove the rear mounting lower body.
 - (a) Remove coupling bolt (arrow) between rear mounting lower body and sub frame.

Tightening torque $150 \pm 10 \text{ N}\cdot\text{m}$ 

- (b) Remove the rear mounting lower body.

Installation

1. Installation is in the reverse order of removal.

Caution:

- Pre-tighten 2 or 3 threads manually first during assembly of bolts and nuts, then pre-tighten and tighten it to specified torque with a tool.

Removal & Installation - Left Mounting Assembly (For CVT Models)

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.


1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Use an engine equalizer to hang engine assembly.
4. Remove the air filter assembly.
5. Remove the battery assembly.
6. Remove the battery tray bracket.
7. Remove the left mounting cushion assembly.

06

(a) Remove 2 coupling bolts (arrow) and 1 coupling nut (1) between left mounting cushion assembly and left mounting bracket.

Tightening torque

$80 \pm 5 \text{ N}\cdot\text{m}$




(b) Remove 3 fixing bolts (arrow) between left mounting cushion assembly and left side rail wheel house assembly.

Tightening torque

$60 \pm 5 \text{ N}\cdot\text{m}$

Tightening torque

$80 \pm 5 \text{ N}\cdot\text{m}$




(c) Remove the left mounting cushion assembly.

8. Remove the left mounting bracket.

(a) Remove 3 fixing bolts (arrow) between left mounting bracket and transmission case.

Tightening torque

$80 \pm 5 \text{ N}\cdot\text{m}$



(b) Remove the left mounting bracket.

Installation

1. Installation is in the reverse order of removal.

Caution:

- When installing left side rail wheel house on left mounting cushion assembly, first tighten locating bolts on side rail, then tighten the other bolt on side rail, and finally tighten the bolt on wheel house.
- Pre-tighten 2 or 3 threads manually first during assembly of bolts and nuts, then pre-tighten and tighten it to specified torque with a tool.

06

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Removal & Installation - Left Mounting Assembly (For MT Models)

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.


1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Use an engine equalizer to hang engine assembly.
4. Remove the air filter assembly.
5. Remove the battery assembly.
6. Remove the battery tray bracket.
7. Remove the left mounting cushion assembly.

06

(a) Remove 2 coupling bolts (arrow) and 1 coupling nut (1) between left mounting cushion assembly and left mounting bracket.

Tightening torque


$80 \pm 5 \text{ N}\cdot\text{m}$



(b) Remove 3 coupling bolts (arrow) between left mounting cushion assembly and left side rail wheel house assembly.

Tightening torque

$60 \pm 5 \text{ N}\cdot\text{m}$



(c) Remove the left mounting cushion assembly.

8. Remove the left mounting bracket.

(a) Remove 4 fixing nuts (arrow) between left mounting bracket and transmission.

Tightening torque

$80 \pm 5 \text{ N}\cdot\text{m}$



(b) Remove the left mounting bracket.

Installation

1. Installation is in the reverse order of removal.

Caution:

- When installing left side rail wheel house on left mounting cushion assembly, first tighten locating bolts on side rail, then tighten the other bolt on side rail, and finally tighten the bolt on wheel house.
- Pre-tighten 2 or 3 threads manually first during assembly of bolts and nuts, then pre-tighten and tighten it to specified torque with a tool.

06

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Removal & Installation - Right Mounting Assembly

Warning/Caution/Hint

Caution:


- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover.
4. Drain the coolant.
5. Remove the expansion tank assembly.
6. Use an engine equalizer to hang engine assembly.
7. Remove the engine right mounting cushion assembly.
 - (a) Remove 2 fixing nuts (1) between right mounting cushion assembly and engine.

06

Tightening torque


$80 \pm 5 \text{ N}\cdot\text{m}$



- (b) Remove 3 coupling bolts (arrow) between right mounting cushion assembly and body.

Tightening torque

$60 \pm 5 \text{ N}\cdot\text{m}$



- (c) Remove the engine right mounting cushion assembly.

Installation


1. Installation is in the reverse order of removal.

Caution:

- When installing right side rail wheel house on right mounting cushion assembly, first tighten the other locating bolt on side rail, and finally tighten the bolt on wheel house.
- Pre-tighten 2 or 3 threads manually first during assembly of bolts and nuts, then pre-tighten and tighten them to specified torque with a tool.

Engine Assembly

Description



EM0263001

Removal

Warning/Caution/Hint


Caution:

- Remove engine and transmission as an assembly.
- Install protector to prevent body from being scratched.
- Plug inlet port of intake pipe to prevent foreign matter from entering after removing intake system components. Or the foreign matter will block cylinder intake passage when starting to seriously damage the engine.

1. Remove the engine trim cover.
2. Release the fuel system pressure.
3. Turn off all electrical equipment and the ENGINE START STOP switch.
4. Remove the battery assembly.
5. Remove the battery tray bracket.
6. Remove the air filter assembly.
7. Remove the brake vacuum pump and mounting bracket.

8. Remove the electric water pump and mounting bracket.
9. Remove the turbocharger assembly.
10. Remove precatalytic converter assembly.
11. Drain the engine oil.
12. Drain the transmission oil.
13. Drain the coolant.
14. Recover the refrigerant.
15. Disconnect engine inlet and outlet hoses.
 - (a) Loosen elastic clamps (1) and disconnect connections between engine inlet and outlet hoses and thermostat seat.

06



16. Disconnect connection between shift cable and transmission (for MT models).
 - (a) Remove gear select and shift cable pins (1) separately, and remove gear select and shift cable joints from transmission rocker arm.




- (b) Detach gear select and shift cable dampers from flexible shaft bracket limit hole (arrow). Then move cables to one side.

Caution:

- For removal and installation, refer to 6MT section.


17. Disconnect the vacuum pipe.

- (a) Loosen elastic clamp (arrow) and disconnect connection between brake vacuum hose and brake vacuum steel pipe.



18. Disconnect connection between hose and heater core.

(a) Loosen elastic clamp (1) and disconnect connection between heater core inlet hose and heater core.




(b) Loosen elastic clamp (2) and disconnect connection between heater core outlet hose and heater core.

19. Remove the expansion tank assembly.
 20. Disconnect the following wire harnesses. (For MT models)


- Disconnect the ECU connector (1).
- Disconnect the front bumper wire harness connector (arrow).
- Remove the engine wire harness ground wire fixing bolt (2).

06




(d) Disconnect the neutral switch connector (1).

(e) Disconnect the back-up switch connector (2).




(f) Remove the power assembly wire harness ground wire fixing bolt (arrow) and move away ground wire.

(g) Disconnect the hydraulic release bearing fixing ring (1).




21. Disconnect the following wire harnesses. (For CVT models)

- (a) Disconnect the ECU connector (1).
- (b) Disconnect the front bumper wire harness connector (arrow).
- (c) Remove the engine wire harness ground wire fixing bolt (2).




06

- (d) Disconnect the transmission connector and wire harness connectors and fixing clip (arrow).



ارین سامانه دیجیتال تعمیرکاران خودرو در ایران

- (e) Remove the power assembly wire harness ground wire fixing bolt (arrow) and move away ground wire.




22. Remove the front wheel.
23. Remove the drive shaft.
24. Remove A/C compressor high and low pressure pipes.

(a) Remove coupling bolt (1) between high/low pressure pipe and A/C compressor assembly and disconnect the high/low pressure pipe.


Tightening torque

$25 \pm 3 \text{ N}\cdot\text{m}$



25. Disconnect the water supply pipe.

(a) Loosen elastic clamp (arrow) and disconnect connection between expansion tank water supply pipe and oil filter module assembly.



26. Use an engine hoist to hang engine assembly.

27. Remove the rear mounting assembly.

28. Remove the left mounting assembly.

29. Remove the right mounting assembly.

30. Check that engine assembly is separated with external components.

31. Hang out engine assembly from engine compartment.

32. Remove engine wire harness and battery wire harness from engine.

33. Separate engine assembly and transmission assembly.

34. Install engine assembly to engine service platform.

Installation


1. Installation is in the reverse order of removal.

CYLINDER BLOCK UNIT REPAIR

Engine Block

Description

06




★ : Non-reusable Part

EM0085001

| | |
|---|---|
| 1 - Cylinder Head Gasket | 2 - Cylinder Block |
| 3 - Crankshaft Main Bearing Upper Shell | 4 - Thrust Washer |
| 5 - Crankshaft | 6 - Crankshaft Main Bearing Lower Shell |
| 7 - Cylinder Block Frame Assembly | ★ - Non-reusable Parts |

Description



| | |
|--|--|
| 1 - Piston | 2 - Piston Pin (semi-floating) |
| 3 - Elastic Circlip | 4 - Connecting Rod Assembly |
| 5 - Connecting Rod Bearing Upper Shell | 6 - Connecting Rod Bearing Lower Shell |
| 7 - Connecting Rod Bearing Cap | 8 - Connecting Rod Bearing Cap Fixing Bolt |
| 9 - First Compression Ring | 10 - Second Compression Ring |

| | |
|-----------------|------------------------|
| 11 - Upper Rail | 12 - Expander |
| 13 - Lower Rail | ★ - Non-reusable Parts |

Disassembly


1. Remove the accessory drive belt (See page 06-19).
2. Remove the idler gear assembly (See page 06-21).
3. Remove the tensioner assembly (See page 07-27).
4. Remove the thermostat assembly.
5. Remove the thermostat seat assembly.
6. Remove the knock sensor.

(a) Remove fixing bolt (arrow) and knock sensor.

Tightening torque

$20 \pm 5 \text{ N}\cdot\text{m}$

06




7. Remove alternator assembly and mounting bracket (See page 25-4).
8. Remove A/C compressor assembly and mounting bracket.
9. Remove the engine discharge steel pipe.
10. Remove the oil filter module.

(a) Remove fixing bolt (1) from cooling pipe assembly I.

Tightening torque

$20 + 5 \text{ N}\cdot\text{m}$



(b) Remove 3 fixing bolts (2) from oil filter module.

Tightening torque

$40 + 5 \text{ N}\cdot\text{m}$


Caution:

- There will be residual coolant inside engine during removal and installation, if your skin contacts coolant directly, clean it with water immediately. If it is serious, please go to hospital.
- Prolonged and repeated contact with engine oil will be harmful to your skin. If engine oil spills on your skin, wash it off immediately with water. In addition, the used engine oil contains potentially harmful contaminants, which may cause skin cancer. Therefore, always take proper skin protection measures when performing vehicle service.
- There will be coolant residue inside engine. Coolant should be handled according to local environmental regulations.

(c) Remove the oil filter module.

11. Remove the crankshaft pulley.

(a) Install flywheel special tool (1) to lock flywheel as shown in illustration.




(b) Remove fixing bolt (arrow) from crankshaft pulley.

Tightening torque

1st step: $100 \pm 10 \text{ N}\cdot\text{m}$

2nd step: $120^\circ \pm 10^\circ$



06

(c) Remove the crankshaft pulley.

12. Remove the crankshaft front oil seal.

13. Remove the flywheel assembly.

14. Remove the crankshaft rear oil seal.

15. Remove the cylinder head cover assembly (See page 06-23).

16. Remove the oil pan assembly.

17. Remove the timing chain.

18. Remove intake and exhaust camshaft assemblies.

19. Remove the cylinder head assembly.

20. Remove the oil strainer assembly.


21. Remove the oil pump assembly.

22. Remove the oil pump chain.

(a) Remove oil pump movable guide rail fixing bolt (arrow), and remove movable guide rail.

Tightening torque

$12 + 2 \text{ N}\cdot\text{m}$




(b) Remove the oil pump chain.

23. Remove the oil deflector assembly.

(a) Remove 6 oil deflector fixing bolts (arrow) from oil deflector.

Tightening torque

8 + 3 N·m




(b) Remove the oil deflector assembly.

24. Remove the piston connecting rod assembly.


(a) Using a ridge reamer or equivalent, remove all the carbon deposit from top of cylinder.

06

(b) Turn crankshaft, so that pistons of cylinders 1 and 4 are at bottom dead center, remove fixing bolts (arrow) from connecting rod bearing caps of cylinders 1 and 4, and remove connecting rod bearing caps of cylinders 1 and 4.



(c) Using a hammer handle (1), push out piston connecting rod assembly (2) of cylinders 1 and 4 from cylinder block.



(d) Removal procedures for piston connecting rod assembly of cylinders 2 and 3 are the same as above.

Caution:


- Please operate carefully when pushing out piston, to avoid cylinder liner damage.
- Mark the removed piston connecting rod assemblies, so as to distinguish them.
- Connecting rod bolts and connecting rod bolt holes must correspond one to one without exchange.
- Replace with new bolts during assembly.

25. Remove the connecting rod bearing shell.

(a) Remove the connecting rod bearing shell (arrow).

Hint:

Arrange removed parts in correct order.




EM0095002

26. Remove the piston rings.

(a) Using a piston ring remover (1), remove 2 compression rings (2).

Caution:

- Before removing piston ring, check piston ring side clearance. If it is necessary to be reused, be sure to mark piston ring position.



EM0096002


(b) Remove oil ring rail and expander by hands.

27. Separate piston and connecting rod.

(a) Using a flat tip screwdriver, pry out elastic circlips at both sides of piston pin carefully from the notch. Carefully pry out elastic circlips on both ends of piston pin.

Caution:

- Elastic circlip has a large tensile force. Be careful during removal to prevent personal injury.



EM0097002


(b) Remove the piston pin assembly.

28. Remove the crankshaft.

(a) Evenly loosen and remove crankshaft frame fixing bolts in order shown in illustration.

Tightening torque

27+ 3 N·m.



EM0098002


(b) Evenly loosen and remove crankshaft main bearing cap fixing bolts in order shown in illustration.

Tightening torque

1st step: $45 \pm 5 \text{ N}\cdot\text{m}$
2nd step: $180^\circ \pm 10^\circ$



Non-reusable Part



EM0099002

(c) Remove the crankshaft frame assembly.

Hint:

If it is difficult to remove crankshaft frame due to seal gum, lightly tap it with a rubber hammer to loosen it. Be sure not to damage surrounding components.

06


(d) Remove the crankshaft assembly.

Caution:

- Take care when removing crankshaft, as it is heavy. If necessary, ask other operators to assist. Avoid scratching contact surfaces between crankshaft and bearing shell.

29. Remove the thrust washers.

(a) Remove crankshaft thrust washers (1) from cylinder block.




EM0100002

30. Remove the crankshaft main bearing shell.

(a) Push out crankshaft main bearing upper shell (1) slightly in direction of arrow to remove it.

Hint:

- Remove other crankshaft main bearing upper shells from cylinder block in the same way.
- Pay attention to the notch position. Push out bearing shell carefully as shown in illustration. It is difficult to push out bearing shell and parts may be damaged if pushing in opposite direction.



EM0101002


(b) Remove crankshaft main bearing lower shell from crankshaft frame in the same way.

31. Remove the piston cooling nozzles.

(a) Remove piston cooling nozzle fixing bolts (arrow), and remove piston cooling nozzles from cylinder block.

Tightening torque

20 + 5 N·m



EM0102002

Inspection

06

1. Check the cylinder block.

- Clean engine block thoroughly and check all hole passages for leakage.
- Check cylinder liner for cracks.
- Check cylinder block for cracks.

Caution:


- DO NOT wash cylinder at high temperature; otherwise, cylinder liner will stick out beyond cylinder block.

2. Check the cylinder block upper surface flatness.

- (a) Clean the cylinder block upper surface.
- (b) Using precision straightedge and feeler gauge, measure cylinder block upper surface flatness.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|---------------------------------------|--------------------|------------------|
| Cylinder Block Upper Surface Flatness | 0.04 | 0.1 |

Never grind the cylinder block upper surface. If the engine block upper surface flatness is above the limit, replace the engine block.




EM0248002

3. Check cylinder diameter and piston clearance.

(a) Using a cylinder gauge, measure cylinder diameter and calculate the gap between cylinder and piston.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|---------------------------------------|--------------------|------------------|
| Cylinder Diameter | 77 | 77.105 |
| Clearance Between Piston and Cylinder | 0.04 | 0.115 |


If the cylinder diameter is beyond the limit, replace the cylinder block. If the clearance between piston and cylinder is beyond the specified value, check cylinder diameter and piston diameter. Replace as necessary.




EM0103002

4. Check the piston.

(a) Using a scraper, remove carbon deposits on piston top.




(b) Using a piston ring, remove carbon deposits from piston ring grooves.



(c) Using a brush and solvent, thoroughly clean piston.

Caution:


- DO NOT use a wire brush to clean.



(d) Using a micrometer, measure the piston diameter at the position where is 28.45 mm away from piston skirt from piston pin in vertical position.

| Measurement Item | Specification (mm) |
|------------------|--------------------|
| Piston Diameter | 76.955 - 76.965 |

If piston diameter is not within specified range, replace the piston connecting rod assembly.




5. Check clearance between piston ring and ring groove side.

(a) Using a feeler gauge, measure clearance between new piston ring and ring groove side.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|---|--------------------|------------------|
| First Compression Ring Groove Side Clearance | 0.02 - 0.065 | 0.13 |
| Second Compression Ring Groove Side Clearance | 0.02 - 0.06 | 0.12 |

If piston ring side clearance exceeds specified range, replace piston ring and piston assembly.



EM0108002

6. Check the piston ring end gap.


(a) Using a piston, push piston ring from top of cylinder to a position, that is 45 mm from bottom of cylinder bore. Keep the piston ring level.

(b) Measure at the specified position, which has the minimum piston ring wear with a feeler gauge.

| Measurement Item | Specification (mm) |
|---------------------|--------------------|
| Piston Ring End Gap | First ring |
| | Second ring |

If piston ring end gap is not within specified range, replace piston ring with a new set.

If end gap is still not within specified range after replacement, replace cylinder block assembly.



EM0109002

7. Check the piston pin.

(a) Using a feeler gauge, measure diameter of piston pin hole.

| Measurement Item | Specification (mm) |
|--------------------------|--------------------|
| Piston Pin Hole Diameter | 18.004 - 18.009 |

If piston pin hole diameter is not within specified range, replace piston.




EM0110002

(b) Using an external micrometer, measure diameter of piston pin.

| Measurement Item | Specification (mm) |
|---------------------|--------------------|
| Piston Pin Diameter | 17.995 - 18 |

If piston pin diameter is not within specified range, replace piston pin.




06 8. Check the crankshaft main journal diameter.

(a) Using an external micrometer, measure crankshaft main journal diameter, and measure again after rotating the crankshaft 90°.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|----------------------------------|--------------------|------------------|
| Crankshaft Main Journal Diameter | 50 | 49.984 |
| Taper and Non-roundness | 0 | 0.008 |


If crankshaft main journal diameter is not within specified range, replace main bearing shells with new ones and check matching clearance of crankshaft main bearing.

If matching clearance of main bearing is still not within specified range after replacing with new main bearing shells, replace crankshaft.



9. Check matching clearance of crankshaft main bearing.

(a) Clean crankshaft main journals and main bearing shells.
 (b) Install the crankshaft. Place feeler gauge (1) on crankshaft main journal, parallel to crankshaft center axis and as wide as distance covered by main bearing cap.



(c) Install crankshaft frame assembly and tighten main bearing cap fixing bolts to specified torque in order.

Tightening torque


1st step: $45 \pm 5 \text{ N}\cdot\text{m}$

2nd step: $180^\circ \pm 10^\circ$

(d) Remove the crankshaft frame assembly. Using a feeler gauge, measure widest part of compressed feeler gauge. Measured value is matching clearance of crankshaft main bearing.

| Measurement Item | Specification (mm) |
|---|--------------------|
| Matching Clearance of Crankshaft Main Bearing | 0.023 - 0.075 |

If matching clearance of crankshaft main bearing is not within specified range, install new main bearing shells. Replace crankshaft assembly if necessary.



EM0114002

Caution:

- Replace bearing shells in pairs.

10. Check the crankshaft axial clearance.

- Clean crankshaft main journals and main bearing shells.
- Install crankshaft frame and tighten main bearing cap fixing bolts to specified torque in order.

Tightening torque


1st step: $45 \pm 5 \text{ N}\cdot\text{m}$

2nd step: $180^\circ \pm 10^\circ$

- Using a flat tip screwdriver, pry crank position left and right, and read value on dial indicator.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|----------------------------|--------------------|------------------|
| Crankshaft Axial Clearance | 0.07 - 0.265 | 0.295 |

If crankshaft axial clearance is not within specified range, replace the thrust washers as a set.




EM0115002

11. Check the crankshaft main journal coaxiality.

- Install crankshaft onto tester and keep it level as shown in illustration.
- Rotate crankshaft slowly and read maximum change value from dial indicator. (Readings on dial indicator)/2 is the coaxiality of crankshaft main journal.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|------------------------------------|--------------------|------------------|
| Crankshaft Main Journal Coaxiality | 0 | 0.05 |

If crankshaft main journal coaxiality is not within specified range, replace crankshaft assembly.



EM0116002


12. Check diameter of crankshaft connecting rod journal.

(a) Using an external micrometer, measure diameter of crankshaft connecting rod journal.

| Measurement Item | Specification (mm) | Limit Value (mm) |
|--|--------------------|------------------|
| Crankshaft Connecting Rod Journal Diameter | 46 | 45.984 |

If connecting rod journal diameter is not within specified range, replace connecting rod bearing shells with new ones, and check radial clearance of connecting rod bearing shell.

If radial clearance of connecting rod bearing shell is still not within specified range after replacement, replace crankshaft.




EM0117002

06

13. Check radial clearance of crankshaft connecting rod bearing shell.

(a) Clean connecting rod journals and connecting rod bearing shells.

(b) Place a feeler gauge (1) on connecting rod journal as shown in illustration.



EM0118002

(c) Install connecting rod bearing caps, and tighten connecting rod bearing cap fixing bolts to specified torque.

Tightening torque

1st step: $15 + 3 \text{ N}\cdot\text{m}$;

2nd step: $60^\circ \pm 2^\circ$

Caution:


- DO NOT turn crankshaft during installation.

(d) Remove the connecting rod bearing cap.

(e) Using gauge scale of feeler gauge, measure the widest part of compressed feeler gauge to obtain radial clearance of connecting rod bearing shell as shown in illustration.

| Measurement Item | Specification (mm) |
|---|--------------------|
| Connecting Rod Bearing Shell Radial Clearance | 0.026 - 0.075 |

If radial clearance of connecting rod bearing shell is not within specified range, replace connecting rod bearing shells. Replace crankshaft assembly if necessary.



EM0119002

14. Check axial clearance of connecting rod.

(a) Install connecting rod bearing caps, and tighten connecting rod bearing cap fixing bolts to specified torque.

Tightening torque

1st step: 15 + 3 N·m;

2nd step: 60° ± 2°


(b) Install a dial indicator (2) with its plunger contacting the side of connecting rod cap (1).

(c) Reset dial of dial indicator to zero.

(d) Push connecting rod cap forward and backward (do not move crankshaft forward and backward) and read value on dial indicator.

| Measurement Item | Specification (mm) |
|--------------------------------|--------------------|
| Connecting Rod Axial Clearance | 0.15 - 0.40 |

If axial clearance of connecting rod is not within specified range, replace piston connecting rod assembly. Replace crankshaft assembly if necessary.




06

Selection of Main Bearing Shell

1. Selection of crankshaft main bearing upper shell

(a) Related letter marks are available on cylinder block (consisting of A and B). Such as "BBBBA" in illustration, each letter from left to right is for one type of crankshaft main bearing upper shell. First letter "B" is for upper shell type of crankshaft main bearing first journal, and so on; fifth letter "A" is for upper shell type of crankshaft main bearing fifth journal.

| Name | Model | Letter Mark |
|-------------------------------------|------------|-------------|
| Crankshaft Main Bearing Upper Shell | Red shell | A |
| | Blue shell | B |




EM0121002

2. Selection of crankshaft main bearing lower shell

(a) Related marks are available on first balancer at front end of crankshaft (consisting of A and B). Such as "BBBBA" on first balancer at front end of crankshaft shown in illustration, first letter "B" is for first journal of crankshaft main bearing lower shell, and so on; fifth letter "A" is for fifth journal of crankshaft main bearing lower shell.

| Name | Model | Letter Mark |
|-------------------------------------|------------|-------------|
| Crankshaft Main Bearing Lower Shell | Red shell | A |
| | Blue shell | B |



EM0122002

3. Precautions for crankshaft main bearing shell assembly:

Caution:

- There is a shell groove and oil hole on the main bearing upper shell, and oil hole should be aligned with that on the engine block, but the main bearing lower shell has no oil hole.


- Apply a coat of engine oil to inner surface of main bearing shell before installation. Back side of bearing shell should be clean without any oil or foreign matter during assembly, and make sure that back side and inner surface are clean.

Selection of Connecting Rod Bearing Shell

1. Selection of connecting rod bearing upper shell

- (a) Connecting rod bearing upper shells are divided into red shell and blue shell. Related marks are available on connecting rod bearing shell cap. Select related connecting rod bearing shell according to marks.
- (b) As shown in illustration, among mark "BC" on connecting rod, "B" indicates blue shell.

| Name | Model | Letter Mark |
|------------------------------------|------------|-------------|
| Connecting Rod Bearing Upper Shell | Red shell | A |
| | Blue shell | B |



06

2. Selection of connecting rod bearing lower shell

- (a) Related digital marks are available on first balancer at front end of crankshaft (consisting of 1 and 2). Such as "1221" on first balancer at front end of crankshaft shown in illustration, first digit "1" is for lower shell type of cylinder 1 piston connecting rod bearing, and so on; fourth digit "1" is for lower shell type of cylinder 4 piston connecting rod bearing.

| Name | Model | Digital Mark |
|------------------------------------|------------|--------------|
| Connecting Rod Bearing Lower Shell | Red shell | 1 |
| | Blue shell | 2 |



3. Precautions for connecting rod bearing shell assembly:

Caution:


- Connecting rod upper and lower bearing shells without oil grooves are universal, but one of the connecting rod bearing shells has an oil hole.
- It is necessary to use a set of connecting rod bearing shells that are provided by the same manufacturer on the same engine.
- Apply a coat of engine oil to inner surface of connecting rod bearing shell before installation. Back side of bearing shell should be clean without any oil or foreign matter during assembly, and make sure that back side and inner surface are clean.

Assembly

1. Install the piston cooling nozzles.
 - (a) Install piston cooling nozzles and tighten fixing bolts (arrow).

Tightening torque

20 + 5 N·m




2. Install the crankshaft main bearing shells.

- (a) Carefully install crankshaft main bearing upper shell (1) in direction of arrow, and notch of each main bearing upper shell should be aligned with cylinder block. Oil passage hole (2) on crankshaft main bearing upper shell should be aligned with passage hole on cylinder block after installation.

Caution:


- Apply a coat of engine oil to inner surface of the main bearing shell before installation.



- (b) Install crankshaft main bearing lower shell to crankshaft frame in the same way.

3. Install the thrust washers.

- (a) Clean thrust washers and cylinder block inner wall before installation.
- (b) Apply engine oil to thrust washers.
- (c) There are 2 thrust washers on the cylinder, which are installed on the front and rear thrust surfaces of 3rd main bearing seat respectively.
- (d) As shown in illustration, the side of crankshaft thrust washers (1) without groove should face cylinder block side while the other side with groove should face crankshaft side.



4. Install the crankshaft.

- (a) Apply seal gum to installation surface of crankshaft frame before installation.

Seal gum


Loctite 518/5182

Seal gum diameter

1.5 - 3mm

Caution:

- DO NOT apply seal gum to bearing shell when applying seal gum.




- Seal gum should not be applied too thick. Avoid seal gum entering bearing shell installation area due to compression.

- Place crankshaft on cylinder block carefully.
- Install crankshaft main bearing cap fixing bolts in place by hands, and then tighten 10 crankshaft main bearing cap fixing bolts in order shown in illustration.

Tightening torque

1st step: $45 \pm 5 \text{ N}\cdot\text{m}$

2nd step: $180^\circ \pm 10^\circ$



06

- Evenly tighten 10 crankshaft frame fixing bolts in order shown in illustration.

Tightening torque

$27+ 3 \text{ N}\cdot\text{m}$

- Assemble piston and piston connecting rod.


Caution:

- Apply clean engine oil to outer surface of piston pin and inner surface of piston hole before assembly.

- Using a small screwdriver, install new elastic circlip to one end of piston pin hole.


Warning:

- Relative angle between elastic circlip opening and removed notch is $180^\circ \pm 40^\circ$.




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

- Align front marks on piston and connecting rod, push piston pin with thumb until it contacts with elastic circlip.




(c) Install elastic circlip to the other end of piston pin hole, and check for free rotation between piston and connecting rod assembly.



EM0132002

6. Install the piston rings.

(a) Apply a small amount of engine oil to piston ring groove and piston. Pay attention that the sides with words of first compression ring (1) and second compression ring (2) should face upward.



EM0133002

06

(b) Oil ring is steel band combination oil ring and composed of upper rail (3), lower rail (5) and expander (4). When installing the oil ring, first install the expander into oil groove, then install upper and lower rails with opening staggered by 90° from the expander closed gap, and the upper and lower rails at 180°. Then install the second compression ring, and install the first compression ring finally with two compression rings staggered by 90° from upper rail opening. The piston ring should rotate in the ring groove freely without any stuck condition.


(c) Rotate piston ring several turns after addling engine oil to piston ring groove, and note that the position of ring notch should be the same with that described above; clean crankshaft connecting rod journal and cylinder with a non-woven fabric cloth.

7. Install the connecting rod bearing shells.


Caution:

- Apply a coat of engine oil to inner surface of connecting rod bearing shell before installation.
- Back side of connecting rod bearing shell should be clean without any foreign matter during assembly.

(a) Carefully install the connecting rod bearing upper shell (1) in direction of arrow, and keep notch of each connecting rod bearing upper shell face the cutout of connecting rod bearing.



(b) Carefully install connecting rod bearing lower shell (1) in direction of arrow, and keep notch of each connecting rod bearing lower shell face the cutout of connecting rod bearing cap.





8. Install the piston connecting rod assembly.

- (a) Rotate crankshaft to top dead center of cylinder 1 and cylinder 4.
- (b) Apply a coat of engine oil to piston surface and cylinder inner wall.
- (c) As shown in illustration, install piston connecting rod assembly to cylinder with piston installer (1).

Caution:


- Pay attention to front marks on piston and connecting rod during assembly, without being reversed.



9. Install the connecting rod bearing cap.

Hint:

Protrusion points on connecting rod and connecting rod bearing cap are in same side.



EM0138002

(a) Install connecting rod bearing caps in place, and screw connecting rod bearing cap fixing bolts (arrow) by hands, then tighten connecting rod bearing cap fixing bolts in 2 steps with a torque wrench.


Tightening torque

1st step: $5 + 3$ N·m
2nd step: $60^\circ \pm 5^\circ$

Caution:

- Apply a small amount of engine lubricant to connecting rods, connecting rod bearing caps and thread joint surfaces.

10. Other assembly is in the reverse order of disassembly.



EM0139002

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

