

PARKING ASSIST SYSTEM

PARKING ASSIST SYSTEM	49-3	B1A21-13	49-34
System Overview	49-3	B1A21-11	49-34
System Components Diagram	49-3	B1A21-12	49-34
System Principle	49-6	B1A22-13	49-37
System Function	49-8	B1A22-11	49-37
Components Operation		B1A22-12	49-37
Description	49-14	B1A23-13	49-40
Radar Sensor	49-14	B1A23-11	49-40
Special Tools and Equipment	49-14	B1A23-12	49-40
General Tools	49-14	B1A27-71	49-43
Tightening Torque List	49-14	U0140-87	49-45
Torque	49-14	U015587	49-45
System Circuit Diagram	49-15	U0126-87	49-45
Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System		U0245-87	49-45
Circuit Diagram	49-15	U0101-87	49-45
Panoramic View Monitor System (AVM) & Automatic Parking Assist System (APA) & Parking Radar (12-Radar) System Circuit Diagram		U0100-87	49-45
49-17	U0129-87	49-45	
49-17	U0131-87	49-45	
49-17	U0164-87	49-45	
49-17	U007388	49-45	
49-17	U100588	49-45	
Diagnosis Information and Procedures	49-20	Matching Learning	49-45
Diagnosis Procedure	49-20	Write Software Configuration Information	49-45
Problem Symptoms Table	49-22	Panoramic Control System Calibration	49-47
Reversing Radar Module (RADAR) Terminal List	49-23	Removal & Installation	49-51
Panoramic View Monitor Control Module (AVM) Terminal List	49-24	Front Radar Sensor	49-51
Diagnostic Trouble Code (DTC) Chart	49-25	Rear Radar Sensor	49-52
B1A25-17	49-27	Front Camera Assembly	49-53
B1A25-16	49-27	Rear Camera Assembly	49-54
B1A20-13	49-30	Left/Right Camera	49-55
B1A20-11	49-30	Reversing Radar Module	49-56
B1A20-12	49-30	Panoramic Control System Module	49-57

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




PARKING ASSIST SYSTEM

System Overview

System Components Diagram


Parking View Monitor System (RVC)



PM0010

1	Audio Head Unit (IHU)	5	Rear Camera Assembly
2	Instrument Cluster (ICM)	6	Rear Right Radar Sensor
3	Rear Left Radar Sensor	7	Reversing Radar Module (RADAR)
4	Rear Center Radar Sensor		


Panoramic View Monitor System (AVM)



PM0020

1	Front Right Side Radar Sensor	11	Panoramic View Monitor Button
2	Front Right Radar Sensor	12	Rear Right Side Radar Sensor
3	Front Right Center Radar Sensor	13	Rear Right Radar Sensor
4	Front Camera Assembly	14	Rear Right Center Radar Sensor
5	Front Left Center Radar Sensor	15	Rear Left Center Radar Sensor
6	Front Left Radar Sensor	16	Rear Camera Assembly
7	Front Left Side Radar Sensor	17	Rear Left Radar Sensor
8	Panoramic View Monitor Control Module (AVM)	18	Rear Left Side Radar Sensor
9	Audio Head Unit (IHU)	19	Left Camera
10	Instrument Cluster (ICM)	20	Right Camera

Automatic Parking Assist System (APA)




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

PM0030

1	Front Right Side Radar Sensor	13	Rear Right Radar Sensor
2	Front Right Radar Sensor	14	Rear Right Center Radar Sensor
3	Front Right Center Radar Sensor	15	Rear Left Center Radar Sensor
4	Front Camera Assembly	16	Rear Camera Assembly
5	Front Left Center Radar Sensor	17	Rear Left Radar Sensor
6	Front Left Radar Sensor	18	Rear Left Side Radar Sensor
7	Front Left Side Radar Sensor	19	Left Camera
8	Panoramic View Monitor Control Module (AVM)	20	Right Camera
9	Audio Head Unit (IHU)	21	EPB Module
10	Instrument Cluster (ICM)	22	Engine Control Module (EMS)
11	Automatic Parking Button	23	Electric Power Steering (EPS)
12	Rear Right Side Radar Sensor	24	Body Control Module (BCM)

System Principle

Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System




The reversing radar module collects reverse gear signals through CAN line, and collects radar signals through hard-wire connection. The audio head unit displays radar information and image screen through data requirements analysis.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Panoramic View Monitor System (AVM) & Automatic Parking Assist System (APA) & Parking Radar (12-Radar) System



PM0050

The automatic parking module is integrated in panoramic view monitor control module. The panoramic view monitor control module collects seat belt signals, door open signals, turn signal light signals, vehicle speed signals and gear position signals through CAN line, and collects radar signals and video signals through hard-wire connection. The audio head unit displays radar information and image screen through data requirements analysis. EPB module controls braking and parking (APA models only), electric power steering controls steering (APA models only), and transmission control module controls gear position (APA models only).

System Function

Parking View Monitor System (RVC)

The parking view monitor system uses three ultrasonic sensors to measure the distance from obstacles, and rear camera collects the rear view of vehicle. The audio head unit displays the rear view of vehicle, radar information and vehicle guideline, to remind the driver of the distance between the rear of vehicle and other objects, so as to reduce personal injuries or vehicle damage caused by parking.

Shift the shift lever to R position to enter parking view monitor screen, and display the parking view and vehicle guideline. Vehicle guideline varies depending on steering wheel rotation and it is used for prejudging the wheel's traveling trace during reversing.

Caution:


- Use the distance as a reference (such as on the hill).
- Vehicle width guideline and predicting line are wider than the actual line.
- Do not scratch the lens when cleaning dirt or snow on the camera surface.
- If tire is replaced with a different size, the displayed predicting line is different from the actual line. Please use the rear view mirror or check and determine the distance to other objects actually.

Warning:

- When reversing, make sure that back door is firmly closed.
- Never distract your attention from surrounding traffic due to images on display.
- Due to the limited monitoring range, parking view monitor system cannot view the bottom and corners of bumper.
- When reversing, always pay extra attention to surrounding children, small animals and objects, because they cannot always be detected by camera.
- Because rear camera uses wide-angle lens, object distance displayed on parking view monitor is different from the actual distance.
- Do not tap the cameras, as they are precision instruments. Failure to do so may cause malfunction or damage, leading to fire or electric shock.
- Do not spray water around the camera when washing vehicle with high pressure water. Otherwise, water drop may enter camera and condense on the lens, causing malfunction, fire or electric shock.
- Rear camera may enlarge and distort the view, so image on display is different from real object or it cannot reflect the real object accurately, and there is also blind spot and a little delay.
- The parking view monitor is convenient, but it is not a substitute for correct reversing operation. When reversing, be sure to look around to check if the surroundings are safe and reverse slowly.

Panoramic View Monitor System (AVM)

The panoramic view monitor system uses ultrasonic sensors to measure the distance from obstacles, and four ultra wide angle cameras collect the front, rear, left and right view of vehicle, then splicing them into a birds-eye view of vehicle surroundings through image processing algorithm. The audio head unit (IHU) displays the sounding view of vehicle, radar information and vehicle guideline, to remind the driver of the distance between the rear of vehicle and other objects, so as to reduce personal injuries or vehicle damage caused by parking.



When vehicle power supply is turned to ON mode and vehicle speed is less than 20 km/h: Press the panoramic view monitor switch to enter the panoramic view monitor system, press the panoramic view monitor switch again to exit.

When vehicle power supply is turned to ON mode and vehicle speed is less than 20 km/h: Shift the shift lever to R position to enter the panoramic view monitor system, shift the shift lever out from P to exit panoramic view monitor system after a delay of 15 s.

When vehicle power supply is turned to ON mode and vehicle speed is less than 15 km/h (D position): After receiving the parking radar obstacle distance signals, enter the panoramic view monitor system (APA models only), shift the shift lever to N/P position or when there is no obstacle distance information, it will exit panoramic view monitor system after a delay of 15 s.

Function	Description
Two-dimensional view/three-dimensional view	Click two-dimensional view/three-dimensional view button to switch two-dimensional/three-dimensional view
Front wide view/rear wide view	Click front wide view/rear wide view button to switch front/rear wide view
Panoramic startup animation	When AVM is starting, surround the vehicle all around
Turn signal light activating panoramic	Click turn signal light activating button, it will enter panoramic view monitor system when left/right turn signal light is turned on
Steering angle activating panoramic	Click steering angle activating panoramic button, it will enter panoramic view monitor system during large-angle steering
Auto enlarging view	Click auto enlarging view button to enter enlarged view automatically according to the obstacle distance
Door opening view	Click door opening view button, it will enter front left/front right door opening view when front left/ front right door is opened
Vehicle guideline	Click vehicle guideline display button, it will load static and dynamic vehicle guidelines and wheel track line when entering panoramic view monitor system
License plate number setting	Click license plate number display button to receive the license plate number sent by audio head unit and display it in 3D vehicle icon

Caution:



- Do not scratch the lens when cleaning dirt or snow on the camera surface.
- Distance from object seen from panoramic view monitor system is different from the actual distance.
- Make sure that the outside rear view mirrors are unfolded and the back door is firmly closed before using panoramic view monitor system.
- Cameras are installed on front grille, outside rear view mirrors and above the rear license plate. Do not place anything on the camera.
- Panoramic view monitor system has professionally calibrated before leaving factory. Any removal and installation behaviors without permission that cause changes in installation position and angle of camera may affect the function and effect of panoramic view monitor system.
- The panoramic view monitor system provides driving assist, however, object in image does not indicate the actual size and distance from it. There is a slight delay and blind spot in image relative to the actual condition. Therefore, the panoramic view function is not a substitute for driver's operation and judgment. During on, off and use of the function, driver should pay attention to the surroundings to ensure safe driving.

Automatic Parking Assist System (APA)

The automatic parking assist system uses ultrasonic sensors to measure the distance from obstacles, and four ultra wide angle cameras detect the parking spaces on both sides of road. After confirming the target parking space by audio head unit, assist the driver to automatically park the vehicle in or out of the target parking space.

The types of parking spaces supported by automatic parking assist system include parallel marked parking space, vertical marked parking space, inclined marked parking space, parallel boundary parking space and vertical boundary parking space.

Press the automatic parking switch to enter the automatic parking assist system; press the automatic parking switch again to exit the automatic parking assist system.



1. Automatic parking in

- (a) Turn on the automatic parking assist system and drive vehicle to search for parking space. Before activating the automatic parking assist system, make sure that the driver's seat belt is fastened and the doors, engine hood and back door are all closed; Press the automatic parking switch to turn on the parking screen, when the transmission is in D position, vehicle speed is < 25 km/h, and the lateral distance between driving path and available parking space is about 0.5 m-1.9 m, it begins to search for the parking space;

The automatic parking assist system searches for the right parking space by default. Turn on the left turn signal light if you need to search for the left parking space.

- (b) The automatic parking assist system finds available parking space, and the driver confirms the target parking space.

When the automatic parking assist system finds available parking spaces, the parking space information will be displayed on the parking screen. Please stop at this time;

When there are multiple available parking spaces, the driver can select the desired parking space on the parking screen. If not selected, the nearest parking space will be selected by default.

- (c) Automatic parking in.

After confirming the target parking space, press the automatic parking switch and operate according to prompts on the parking screen to enter the automatic parking process;

During automatic parking in, the driver does not need to perform vehicle operations, but needs to pay attention to the surroundings at all times. Be ready to brake vehicle at any time to ensure that the vehicle can be controlled in dangerous situations.

- (d) Complete parking.

After the vehicle is parked in target parking space, the parking screen prompts that parking is completed. The automatic parking assist system applies electronic parking brake automatically, and shift to P position. At this time, the driver takes over the vehicle operation.

2. Automatic parking space selection

- (a) Turn on automatic parking assist system, and the driver confirms the target parking space.

Before activating the automatic parking assist system, make sure that the driver's seat belt is fastened and the doors, engine hood and back door are all closed;

Press the automatic parking switch while depressing and holding the brake pedal, to turn on the parking screen. Select the automatic parking space selection to enter the automatic parking space selection screen;

The automatic parking assist system provides vertical parking spaces by default. Double click the vehicle icon to switch between horizontal parking space and inclined parking space. Select the type of required parking space, dragging the vehicle icon to determine the parking position, and control the four-axes of vehicle icon to adjust the angle slightly; The right panoramic view screen will display the target parking position, and the driver should ensure the availability of the position.

(b) Automatic parking in.

After confirming the target parking space, press the automatic parking switch and operate according to prompts on the parking screen to enter the automatic parking process;

During automatic parking in, the driver does not need to perform vehicle operations, but needs to pay attention to the surroundings at all times. Be ready to brake vehicle at any time to ensure that the vehicle can be controlled in dangerous situations.

(c) Complete parking.

After the vehicle is parked in target parking space, the parking screen prompts that parking is completed. The automatic parking assist system applies electronic parking brake automatically, and shift to P position. At this time, the driver takes over the vehicle operation.

3. Automatic moving out

(a) Turn on automatic parking assist system, and the driver selects the direction of moving out.

Before activating the automatic parking assist system, make sure that the driver's seat belt is fastened and the doors, engine hood and back door are all closed;

Start the engine, the transmission is in P position, press the automatic parking switch to turn on the parking screen. Select automatic moving out to enter the automatic moving out screen;

The driver can select the direction of moving out by toggling the combination switch (left/right turn signal light).

(b) Automatic moving out.

The parking spaces supported by automatic moving out are only horizontal parking spaces and there are obstacles ahead;

After selecting the direction of moving out, operate according to prompts on the parking screen to enter the automatic moving out process;

During automatic moving out, the driver does not need to perform vehicle operations, but needs to pay attention to the surroundings at all times. Be ready to brake vehicle at any time to ensure that the vehicle can be controlled in dangerous situations.

(c) Complete parking.

After the vehicle is parked in target parking space, the parking screen prompts that parking is completed. The automatic parking assist system applies electronic parking brake automatically, and shift to P position. At this time, the driver takes over the vehicle operation.

Hint:

- When searching for a parking space, the distance between vehicle and obstacles that make up the parking space should be 0.5 m-1.9 m. The parking space may not be found if exceeds the range.
- When searching for a parking space, try to keep the vehicle passing through the parking space in a straight line, thus to achieve a better parking space detection effect.
- The rattling sound during parking is the normal operating noise of brake system, and it is no need to worry about it.
- When parking on uneven road, fluctuation may occur in parking speed, and the vehicle may bump. Try to avoid using this system on uneven road.
- The automatic parking assist system only supports the moving out function of parallel parking spaces. Appropriate adjustment space is required in front and rear of vehicle body. The moving out function may not be available when there is abnormal change in the parking space.
- During parking, the steering, braking, accelerator pedal and gear position are controlled by the automatic parking assist system. The driver can operate the brake pedal to control vehicle speed or stop the vehicle. The vehicle can continue to park after release the brake pedal.

Caution:

- The automatic parking assist system does not consider the changes in recognized target parking space, which may cause parking failure.
- When using automatic parking assist system, the vehicle may cross or hit the curbs during steering. Therefore, the driver must ensure that the brake intervention can be performed at any time, otherwise it may cause wheel or vehicle damage.
- Target recognition is restricted by the ultrasonic measurement physical laws and camera vision algorithms. The ability to recognize person, animals and various obstacles around the vehicle is limited. In addition, external sound sources or light and shadow may cause interference to the system, resulting in missing recognition or misrecognition of system. Therefore, before confirming the target parking space, the driver is responsible for paying attention to the surroundings of vehicle and confirming the availability of target parking space.

Warning:

- The automatic parking assist system only provides assistance to the driver, and cannot operate normally under all driving conditions, weather conditions, traffic or road conditions.
- When using automatic parking assist system, the driver has responsibility to control the vehicle, monitor the system operation and intervene when necessary to avoid danger.


Reversing Radar (3-Radar) System

Turn vehicle power supply to ON mode and shift the shift lever to R position to activate the parking radar system; When the radar sensor detects an obstacle, the audio head unit will display the corresponding distance information, and the buzzer sounds. When the radar sensor is faulty, it will sound for 2 s continuously when parking radar system is turned on.

Distance/cm	Display Method			Note
	Rear Left	Rear Center	Rear Right	
≤ 35				Continuous sound
40 ≤ L ≤ 60				Sound at 4Hz
65 ≤ L ≤ 90				Sound at 2Hz
95 ≤ L ≤ 150				Sound at 1Hz

Parking Radar (12-Radar) System

Turn vehicle power supply to ON mode and shift the shift lever to R position to activate the parking radar system; When the front/rear radar sensor detects an obstacle, the audio head unit will display the corresponding distance information with sounding; When the side radar sensor detects an obstacle, the audio head unit will display the corresponding distance information without sounding; When the radar sensor is faulty, it will sound for 2 s continuously when parking radar system is turned on (applying parking brake or shifting the transmission gear to P position will block the radar sensor failure alarm sound).



The parking radar system is turned on by default when powered-on for the first time, and the parking radar switch indicator comes on; Press parking radar switch, the parking radar switch indicator goes off and exit the parking radar system; When vehicle speed is > 15 km/h, it will exit parking radar system; When vehicle speed is < 15 km/h, press the parking radar switch to activate the parking radar system again.

Distance/cm	Display Method						Note
	Front Left Side	Front Left	Front Left Center	Front Right Center	Front Right	Front Right Side	
≤ 35							Continuous sound
$40 \leq L \leq 60$							Sound at 4Hz
$65 \leq L \leq 90$							Sound at 2Hz

Distance/cm	Display Method						Note
	Rear Left Side	Rear Left	Rear Left Center	Rear Right Center	Rear Right	Rear Right Side	
≤ 35							Continuous sound
$40 \leq L \leq 60$							Sound at 4Hz
$65 \leq L \leq 90$							Sound at 2Hz
$95 \leq L \leq 150$							Sound at 1Hz

Caution:

The parking radar system may not operate normally in the following conditions:


- When the vehicle is on a steep slope.
- When driving in jelly-like snow or in rain.
- Low objects such as rocks, etc. cannot be detected.
- Objects that are higher than bumper may not be detected.
- Thin objects such as wires, fences and ropes, etc. cannot be detected.
- When vehicle is equipped with high frequency radio or antenna is in use.
- When radar sensor surface is frozen, it will not detect any obstacle.
- When radar sensor is covered by dirt, snow or mud, it may not detect obstacles.
- Objects that can easily absorb ultrasonic waves such as soft snow, cotton, sponge, etc. cannot be detected.
- The vicinity of vehicle is noisy (such as vehicle horns, motorcycle engines, air brakes of large vehicles, or other loud noises producing ultrasonic waves).
- If multiple radar sensors have detected an obstacle, audio head unit will display distances between each radar sensor and obstacle simultaneously, and sound alarm will be sound from nearest obstacle.
- For obstacles out of the detection range, radar sensors do not give a warning.
- When vehicle is moving, please note that the reversing radar sensor on the other side may get close to other obstacles.

Components Operation Description

Radar Sensor



Main Function

After radar sensors send out ultrasonic and receive back wave from obstacle, control module calculates obstacle distance ($S=t \times 340 \div 2$) according to ultrasonic distance measuring principle, and sends data to display terminal to display and alarm.



Special Tools and Equipment

General Tools

Tool Name	Tool Drawing
Digital Multimeter	 RCH0002006
Diagnostic Tester	 RCH0001006

Tightening Torque List


Torque


49

Description	Tightening Torque
Outside Rear View Mirror Fixing Bolt	$7 \pm 1 \text{ N}\cdot\text{m}$
Reversing Radar Control Module Fixing Bolt	$5 \pm 1 \text{ N}\cdot\text{m}$
Panoramic Control System Module Fixing Bolt	$7 \pm 1 \text{ N}\cdot\text{m}$

System Circuit Diagram

Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System Circuit Diagram






Digitalkhodro


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


PM0160

Panoramic View Monitor System (AVM) & Automatic Parking Assist System (APA) & Parking Radar (12-Radar) System Circuit Diagram





PM0150



Diagnosis Information and Procedures

Diagnosis Procedure

Hint:

Use following procedures to troubleshoot the parking assist system.

1	Vehicle brought to workshop
---	-----------------------------

NEXT

2	Check battery voltage
---	-----------------------

Check if battery voltage is normal.

OK

Standard voltage: Not less than 12 V.

Result

Result	Go to
OK	A
NG	B

B	Replace battery
---	-----------------

A

3	Customer problem analysis
---	---------------------------

NEXT

4	Read DTCs
---	-----------

Result

Result	Go to
DTC exists	A
No DTC	B

B	Repair according to Problem Symptoms Table
---	--

A

49

5	Read DTCs (current DTC and history DTC)
---	---

Result

Result	Go to
DTC exists	A
No DTC	B

B	
---	--

Troubleshoot according to intermittent
DTC Troubleshooting

A

6 Repair according to Diagnostic Trouble Code (DTC) Chart

NEXT

7 Adjust, repair or replace

NEXT

8 Conduct test and confirm malfunction has been repaired

NEXT

End

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software).
- Turn ENGINE START STOP switch to ON.
- Use the diagnostic tester to record and clear DTCs stored in system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON and check the DTCs in system again.
- If DTC is detected, it indicates current malfunction.
- If no DTC is detected, malfunction indicated by the DTC is intermittent.

**Intermittent DTC Troubleshooting**

- Check if connector is loose.
- Check if wire harness is worn, pierced, pinched or partially broken.
- Wiggle related wire harness and connector and observe if signal in related circuit is interrupted.
- If possible, try to duplicate conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggle test.
- Check for broken, bent, protruded or corroded terminals.
- Check and clean all wire harness connectors and ground parts related to DTC.
- If multiple trouble codes were set, refer to circuit diagrams to look for any common ground circuit or power supply circuit applied to DTC.
- Refer to any Technical Bulletin that may apply to this malfunction.

Ground Inspection

Ground points are very important to the proper operation of circuits. Ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) may increase load resistance. This situation may change the way in which a circuit works. Circuits are very sensitive to proper grounding. A loose or corroded ground can affect the control circuit. Check the ground points as follows:

- Remove ground bolt or nut.
- Check all contact surfaces for tarnish, dirt and rust, etc.
- Clean as necessary to ensure that contact is in good condition.
- Reinstall ground bolt or nut securely.
- Check if add-on accessories interfere with ground circuit.

- If several wire harnesses are crimped into one ground terminal, check for proper crimps. Make sure that all wire harnesses are clean and securely fastened while providing a good ground path.

Problem Symptoms Table

Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System Circuit Diagram

Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

Symptom	Suspected Area
Parking view monitor system (RVC) operate abnormally	Radar sensor
	Reversing radar module (RADAR)
	Audio head unit
	Wire harness fault
	Fuse
CAN network failure	Fuse
	Wire harness fault
	Central gateway (CGW)
	Reversing radar module (RADAR)


Panoramic View Monitor System (AVM) & Automatic Parking Assist System (APA) & Parking Radar System(12-Radar) Circuit Diagram

Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

Symptom	Suspected Area
Panoramic view monitor system (AVM) operate abnormally	Radar sensor
	Panoramic View Monitor Control Module (AVM)
	Audio head unit
	Wire harness fault
	Fuse
	Camera
	Auxiliary fascia console switch
CAN network failure	Fuse
	Wire harness fault
	Central gateway (CGW)
	Panoramic View Monitor Control Module (AVM)

Reversing Radar Module (RADAR) Terminal List




B-082

PM0100

Terminal No.	Terminal Definition	Terminal No.	Terminal Definition
1	\	9	\
2	\	10	\
3	Radar Control Module Power Supply	11	Sensor Power Supply
4	\	12	Sensor Ground
5	CAN2-H	13	CAN2-L
6	\	14	Ground
7	Rear Left Radar Sensor Signal	15	Rear Right Radar Sensor Signal
8	Rear Center Radar Sensor Signal	16	Ground

Panoramic View Monitor Control Module (AVM) Terminal List



B-005

PM0110

Terminal No.	Terminal Definition	Terminal No.	Terminal Definition
1	APA Indicator	17	APA Switch
2	PDC Indicator	18	PDC Switch
3	Rear Sensor Ground	19	Rear Sensor Power Supply
4	Rear Right Side Sensor Signal	20	Rear Left Side Sensor Signal
5	Rear Left Sensor Signal	21	Rear Left Center Sensor Signal
6	Rear Right Center Sensor Signal	22	Rear Right Sensor Signal
7	Front Sensor Ground	23	Front Sensor Power Supply
8	Front Right Side Sensor Signal	24	Front Left Side Sensor Power Supply
9	Front Left Sensor Signal	25	Front Left Center Sensor Signal
10	Front Right Center Sensor Signal	26	Front Right Sensor Signal
11	\	27	AVM Switch
12	\	28	\
13	B CAN-L	29	B CAN-H
14	C CAN-L	30	C CAN-H
15	\	31	IGN
16	Ground	32	Power Supply

Diagnostic Trouble Code (DTC) Chart

DTC	DTC Definition
B1A20-13	AVM Left Camera LVDS Cable Open
B1A21-13	AVM Rear Camera LVDS Cable Open
B1A22-13	AVM Left Camera LVDS Cable Open
B1A23-13	AVM Right Camera LVDS Cable Open
B1A20-11	AVM Front Camera Power Short to Ground
B1A20-12	AVM Front Camera Power Short to Battery
B1A21-11	AVM Rear Camera Power Short to Ground
B1A21-12	AVM Rear Camera Power Short to Battery
B1A22-11	AVM Left Camera Power Short to Ground
B1A22-12	AVM Left Camera Power Short to Battery
B1A23-11	AVM Right Camera Power Short to Ground
B1A23-12	AVM Right Camera Power Short to Battery
B1A24-04	AVM ECU Trouble
B1A25-17	Control Module Input Power High
B1A25-16	Control Module Input Power Low
B1A26-54	AVM No Calibration
B1A27-71	AVM On/Off Switch Mechanical Adhesion
B1A28-71	APS On/Off Switch Mechanical Adhesion
B1A28-96	APS Function Indicator Light Circuit Failure
B1A29-71	PDC On/Off Switch Mechanical Adhesion
B1A29-96	PDC Function Indicator Light Circuit Failure
B1A3009	Rear Right Side Long Distance Ultrasonic Sensor Hardware Fault
B1A3109	Rear Right Lateral Ultrasonic Sensor Hardware Fault
B1A3209	Rear Right Ultrasonic Sensor Hardware Fault
B1A3309	Rear Left Ultrasonic Sensor Hardware Fault
B1A3409	Rear Left Lateral Ultrasonic Sensor Hardware Fault
B1A3509	Rear Left Side Long Distance Ultrasonic Sensor Hardware Fault
B1A3609	Front Right Side Long Distance Ultrasonic Sensor Hardware Fault
B1A3709	Front Right Lateral Ultrasonic Sensor Hardware Fault
B1A3809	Front Right Ultrasonic Sensor Hardware Fault
B1A3909	Front Left Ultrasonic Sensor Hardware Fault
B1A3A09	Front Left Lateral Ultrasonic Sensor Hardware Fault
B1A3B09	Front Left Side Long Distance Ultrasonic Sensor Hardware Fault
B1A3096	Rear Right Side Long Distance Ultrasonic Sensor Probe Failure
B1A3196	Rear Right Lateral Ultrasonic Sensor Probe Failure
B1A3296	Rear Right Ultrasonic Sensor Probe Failure
B1A3396	Rear Left Ultrasonic Sensor Probe Failure
B1A3496	Rear Left Lateral Ultrasonic Sensor Probe Failure
B1A3596	Rear Left Side Long Distance Ultrasonic Sensor Probe Failure
B1A3696	Front Right Side Long Distance Ultrasonic Sensor Probe Failure
B1A3796	Front Right Lateral Ultrasonic Sensor Probe Failure
B1A3896	Front Right Ultrasonic Sensor Probe Failure
B1A3996	Front Left Ultrasonic Sensor Probe Failure
B1A3A96	Front Left Lateral Ultrasonic Sensor Probe Failure
B1A3B96	Front Left Side Long Distance Ultrasonic Sensor Probe Failure
U0140-87	Lost Communication With BCM
U015587	Lost Communication With ICM

DTC	DTC Definition
U0126-87	Lost Communication With SAM
U0245-87	Lost Communication With MMI (RRM)
U0101-87	Lost Communication With TCU
U0100-87	Lost Communication With EMS
U0129-87	Lost Communication With ESC
U0131-87	Lost Communication With EPS
U0164-87	Lost Communication With CLM
U007388	Body CAN BusOff Error
U100588	Chassis CAN BusOff Error

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	B1A25-17	Control Module Input Power High
------------	-----------------	--

DTC	B1A25-16	Control Module Input Power Low
------------	-----------------	---------------------------------------

Description

DTC	DTC Definition	Possible Cause
B1A25-17	Control Module Input Power High	Battery Panoramic view monitor control module (AVM) Wire harness fault
B1A25-16	Control Module Input Power Low	

1 Check battery voltage

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the negative battery cable.
- (c) Check battery voltage with a digital multimeter (not less than 12 V).

Result

Result	Go to
OK	B
NG	A

A**Replace battery****B****2 Check charging system**

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Check positive and negative battery cables for broken or damage.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Start the engine.
- (e) Check if voltage of positive and negative battery is normal with a digital multimeter (13.5V-14.8V).

Result

Result	Go to
OK	B
NG	A


A**Repair or replace positive and negative cables and alternator****B****49****3 Check AVM module power supply wire harness**

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the AVM connector B-005.
- (c) Turn ENGINE START STOP switch to ON.

- (d) Using a digital multimeter, check if the voltage between terminal B-005 (32), (31) and body ground is normal.

Standard Condition

Multimeter Connection	Condition	Specified Condition
B-005 (32) - Body ground	Always	Not less than 12 V
B-005 (31) - Body ground	Always	Not less than 12 V



Result

Result	Go to
OK	B
NG	A

A

Repair or replace wire harness

B


4

Check AVM module ground circuit

- (a) Turn ENGINE START STOP switch to OFF.
 (b) Disconnect the AVM connector B-005.
 (c) Using a digital multimeter, check for continuity between B-005 (16) and body ground to check ground circuit for open.

Standard Condition

Multimeter Connection	Condition	Specified Condition
B-005 (16) - Body ground	Always	$\leq 1 \Omega$




- (d) Turn ENGINE START STOP switch to ON.

- (e) Using voltage band of digital multimeter, measure voltage between B-005 (16) and body ground to check for short to power supply.

Standard Condition

Multimeter Connection	Condition	Specified Condition
B-005 (16) - Body ground	Always	0V



Result

Result	Go to
OK	B
NG	A

B

Replace AVM module

A

Replace wire harness

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




DTC	B1A20-13	AVM Left Camera LVDS Cable Open
-----	----------	---------------------------------

DTC	B1A20-11	AVM Front Camera Power Short to Ground
-----	----------	--

DTC	B1A20-12	AVM Front Camera Power Short to Battery
-----	----------	---

Circuit Diagram



49

Description

DTC	DTC Definition	Possible Cause
B1A20-13	AVM Left Camera LVDS Cable Open	
B1A20-11	AVM Front Camera Power Short to Ground	<ul style="list-style-type: none"> • Camera • Wire harness
B1A20-12	AVM Front Camera Power Short to Battery	

1 Replace camera with a new one

(a) Turn ENGINE START STOP switch to OFF.

- (b) Replace front camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

Result

Result	Go to
OK	B
NG	A

B

Replace front camera

A

2 Check wire harness and connector

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the AVM connector B-009.
- (c) Disconnect the front camera connector Q-532.

دُخْلَدْ كِيَجِيَّال

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



- (d) Using ohm band of multimeter, check for continuity between B-009 (2-1) and Q-532 (1).

Standard Condition


Multimeter Connection	Condition	Specified Condition
B-009 (2-1) - Q-532 (1)	Always	$\leq 1 \Omega$



- (e) Using ohm band of multimeter, check for continuity between B-009 (2-2) and Q-532 (2).

Standard Condition

Multimeter Connection	Condition	Specified Condition
B-009 (2-2) - Q-532 (2)	Always	$\leq 1 \Omega$




Result

Result	Go to
OK	B
NG	A



Repair or replace wire harness and connector



49


3 Check for short to ground in wire harness or connector

- Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
- Disconnect the AVM connector B-009.
- Disconnect the front camera connector Q-532.

- (d) Using ohm band of multimeter, check for continuity between B-009 (2-1) and body ground, B-009 (2-2) and body ground separately.

Standard Condition

Multimeter Connection	Condition	Normal Condition
B-009 (2-1) - Body ground	Always	No continuity
B-009 (2-2) - Body ground	Always	No continuity



PM0250

Result

Result	Go to
OK	B
NG	A

B

Replace AVM module

A

Repair or replace connector or wire harness that is shorted to ground


شرکت دیجیتال خودرو سامانه (مستولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	B1A21-13	AVM Rear Camera LVDS Cable Open
DTC	B1A21-11	AVM Rear Camera Power Short to Ground
DTC	B1A21-12	AVM Rear Camera Power Short to Battery

Circuit Diagram



49

Description

DTC	DTC Definition	Possible Cause
B1A21-13	AVM Rear Camera LVDS Cable Open	
B1A21-11	AVM Rear Camera Power Short to Ground	Camera Wire harness
B1A21-12	AVM Rear Camera Power Short to Battery	

1	Check rear camera
---	-------------------

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.

- (b) Replace rear camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

Result

Result	Go to
OK	B
NG	A

B

Replace rear camera


A

2 Check wire harness and connector

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
 (b) Disconnect the AVM connector B-008.
 (c) Disconnect the rear camera connector T-010.
 (d) Using ohm band of multimeter, check for continuity between B-008 (3-1) and T-010 (1), B-008 (3-2) and T-010 (2) separately.

Standard Condition

Multimeter Connection	Condition	Normal Condition
B-008 (3-1) - T-010 (1)	Always	$\leq 1 \Omega$
B-008 (3-2) - T-010 (2)	Always	$\leq 1 \Omega$



PM0260

Result

Result	Go to
OK	B
NG	A

A

Repair or replace wire harness and connector

B

49


3 Check for short to ground in wire harness and connector

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
 (b) Disconnect the AVM connector B-008.

- (c) Using ohm band of multimeter, check for continuity between B-008 (3-1) and body ground, B-008 (3-2) and body ground separately.

Standard Condition


Multimeter Connection	Condition	Normal Condition
B-008 (3-1) - Body ground	Always	∞
B-008 (3-2) - Body ground	Always	∞



PM0270

Result

Result	Go to
OK	B
NG	A



شرکت دیجیتال خودرو سامانه (مسئلیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




DTC	B1A22-13	AVM Left Camera LVDS Cable Open
-----	----------	---------------------------------

DTC	B1A22-11	AVM Left Camera Power Short to Ground
-----	----------	---------------------------------------

DTC	B1A22-12	AVM Left Camera Power Short to Battery
-----	----------	--

Circuit Diagram



Description

DTC	DTC Definition	Possible Cause
B1A22-13	AVM Left Camera LVDS Cable Open	Wire harness, camera
B1A22-11	AVM Left Camera Power Short to Ground	
B1A22-12	AVM Left Camera Power Short to Battery	

1 Check left camera

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.

- (b) Replace left camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

Result

Result	Go to
OK	B
NG	A




2 Check for open in wire harness and connector

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
 (b) Disconnect the AVM connector B-007.
 (c) Disconnect the left camera connector F-005.
 (d) Using ohm band of multimeter, check for continuity between B-007(4-1) and F-005(1), B-007(4-2) and F-005(2) separately.

Standard Condition

Multimeter Connection	Condition	Normal Condition
B-007 (4-1) - F-005 (1)	Always	$\leq 1 \Omega$
B-007 (4-2) - F-005 (2)	Always	$\leq 1 \Omega$



Result

Result	Go to
OK	B
NG	A



49

3 Check for short to ground in wire harness or connector

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
 (b) Disconnect the AVM connector B-007.

- (c) Using ohm band of multimeter, check for continuity between B-007(4-1) and ground, B-007(4-2) and ground separately.

Standard Condition

Multimeter Connection	Condition	Normal Condition
B-007 (4-1) - Ground	Always	∞
B-007 (4-2) - Ground	Always	∞



(B-007)



PM0290

Result

Result	Go to
OK	B
NG	A



Repair or replace connector or wire harness that is shorted to ground



Replace AVM module

شرکت دیجیتال خودرو سامانه (مستولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




DTC	B1A23-13	AVM Right Camera LVDS Cable Open
-----	----------	----------------------------------

DTC	B1A23-11	AVM Right Camera Power Short to Ground
-----	----------	--

DTC	B1A23-12	AVM Right Camera Power Short to Battery
-----	----------	---

Circuit Diagram



49

Description

DTC	DTC Definition	Possible Cause
B1A23-13	AVM Right Camera LVDS Cable Open	Wire harness, camera
B1A23-11	AVM Right Camera Power Short to Ground	
B1A23-12	AVM Right Camera Power Short to Battery	

1 Check right camera

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.

- (b) Replace right camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

Result

Result	Go to
OK	B
NG	A

B

Replace right camera


A

2 Check for open in wire harness and connector

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
 (b) Disconnect the AVM connector B-006.
 (c) Disconnect the right camera connector H-004.
 (d) Using ohm band of multimeter, check for continuity between B-006 (5-1) and H-004 (1), B-006 (5-2) and H-004 (2) separately.

Standard Condition

Multimeter Connection	Condition	Normal Condition
B-006 (5-1) - H-004 (1)	Always	$\leq 1 \Omega$
B-006 (5-2) - H-004 (2)	Always	$\leq 1 \Omega$



Result

Result	Go to
OK	B
NG	A

A

Repair or replace wire harness and connector

B

49


3 Check for short to ground in wire harness or connector

- (a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
 (b) Disconnect the AVM connector B-006.

- (c) Using ohm band of multimeter, check for continuity between B-006 (5-1) and body ground, B-006 (5-2) and body ground separately.

Standard Condition


Multimeter Connection	Condition	Normal Condition
B-006 (5-1) - Body ground	Always	∞
B-006 (5-2) - Body ground	Always	∞



PM0310

Result


Result	Go to
OK	B
NG	A



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DTC B1A27-71 AVM On/Off Switch Mechanical Adhesion

Circuit Diagram



Description

DTC	DTC Definition	Possible Cause
B1A27-71	AVM On/Off Switch Mechanical Adhesion	AVM module Switch

1 Replace AVM switch with a new one

- Turn ENGINE START STOP switch to OFF.
- Remove the old AVM switch.
- Install new switch and perform running test.

Result

Result	Go to
OK	B
NG	A

B

Replace AVM switch


A

2 Check wire harness for open or short

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the AVM connector B-005.
- Disconnect the auxiliary fascia console switch connector I-048.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, check for continuity between B-005 (27) and I-048 (13) to check circuit for open.

Standard Condition

Multimeter Connection	Condition	Specified Condition
B-005 (27) - I-048 (13)	Always	$\leq 1 \Omega$




PM0320

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

- Using ohm band of digital multimeter, check for continuity between I-048 (13) and body ground to check instrument panel wire harness for short to ground.

Standard Condition

Multimeter Connection	Condition	Specified Condition
I-048 (13) - Body ground	Always	No continuity




PM0330

49

Result

Result	Go to
OK	B
NG	A





DTC	U0140-87	Lost Communication With BCM
DTC	U015587	Lost Communication With ICM
DTC	U0126-87	Lost Communication With SAM
DTC	U0245-87	Lost Communication With MMI (RRM)
DTC	U0101-87	Lost Communication With TCU
DTC	U0100-87	Lost Communication With EMS
DTC	U0129-87	Lost Communication With ESC
DTC	U0131-87	Lost Communication With EPS
DTC	U0164-87	Lost Communication With CLM
DTC	U007388	Body CAN BusOff Error
DTC	U100588	Chassis CAN BusOff Error

Refer to CAN communication system

Matching Learning

Write Software Configuration Information

1. Click "AVM (Around View Monitor Module)".
2. Click "Special Function".
3. Click "Write Software Configuration Information".



Panoramic Control System Calibration

Camera Calibration

1. Situations needs to perform camera calibration:
 - When service station removes or installs camera or rear view mirror with camera.
 - When camera position changes due to vehicle accident.
 - After replacing panoramic view monitor system controller.
 - When removing and installing front and rear bumpers.
2. Calibration method:
 - (a) Park vehicle at the fixed location.
 - (b) Lay calibration cloth (front and rear sides) at front and rear of vehicle.


Caution:

- "Front center" of calibration cloth corresponds to the front side of vehicle.
- Center line position of calibration cloth should align with the middle position of front and rear of vehicle.



ولین سامانه دیجیتال تعیین کاران خودرو در ایران

- (c) Unfold calibration cloth (left and right sides) and lay it onto both sides of vehicle.
 - Center line corresponds to front left and right wheel positions.
 - Left and right sides and front and rear sides of calibration cloth should be placed in accordance with single and double arrow marks respectively.



- (d) Entering calibration mode (calibration function activated).
 - (1) With IGN-ON or panoramic view monitor system turned on by pressing AVM switch, press "HOME+NAVI+SET" buttons on the head unit at the same time and then release them, if the operation is valid, audio display will display the screen shown in illustration. "Automatic calibration" is used for production line, and "manual calibration" is used for after-sales calibration.
- #### Caution:
- The command is valid only when three buttons are pressed at the same time and then released. If the first operation is unsuccessful, repeat the operation several times until above screen prompt appears.
3. Manual calibration process
- 49
- WWW.DIGITALKHODRO.COM
- 021 62 99 92 92

- (a) After entering the manual calibration screen in the previous step, it is necessary to manually calibrate the front, right, rear and left views. Front view calibration operation is taken as an example:
- (1) Manually click "front" view (red frame) of panorama view on right side, and 5 square color lumps in the single side view can be seen. The selected color lump is black and unselected color lump is white.



- (2) Manually click to select the color lump, and perform adjustment by up, down, left and right buttons (red frame). Adjust the center of color lump to the focus of two triangles, and click "√" after completing to save.

Caution:

It is necessary to adjust the corresponding red triangle focus for front and rear views, and green triangle focus for left and right views.



- (3) According to the previous step, make 5 color lumps correspond to the 5 different triangle focus in illustration respectively, thus the calibration operation of "front" view is completed. Then, perform calibrations for "left", "right" and "rear" views in accordance with the procedures above.
- (4) After calibration of 4 directions are completed, it is necessary to observe if panoramic view screen on right side is displayed smoothly without misalignment, which can be determined by lines on calibration cloth. If the line is straight without any misalignment or twist, it is determined that the calibration is OK.
- (5) After calibration is confirmed, click "EXIT" button to exit, then select "√" in the pop-up dialog box to complete the whole calibration operation.



4. Calibration environment requirement

49

- (a) Site requirement
- Calibration site size: About 5.6 m in width and 8.4 m in length, which can accommodate the vehicle driving and calibration cloth laying.
- (b) Ground flatness and calibration cloth laying requirement:
- To ensure the calibration effect, calibration site requires the ground as flat as possible, and calibration cloth has no any obvious bumps after laying.
 - When laying a calibration cloth, pay attention that it is fully unfolded and laid smoothly, and each piece should be corresponded according to requirement.
- (c) Light condition
- There is no special requirement for light environment of calibration site. Make sure each positioning triangle and its focus can be clearly seen during calibration.

(d) Calibration cloth storage

- Calibration cloth should be rolled up smoothly (with left and right sides separated) after use for safekeeping.

Caution:

If calibration cloth is wet, please dry it and then roll it up. Avoid wrinkles during rolling, so as not to affect the subsequent use.


5. Calibration cloth drawing

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران






Removal & Installation

Front Radar Sensor

Removal

Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing front radar sensor.
 - Operate carefully to avoid damaging front radar sensor, when removing front radar sensor.
 - Install connectors in place when installing front radar sensor.
 - Check front radar system for proper operation, after installing front radar sensor.
 - When installing front radar sensor, align the boss at end of front radar sensor with the slot on front bumper assembly, and then firmly install front radar sensor.
1. Turn off all electrical equipment and the ENGINE START STOP switch.
 2. Disconnect the negative battery cable.
 3. Remove the front bumper assembly ([See page 61-6](#)).
 4. Disconnect the front radar sensor connectors.



5. Remove the front radar sensor.

Installation شرکت دیجیتال خودرو سامانه (مسئول بود) Installation is in the reverse order of removal.


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Rear Radar Sensor

Removal

Caution:

- Install connectors in place when installing rear radar sensor.
 - Check reversing radar system for proper operation, after installing rear radar sensor.
 - Be sure to wear necessary safety equipment to prevent accidents, when removing rear radar sensor.
 - Operate carefully to avoid damaging rear radar sensor, when removing rear radar sensor.
1. Turn off all electrical equipment and the ENGINE START STOP switch.
 2. Disconnect the negative battery cable.
 3. Remove the rear bumper assembly (See page 61-6).
 4. Disconnect the rear radar sensor connectors.



5. Remove the rear radar sensor.

Installation

Installation is in the reverse order of removal.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Front Camera Assembly


Removal

Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing front camera assembly.
 - Appropriate force should be applied when removing front camera assembly. Be careful not to operate roughly.
1. Turn off all electrical equipment and the ENGINE START STOP switch.
 2. Disconnect the negative battery cable.
 3. Remove the front bumper assembly (See page 61-6).
 4. Disconnect the front camera connector.
 5. Using an interior crow plate, pry off fixing clips from front camera wire harness assembly.



6. Remove 2 fixing screws from front camera.



7. Remove the front camera assembly.

Installation


Installation is in the reverse order of removal.

Rear Camera Assembly


Removal

Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing rear camera assembly.
 - Appropriate force should be applied when removing rear camera assembly. Be careful not to operate roughly.
1. Turn off all electrical equipment and the ENGINE START STOP switch.
 2. Disconnect the negative battery cable.
 3. Remove the back door lower protector assembly.
 4. Disconnect the rear camera connector.



5. Reach your hand to the metal plate of back door to take out the camera.



Installation

Installation is in the reverse order of removal.

Left/Right Camera

Removal

Hint:

As left/right camera is installed inside the outside rear view mirror assembly, it must be replaced together with outside rear view mirror assembly when damaged.

Caution:

- Install connector in place and tighten fixing nuts to the specified torque, when installing the outside rear view mirror assembly.
 - Make sure the outside rear view mirror assembly can move smoothly, flexibly and reliably after installing.
 - After installing outside rear view mirror assembly, it is necessary to perform panoramic image calibration.
1. Remove the outside rear view mirror assembly.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Reversing Radar Module

Removal

Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing reversing radar control module assembly.
 - Appropriate force should be applied when removing reversing radar control module assembly. Be careful not to operate roughly.
 - Tighten fixing bolts to the specified torque, when installing reversing radar control module assembly.
 - Install connector in place when installing reversing radar control module assembly.
 - Check reversing radar system for proper operation, after installing reversing radar control module assembly.
1. Turn off all electrical equipment and the ENGINE START STOP switch.
 2. Disconnect the negative battery cable.
 3. Remove the luggage compartment left wheel house assembly.
 4. Disconnect the reversing radar module connector.



5. Remove 2 fixing bolts from reversing radar control module assembly.



6. Remove the reversing radar module.

Installation


Installation is in the reverse order of removal.

Panoramic Control System Module

Removal

Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing panoramic control system module assembly.
 - Appropriate force should be applied, when removing panoramic control system module assembly. Be careful not to operate roughly.
 - Tighten fixing bolts to the specified torque, when installing panoramic view monitor control module assembly.
 - Install connector in place when installing panoramic view monitor control module assembly.
 - Check reversing radar system for proper operation, after installing panoramic view monitor control module assembly.
- Turn off all electrical equipment and the ENGINE START STOP switch.
 - Disconnect the negative battery cable.
 - Remove the glove box assembly ([See page 58-13](#)).
 - Remove the right soundproof board assembly.
 - Disconnect the panoramic view monitor control module connector.
 - Remove 2 fixing bolts and 1 fixing nut from panoramic view monitor control module.
 - Remove the panoramic view monitor control module.



دigiتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

- Remove the panoramic view monitor control module.

Installation

Installation is in the reverse order of removal.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

