


BLIND SPOT DETECTION SYSTEM

| | | | |
|--------------------------------------|---------|-----------------------------|---------|
| GENERAL INFORMATION | 29 - 2 | B1A40-15 | 29 - 13 |
| System Overview | 29 - 2 | B1A41-11 | 29 - 13 |
| Description | 29 - 2 | B1A41-15 | 29 - 13 |
| System Principle | 29 - 2 | B1A49-11 | 29 - 16 |
| System Function | 29 - 3 | B1A49-15 | 29 - 16 |
| Component Operation Description | 29 - 5 | B1A4A-11 | 29 - 16 |
| Tools | 29 - 6 | B1A4A-15 | 29 - 16 |
| Fasteners Torque List | 29 - 6 | U0146 - 87 | 29 - 18 |
| DIAGNOSIS & TESTING | 29 - 7 | U0146 - 87 | 29 - 18 |
| Problem Symptoms Table | 29 - 7 | U0100-87 | 29 - 18 |
| Blind Spot Detection Module Terminal | | U0101-87 | 29 - 18 |
| Definition | 29 - 8 | U1300-55 | 29 - 18 |
| Main Blind Spot Detection | 29 - 8 | U0140-87 | 29 - 18 |
| Sub Blind Spot Detection | 29 - 9 | U0129-87 | 29 - 18 |
| DTC Confirmation Procedure | 29 - 9 | U0126-87 | 29 - 18 |
| Diagnostic Help | 29 - 10 | U0418-81 | 29 - 18 |
| Intermittent DTC Troubleshooting | 29 - 10 | U0428-81 | 29 - 18 |
| Ground Inspection | 29 - 10 | U0422-81 | 29 - 18 |
| Diagnostic Trouble Code (DTC) Chart | 29 - 10 | ON-VEHICLE SERVICE | 29 - 19 |
| DTC Diagnosis Procedure | 29 - 11 | Blind Spot Detection Module | 29 - 19 |
| B1A44-16 | 29 - 11 | Removal | 29 - 19 |
| B1A44-17 | 29 - 11 | Installation | 29 - 19 |
| B1A40-11 | 29 - 13 | | |




شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

GENERAL INFORMATION

System Overview

Description



IS0010001


| | | | |
|---|-----------------------------------|---|----------------------------------|
| 1 | Left LED Light | 2 | Hyperscreen |
| 3 | Right LED Light | 4 | Left Blind Spot Detection Module |
| 5 | Right Blind Spot Detection Module | 6 | |

System Principle


Blind spot detection (SBD), door open collision warning system (DOW) and rear approach warning system (RCW) are turned on/off by audio head unit. Main blind spot detection radar/sub blind spot detection radar collects wheel speed signal, door open signal, gear signal, turn signal light signal and ENGINE START STOP switch status signal through CAN line. Outside rear view mirror LED indicator and rear door LED indicator operate and instrument cluster displays relevant warning information through data requirements analysis.

System Function

Blind Spot Detection (BSD)/Lane Change Assist (LCA)




Door Open Collision Warning System (DOW)



When the vehicle is stationary, blind spot detection detects that there are approaching vehicles on left and right sides and the door is opened, door open collision warning system will give an alarm to remind the driver/occupant to pay attention to the vehicle from rear side when exiting the vehicle to avoid collision.

29 - BLIND SPOT DETECTION SYSTEM


Rear Cross Traffic Alert (RCTA)



IS0050

When reversing (shift lever is in R), blind spot detection detects that there are approaching vehicles on left and right sides, it sends the information to driver to remind the driver to pay attention to the vehicle from rear side to avoid collision.

Rear Approach Warning System (RCW)



IS0060

When driving, blind spot detection detects that there is a rapid approach in the rear of vehicle and there is a danger of rear collision with this vehicle, it sends the information to driver to remind the driver of this vehicle and following vehicle to avoid collision.



Component Operation Description

Main/Sub Blind Spot Detection Radar

Blind spot detection uses 77 GHz microwave radar technology to detect through the principle of ultrasonic reflection. Main/sub blind spot detection radar sends out ultrasonic and receive back wave from obstacle,

control module calculates obstacle position and distance according to ultrasonic distance measuring principle, and sends data to display terminal to remind.

Tools

| Tool Name | Tool Drawing |
|-----------------------------|---|
| X-431 PAD Diagnostic Tester |  RCH0001006 |
| Digital Multimeter |  RCH0002006 |

Fasteners Torque List

| Item | Tightening Torque |
|--|-------------------|
| Main Blind Spot Detection Radar Fixing Nut | 3.5 ± 0.5 N·m |
| Sub Blind Spot Detection Radar Fixing Nut | 3.5 ± 0.5 N·m |

DIAGNOSIS & TESTING

Problem Symptoms Table

Hint:


Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair or adjust faulty components, or replace as necessary.

| Symptom | Possible Cause |
|---|---|
| Blind spot detection (BSD) malfunction indicator comes on | Fuse |
| | Wire harness fault |
| | Main/sub blind spot detection radar |
| Blind spot detection (BSD) operates abnormally | Main/sub blind spot detection radar |
| | Main/sub blind spot detection radar is obstructed or shielded |
| CAN network fault | Fuse |
| | Wire harness fault |
| | Central gateway (CGW) |
| | Main/sub blind spot detection radar |




Blind Spot Detection Module Terminal Definition

Main Blind Spot Detection



IS0070

| PIN | Description | PIN | Description |
|-----|-------------------|-----|----------------------------|
| 1 | \ | 6 | \ |
| 2 | LOW Warning Light | 7 | CCAN-H |
| 3 | CCAN-L | 8 | Left Side Indicator Signal |
| 4 | Internal CAN-H | 9 | Ground |
| 5 | KL30 | 10 | Internal CAN-L |

Sub Blind Spot Detection**B-082****B**

شرکت دیجیتال خودرو سامانه (مسئولیت محدود

IS0080

| PIN | Description | PIN | Description |
|-----|-----------------------------|-----|-------------------|
| 1 | \ | 6 | \ |
| 2 | \ | 7 | LOW Warning Light |
| 3 | Right Side Indicator Signal | 8 | \ |
| 4 | Internal CAN-H | 9 | Ground |
| 5 | KL30 | 10 | Internal CAN-L |

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing following procedures.

1. Turn ENGINE START STOP switch to LOCK.
2. Connect diagnostic tester (the latest software) to diagnostic interface.
3. Connect diagnostic tester (the latest software) to diagnostic interface.
4. Use the diagnostic tester to record and clear DTCs stored in the blind spot detection system.
5. Turn ENGINE START STOP switch to LOCK and wait for a few seconds.
6. Turn ENGINE START STOP switch to ON, and then select read DTC.
7. If DTC is detected, it indicates current malfunction. Go to inspection procedure - Step 1.
8. If no DTC is detected, malfunction indicated by the DTC is intermittent.

Diagnostic Help

1. Connect diagnostic tester X-431 3G (the latest software) to Data Link Connector (DLC), and make it communicate with vehicle electronic module through data network.
2. Confirm that malfunction is current, and carry out diagnostic test and repair procedures.
3. If Diagnostic Trouble Code (DTC) cannot be cleared, it indicates that there is a current malfunction.
4. Only use a digital multimeter to measure voltage of electronic system.
5. Refer to any Technical Bulletin that may apply to this malfunction.
6. Visually check related wire harness and connector.
7. Check and clean all CD system grounds related to the latest DTCs.
8. If numerous trouble codes are set, refer to circuit diagram and look for any common ground circuit or power supply circuit applied to DTC.

Intermittent DTC Troubleshooting

If malfunction is intermittent, perform the followings:

- Check if connector is loose.
- Check if wire harness is worn, pierced, pinched or partially broken.
- Monitor diagnostic tester (the latest software) data that is related to this circuit.
- Wiggle related wire harnesses and connectors and observe if signal is interrupt in related circuit.
- If possible, try to duplicate the conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggling test.
- Look for broken, bent, protruded or corroded terminals.
- Inspect airbag components and mounting areas for damage, foreign matter, etc. that will cause incorrect signals.
- Check and clean all wire harness connectors and ground parts related to DTC.
- If multiple trouble codes were set, refer to circuit diagrams to look for any common ground circuit or power supply circuit applied to DTC.
- Refer to any Technical Bulletin that may apply to this malfunction.

Ground Inspection

Ground points are very important to the proper operation of circuits. Ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) may increase load resistance. This situation may change the way in which a circuit operates. Circuits are very sensitive to proper grounding. A loose or corroded ground can seriously affect the control circuit. Check the ground points as follows:

1. Remove ground bolt or nut.
2. Check all contact surfaces for tarnish, dirt and rust, etc.
3. Clean as necessary to ensure that contact is in good condition.
4. Reinstall ground bolt or nut securely.
5. Check if any additional accessories interfere with ground circuit.
6. If several wire harnesses are crimped into one ground terminal, check for proper crimp condition. Make sure that all wire harnesses are clean and securely fastened while providing a proper ground path.

Diagnostic Trouble Code (DTC) Chart

| DTC | DTC Definition |
|----------|--|
| B1A40-11 | LED Right Circuit Short to Ground |
| B1A40-15 | LED Right Circuit Short to Battery or Open |

29 - BLIND SPOT DETECTION SYSTEM

| DTC | DTC Definition |
|------------|---|
| B1A41-11 | LED Left Circuit Short to Ground |
| B1A41-15 | LED Left Circuit Short to Battery or Open |
| B1A43-4B | System Over Temperature |
| B1A43-97 | System Environmental Failure |
| B1A44-16 | Battery Voltage - Circuit Voltage Below Threshold |
| B1A44-17 | Battery Voltage - Circuit Voltage Above Threshold |
| B1A45-42 | Slave Internal Memory Failure |
| B1A46-49 | Master Internal Electronic Failure |
| B1A45-49 | Slave Internal Electronic Failure |
| B1A47-87 | Lost Communication With Slave |
| B1A46-42 | Master Internal Memory Failure |
| B1A48-00 | Autocalibration Failure |
| B1A49-11 | DOW Right Circuit Short to Ground |
| B1A49-15 | DOW Right Circuit Short to Battery or Open |
| B1A4A-11 | DOW Left Circuit Short to Ground |
| B1A4A-15 | DOW Left Circuit Short to Battery or Open |
| U0146 - 87 | Lost Communication With CGW |
| U0146 - 87 | Lost Communication With CGW |
| U0100-87 | Lost Communication with EMS |
| U0101-87 | Lost Communication with TCU |
| U1300-55 | Central Configuration - Not Configured |
| U0140-87 | Lost Communication with BCM |
| U0129-87 | Lost Communication With Brake System Control Module |
| U0126-87 | Lost Communication with SAM |
| U0418-81 | Invalid Data Received from BSM-Invalid Serial Data Received |
| U0428-81 | Invalid Data Received from SAM |
| U0422-81 | Invalid Data Received from BCM-Invalid Serial Data Received |

DTC Diagnosis Procedure

| | | |
|-----|----------|---|
| DTC | B1A44-16 | Battery Voltage - Circuit Voltage Below Threshold |
| DTC | B1A44-17 | Battery Voltage - Circuit Voltage Above Threshold |

| DTC | DTC Definition | Possible Causes |
|----------|---|--|
| B1A44-16 | Battery Voltage - Circuit Voltage Below Threshold | <ul style="list-style-type: none"> Fuse Wire harness damaged Main/sub blind spot detection module |
| B1A44-17 | Battery Voltage - Circuit Voltage Above Threshold | |

DTC Confirmation Procedure

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check fuse

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Check the fuse EF32 (10A).



2 Check wire harness and connector


(a) Turn ENGINE START STOP switch to “OFF”, and disconnect the negative battery cable.

(b) Disconnect main blind spot detection module connector B-078 and sub blind spot detection module connector B-082.

(c) Turn ENGINE START STOP switch to ON.

(d) Using ohm band of multimeter, check the voltage between B-078 (5) and body ground, B-082 (5) and body ground separately.


| Multimeter Connection | Condition | Specified Condition |
|-------------------------|------------------------------|---------------------|
| B-078 (5) - Body ground | ENGINE START STOP switch OFF | Not less than 12 V |
| B-082 (5) - Body ground | | Not less than 12 V |



29 - BLIND SPOT DETECTION SYSTEM

(e) Using ohm band of multimeter, check the resistance between B-078 (9) and body ground, B-082 (9) and body ground separately.

| Multimeter Connection | Condition | Specified Condition |
|-------------------------|------------------------------------|---------------------|
| B-078 (9) - Body ground | ENGINE START STOP switch OFF | $\leq 1 \Omega$ |
| B-082 (9) - Body ground | | $\leq 1 \Omega$ |



NG

Repair or replace faulty wire harness

OK

3 Confirm DTCs again


(a) Connect all the connectors.
 (b) Connect the negative battery cable.
 (c) Use diagnostic tester to clear DTCs.
 (d) Start the engine.
 (e) Check if the same DTCs are still output.

OK

Confirm that system is normal

NG

Replace main blind spot detection module



| | | |
|-----|----------|--|
| DTC | B1A40-11 | LED Right Circuit Short to Ground |
| DTC | B1A40-15 | LED Right Circuit Short to Battery or Open |
| DTC | B1A41-11 | LED Left Circuit Short to Ground |
| DTC | B1A41-15 | LED Left Circuit Short to Battery or Open |

| DTC | DTC Definition | Possible Causes |
|----------|--|--|
| B1A40-11 | LED Right Circuit Short to Ground | |
| B1A40-15 | LED Right Circuit Short to Battery or Open | <ul style="list-style-type: none"> • Wire harness damaged • Power rear view mirror • Main/sub blind spot detection module |
| B1A41-11 | LED Left Circuit Short to Ground | |
| B1A41-15 | LED Left Circuit Short to Battery or Open | |

DTC Confirmation Procedure

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check LED light


Use circuit diagram as a guide to perform the following inspection procedures:

- (a) Turn off all electrical equipment and ENGINE START STOP switch.
- (b) Disconnect the negative battery cable.
- (c) Check if LED light comes on by connecting positive battery cable to terminal 16 of front right power rear view mirror H-003 (terminal 16 of front left rear view mirror F-004) and negative battery cable to terminal 9 according to table below.

| Multimeter Connection | Condition | Specified Condition |
|--|-----------|---------------------|
| F-004 (9) - Battery negative, F-004 (16) - Battery positive | Always | LED light comes on |
| H-003 (9) - Battery negative, H-003 (16) - Battery positive | | LED light comes on |

NG

Replace power mirror/lens



OK


2 Check wire harness and connector

29 - BLIND SPOT DETECTION SYSTEM

(a) Disconnect blind spot detection module connectors B-082, B-078, F-004, H-003 separately.


(b) Using ohm band of multimeter, check for continuity between B-078 (8) - F-004 (16), or B-082 (3) - H-003 (16) separately.

| Multimeter Connection | Condition | Specified Condition |
|------------------------|------------------------------------|---------------------|
| B-078 (8) - F-004 (16) | ENGINE START STOP switch OFF | $\leq 1 \Omega$ |
| B-082 (3) - H-003 (16) | | $\leq 1 \Omega$ |



(c) Using ohm band of multimeter, check for continuity between F-004 (9) or H-003 (9) and body ground separately.

| Multimeter Connection | Condition | Specified Condition |
|-------------------------|------------------------------------|---------------------|
| F-004 (9) - Body ground | ENGINE START STOP switch OFF | $\leq 1 \Omega$ |
| H-004 (9) - Body ground | | $\leq 1 \Omega$ |



NG

Repair or replace faulty wire harness

OK

3

Confirm DTCs again

(a) Connect all the connectors.

(b) Connect the negative battery cable.

(c) Use diagnostic tester to clear DTCs.

(d) Start the engine.

(e) Check if the same DTCs are still output.

OK

Confirm that system is normal

NG

Replace sub blind spot detection module

| | | |
|-----|----------|--|
| DTC | B1A49-11 | DOW Right Circuit Short to Ground |
| DTC | B1A49-15 | DOW Right Circuit Short to Battery or Open |
| DTC | B1A4A-11 | DOW Left Circuit Short to Ground |
| DTC | B1A4A-15 | DOW Left Circuit Short to Battery or Open |

| DTC | DTC Definition | Possible Causes |
|----------|--|--|
| B1A49-11 | DOW Right Circuit Short to Ground | <ul style="list-style-type: none"> Wire harness damaged Rear DOW indicator Main/sub blind spot detection module |
| B1A49-15 | DOW Right Circuit Short to Battery or Open | |
| B1A4A-11 | DOW Left Circuit Short to Ground | |
| B1A4A-15 | DOW Left Circuit Short to Battery or Open | |

DTC Confirmation Procedure

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.


اولین سامانه دیجیتال تعمیر کاران خودرو در ایران
The following diagnosis takes the left DOW as an example.

| | |
|---|-----------------|
| 1 | Check LED light |
|---|-----------------|

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn off all electrical equipment and ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Check if LED light comes on by connecting positive battery cable to terminal 1 of front left power mirror L-005 and negative battery cable to terminal 2 of front right power mirror L-005 according to table below.

| Multimeter Connection | Condition | Specified Condition |
|---|-----------|---------------------|
| L-005 (2) - Battery negative, L-005 (1) - Battery positive | Always | LED light comes on |



IS0140

| | |
|----|-----------------------|
| NG | Replace DOW indicator |
|----|-----------------------|

29 - BLIND SPOT DETECTION SYSTEM


OK

2 Check wire harness and connector

(a) Disconnect connectors B-078 and L-005.

(b) Using ohm band of multimeter, check for continuity between B-078 (2) - L-005 (1), L-005 (1) - L-005 (2) separately.


| Multimeter Connection | Condition | Specified Condition |
|-----------------------|------------------------------------|---------------------|
| B-078 (2) - L-005 (1) | ENGINE START STOP switch OFF | $\leq 1 \Omega$ |
| L-005 (1) - L-005 (2) | | $\leq 1 \Omega$ |



IS0150

(c) Using ohm band of multimeter, check for continuity between L-005 (2) and body ground separately.

| Multimeter Connection | Condition | Specified Condition |
|-------------------------|------------------------------------|---------------------|
| L-005 (2) - Body ground | ENGINE START STOP switch OFF | $\leq 1 \Omega$ |



IS0160

NG

Repair or replace faulty wire harness

OK

3 Confirm DTCs again

(a) Connect all the connectors.

(b) Connect the negative battery cable.

(c) Use diagnostic tester to clear DTCs.

(d) Start the engine.

(e) Check if the same DTCs are still output.

| | |
|----|-------------------------------------|
| OK | Confirm that system is normal |
| NG | Replace blind spot detection module |

| | | |
|-----|------------|---|
| DTC | U0146 - 87 | Lost Communication With CGW |
| DTC | U0146 - 87 | Lost Communication With CGW |
| DTC | U0100-87 | Lost Communication with EMS |
| DTC | U0101-87 | Lost Communication with TCU |
| DTC | U1300-55 | Central Configuration - Not Configured |
| DTC | U0140-87 | Lost Communication with BCM |
| DTC | U0129-87 | Lost Communication With Brake System Control Module |
| DTC | U0126-87 | Lost Communication with SAM |
| DTC | U0418-81 | Invalid Data Received from BSM-Invalid Serial Data Received |
| DTC | U0428-81 | Invalid Data Received from SAM |
| DTC | U0422-81 | Invalid Data Received from BCM-Invalid Serial Data Received |

DTC Confirmation Procedure

Refer to CAN communication system



ON-VEHICLE SERVICE

Blind Spot Detection Module

Removal

WARNING


- Be sure to wear safety equipment to prevent accidents, when removing blind spot detection module.
- Operate carefully to prevent damage to blind spot detection module, when removing blind spot detection module.

- Turn off all electrical equipment and ENGINE START STOP switch.
- Disconnect the negative battery cable for more than 1 minute.
- Remove the rear bumper assembly.
- Remove the main blind spot detection radar module.

- Disconnect main blind spot detection radar module connector (1), remove 3 fixing screws (arrow) from main blind spot detection radar module.

Tightening Torque

$3.5 \pm 0.5 \text{ N m}$




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

- Disconnect sub blind spot detection radar module connector (arrow), remove 3 fixing screws from sub blind spot detection radar module.

Tightening Torque

$3.5 \pm 0.5 \text{ N m}$



Installation

CAUTION

- Install connector in place, when installing blind spot detection module.
- Check blind spot detection module system for proper operation, after installing blind spot detection module.
- When sheet metal paint operation is performed on the rear bumper, there should not be a sudden change in the thickness of rear bumper. Dielectric constant of paint < 100 : Thickness of paint is less than 15um, weight of metal component is about 7% dielectric constant of paint < 50 (Thickness of paint is less than 45 um)

1. Installation is in the reverse order of removal.

دجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

