

|     |          |   |
|-----|----------|---|
| DTC | U0100-87 | Lost Communication With EMS   |
| DTC | U0101-87 | Lost Communication With TCU   |
| DTC | U0245-87 | Lost Communication With RRM   |
| DTC | U0129-87 | Lost Communication With Brake System Control Module -Missing Message      |
| DTC | U0131-87 | Lost Communication With Electronic Power Steering Module -Missing Message |
| DTC | U0151-87 | Lost Communication With Air Bag Module - Missing Message                  |
| DTC | U0140-87 | Lost Communication With Body Control Module - Missing Message             |
| DTC | U0214-87 | Lost Communication With Passive Entry Passive Start Unit -Missing Message |
| DTC | U0164-87 | Lost Communication With Climate Module - Missing Message                  |
| DTC | U0141-87 | Lost Communication With RADAR-Missing Message                             |
| DTC | U0142-87 | Lost Communication With AVM-Missing Message                               |
| DTC | U1157-87 | Lost Communication With Air Bag Module - Missing Message                  |
| DTC | U0230-87 | Lost Communication With PLG-Missing Message                               |
| DTC | U1162-87 | Lost Communication With FCM-Missing Message                               |
| DTC | U1163-87 | Lost Communication With FRM-Missing Message                               |
| DTC | U1193-87 | Lost Communication With EGS-Missing Message                               |
| DTC | U1190-87 | Lost Communication with ESCL  |
| DTC | U1189-87 | Lost Communication With MFS-Missing Message                               |


|     |          |   |
|-----|----------|---|
| DTC | U1300-55 | Software Configuration Error-Not Configured |
|-----|----------|---|



Refer to CAN communication system

## Matching learning

### Write software configuration information


1. Click "ICM (Instrument Cluster Module)"
2. Click "Special Function".
3. Click "Write Software Configuration Information".







## Write software configuration information

1. Click "ICM (Instrument Cluster Module)".
2. Click "Special Function".
3. Click "Vehicle Maintenance Function Reset".





## Removal & Installation

### Instrument Cluster (3.5 inch/7 inch color/7 inch combined) (If equipped)

#### Removal

##### Warning:

- Be sure to wear necessary safety equipment to prevent accidents, when removing instrument cluster.
- Appropriate force should be applied, when removing combination cluster. Be careful not to operate roughly.
- When removing the instrument cluster, handle it with care, so as to avoid bump caused by meter needle and dial looseness or deviation to initial position.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Adjust steering column to lowest position.
4. Gently shake the front cover of instrument and pull it out in the direction of front cover of instrument cluster.




5. Remove 4 fixing screws from instrument cluster trim frame.



6. Shake instrument cluster trim frame gently to pull it in a direction perpendicular to the surface of display.

7. Remove 2 fixing screws from instrument cluster. Pull out instrument cluster in perpendicular direction until clips return to stopper groove.  
**Torque:  $1.5 \pm 0.5 \text{ N}\cdot\text{m}$**



8. Disconnect the combination cluster connector and remove combination cluster.

#### Installation

Installation is in the reverse order of removal.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## Instrument Cluster (12.3 inch)

### Removal

#### Warning:

- Be sure to wear necessary safety equipment to prevent accidents, when removing instrument cluster.
- Appropriate force should be applied, when removing combination cluster. Be careful not to operate roughly.
- When removing the instrument cluster, handle it with care, so as to avoid bump caused by meter needle and dial looseness or deviation to initial position.

- Turn off all electrical equipment and ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Adjust steering column to lowest position.
- Gently shake the front cover of instrument and pull it out in the direction of front cover of instrument cluster.



- Remove 4 fixing screws from instrument cluster trim frame.




- Shake instrument cluster trim frame gently to pull it in a direction perpendicular to the surface of display.



- Remove 4 fixing screws from instrument cluster and pull out it with force in the vertical direction until the clip moves out of stopper groove.

**Torque:  $1.5 \pm 0.5 \text{ N}\cdot\text{m}$**



8. Disconnect the combination cluster connector and remove combination cluster.

**Installation**

Installation is in the reverse order of removal.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# AUDIO AND ENTERTAINMENT SYSTEM

|                                     |       |                                    |       |       |
|-------------------------------------|-------|------------------------------------|-------|-------|
| <b>GENERAL INFORMATION</b>          |       |                                    |       | 48-24 |
| Overview                            | 48-3  | B1842-19                           |       | 48-24 |
| Description                         | 48-3  | B1844-04                           |       | 48-24 |
| Inspection                          | 48-4  | B1845-04                           |       | 48-24 |
| Specifications                      | 48-5  | B1845-04                           |       | 48-24 |
| Tools                               | 48-5  |                                    |       |       |
| <b>DIAGNOSIS &amp; TESTING</b>      | 48-6  | <b>ON-VEHICLE SERVICE</b>          | 48-26 |       |
| <b>Diagnostic Content</b>           | 48-6  | <b>Audio Head Unit Display</b>     | 48-26 |       |
| Problem Symptoms Table              | 48-6  | Removal                            |       | 48-26 |
| Diagnosis Tools                     | 48-6  | Installation                       |       | 48-26 |
| Audio and Entertainment System      |       | <b>No Disc DVD/Audio Head Unit</b> | 48-27 |       |
| Controller Terminal List            | 48-8  | Removal                            |       | 48-27 |
| Diagnosis Procedure                 | 48-9  | Inspection                         |       | 48-27 |
| Diagnostic Trouble Code (DTC) Chart | 48-11 | Installation                       |       | 48-27 |
| <b>B1800-16</b>                     | 48-12 | <b>Door Speaker</b>                | 48-28 |       |
| <b>B1800-17</b>                     | 48-12 | Removal                            |       | 48-28 |
| <b>B1810-00</b>                     | 48-16 | Inspection                         |       | 48-28 |
| <b>B1811-00</b>                     | 48-18 | Installation                       |       | 48-28 |
| <b>B1814-00</b>                     | 48-22 | <b>Tweeter</b>                     | 48-29 |       |
| <b>B1814-00</b>                     | 48-22 | Removal                            |       | 48-29 |
| <b>B1830-04</b>                     | 48-24 | Inspection                         |       | 48-29 |
| <b>B1832-04</b>                     | 48-24 | Installation                       |       | 48-29 |
| <b>B1835-04</b>                     | 48-24 | <b>Combined Antenna</b>            | 48-30 |       |
| <b>B1840-4B</b>                     | 48-24 | Removal                            |       | 48-30 |
| <b>B1841-19</b>                     | 48-24 | Installation                       |       | 48-30 |
|                                     |       | <b>Multi-function Interface</b>    | 48-31 |       |
|                                     |       | Removal                            |       | 48-31 |
|                                     |       | Installation                       |       | 48-32 |

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## GENERAL INFORMATION

### Overview

### Description



|                                    |                                |
|------------------------------------|--------------------------------|
| 1 - Multi-function Button Assembly | 2 - Audio Head Unit Display    |
| 3 - Multi-function Interface       | 4 - Backup Power Supply        |
| 5 - Front Left Woofer Assembly     | 6 - Rear Left Woofer Assembly  |
| 7 - Left Tweeter Assembly          | 8 - Rear Right Woofer Assembly |

9 - Front Right Woofer Assembly

10 - Front Right Tweeter Assembly

Audio system mainly consists of no disc DVD/audio head unit (if equipped), speakers and antenna. No disc DVD mainly consists of no disc DVD head unit, center control panel, multi-function interface.

## Inspection

### Hint:

If some functions of system are found failure before repairing, please read the instruction carefully, and then check the table below, which will help you to clear DTC.

| Current Status     | Symptom  | Possible Cause and Solution   |
|--------------------|--|---|
| General condition  | Head unit operates, but has no sound or sound is very low.                   | Turn up the volume. Check setting of front and rear, left and right balance for horn.   |
|                    | Navigation volume can not be adjusted  | Stop vehicle, and adjust volume on navigation screen or volume setting screen.  |
|                    | Head unit screen can not be operated   | In some states, operations of screen are not available. End current state, long press the Power button for 10S to restart the system and try to operate the screen again. Or click the [SET] button to restore factory setting in the system setting.   |
|                    | Some functions in air conditioning and setting are not available.            | Some functions related to the vehicle are available only when ENGINE START STOP switch is in ON.  |
| Radio playback     | Poor reception   | Check if antenna is fully deployed, connection is correct (whether negative is grounded). The required radio signal is too weak, please use manual search.  |
|                    | Automatic search can not search a available station                          | When there are several available stations in current range and favorite station is 0, only 40 stations with the strongest signal can be searched. If you have other favorite ones, please manually search and store them.   |
| USB file playback  | There are unplayable files   | The system can not support all formats files. There are many audio and video formats nowadays. Even file formats supported by audio video descriptions may not be supported due to the different encoding formats. Please refer to audio video descriptions, download supported formats and try.                              |
|                    | Volume fluctuates up and down during playback                                | Because there is no uniform standard, the volume can not be handled uniformly, please adjust the volume knob by yourself.   |
|                    | Knocking / noise   | It may be caused when the original file is being recorded or caused by noise. Please confirm if it is a native problem with other players.  |
|                    | USB audio, video, pictures can not be played normally and no prompt is given | Due to large number of USB manufacturers, the file system, supported protocols, etc. are very different, the system can not support all of them. Please try another USB. USB device types supported by the system are defined in [music] section, please use it as a reference.   |
| Music playback     | Bluetooth music name is showed as unknown                                    | The model shows name in accordance with Bluetooth standard, if phone does not comply with the standard, it will be shown as unknown. Please change your phone and try again.  |
| Speech recognition | Inaccurate speech recognition  | Say out voice command words provided by voice recognition system as much as possible and use Mandarin; Try to keep the vehicle quiet, and use voice recognition function in low noise surroundings; Microphone is in dome light position, so if noise is unavoidable, say command out as close to the microphone as possible. |

### Hint:

When checking general malfunctions of audio system, perform inspection at spacious area without obstacle nearby.



## Specifications

### Torque Specifications

| Description                              | Torque (N·m) |
|--|--------------|
| No Disc DVD/Audio Head Unit Fixing Screw | 5 ± 1        |
| Audio Head Unit Display Fixing Screw     | 1.5 ± 0.5    |
| Front Speaker Fixing Screw               | 2 ± 0.5      |
| Rear Speaker Fixing Screw                | 2 ± 0.5      |
| Front Speaker Fixing Screw               | 2 ± 0.5      |
| Combined Antenna Fixing Nut              | 5 ± 1        |

## Tools

### General Tools



# DIAGNOSIS & TESTING

## Diagnostic Content

### Problem Symptoms Table

#### Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

| Symptom   | Suspected Area                            |
|---|---|
| Noise occurs  | Noise source (interference)               |
|   | Tweeter assembly                          |
|   | Instrument cluster                        |
| No disc DVD/audio head unit assembly does not operate     | Center control panel (malfunction)        |
|   | No disc DVD/audio head unit fuse (blown)  |
|   | No disc DVD/audio head unit (malfunction) |
|   | Wire harness and connector (malfunction)  |
| No sound can be heard from speakers                       | System setting (incorrect)                |
|   | Speaker assembly                          |
|   | Center control panel                      |
|   | Wire harness and connector                |
| Radio broadcast signal cannot be received(poor reception) | Center control panel (malfunction)        |
|   | No disc DVD/audio head unit (malfunction) |
|   | Options (interference)                    |
|   | Combined antenna (malfunction)            |
|   | Wire harness and connector                |

#### Hint:

When checking general malfunctions of audio system, perform inspection at spacious area without obstacle nearby.

## Diagnosis Tools

### Diagnostic Tester

When connecting the diagnostic tester:

- Connect diagnostic tester (the latest software) to diagnostic interface for communication with vehicle.
- Diagnostic interface is located on instrument panel lower left protector.
- Diagnostic interface uses a trapezoidal design which can hold 16 terminals.

### Digital Multimeter

When using digital multimeter:

- Troubleshoot electrical malfunctions and wire harness system.
- Look for basic malfunction.
- Measure voltage, current and resistance.

### Diagnostic Help

When using digital multimeter:

1. Connect diagnostic tester (the latest software) to diagnostic interface, and make it communicate with vehicle electronic module through data network.
2. Confirm that malfunction is current, and carry out diagnostic test and repair procedures.
3. If Diagnostic Trouble Code (DTC) cannot be cleared, it indicates that there is a current malfunction.
4. Only use a digital multimeter to measure voltage of electronic system.
5. Refer to any Technical Bulletin that may apply to this malfunction.
6. Visually check related wire harness and connector.
7. Check and clean all audio entertainment system grounds related to the latest DTC.

8. If multiple trouble codes were set, use circuit diagrams and look for any common ground circuit or power supply circuit applied to DTC.

### Intermittent DTC Troubleshooting

#### Intermittent DTC Troubleshooting

- If malfunction is intermittent, perform the followings:
- Check if connector is loose.
- Check if wire harness is worn, pierced, pinched or partially broken.
- Wiggle related wire harness and connector and observe if signal in related circuit is interrupted.
- If possible, try to duplicate the conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggle test.
- Look for broken, bent, protruded or corroded terminals.
- Inspect the mounting areas of audio system, wire harness or wire harness connector and so on for damage, foreign matter, etc. that will cause incorrect signals.
- Check and clean all wire harness connectors and ground parts related to DTC.
- Remove the no disc DVD/audio head unit from the malfunctioning vehicle and install it to a new vehicle and perform a test. If this DTC cannot be cleared, no disc DVD/audio head unit is malfunctioning. If DTC can be cleared, reinstall no disc DVD/audio head unit to original vehicle.
- If multiple trouble codes were set, refer to circuit diagrams to look for any common ground circuit or power supply circuit applied to DTC.
- Refer to any Technical Bulletin that may apply to this malfunction.


### Ground Inspection

Groundings are very important to entire circuit system, which are normal or not can seriously affect the entire circuit system. Ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) and oxidation may increase load resistance. This case will seriously affect normal operation of circuit. Check the ground points as follows:

1. Remove ground bolt or nut.
2. Check all contact surfaces for tarnish, dirt and rust, etc.
3. Clean as necessary to ensure that contact is in good condition.
4. Reinstall ground bolt or nut securely.
5. Check if add-on accessories interfere with ground circuit.
6. If several wire harnesses are crimped into one ground terminal, check for proper crimps. Make sure that all wire harnesses are clean and securely fastened while providing a good ground path.

## Audio and Entertainment System Controller Terminal List

### Instrument Panel Wire Harness Connector Terminal List



| Terminal No. | Terminal Definition            | Terminal No. | Terminal Definition              |
|--------------|--------------------------------|--------------|----------------------------------|
| A1           | Rear Right Woofer +            | C5           | Camera Power Supply Ground       |
| A2           | Front Right Woofer +           | C6           | Video Signal -                   |
| A3           | Front Left Woofer +            | C7           | CAN Low Signal                   |
| A4           | Rear Left Woofer +             | C8           | Power Supply Switch (With Reset) |
| A5           | Rear Right Woofer -            | C9           | MIC+ Signal                      |
| A6           | Front Right Woofer -           | C10          | Control Panel Signal Ground      |
| A7           | Front Left Woofer -            | C11          | Camera Power Supply              |
| A8           | Rear Left Woofer -             | C12          | Video Signal +                   |
| B9           | Steering Wheel Button Signal 1 | D1           | Audio Signal Output Positive     |
| B10          | Steering Wheel Button Ground   | D2           | Audio Signal Output Negative     |
| B11          | Steering Wheel Button Signal 2 | D3           | Mute                             |
| B12          | Power Supply Ground            | D4           | -                                |

| Terminal No. | Terminal Definition           | Terminal No. | Terminal Definition |
|--------------|-------------------------------|--------------|---------------------|
| B13          | Trigger Power Supply Signal   | D5           | -                   |
| B14          | -                             | D6           | Volume -            |
| B15          | Operation/Memory Power Supply | D7           | -                   |
| B16          | Night Light Power Supply      | D8           | MIC+                |
| C1           | CAN High Signal               | D9           | MIC-                |
| C2           | Starting Signal               | D10          | -                   |
| C3           | MIC Signal                    | D11          | -                   |
| C4           | Control Panel Signal          | D12          | Volume +            |

## Diagnosis Procedure

### HINT

Use following procedures to troubleshoot the audio system.

**1** Vehicle brought to workshop

### Result

Go to

NEXT

NEXT

**2** Check battery voltage

Check if battery voltage is normal.

OK

Standard voltage: Not less than 12 V.

### Result

Go to

OK

NG

NG

Replace battery

OK

**3** Customer problem analysis

48

### Result

Go to

NEXT

NEXT

**4 Read DTCs**

**Result**

Go to  
DTC output  
No DTC is output

No DTC is output

**Repair according to Problem Symptoms Table**

DTC output

**5 Read DTCs (current DTC and history DTC)**

**Result**

Go to  
Current DTC  
History DTC

History DTC

**Troubleshooting according to intermittent DTC troubleshooting flow**

Current DTC

**6 Repair according to Diagnostic Trouble Code (DTC) Chart**

**Result**

Go to  
NEXT

NEXT

**7 Adjust, repair or replace**

**Result**

48

Go to  
NEXT

NEXT

**8 Conduct test and confirm malfunction has been repaired**

**Result**


Go to  
NEXT

NEXT

End


## Diagnostic Trouble Code (DTC) Chart

| DTC      | DTC Definition                                       |
|----------|--|
| B1800-16 | Power Supply Voltage Below Threshold                 |
| B1800-17 | Power Supply Voltage Above Threshold                 |
| B1810-00 | Front Switch Error                                   |
| B1811-00 | Steering Switch Error                                |
| B1812-00 | Speed Signal Abnormal                                |
| B1813-00 | Speakers Connected Amplifier Failure                 |
| B1814-00 | Tuner Antenna Abnormal                               |
| B1830-04 | Amplifier Failure                                    |
| B1832-04 | Tuner IC R/W Failure                                 |
| B1834-04 | Voice Recognition IC R/W Failure                     |
| B1846-04 | DSP IC R/W Failure                                   |
| B1835-04 | Communication Failure Between MCU and Main Processor |
| B1840-4B | MMI Over Temperature                                 |
| B1841-19 | USB1 Current Above Threshold                         |
| B1842-19 | USB2 Current Above Threshold                         |
| B1844-04 | SOC Communication Error With DESerializer            |
| B1845-04 | SOC Communication Error With TFTMCU                  |



|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>B1800-16</b> | <b>Power Supply Voltage Below Threshold</b> |
| <b>DTC</b> | <b>B1800-17</b> | <b>Power Supply Voltage Above Threshold</b> |

**Circuit Diagram**



AE0002501

**Description**

DTC is stored when stopping high voltage DC output is detected.

| <b>DTC</b> | <b>DTC Definition</b>                | <b>DTC Detection Condition</b>                          | <b>Possible Cause</b>  |
|------------|--------------------------------------|---|--|
| B1800-16   | Power Supply Voltage Below Threshold |   | Charging system<br>Poor connection of no disc DVD/audio head unit ground wire<br>Fuse malfunctions<br>No disc DVD/audio head unit assembly damaged |
| B1800-17   | Power Supply Voltage Above Threshold | ENGINE START STOP switch is in ON and engine is running |  |

**DTC Confirmation Procedure**

Confirm that battery voltage is not less than 12 V before performing following procedures.

48

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software) to diagnostic interface.
- Turn ENGINE START STOP switch to ON.
- Use diagnostic tester to record and clear DTCs stored in DVD system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON, select "Read DTC".
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure - Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent.

**CAUTION**

**Caution:**

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

**Diagnosis Procedure****1 Check the battery**

(a) Check if battery voltage is normal.

**Result**

Go to

OK

NG

**NG****Recharge or replace battery****OK****2 Check battery terminal**

(a) Check if battery terminals are loose or corroded.

**Result**


Go to

OK

NG

**NG****Tighten or replace battery terminal.****OK****3 Check fuse**

(a) Unplug the fuses RF09 (10A), RF26 (10A) and RF07 (10A) from instrument panel fuse and relay box.



(b) Inspect resistance of fuses RF09 (10A), RF26 (10A) and RF07 (10A).

**Result**

Go to


OK

NG

**NG****Replace fuse****OK**

**4 Check instrument panel wire harness**

(a) Turn ENGINE START STOP switch to OFF.




(b) Disconnect the negative battery cable.  
 (c) Disconnect the connector I-052 from the no disc DVD.  
 (d) Connect the negative battery cable.  
 (e) Turn ENGINE START STOP switch to ON.  
 (f) Using a digital multimeter, measure voltage between no disc DVD connector I-036, I-037 and body, and detect it with a 21 W test lamp according to table below.

**OK**

| Multimeter Connection | Condition | Specified Condition |
|-----------------------|-----------|---------------------|
| I-036 (B15) - Ground  | Always    | Not less than 12 V  |
| I-036 (B13) - Ground  | Always    | Not less than 12 V  |
| I-037 (C2) - Ground   | Always    | Not less than 12 V  |

**Result**

| Go to |
|-------|
| OK    |
| NG    |



**48**

(g) Using a digital multimeter, check for continuity between instrument panel fuse and relay box and no disc DVD connectors I-036, I-037 according to the table below.

**OK**

| Multimeter Connection    | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| I-007 (19) - I-037 (C2)  | Always    | $\leq 1 \Omega$     |
| I-007 (34) - I-036 (B15) | Always    | $\leq 1 \Omega$     |
| I-007 (58) - I-036 (B13) | Always    | $\leq 1 \Omega$     |

**NEXT**

**Repair or replace body wire harness and connector**

NEXT

**5 | Reconfirm DTCs**

- (a) Connect all connectors.
- (b) Connect the negative battery cable.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Use diagnostic tester (the latest software) to record and clear DTCs stored in audio entertainment system.
- (e) Turn ENGINE START STOP switch to OFF and wait several seconds.
- (f) Turn ENGINE START STOP switch to ON.
- (g) Use diagnostic tester (the latest software) to read DTCs stored in audio entertainment system again.

**Result**

Go to

OK

NG

OK

System operates normally

NG

Replace no disc DVD

دیجیتال خودرو سامانه

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|            |                 |                           |
|------------|-----------------|---------------------------|
| <b>DTC</b> | <b>B1810-00</b> | <b>Front Switch Error</b> |
|------------|-----------------|---------------------------|

### **Description**

Detect that any front panel button is pressed for more than 30s

| <b>DTC</b> | <b>DTC Definition</b> | <b>DTC Detection Condition</b>    | <b>Possible Cause</b> |
|------------|-----------------------|-----------------------------------|-----------------------|
| B1810-00   | Front Switch Error    | ENGINE START STOP switch is in ON | Center control panel  |

### **DTC Confirmation Procedure**

Confirm that battery voltage is not less than 12 V before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software) to diagnostic interface.
- Turn ENGINE START STOP switch to ON.
- Use diagnostic tester to record and clear DTCs stored in DVD system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON, select "Read DTC".
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure - Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent.

### **CAUTION**

#### **Caution:**

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

### **Diagnosis Procedure**

|          |   |
|----------|---|
| <b>1</b> | <b>Check center control panel operation</b> |
|----------|---|

- (a) Remove center control panel from malfunctioning vehicle. then install it to a new vehicle and perform a test.
- (b) Connect all connectors.
- (c) Connect negative battery cable, and turn ENGINE START STOP switch to ON.
- (d) Check center control panel status.

#### **Result**

|              |
|--------------|
| <b>Go to</b> |
| OK           |
| NG           |

|           |                                     |
|-----------|-------------------------------------|
| <b>NG</b> | <b>Replace center control panel</b> |
|-----------|-------------------------------------|



**48**

|          |                       |
|----------|-----------------------|
| <b>2</b> | <b>Reconfirm DTCs</b> |
|----------|-----------------------|

- (a) Connect all connectors.
- (b) Connect the negative cable to negative battery cable.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Use diagnostic tester (the latest software) to record and clear DTCs stored in audio entertainment system.
- (e) Turn ENGINE START STOP switch to OFF and wait several seconds.
- (f) Turn ENGINE START STOP switch to ON.
- (g) Use diagnostic tester (the latest software) to read DTCs stored in audio entertainment system again.

**Result**

|       |
|-------|
| Go to |
| OK    |
| NG    |



# دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|            |                 |                              |
|------------|-----------------|------------------------------|
| <b>DTC</b> | <b>B1811-00</b> | <b>Steering Switch Error</b> |
|------------|-----------------|------------------------------|

**Circuit Diagram**



AE0003501

**Description**

Detect that any steering wheel line control button is pressed for more than 30s

| <b>DTC</b> | <b>DTC Definition</b> | <b>DTC Detection Condition</b>    | <b>Possible Cause</b>       |
|------------|-----------------------|-----------------------------------|-----------------------------|
| B1811-00   | Steering Switch Error | ENGINE START STOP switch is in ON | Steering wheel quick button |

**DTC Confirmation Procedure**

Confirm that battery voltage is not less than 12V before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software) to diagnostic interface.
- Turn ENGINE START STOP switch to ON.
- Use diagnostic tester to record and clear DTCs stored in audio entertainment system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON, select "Read DTC".
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure - Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent.

**Caution**

**Caution:**


When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

## Diagnosis Procedure

## 1 Check connector wire harness between multi-function button assembly and no disc DVD/audio head unit

(a) Turn ENGINE START STOP switch to OFF.  
 (b) Remove the No Disc DVD/audio head unit.  
 (c) Check connector wire harness between multi-function button assembly and no disc DVD/audio head unit.  
 Using a digital multimeter, check for continuity between connector wire harness of multi-function button assembly and no disc DVD/audio head unit according to the table.

| Multimeter Connection     | Condition                  | Operation Resistance (Ω) |
|---------------------------|----------------------------|--------------------------|
| I-036 (B11) - I-036 (B10) | Press voice                | $\leq 1 \Omega$          |
| I-036 (B10) - I-036 (B9)  | Press volume +             | 1.4 KΩ                   |
| I-036 (B10) - I-036 (B9)  | Press volume -             | 3.6 KΩ                   |
| I-036 (B10) - I-036 (B9)  | Press previous song/answer | $\leq 1 \Omega$          |
| I-036 (B10) - I-036 (B9)  | Press next song/hang up    | 470Ω                     |
| I-036 (B10) - I-036 (B9)  | Press mode                 | 10KΩ                     |



AE0031002

## Result

| Go to |
|-------|
| NG    |
| OK    |

OK

Reconfirm DTCs

NG

## 2 Check multi-function button assembly

(a) Turn ENGINE START STOP switch to OFF.  
 (b) Remove the driver airbag.  
 (c) Check multi-function button assembly.  
 Using a digital multimeter, check for continuity between multi-function button assembly according to the table.

| Multimeter Connection   | Condition                  | Operation Resistance (Ω) |
|-------------------------|----------------------------|--------------------------|
| Terminal 3 - Terminal 6 | Press voice                | $\leq 1 \Omega$          |
| Terminal 3 - Terminal 5 | Press volume +             | 1.4 KΩ                   |
| Terminal 3 - Terminal 5 | Press volume -             | 3.6 KΩ                   |
| Terminal 3 - Terminal 5 | Press previous song/answer | $\leq 1 \Omega$          |
| Terminal 3 - Terminal 5 | Press next song/hang up    | 470Ω                     |
| Terminal 3 - Terminal 5 | Press mode                 | 10KΩ                     |



AE0017002

48

**Result**

| Go to |
|-------|
| OK    |
| NG    |

**NG**

**Replace multi-function button assembly**


**OK**

**3 Check instrument panel wire harness no disc DVD/audio head unit to clock spring**

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect no disc DVD/audio head unit connector I-036 and spiral cable connector I-016.
- Using a digital multimeter, measure resistance between no disc DVD/ audio head unit connector I-052 and spiral cable connector I-016 and check for open according to table below.

**Standard Condition**

| Multimeter Connection    | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| I-016 (11) - I-036 (B11) | Always    | $\leq 1 \Omega$     |
| I-016 (5) - I-036 (B10)  | Always    | $\leq 1 \Omega$     |
| I-016 (10) - I-036 (B9)  | Always    | $\leq 1 \Omega$     |



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

**Result**

| Go to |
|-------|
| OK    |
| NG    |

Repair or replace instrument panel wire harness and connector

**4 Repair the clock spring and reconfirm DTCs**

- (a) Connect all connectors.
- (b) Connect the negative cable to negative battery cable.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Use diagnostic tester (the latest software) to record and clear DTCs stored in audio entertainment system.
- (e) Turn ENGINE START STOP switch to OFF and wait several seconds.
- (f) Turn ENGINE START STOP switch to ON.
- (g) Use diagnostic tester (the latest software) to read DTCs stored in audio entertainment system again.

**Result**

| Go to |
|-------|
| OK    |
| NG    |

System operates normally

Replace no disc DVD/audio head unit

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|            |                 |                               |
|------------|-----------------|-------------------------------|
| <b>DTC</b> | <b>B1814-00</b> | <b>Tuner Antenna Abnormal</b> |
| <b>DTC</b> | <b>B1814-00</b> | <b>Tuner Antenna Abnormal</b> |

#### **Description**

When it detects the tuner antenna is abnormal, current DTC will be stored.

| <b>DTC</b> | <b>DTC Definition</b>  | <b>DTC Detection Condition</b>    | <b>Possible Cause</b>  |
|------------|------------------------|-----------------------------------|--|
| B1814-00   | Tuner Antenna Abnormal | ENGINE START STOP switch is in ON | <ul style="list-style-type: none"> <li>• Antenna assembly (w/ amplifier)</li> <li>• No disc DVD/audio head unit</li> <li>• Wire harness and connector</li> </ul> |

#### **DTC Confirmation Procedure**

Confirm that battery voltage is not less than 12V before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester to Data Link Connector (diagnostic interface).
- Turn ENGINE START STOP switch to ON.
- Use diagnostic tester to record and clear DTCs stored in audio entertainment system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON, select "Read DTC".
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure - Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent.

#### **CAUTION**

##### **Caution:**

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

#### **Diagnosis Procedure**

|          |                          |
|----------|--------------------------|
| <b>1</b> | <b>Check the battery</b> |
|----------|--------------------------|

(a) Check if battery voltage is normal.

##### **Result**

|              |
|--------------|
| <b>Go to</b> |
| OK           |
| NG           |

**NG** **Recharge or replace battery**

**OK**

**48**

|          |                               |
|----------|-------------------------------|
| <b>2</b> | <b>Check battery terminal</b> |
|----------|-------------------------------|

(a) Check if battery terminals are loose or corroded.

##### **Result**

|              |
|--------------|
| <b>Go to</b> |
| OK           |
| NG           |

**NG** **Tighten or replace battery terminal.**

OK

**3 Check combined antenna**

- (a) Remove combined antenna from malfunctioning vehicle, then install it to a new vehicle and perform a test.
- (b) Check the radio operation.

**Result**

Go to

OK

NG

NG

**Replace combined antenna**

OK

**4 Check wire harness and connector of radio and combined antenna**

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the negative battery cable.
- (c) Disconnect no disc DVD/audio head unit connector of instrument panel wire harness.
- (d) Disconnect the combined antenna wire harness connector.
- (e) Using a digital multimeter, check for continuity of antenna connecting cable.

**Result**

Go to

OK

NG

Repair or replace faulty circuit

**5 Reconfirm DTCs**

- (a) Connect all connectors.
- (b) Connect the negative battery cable.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Use diagnostic tester (the latest software) to record and clear DTCs stored in audio entertainment system.
- (e) Turn ENGINE START STOP switch to OFF and wait several seconds.
- (f) Turn ENGINE START STOP switch to ON.
- (g) Use diagnostic tester (the latest software) to read DTCs stored in audio entertainment system again.

**Result**

48

Go to

OK

NG

System operates normally

Replace no disc DVD/audio head unit

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>B1830-04</b> | <b>Amplifier Failure</b>                                    |
| <b>DTC</b> | <b>B1832-04</b> | <b>Tuner IC R/W Failure</b>                                 |
| <b>DTC</b> | <b>B1835-04</b> | <b>Communication Failure Between MCU and Main Processor</b> |
| <b>DTC</b> | <b>B1840-4B</b> | <b>MMI Over Temperature</b>                                 |
| <b>DTC</b> | <b>B1841-19</b> | <b>USB1 Current Above Threshold</b>                         |
| <b>DTC</b> | <b>B1842-19</b> | <b>USB2 Current Above Threshold</b>                         |
| <b>DTC</b> | <b>B1844-04</b> | <b>SOC Communication Error With DESerializer</b>            |
| <b>DTC</b> | <b>B1845-04</b> | <b>SOC Communication Error With TFTMCU</b>                  |
| <b>DTC</b> | <b>B1845-04</b> | <b>SOC Communication Error With TFTMCU</b>                  |

**Description**

| <b>DTC</b> | <b>DTC Definition</b>                                | <b>DTC Detection Condition</b>    | <b>Possible Cause</b>   |
|------------|--|-----------------------------------|---|
| B1830-04   | Amplifier Failure                                    |                                   |   |
| B1832-04   | Tuner IC R/W Failure                                 |                                   |   |
| B1835-04   | Communication Failure Between MCU and Main Processor |                                   |   |
| B1845-04   | SOC Communication Error With TFTMCU                  |                                   |   |
| B1840-4B   | MMI Over Temperature                                 |                                   |   |
| B1841-19   | USB1 Current Above Threshold                         |                                   |   |
| B1842-19   | USB2 Current Above Threshold                         |                                   |   |
| B1844-04   | SOC Communication Error With DESerializer            |                                   |   |
|            |  | ENGINE START STOP switch is in ON | <ul style="list-style-type: none"> <li>• No disc DVD/audio head unit</li> </ul> |

**DTC Confirmation Procedure**

Confirm that battery voltage is not less than 12 V before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software) to diagnostic interface.
- Turn ENGINE START STOP switch to ON.
- Use diagnostic tester to record and clear DTCs stored in audio entertainment system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON, select "Read DTC".
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure - Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent.

**CAUTION****Caution:**

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

**Diagnosis Procedure****1 Check no disc DVD/audio head unit**

- (a) Remove no disc DVD/audio head unit from malfunctioning vehicle, then install it to a new vehicle and perform a test.
- (b) Connect all connectors.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Check if no disc DVD/audio head unit operates normally.

**Result**

Go to

OK

NG

OK

System operates normally

اوین سامانه دی

NG

Replace no disc DVD/audio head unit



## ON-VEHICLE SERVICE


### Audio Head Unit Display

#### Removal

##### WARNING:

- Be sure to wear necessary safety equipment to prevent accidents, when removing audio head unit display.
- Appropriate force should be applied, when removing audio head unit display. Be careful not to operate roughly.
- Try to prevent interior from being scratched, when removing audio head unit display.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the audio head unit display.
  - (a) Using an interior crow plate, pry up the cover (arrow) of audio head unit display.



- (b) Remove 2 fixing screws from audio head unit display and disconnect audio head unit display connector.

#### Tightening torque


$1.5 \pm 0.5 \text{ N}\cdot\text{m}$

### اولین سامانه دیجیتال تعمیرکاران خودرو در ایران Installation

1. Installation is in the reverse order of removal.

#### Caution:

- Operate carefully to prevent other components from being damaged, when installing audio head unit display.
- Make sure to tighten fixing screws to specified torque, when installing audio head unit display.
- Install each connector into place when installing audio head unit display.
- When installing audio head unit display, check no disc DVD for proper operation.




## No Disc DVD/Audio Head Unit

### Removal

#### WARNING:


- After replacing No Disc DVD/Audio Head Unit, it is necessary to write software configuration code.
- Be sure to wear safety equipment to prevent accidents, when removing no disc DVD/audio head unit.
- Appropriate force should be applied, when removing no disc DVD/audio head unit. Be careful not to operate roughly.
- DO NOT scratch interior when removing no disc DVD/audio head unit.

- Turn off all electrical equipment and ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Remove the instrument panel assembly.
- Remove the No Disc DVD/audio head unit.
- Disconnect no disc DVD/audio head unit connector (arrow).



AE0008002

(b) Remove 4 fixing bolts (arrow) from no disc DVD/audio head unit.



AE0009002

#### Tightening torque

$5 \pm 1 \text{ N}\cdot\text{m}$

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

### Inspection

- Check if no disc DVD/audio head unit connector and terminal is deformed or damaged. Replace them if necessary.
- Check if connectors are damaged. Replace them if necessary.
- Check if no disc DVD/audio head unit housing is deformed or damaged. Replace it if necessary.

48

### Installation

- Installation is in the reverse order of removal.

#### Caution:

- Operate carefully to prevent other components from being damaged, when installing no disc DVD/audio head unit.
- Be sure to tighten fixing screws to the specified torque, when installing no disc DVD/audio head unit.
- Install each connector in place, when installing no disc DVD/audio head unit.
- When installing no disc DVD/audio head unit, check no disc DVD for proper operation.

## Door Speaker

### Removal

#### Hint:

- The 4-door procedure is the same as the left.
- Procedures listed below are for left side.

#### Caution:


#### Caution:

- Be sure to wear safety equipment to prevent accidents, when removing door speaker.
- Appropriate force should be applied when removing door speaker. Be careful not to operate roughly.
- DO NOT scratch front door inner protector assembly, when removing door speaker.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the front left door protector assembly.
4. Remove front left door woofer.
  - (a) Disconnect front left door woofer connector (1), and remove 3 fixing screws (arrow) from front left door.

#### Tightening torque

$2 \pm 0.5 \text{ N}\cdot\text{m}$



(b) Remove front left door woofer.


### Inspection

#### اولین سامانه دیجیتال تعمیر کارخانه خودرو و دانش

1. Check front left door woofer.

- (a) Using a digital multimeter, measure resistance of rear left speaker according to table below.

| Multimeter Connection   | Condition             | Specified Condition        |
|-------------------------|-----------------------|----------------------------|
| Terminal 1 - Terminal 2 | At normal temperature | Approximately 4.5 $\Omega$ |



48

- (b) Check cone paper of rear left speaker for damage or deformation. Replace it if necessary.
- (c) Check rear left speaker connector for damage and terminals for bend or poor connection. Replace them if necessary.

### Installation

1. Installation is in the reverse order of removal.

## Tweeter

### Removal

#### HINT:

- Use same procedures for right and left sides.
- Procedures listed below are for left side.

#### Caution:

#### Caution:

- Be sure to wear safety equipment to prevent accidents, when removing tweeter.
- Appropriate force should be applied when removing tweeter. Be careful not to operate roughly.
- DO NOT scratch A-pillar upper protector assembly, when removing door speaker.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the A-pillar upper protector assembly.
4. Remove the left tweeter.
  - (a) Detach 3 fixing clips (arrow) from left tweeter, remove front left door tweeter.



شرکت دیجیتال خودرو سامانه های صوتی (حدود) (b) Remove left tweeter.

### Installation

اولین سامانه های صوتی کارخانه ای ایران

1. Installation is in the reverse order of removal.

## Combined Antenna


### Removal

#### Caution:

- Be sure to wear safety equipment to prevent accidents, when removing combined antenna.
- Appropriate force should be applied when removing combined antenna. Be careful not to operate roughly.
- DO NOT scratch interior removing combined antenna.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the roof.
4. Remove the combined antenna.

- (a) Disconnect the combined antenna connector (arrow).



- (b) Remove the combined antenna fixing nut (1).

#### Tightening torque

$5 \pm 1\text{N}\cdot\text{m}$

- (c) Remove the combined antenna assembly.

#### Caution:

Hold the antenna by hand when tightening the nut, pay attention to the gap between antenna base and metal plate hole, try to keep the gap even, and ensure that there is no obvious deflection after installation.

### Installation

1. Installation is in the reverse order of removal.


## Multi-function Interface

### Removal


#### CAUTION:

- Be sure to wear safety equipment to prevent accidents, when removing multi-function interface.
- Appropriate force should be applied when removing multi-function interface. Be careful not to operate roughly.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the front storage box cover plate.
  - (a) Remove the rubber pad (1) from the front storage box of auxiliary fascia console panel.
  - (b) Pry off the front storage box cover plate assembly (1) with interior crow plate.




AE0014002



AE0014102


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

4. Remove the multi-function interface.
  - (a) Remove USB Panel Assembly.



AE0014202

(b) Disconnect the backup power supply connector (arrow) and 2 USB connectors (1).



## **Installation**

1. Installation is in the reverse order of removal.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# PARKING ASSIST SYSTEM

|   |              |  |              |
|---|--------------|--|--------------|
| <b>PARKING ASSIST SYSTEM</b>  | <b>49-3</b>  | <b>B1A21-13</b>                          | <b>49-34</b> |
| <b>System Overview</b>  | <b>49-3</b>  | <b>B1A21-11</b>                          | <b>49-34</b> |
| System Components Diagram   | 49-3         | <b>B1A21-12</b>                          | <b>49-34</b> |
| System Principle  | 49-6         | <b>B1A22-13</b>                          | <b>49-37</b> |
| System Function   | 49-8         | <b>B1A22-11</b>                          | <b>49-37</b> |
| <b>Components Operation</b>   |              | <b>B1A22-12</b>                          | <b>49-37</b> |
| <b>Description</b>  | <b>49-14</b> | <b>B1A23-13</b>                          | <b>49-40</b> |
| Radar Sensor  | 49-14        | <b>B1A23-11</b>                          | <b>49-40</b> |
| <b>Special Tools and Equipment</b>  | <b>49-14</b> | <b>B1A23-12</b>                          | <b>49-40</b> |
| General Tools   | 49-14        | <b>B1A27-71</b>                          | <b>49-43</b> |
| <b>Tightening Torque List</b>   | <b>49-14</b> | <b>U0140-87</b>                          | <b>49-45</b> |
| Torque  | 49-14        | <b>U015587</b>                           | <b>49-45</b> |
| <b>System Circuit Diagram</b>   | <b>49-15</b> | <b>U0126-87</b>                          | <b>49-45</b> |
| Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System  |              | <b>U0245-87</b>                          | <b>49-45</b> |
| Circuit Diagram   | 49-15        | <b>U0101-87</b>                          | <b>49-45</b> |
| Panoramic View Monitor System (AVM) & Automatic Parking Assist System (APA) & Parking Radar (12-Radar) System Circuit Diagram | 49-17        | <b>U0100-87</b>                          | <b>49-45</b> |
| Diagram   | 49-17        | <b>U0129-87</b>                          | <b>49-45</b> |
| Automatic Parking Assist System (APA) & Parking Radar (12-Radar) System Circuit Diagram                                       |              | <b>U0131-87</b>                          | <b>49-45</b> |
| Diagram   | 49-17        | <b>U0164-87</b>                          | <b>49-45</b> |
| Parking Radar (12-Radar) System Circuit Diagram   |              | <b>U007388</b>                           | <b>49-45</b> |
| Diagram   | 49-17        | <b>U100588</b>                           | <b>49-45</b> |
| <b>Diagnosis Information and Procedures</b>   | <b>49-20</b> | <b>Matching Learning</b>                 | <b>49-45</b> |
| Diagnosis Procedure   | 49-20        | Write Software Configuration Information | 49-45        |
| Problem Symptoms Table  | 49-22        | Panoramic Control System Calibration     | 49-47        |
| Reversing Radar Module (RADAR) Terminal List  | 49-23        | <b>Removal &amp; Installation</b>        | <b>49-51</b> |
| Panoramic View Monitor Control Module (AVM) Terminal List   | 49-24        | Front Radar Sensor                       | 49-51        |
| Diagnostic Trouble Code (DTC) Chart   | 49-25        | Rear Radar Sensor                        | 49-52        |
| <b>B1A25-17</b>   | <b>49-27</b> | Front Camera Assembly                    | 49-53        |
| <b>B1A25-16</b>   | <b>49-27</b> | Rear Camera Assembly                     | 49-54        |
| <b>B1A20-13</b>   | <b>49-30</b> | Left/Right Camera                        | 49-55        |
| <b>B1A20-11</b>   | <b>49-30</b> | Reversing Radar Module                   | 49-56        |
| <b>B1A20-12</b>   | <b>49-30</b> | Panoramic Control System Module          | 49-57        |

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# PARKING ASSIST SYSTEM

## System Overview


### System Components Diagram

#### Parking View Monitor System (RVC)



|   |                          |   |                                |
|---|--------------------------|---|--------------------------------|
| 1 | Audio Head Unit (IHU)    | 5 | Rear Camera Assembly           |
| 2 | Instrument Cluster (ICM) | 6 | Rear Right Radar Sensor        |
| 3 | Rear Left Radar Sensor   | 7 | Reversing Radar Module (RADAR) |
| 4 | Rear Center Radar Sensor |   |                                |


## Panoramic View Monitor System (AVM)



PM0020

|    |   |    |                                |
|----|---|----|--------------------------------|
| 1  | Front Right Side Radar Sensor               | 11 | Panoramic View Monitor Button  |
| 2  | Front Right Radar Sensor                    | 12 | Rear Right Side Radar Sensor   |
| 3  | Front Right Center Radar Sensor             | 13 | Rear Right Radar Sensor        |
| 4  | Front Camera Assembly                       | 14 | Rear Right Center Radar Sensor |
| 5  | Front Left Center Radar Sensor              | 15 | Rear Left Center Radar Sensor  |
| 6  | Front Left Radar Sensor                     | 16 | Rear Camera Assembly           |
| 7  | Front Left Side Radar Sensor                | 17 | Rear Left Radar Sensor         |
| 8  | Panoramic View Monitor Control Module (AVM) | 18 | Rear Left Side Radar Sensor    |
| 9  | Audio Head Unit (IHU)                       | 19 | Left Camera                    |
| 10 | Instrument Cluster (ICM)                    | 20 | Right Camera                   |

## Automatic Parking Assist System (APA)



شرکت اسپریت خودرو (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

PM0030

|    |   |    |                                |
|----|---|----|--------------------------------|
| 1  | Front Right Side Radar Sensor               | 13 | Rear Right Radar Sensor        |
| 2  | Front Right Radar Sensor                    | 14 | Rear Right Center Radar Sensor |
| 3  | Front Right Center Radar Sensor             | 15 | Rear Left Center Radar Sensor  |
| 4  | Front Camera Assembly                       | 16 | Rear Camera Assembly           |
| 5  | Front Left Center Radar Sensor              | 17 | Rear Left Radar Sensor         |
| 6  | Front Left Radar Sensor                     | 18 | Rear Left Side Radar Sensor    |
| 7  | Front Left Side Radar Sensor                | 19 | Left Camera                    |
| 8  | Panoramic View Monitor Control Module (AVM) | 20 | Right Camera                   |
| 9  | Audio Head Unit (IHU)                       | 21 | EPB Module                     |
| 10 | Instrument Cluster (ICM)                    | 22 | Engine Control Module (EMS)    |
| 11 | Automatic Parking Button                    | 23 | Electric Power Steering (EPS)  |
| 12 | Rear Right Side Radar Sensor                | 24 | Body Control Module (BCM)      |

## System Principle

### Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System




The reversing radar module collects reverse gear signals through CAN line, and collects radar signals through hard-wire connection. The audio head unit displays radar information and image screen through data requirements analysis.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

## Panoramic View Monitor System (AVM) &amp; Automatic Parking Assist System (APA) &amp; Parking Radar (12-Radar) System



PM0050

The automatic parking module is integrated in panoramic view monitor control module. The panoramic view monitor control module collects seat belt signals, door open signals, turn signal light signals, vehicle speed signals and gear position signals through CAN line, and collects radar signals and video signals through hard-wire connection. The audio head unit displays radar information and image screen through data requirements analysis. EPB module controls braking and parking (APA models only), electric power steering controls steering (APA models only), and transmission control module controls gear position (APA models only).

## **System Function**

### **Parking View Monitor System (RVC)**

The parking view monitor system uses three ultrasonic sensors to measure the distance from obstacles, and rear camera collects the rear view of vehicle. The audio head unit displays the rear view of vehicle, radar information and vehicle guideline, to remind the driver of the distance between the rear of vehicle and other objects, so as to reduce personal injuries or vehicle damage caused by parking.

Shift the shift lever to R position to enter parking view monitor screen, and display the parking view and vehicle guideline. Vehicle guideline varies depending on steering wheel rotation and it is used for prejudging the wheel's traveling trace during reversing.

#### **Caution:**


- Use the distance as a reference (such as on the hill).
- Vehicle width guideline and predicting line are wider than the actual line.
- Do not scratch the lens when cleaning dirt or snow on the camera surface.
- If tire is replaced with a different size, the displayed predicting line is different from the actual line. Please use the rear view mirror or check and determine the distance to other objects actually.

#### **Warning:**

- When reversing, make sure that back door is firmly closed.
- Never distract your attention from surrounding traffic due to images on display.
- Due to the limited monitoring range, parking view monitor system cannot view the bottom and corners of bumper.
- When reversing, always pay extra attention to surrounding children, small animals and objects, because they cannot always be detected by camera.
- Because rear camera uses wide-angle lens, object distance displayed on parking view monitor is different from the actual distance.
- Do not tap the cameras, as they are precision instruments. Failure to do so may cause malfunction or damage, leading to fire or electric shock.
- Do not spray water around the camera when washing vehicle with high pressure water. Otherwise, water drop may enter camera and condense on the lens, causing malfunction, fire or electric shock.
- Rear camera may enlarge and distort the view, so image on display is different from real object or it cannot reflect the real object accurately, and there is also blind spot and a little delay.
- The parking view monitor is convenient, but it is not a substitute for correct reversing operation. When reversing, be sure to look around to check if the surroundings are safe and reverse slowly.

### **Panoramic View Monitor System (AVM)**

The panoramic view monitor system uses ultrasonic sensors to measure the distance from obstacles, and four ultra wide angle cameras collect the front, rear, left and right view of vehicle, then splicing them into a birds-eye view of vehicle surroundings through image processing algorithm. The audio head unit (IHU) displays the sounding view of vehicle, radar information and vehicle guideline, to remind the driver of the distance between the rear of vehicle and other objects, so as to reduce personal injuries or vehicle damage caused by parking.



When vehicle power supply is turned to ON mode and vehicle speed is less than 20 km/h: Press the panoramic view monitor switch to enter the panoramic view monitor system, press the panoramic view monitor switch again to exit.

When vehicle power supply is turned to ON mode and vehicle speed is less than 20 km/h: Shift the shift lever to R position to enter the panoramic view monitor system, shift the shift lever out from P to exit panoramic view monitor system after a delay of 15 s.

When vehicle power supply is turned to ON mode and vehicle speed is less than 15 km/h (D position): After receiving the parking radar obstacle distance signals, enter the panoramic view monitor system (APA models only), shift the shift lever to N/P position or when there is no obstacle distance information, it will exit panoramic view monitor system after a delay of 15 s.

| Function                                    | Description   |
|---|---|
| Two-dimensional view/three-dimensional view | Click two-dimensional view/three-dimensional view button to switch two-dimensional/three-dimensional view   |
| Front wide view/rear wide view              | Click front wide view/rear wide view button to switch front/rear wide view  |
| Panoramic startup animation                 | When AVM is starting, surround the vehicle all around   |
| Turn signal light activating panoramic      | Click turn signal light activating button, it will enter panoramic view monitor system when left/right turn signal light is turned on                       |
| Steering angle activating panoramic         | Click steering angle activating panoramic button, it will enter panoramic view monitor system during large-angle steering                                   |
| Auto enlarging view                         | Click auto enlarging view button to enter enlarged view automatically according to the obstacle distance  |
| Door opening view                           | Click door opening view button, it will enter front left/front right door opening view when front left/ front right door is opened                          |
| Vehicle guideline                           | Click vehicle guideline display button, it will load static and dynamic vehicle guidelines and wheel track line when entering panoramic view monitor system |
| License plate number setting                | Click license plate number display button to receive the license plate number sent by audio head unit and display it in 3D vehicle icon                     |

**Caution:**



- Do not scratch the lens when cleaning dirt or snow on the camera surface.
- Distance from object seen from panoramic view monitor system is different from the actual distance.
- Make sure that the outside rear view mirrors are unfolded and the back door is firmly closed before using panoramic view monitor system.
- Cameras are installed on front grille, outside rear view mirrors and above the rear license plate. Do not place anything on the camera.
- Panoramic view monitor system has professionally calibrated before leaving factory. Any removal and installation behaviors without permission that cause changes in installation position and angle of camera may affect the function and effect of panoramic view monitor system.
- The panoramic view monitor system provides driving assist, however, object in image does not indicate the actual size and distance from it. There is a slight delay and blind spot in image relative to the actual condition. Therefore, the panoramic view function is not a substitute for driver's operation and judgment. During on, off and use of the function, driver should pay attention to the surroundings to ensure safe driving.

### Automatic Parking Assist System (APA)

The automatic parking assist system uses ultrasonic sensors to measure the distance from obstacles, and four ultra wide angle cameras detect the parking spaces on both sides of road. After confirming the target parking space by audio head unit, assist the driver to automatically park the vehicle in or out of the target parking space.

The types of parking spaces supported by automatic parking assist system include parallel marked parking space, vertical marked parking space, inclined marked parking space, parallel boundary parking space and vertical boundary parking space.

Press the automatic parking switch to enter the automatic parking assist system; press the automatic parking switch again to exit the automatic parking assist system.



#### 1. Automatic parking in

- (a) Turn on the automatic parking assist system and drive vehicle to search for parking space. Before activating the automatic parking assist system, make sure that the driver's seat belt is fastened and the doors, engine hood and back door are all closed; Press the automatic parking switch to turn on the parking screen, when the transmission is in D position, vehicle speed is < 25 km/h, and the lateral distance between driving path and available parking space is about 0.5 m-1.9 m, it begins to search for the parking space;

The automatic parking assist system searches for the right parking space by default. Turn on the left turn signal light if you need to search for the left parking space.

- (b) The automatic parking assist system finds available parking space, and the driver confirms the target parking space.

When the automatic parking assist system finds available parking spaces, the parking space information will be displayed on the parking screen. Please stop at this time;

When there are multiple available parking spaces, the driver can select the desired parking space on the parking screen. If not selected, the nearest parking space will be selected by default.

- (c) Automatic parking in.

After confirming the target parking space, press the automatic parking switch and operate according to prompts on the parking screen to enter the automatic parking process;

During automatic parking in, the driver does not need to perform vehicle operations, but needs to pay attention to the surroundings at all times. Be ready to brake vehicle at any time to ensure that the vehicle can be controlled in dangerous situations.

- (d) Complete parking.

After the vehicle is parked in target parking space, the parking screen prompts that parking is completed. The automatic parking assist system applies electronic parking brake automatically, and shift to P position. At this time, the driver takes over the vehicle operation.

#### 2. Automatic parking space selection

- (a) Turn on automatic parking assist system, and the driver confirms the target parking space.

Before activating the automatic parking assist system, make sure that the driver's seat belt is fastened and the doors, engine hood and back door are all closed;

Press the automatic parking switch while depressing and holding the brake pedal, to turn on the parking screen. Select the automatic parking space selection to enter the automatic parking space selection screen;

The automatic parking assist system provides vertical parking spaces by default. Double click the vehicle icon to switch between horizontal parking space and inclined parking space. Select the type of required parking space, dragging the vehicle icon to determine the parking position, and control the four-axes of vehicle icon to adjust the angle slightly; The right panoramic view screen will display the target parking position, and the driver should ensure the availability of the position.

(b) Automatic parking in.

After confirming the target parking space, press the automatic parking switch and operate according to prompts on the parking screen to enter the automatic parking process;

During automatic parking in, the driver does not need to perform vehicle operations, but needs to pay attention to the surroundings at all times. Be ready to brake vehicle at any time to ensure that the vehicle can be controlled in dangerous situations.

(c) Complete parking.

After the vehicle is parked in target parking space, the parking screen prompts that parking is completed. The automatic parking assist system applies electronic parking brake automatically, and shift to P position. At this time, the driver takes over the vehicle operation.

3. Automatic moving out

(a) Turn on automatic parking assist system, and the driver selects the direction of moving out.

Before activating the automatic parking assist system, make sure that the driver's seat belt is fastened and the doors, engine hood and back door are all closed;

Start the engine, the transmission is in P position, press the automatic parking switch to turn on the parking screen. Select automatic moving out to enter the automatic moving out screen;

The driver can select the direction of moving out by toggling the combination switch (left/right turn signal light).

(b) Automatic moving out.

The parking spaces supported by automatic moving out are only horizontal parking spaces and there are obstacles ahead;

After selecting the direction of moving out, operate according to prompts on the parking screen to enter the automatic moving out process;

During automatic moving out, the driver does not need to perform vehicle operations, but needs to pay attention to the surroundings at all times. Be ready to brake vehicle at any time to ensure that the vehicle can be controlled in dangerous situations.

(c) Complete parking.

After the vehicle is parked in target parking space, the parking screen prompts that parking is completed. The automatic parking assist system applies electronic parking brake automatically, and shift to P position. At this time, the driver takes over the vehicle operation.

**Hint:**

- When searching for a parking space, the distance between vehicle and obstacles that make up the parking space should be 0.5 m-1.9 m. The parking space may not be found if exceeds the range.
- When searching for a parking space, try to keep the vehicle passing through the parking space in a straight line, thus to achieve a better parking space detection effect.
- The rattling sound during parking is the normal operating noise of brake system, and it is no need to worry about it.
- When parking on uneven road, fluctuation may occur in parking speed, and the vehicle may bump. Try to avoid using this system on uneven road.
- The automatic parking assist system only supports the moving out function of parallel parking spaces. Appropriate adjustment space is required in front and rear of vehicle body. The moving out function may not be available when there is abnormal change in the parking space.
- During parking, the steering, braking, accelerator pedal and gear position are controlled by the automatic parking assist system. The driver can operate the brake pedal to control vehicle speed or stop the vehicle. The vehicle can continue to park after release the brake pedal.

**Caution:**

- The automatic parking assist system does not consider the changes in recognized target parking space, which may cause parking failure.
- When using automatic parking assist system, the vehicle may cross or hit the curbs during steering. Therefore, the driver must ensure that the brake intervention can be performed at any time, otherwise it may cause wheel or vehicle damage.
- Target recognition is restricted by the ultrasonic measurement physical laws and camera vision algorithms. The ability to recognize person, animals and various obstacles around the vehicle is limited. In addition, external sound sources or light and shadow may cause interference to the system, resulting in missing recognition or misrecognition of system. Therefore, before confirming the target parking space, the driver is responsible for paying attention to the surroundings of vehicle and confirming the availability of target parking space.

**Warning:**

- The automatic parking assist system only provides assistance to the driver, and cannot operate normally under all driving conditions, weather conditions, traffic or road conditions.
- When using automatic parking assist system, the driver has responsibility to control the vehicle, monitor the system operation and intervene when necessary to avoid danger.


**Reversing Radar (3-Radar) System**

Turn vehicle power supply to ON mode and shift the shift lever to R position to activate the parking radar system; When the radar sensor detects an obstacle, the audio head unit will display the corresponding distance information, and the buzzer sounds. When the radar sensor is faulty, it will sound for 2 s continuously when parking radar system is turned on.

| Distance/cm  | Display Method |             |            | Note             |
|--------------|----------------|-------------|------------|------------------|
|              | Rear Left      | Rear Center | Rear Right |                  |
| ≤ 35         |                |             |            | Continuous sound |
| 40 ≤ L ≤ 60  |                |             |            | Sound at 4Hz     |
| 65 ≤ L ≤ 90  |                |             |            | Sound at 2Hz     |
| 95 ≤ L ≤ 150 |                |             |            | Sound at 1Hz     |

**Parking Radar (12-Radar) System**

Turn vehicle power supply to ON mode and shift the shift lever to R position to activate the parking radar system; When the front/rear radar sensor detects an obstacle, the audio head unit will display the corresponding distance information with sounding; When the side radar sensor detects an obstacle, the audio head unit will display the corresponding distance information without sounding; When the radar sensor is faulty, it will sound for 2 s continuously when parking radar system is turned on (applying parking brake or shifting the transmission gear to P position will block the radar sensor failure alarm sound).



The parking radar system is turned on by default when powered-on for the first time, and the parking radar switch indicator comes on; Press parking radar switch, the parking radar switch indicator goes off and exit the parking radar system; When vehicle speed is  $> 15$  km/h, it will exit parking radar system; When vehicle speed is  $< 15$  km/h, press the parking radar switch to activate the parking radar system again.

| Distance/cm         | Display Method  |            |                   |                    |             |                  | Note             |
|---------------------|-----------------|------------|-------------------|--------------------|-------------|------------------|------------------|
|                     | Front Left Side | Front Left | Front Left Center | Front Right Center | Front Right | Front Right Side |                  |
| $\leq 35$           |                 |            |                   |                    |             |                  | Continuous sound |
| $40 \leq L \leq 60$ |                 |            |                   |                    |             |                  | Sound at 4Hz     |
| $65 \leq L \leq 90$ |                 |            |                   |                    |             |                  | Sound at 2Hz     |

| Distance/cm          | Display Method |           |                  |                   |            |                 | Note             |
|----------------------|----------------|-----------|------------------|-------------------|------------|-----------------|------------------|
|                      | Rear Left Side | Rear Left | Rear Left Center | Rear Right Center | Rear Right | Rear Right Side |                  |
| $\leq 35$            |                |           |                  |                   |            |                 | Continuous sound |
| $40 \leq L \leq 60$  |                |           |                  |                   |            |                 | Sound at 4Hz     |
| $65 \leq L \leq 90$  |                |           |                  |                   |            |                 | Sound at 2Hz     |
| $95 \leq L \leq 150$ |                |           |                  |                   |            |                 | Sound at 1Hz     |

### Caution:

The parking radar system may not operate normally in the following conditions:


- When the vehicle is on a steep slope.
- When driving in jelly-like snow or in rain.
- Low objects such as rocks, etc. cannot be detected.
- Objects that are higher than bumper may not be detected.
- Thin objects such as wires, fences and ropes, etc. cannot be detected.
- When vehicle is equipped with high frequency radio or antenna is in use.
- When radar sensor surface is frozen, it will not detect any obstacle.
- When radar sensor is covered by dirt, snow or mud, it may not detect obstacles.
- Objects that can easily absorb ultrasonic waves such as soft snow, cotton, sponge, etc. cannot be detected.
- The vicinity of vehicle is noisy (such as vehicle horns, motorcycle engines, air brakes of large vehicles, or other loud noises producing ultrasonic waves).
- If multiple radar sensors have detected an obstacle, audio head unit will display distances between each radar sensor and obstacle simultaneously, and sound alarm will be sound from nearest obstacle.
- For obstacles out of the detection range, radar sensors do not give a warning.
- When vehicle is moving, please note that the reversing radar sensor on the other side may get close to other obstacles.

## Components Operation Description

### Radar Sensor



#### Main Function

After radar sensors send out ultrasonic and receive back wave from obstacle, control module calculates obstacle distance ( $S=t \times 340 \div 2$ ) according to ultrasonic distance measuring principle, and sends data to display terminal to display and alarm.



## Special Tools and Equipment

### General Tools

| Tool Name          | Tool Drawing   |
|--------------------|--|
| Digital Multimeter | <br>RCH0002006  |
| Diagnostic Tester  | <br>RCH0001006 |

## Tightening Torque List


### Torque


49

| Description                                 | Tightening Torque                |
|---|----------------------------------|
| Outside Rear View Mirror Fixing Bolt        | $7 \pm 1 \text{ N}\cdot\text{m}$ |
| Reversing Radar Control Module Fixing Bolt  | $5 \pm 1 \text{ N}\cdot\text{m}$ |
| Panoramic Control System Module Fixing Bolt | $7 \pm 1 \text{ N}\cdot\text{m}$ |

## System Circuit Diagram

### Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System Circuit Diagram






Digitalkhodro


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

PM0160

## Panoramic View Monitor System (AVM) & Automatic Parking Assist System (APA) & Parking Radar (12-Radar) System Circuit Diagram







## Diagnosis Information and Procedures

### Diagnosis Procedure

#### Hint:

Use following procedures to troubleshoot the parking assist system.

|   |                             |
|---|-----------------------------|
| 1 | Vehicle brought to workshop |
|---|-----------------------------|

NEXT

|   |                       |
|---|-----------------------|
| 2 | Check battery voltage |
|---|-----------------------|

Check if battery voltage is normal.

OK

Standard voltage: Not less than 12 V.

#### Result

| Result | Go to |
|--------|-------|
| OK     | A     |
| NG     | B     |

|   |                 |
|---|-----------------|
| B | Replace battery |
|---|-----------------|

A

|   |                           |
|---|---------------------------|
| 3 | Customer problem analysis |
|---|---------------------------|

NEXT

|   |           |
|---|-----------|
| 4 | Read DTCs |
|---|-----------|

#### Result

| Result     | Go to |
|------------|-------|
| DTC exists | A     |
| No DTC     | B     |

|   |  |
|---|--|
| B | Repair according to Problem Symptoms Table |
|---|--|

A

49

|   |   |
|---|---|
| 5 | Read DTCs (current DTC and history DTC) |
|---|---|

#### Result

| Result     | Go to |
|------------|-------|
| DTC exists | A     |
| No DTC     | B     |

|   |  |
|---|--|
| B |  |
|---|--|

Troubleshoot according to intermittent  
DTC Troubleshooting

A

6 Repair according to Diagnostic Trouble Code (DTC) Chart

NEXT

7 Adjust, repair or replace

NEXT

8 Conduct test and confirm malfunction has been repaired

NEXT

End

**DTC Confirmation Procedure**

Confirm that battery voltage is not less than 12 V before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software).
- Turn ENGINE START STOP switch to ON.
- Use the diagnostic tester to record and clear DTCs stored in system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON and check the DTCs in system again.
- If DTC is detected, it indicates current malfunction.
- If no DTC is detected, malfunction indicated by the DTC is intermittent.

**Intermittent DTC Troubleshooting**

- Check if connector is loose.
- Check if wire harness is worn, pierced, pinched or partially broken.
- Wiggle related wire harness and connector and observe if signal in related circuit is interrupted.
- If possible, try to duplicate conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggle test.
- Check for broken, bent, protruded or corroded terminals.
- Check and clean all wire harness connectors and ground parts related to DTC.
- If multiple trouble codes were set, refer to circuit diagrams to look for any common ground circuit or power supply circuit applied to DTC.
- Refer to any Technical Bulletin that may apply to this malfunction.

**Ground Inspection**

Ground points are very important to the proper operation of circuits. Ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) may increase load resistance. This situation may change the way in which a circuit works. Circuits are very sensitive to proper grounding. A loose or corroded ground can affect the control circuit. Check the ground points as follows:

- Remove ground bolt or nut.
- Check all contact surfaces for tarnish, dirt and rust, etc.
- Clean as necessary to ensure that contact is in good condition.
- Reinstall ground bolt or nut securely.
- Check if add-on accessories interfere with ground circuit.

- If several wire harnesses are crimped into one ground terminal, check for proper crimps. Make sure that all wire harnesses are clean and securely fastened while providing a good ground path.

### Problem Symptoms Table

#### Parking View Monitor System (RVC) & Reversing Radar (3-Radar) System Circuit Diagram

##### Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

| Symptom  | Suspected Area                 |
|--|--------------------------------|
| Parking view monitor system (RVC) operate abnormally | Radar sensor                   |
|  | Reversing radar module (RADAR) |
|  | Audio head unit                |
|  | Wire harness fault             |
|  | Fuse                           |
| CAN network failure                                  | Fuse                           |
|  | Wire harness fault             |
|  | Central gateway (CGW)          |
|  | Reversing radar module (RADAR) |


#### Panoramic View Monitor System (AVM) & Automatic Parking Assist System (APA) & Parking Radar System(12-Radar) Circuit Diagram

##### Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

| Symptom  | Suspected Area                              |
|--|---|
| Panoramic view monitor system (AVM) operate abnormally | Radar sensor                                |
|  | Panoramic View Monitor Control Module (AVM) |
|  | Audio head unit                             |
|  | Wire harness fault                          |
|  | Fuse  |
|  | Camera                                      |
|  | Auxiliary fascia console switch             |
| CAN network failure                                    | Fuse  |
|  | Wire harness fault                          |
|  | Central gateway (CGW)                       |
|  | Panoramic View Monitor Control Module (AVM) |

## Reversing Radar Module (RADAR) Terminal List




B-082

PM0100

| Terminal No. | Terminal Definition               | Terminal No. | Terminal Definition            |
|--------------|-----------------------------------|--------------|--------------------------------|
| 1            | \                                 | 9            | \                              |
| 2            | \                                 | 10           | \                              |
| 3            | Radar Control Module Power Supply | 11           | Sensor Power Supply            |
| 4            | \                                 | 12           | Sensor Ground                  |
| 5            | CAN2-H                            | 13           | CAN2-L                         |
| 6            | \                                 | 14           | Ground                         |
| 7            | Rear Left Radar Sensor Signal     | 15           | Rear Right Radar Sensor Signal |
| 8            | Rear Center Radar Sensor Signal   | 16           | Ground                         |

**Panoramic View Monitor Control Module (AVM) Terminal List**



**B-005**

PM0110

| Terminal No. | Terminal Definition              | Terminal No. | Terminal Definition                 |
|--------------|----------------------------------|--------------|-------------------------------------|
| 1            | APA Indicator                    | 17           | APA Switch                          |
| 2            | PDC Indicator                    | 18           | PDC Switch                          |
| 3            | Rear Sensor Ground               | 19           | Rear Sensor Power Supply            |
| 4            | Rear Right Side Sensor Signal    | 20           | Rear Left Side Sensor Signal        |
| 5            | Rear Left Sensor Signal          | 21           | Rear Left Center Sensor Signal      |
| 6            | Rear Right Center Sensor Signal  | 22           | Rear Right Sensor Signal            |
| 7            | Front Sensor Ground              | 23           | Front Sensor Power Supply           |
| 8            | Front Right Side Sensor Signal   | 24           | Front Left Side Sensor Power Supply |
| 9            | Front Left Sensor Signal         | 25           | Front Left Center Sensor Signal     |
| 10           | Front Right Center Sensor Signal | 26           | Front Right Sensor Signal           |
| 11           | \                                | 27           | AVM Switch                          |
| 12           | \                                | 28           | \                                   |
| 13           | B CAN-L                          | 29           | B CAN-H                             |
| 14           | C CAN-L                          | 30           | C CAN-H                             |
| 15           | \                                | 31           | IGN                                 |
| 16           | Ground                           | 32           | Power Supply                        |

## Diagnostic Trouble Code (DTC) Chart

| DTC      | DTC Definition  |
|----------|---|
| B1A20-13 | AVM Left Camera LVDS Cable Open                                 |
| B1A21-13 | AVM Rear Camera LVDS Cable Open                                 |
| B1A22-13 | AVM Left Camera LVDS Cable Open                                 |
| B1A23-13 | AVM Right Camera LVDS Cable Open                                |
| B1A20-11 | AVM Front Camera Power Short to Ground                          |
| B1A20-12 | AVM Front Camera Power Short to Battery                         |
| B1A21-11 | AVM Rear Camera Power Short to Ground                           |
| B1A21-12 | AVM Rear Camera Power Short to Battery                          |
| B1A22-11 | AVM Left Camera Power Short to Ground                           |
| B1A22-12 | AVM Left Camera Power Short to Battery                          |
| B1A23-11 | AVM Right Camera Power Short to Ground                          |
| B1A23-12 | AVM Right Camera Power Short to Battery                         |
| B1A24-04 | AVM ECU Trouble   |
| B1A25-17 | Control Module Input Power High                                 |
| B1A25-16 | Control Module Input Power Low                                  |
| B1A26-54 | AVM No Calibration  |
| B1A27-71 | AVM On/Off Switch Mechanical Adhesion                           |
| B1A28-71 | APS On/Off Switch Mechanical Adhesion                           |
| B1A28-96 | APS Function Indicator Light Circuit Failure                    |
| B1A29-71 | PDC On/Off Switch Mechanical Adhesion                           |
| B1A29-96 | PDC Function Indicator Light Circuit Failure                    |
| B1A3009  | Rear Right Side Long Distance Ultrasonic Sensor Hardware Fault  |
| B1A3109  | Rear Right Lateral Ultrasonic Sensor Hardware Fault             |
| B1A3209  | Rear Right Ultrasonic Sensor Hardware Fault                     |
| B1A3309  | Rear Left Ultrasonic Sensor Hardware Fault                      |
| B1A3409  | Rear Left Lateral Ultrasonic Sensor Hardware Fault              |
| B1A3509  | Rear Left Side Long Distance Ultrasonic Sensor Hardware Fault   |
| B1A3609  | Front Right Side Long Distance Ultrasonic Sensor Hardware Fault |
| B1A3709  | Front Right Lateral Ultrasonic Sensor Hardware Fault            |
| B1A3809  | Front Right Ultrasonic Sensor Hardware Fault                    |
| B1A3909  | Front Left Ultrasonic Sensor Hardware Fault                     |
| B1A3A09  | Front Left Lateral Ultrasonic Sensor Hardware Fault             |
| B1A3B09  | Front Left Side Long Distance Ultrasonic Sensor Hardware Fault  |
| B1A3096  | Rear Right Side Long Distance Ultrasonic Sensor Probe Failure   |
| B1A3196  | Rear Right Lateral Ultrasonic Sensor Probe Failure              |
| B1A3296  | Rear Right Ultrasonic Sensor Probe Failure                      |
| B1A3396  | Rear Left Ultrasonic Sensor Probe Failure                       |
| B1A3496  | Rear Left Lateral Ultrasonic Sensor Probe Failure               |
| B1A3596  | Rear Left Side Long Distance Ultrasonic Sensor Probe Failure    |
| B1A3696  | Front Right Side Long Distance Ultrasonic Sensor Probe Failure  |
| B1A3796  | Front Right Lateral Ultrasonic Sensor Probe Failure             |
| B1A3896  | Front Right Ultrasonic Sensor Probe Failure                     |
| B1A3996  | Front Left Ultrasonic Sensor Probe Failure                      |
| B1A3A96  | Front Left Lateral Ultrasonic Sensor Probe Failure              |
| B1A3B96  | Front Left Side Long Distance Ultrasonic Sensor Probe Failure   |
| U0140-87 | Lost Communication With BCM                                     |
| U015587  | Lost Communication With ICM                                     |

| DTC      | DTC Definition                    |
|----------|-----------------------------------|
| U0126-87 | Lost Communication With SAM       |
| U0245-87 | Lost Communication With MMI (RRM) |
| U0101-87 | Lost Communication With TCU       |
| U0100-87 | Lost Communication With EMS       |
| U0129-87 | Lost Communication With ESC       |
| U0131-87 | Lost Communication With EPS       |
| U0164-87 | Lost Communication With CLM       |
| U007388  | Body CAN BusOff Error             |
| U100588  | Chassis CAN BusOff Error          |

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|            |                 |  |
|------------|-----------------|--|
| <b>DTC</b> | <b>B1A25-17</b> | <b>Control Module Input Power High</b> |
|------------|-----------------|--|

|            |                 |                                       |
|------------|-----------------|---------------------------------------|
| <b>DTC</b> | <b>B1A25-16</b> | <b>Control Module Input Power Low</b> |
|------------|-----------------|---------------------------------------|

**Description**

| <b>DTC</b> | <b>DTC Definition</b>           | <b>Possible Cause</b>  |
|------------|---------------------------------|--|
| B1A25-17   | Control Module Input Power High | Battery<br>Panoramic view monitor control module (AVM)<br>Wire harness fault |
| B1A25-16   | Control Module Input Power Low  |  |

**1 Check battery voltage**

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the negative battery cable.
- (c) Check battery voltage with a digital multimeter (not less than 12 V).

**Result**

| <b>Result</b> | <b>Go to</b> |
|---------------|--------------|
| OK            | B            |
| NG            | A            |

**A****Replace battery****B****2 Check charging system**

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Check positive and negative battery cables for broken or damage.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Start the engine.
- (e) Check if voltage of positive and negative battery is normal with a digital multimeter (13.5V-14.8V).

**Result**

| <b>Result</b> | <b>Go to</b> |
|---------------|--------------|
| OK            | B            |
| NG            | A            |


**A****Repair or replace positive and negative cables and alternator****B****49****3 Check AVM module power supply wire harness**

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the AVM connector B-005.
- (c) Turn ENGINE START STOP switch to ON.

(d) Using a digital multimeter, check if the voltage between terminal B-005 (32), (31) and body ground is normal.

**Standard Condition**

| Multimeter Connection    | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| B-005 (32) - Body ground | Always    | Not less than 12 V  |
| B-005 (31) - Body ground | Always    | Not less than 12 V  |



PM0200

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

A

**Repair or replace wire harness**

B


4

**Check AVM module ground circuit**

(a) Turn ENGINE START STOP switch to OFF.  
 (b) Disconnect the AVM connector B-005.  
 (c) Using a digital multimeter, check for continuity between B-005 (16) and body ground to check ground circuit for open.

**Standard Condition**

| Multimeter Connection    | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| B-005 (16) - Body ground | Always    | $\leq 1 \Omega$     |



PM0210


49

(d) Turn ENGINE START STOP switch to ON.

(e) Using voltage band of digital multimeter, measure voltage between B-005 (16) and body ground to check for short to power supply.

**Standard Condition**

| Multimeter Connection    | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| B-005 (16) - Body ground | Always    | 0V                  |



**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

B

Replace AVM module

A

Replace wire harness

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




|     |          |                                 |
|-----|----------|---------------------------------|
| DTC | B1A20-13 | AVM Left Camera LVDS Cable Open |
|-----|----------|---------------------------------|

|     |          |  |
|-----|----------|--|
| DTC | B1A20-11 | AVM Front Camera Power Short to Ground |
|-----|----------|--|

|     |          |   |
|-----|----------|---|
| DTC | B1A20-12 | AVM Front Camera Power Short to Battery |
|-----|----------|---|

Circuit Diagram



49

### Description

| DTC      | DTC Definition                          | Possible Cause   |
|----------|---|--|
| B1A20-13 | AVM Left Camera LVDS Cable Open         |  |
| B1A20-11 | AVM Front Camera Power Short to Ground  | <ul style="list-style-type: none"> <li>• Camera</li> <li>• Wire harness</li> </ul> |
| B1A20-12 | AVM Front Camera Power Short to Battery |  |

1 Replace camera with a new one

(a) Turn ENGINE START STOP switch to OFF.

(b) Replace front camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

**B**

**Replace front camera**

**A**

**2 Check wire harness and connector**

(a) Turn ENGINE START STOP switch to OFF.  
 (b) Disconnect the AVM connector B-009.  
 (c) Disconnect the front camera connector Q-532.

دُخْلَدِيْجِيْتَال

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



(d) Using ohm band of multimeter, check for continuity between B-009 (2-1) and Q-532 (1).

**Standard Condition**


| Multimeter Connection   | Condition | Specified Condition |
|-------------------------|-----------|---------------------|
| B-009 (2-1) - Q-532 (1) | Always    | $\leq 1 \Omega$     |



(e) Using ohm band of multimeter, check for continuity between B-009 (2-2) and Q-532 (2).

**Standard Condition**

| Multimeter Connection   | Condition | Specified Condition |
|-------------------------|-----------|---------------------|
| B-009 (2-2) - Q-532 (2) | Always    | $\leq 1 \Omega$     |



**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |



**Repair or replace wire harness and connector**



49


**3 Check for short to ground in wire harness or connector**

- Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.
- Disconnect the AVM connector B-009.
- Disconnect the front camera connector Q-532.

(d) Using ohm band of multimeter, check for continuity between B-009 (2-1) and body ground, B-009 (2-2) and body ground separately.

**Standard Condition**

| Multimeter Connection     | Condition | Normal Condition |
|---------------------------|-----------|------------------|
| B-009 (2-1) - Body ground | Always    | No continuity    |
| B-009 (2-2) - Body ground | Always    | No continuity    |



PM0250

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

B

Replace AVM module

A

Repair or replace connector or wire harness that is shorted to ground


شرکت دیجیتال خودرو سامانه (مستولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|     |          |  |
|-----|----------|--|
| DTC | B1A21-13 | AVM Rear Camera LVDS Cable Open        |
| DTC | B1A21-11 | AVM Rear Camera Power Short to Ground  |
| DTC | B1A21-12 | AVM Rear Camera Power Short to Battery |

Circuit Diagram



49

### Description

| DTC      | DTC Definition                         | Possible Cause      |
|----------|--|---------------------|
| B1A21-13 | AVM Rear Camera LVDS Cable Open        |                     |
| B1A21-11 | AVM Rear Camera Power Short to Ground  | Camera Wire harness |
| B1A21-12 | AVM Rear Camera Power Short to Battery |                     |

|   |                   |
|---|-------------------|
| 1 | Check rear camera |
|---|-------------------|

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.

(b) Replace rear camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

### Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

B

Replace rear camera


A

### 2 Check wire harness and connector

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.  
 (b) Disconnect the AVM connector B-008.  
 (c) Disconnect the rear camera connector T-010.  
 (d) Using ohm band of multimeter, check for continuity between B-008 (3-1) and T-010 (1), B-008 (3-2) and T-010 (2) separately.

#### Standard Condition

| Multimeter Connection   | Condition | Normal Condition |
|-------------------------|-----------|------------------|
| B-008 (3-1) - T-010 (1) | Always    | $\leq 1 \Omega$  |
| B-008 (3-2) - T-010 (2) | Always    | $\leq 1 \Omega$  |



PM0260

### Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

A

Repair or replace wire harness and connector

B

49


### 3 Check for short to ground in wire harness and connector

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.  
 (b) Disconnect the AVM connector B-008.

(c) Using ohm band of multimeter, check for continuity between B-008 (3-1) and body ground, B-008 (3-2) and body ground separately.


**Standard Condition**

| Multimeter Connection     | Condition | Normal Condition |
|---------------------------|-----------|------------------|
| B-008 (3-1) - Body ground | Always    | $\infty$         |
| B-008 (3-2) - Body ground | Always    | $\infty$         |



**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |



شرکت دیجیتال خودرو سامانه (مسئلیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

|     |          |                                 |
|-----|----------|---------------------------------|
| DTC | B1A22-13 | AVM Left Camera LVDS Cable Open |
|-----|----------|---------------------------------|

|     |          |                                       |
|-----|----------|---------------------------------------|
| DTC | B1A22-11 | AVM Left Camera Power Short to Ground |
|-----|----------|---------------------------------------|

|     |          |  |
|-----|----------|--|
| DTC | B1A22-12 | AVM Left Camera Power Short to Battery |
|-----|----------|--|

Circuit Diagram



### Description

| DTC      | DTC Definition                         | Possible Cause       |
|----------|--|----------------------|
| B1A22-13 | AVM Left Camera LVDS Cable Open        | Wire harness, camera |
| B1A22-11 | AVM Left Camera Power Short to Ground  |                      |
| B1A22-12 | AVM Left Camera Power Short to Battery |                      |

### 1 Check left camera

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.

(b) Replace left camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |




**2 Check for open in wire harness and connector**

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.  
 (b) Disconnect the AVM connector B-007.  
 (c) Disconnect the left camera connector F-005.  
 (d) Using ohm band of multimeter, check for continuity between B-007(4-1) and F-005(1), B-007(4-2) and F-005(2) separately.

**Standard Condition**

| Multimeter Connection   | Condition | Normal Condition |
|-------------------------|-----------|------------------|
| B-007 (4-1) - F-005 (1) | Always    | $\leq 1 \Omega$  |
| B-007 (4-2) - F-005 (2) | Always    | $\leq 1 \Omega$  |



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |



**49**

**3 Check for short to ground in wire harness or connector**

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.  
 (b) Disconnect the AVM connector B-007.

(c) Using ohm band of multimeter, check for continuity between B-007(4-1) and ground, B-007(4-2) and ground separately.

**Standard Condition**

| Multimeter Connection | Condition | Normal Condition |
|-----------------------|-----------|------------------|
| B-007 (4-1) - Ground  | Always    | $\infty$         |
| B-007 (4-2) - Ground  | Always    | $\infty$         |



(B-007)



PM0290

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |



**Repair or replace connector or wire harness that is shorted to ground**



**Replace AVM module**


شرکت دیجیتال خودرو سامانه (مستولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|     |          |   |
|-----|----------|---|
| DTC | B1A23-13 | AVM Right Camera LVDS Cable Open        |
| DTC | B1A23-11 | AVM Right Camera Power Short to Ground  |
| DTC | B1A23-12 | AVM Right Camera Power Short to Battery |

## Circuit Diagram



49

## Description

| DTC      | DTC Definition                          | Possible Cause       |
|----------|---|----------------------|
| B1A23-13 | AVM Right Camera LVDS Cable Open        | Wire harness, camera |
| B1A23-11 | AVM Right Camera Power Short to Ground  |                      |
| B1A23-12 | AVM Right Camera Power Short to Battery |                      |

|   |                    |
|---|--------------------|
| 1 | Check right camera |
|---|--------------------|

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.

(b) Replace right camera with a new one, connect negative battery cable, and turn ENGINE START STOP switch to ON. Start panoramic view monitor system and observe if the camera is working properly.

### Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

B

Replace right camera


A

### 2 Check for open in wire harness and connector

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.  
 (b) Disconnect the AVM connector B-006.  
 (c) Disconnect the right camera connector H-004.  
 (d) Using ohm band of multimeter, check for continuity between B-006 (5-1) and H-004 (1), B-006 (5-2) and H-004 (2) separately.

#### Standard Condition

| Multimeter Connection   | Condition | Normal Condition |
|-------------------------|-----------|------------------|
| B-006 (5-1) - H-004 (1) | Always    | $\leq 1 \Omega$  |
| B-006 (5-2) - H-004 (2) | Always    | $\leq 1 \Omega$  |



### Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

A

Repair or replace wire harness and connector

B

49


### 3 Check for short to ground in wire harness or connector

(a) Turn ENGINE START STOP switch to OFF, disconnect the negative battery cable.  
 (b) Disconnect the AVM connector B-006.

(c) Using ohm band of multimeter, check for continuity between B-006 (5-1) and body ground, B-006 (5-2) and body ground separately.

**Standard Condition**


| Multimeter Connection     | Condition | Normal Condition |
|---------------------------|-----------|------------------|
| B-006 (5-1) - Body ground | Always    | $\infty$         |
| B-006 (5-2) - Body ground | Always    | $\infty$         |



PM0310

**Result**


| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

## DTC B1A27-71 AVM On/Off Switch Mechanical Adhesion

Circuit Diagram



## Description

| DTC      | DTC Definition                        | Possible Cause       |
|----------|---------------------------------------|----------------------|
| B1A27-71 | AVM On/Off Switch Mechanical Adhesion | AVM module<br>Switch |

## 1 Replace AVM switch with a new one

- Turn ENGINE START STOP switch to OFF.
- Remove the old AVM switch.
- Install new switch and perform running test.

## Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

B

Replace AVM switch


A

## 2 Check wire harness for open or short

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the AVM connector B-005.
- Disconnect the auxiliary fascia console switch connector I-048.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, check for continuity between B-005 (27) and I-048 (13) to check circuit for open.

### Standard Condition

| Multimeter Connection   | Condition | Specified Condition |
|-------------------------|-----------|---------------------|
| B-005 (27) - I-048 (13) | Always    | $\leq 1 \Omega$     |




PM0320

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

- Using ohm band of digital multimeter, check for continuity between I-048 (13) and body ground to check instrument panel wire harness for short to ground.

### Standard Condition

| Multimeter Connection    | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| I-048 (13) - Body ground | Always    | No continuity       |




PM0330

49

### Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |





|     |          |                                   |
|-----|----------|-----------------------------------|
| DTC | U0140-87 | Lost Communication With BCM       |
| DTC | U015587  | Lost Communication With ICM       |
| DTC | U0126-87 | Lost Communication With SAM       |
| DTC | U0245-87 | Lost Communication With MMI (RRM) |
| DTC | U0101-87 | Lost Communication With TCU       |
| DTC | U0100-87 | Lost Communication With EMS       |
| DTC | U0129-87 | Lost Communication With ESC       |
| DTC | U0131-87 | Lost Communication With EPS       |
| DTC | U0164-87 | Lost Communication With CLM       |
| DTC | U007388  | Body CAN BusOff Error             |
| DTC | U100588  | Chassis CAN BusOff Error          |

Refer to CAN communication system

## Matching Learning

### Write Software Configuration Information

1. Click "AVM (Around View Monitor Module)".
2. Click "Special Function".
3. Click "Write Software Configuration Information".



## Panoramic Control System Calibration

### Camera Calibration

1. Situations needs to perform camera calibration:
  - When service station removes or installs camera or rear view mirror with camera.
  - When camera position changes due to vehicle accident.
  - After replacing panoramic view monitor system controller.
  - When removing and installing front and rear bumpers.
2. Calibration method:
  - (a) Park vehicle at the fixed location.
  - (b) Lay calibration cloth (front and rear sides) at front and rear of vehicle.


#### Caution:

- "Front center" of calibration cloth corresponds to the front side of vehicle.
- Center line position of calibration cloth should align with the middle position of front and rear of vehicle.



### ولین سامانه دیجیتال تعیین کاران خودرو در ایران

- (c) Unfold calibration cloth (left and right sides) and lay it onto both sides of vehicle.
  - Center line corresponds to front left and right wheel positions.
  - Left and right sides and front and rear sides of calibration cloth should be placed in accordance with single and double arrow marks respectively.



- (d) Entering calibration mode (calibration function activated).
  - (1) With IGN-ON or panoramic view monitor system turned on by pressing AVM switch, press "HOME+NAVI+SET" buttons on the head unit at the same time and then release them, if the operation is valid, audio display will display the screen shown in illustration. "Automatic calibration" is used for production line, and "manual calibration" is used for after-sales calibration.

#### Caution:

The command is valid only when three buttons are pressed at the same time and then released. If the first operation is unsuccessful, repeat the operation several times until above screen prompt appears.

3. Manual calibration process

49

WWW.DIGITALKHODRO.COM

021 62 99 92 92

(a) After entering the manual calibration screen in the previous step, it is necessary to manually calibrate the front, right, rear and left views. Front view calibration operation is taken as an example:

(1) Manually click "front" view (red frame) of panorama view on right side, and 5 square color lumps in the single side view can be seen. The selected color lump is black and unselected color lump is white.



(2) Manually click to select the color lump, and perform adjustment by up, down, left and right buttons (red frame). Adjust the center of color lump to the focus of two triangles, and click "√" after completing to save.

**Caution:**

It is necessary to adjust the corresponding red triangle focus for front and rear views, and green triangle focus for left and right views.



(3) According to the previous step, make 5 color lumps correspond to the 5 different triangle focus in illustration respectively, thus the calibration operation of "front" view is completed. Then, perform calibrations for "left", "right" and "rear" views in accordance with the procedures above.

(4) After calibration of 4 directions are completed, it is necessary to observe if panoramic view screen on right side is displayed smoothly without misalignment, which can be determined by lines on calibration cloth. If the line is straight without any misalignment or twist, it is determined that the calibration is OK.

(5) After calibration is confirmed, click "EXIT" button to exit, then select "√" in the pop-up dialog box to complete the whole calibration operation.



#### 4. Calibration environment requirement

49

(a) Site requirement

- Calibration site size: About 5.6 m in width and 8.4 m in length, which can accommodate the vehicle driving and calibration cloth laying.

(b) Ground flatness and calibration cloth laying requirement:

- To ensure the calibration effect, calibration site requires the ground as flat as possible, and calibration cloth has no any obvious bumps after laying.
- When laying a calibration cloth, pay attention that it is fully unfolded and laid smoothly, and each piece should be corresponded according to requirement.

(c) Light condition

- There is no special requirement for light environment of calibration site. Make sure each positioning triangle and its focus can be clearly seen during calibration.

## (d) Calibration cloth storage

- Calibration cloth should be rolled up smoothly (with left and right sides separated) after use for safekeeping.

**Caution:**

If calibration cloth is wet, please dry it and then roll it up. Avoid wrinkles during rolling, so as not to affect the subsequent use.


## 5. Calibration cloth drawing

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





## Removal & Installation


### Front Radar Sensor

#### Removal

##### Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing front radar sensor.
- Operate carefully to avoid damaging front radar sensor, when removing front radar sensor.
- Install connectors in place when installing front radar sensor.
- Check front radar system for proper operation, after installing front radar sensor.
- When installing front radar sensor, align the boss at end of front radar sensor with the slot on front bumper assembly, and then firmly install front radar sensor.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the front bumper assembly ([See page 61-6](#)).
4. Disconnect the front radar sensor connectors.



5. Remove the front radar sensor.

**Installation** شرکت دیجیتال خودرو سامانه (مسئول بود)  
Installation is in the reverse order of removal.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


## Rear Radar Sensor

### Removal

#### Caution:

- Install connectors in place when installing rear radar sensor.
- Check reversing radar system for proper operation, after installing rear radar sensor.
- Be sure to wear necessary safety equipment to prevent accidents, when removing rear radar sensor.
- Operate carefully to avoid damaging rear radar sensor, when removing rear radar sensor.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the rear bumper assembly (See page 61-6).
4. Disconnect the rear radar sensor connectors.



5. Remove the rear radar sensor.

### Installation

Installation is in the reverse order of removal.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


## Front Camera Assembly

### Removal


#### Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing front camera assembly.
- Appropriate force should be applied when removing front camera assembly. Be careful not to operate roughly.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the front bumper assembly (See page 61-6).
4. Disconnect the front camera connector.
5. Using an interior crow plate, pry off fixing clips from front camera wire harness assembly.



6. Remove 2 fixing screws from front camera.



7. Remove the front camera assembly.

### Installation

Installation is in the reverse order of removal.


## Rear Camera Assembly

### Removal


#### Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing rear camera assembly.
- Appropriate force should be applied when removing rear camera assembly. Be careful not to operate roughly.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the back door lower protector assembly.
4. Disconnect the rear camera connector.



5. Reach your hand to the metal plate of back door to take out the camera.



### Installation

Installation is in the reverse order of removal.

## Left/Right Camera

### Removal

#### Hint:

As left/right camera is installed inside the outside rear view mirror assembly, it must be replaced together with outside rear view mirror assembly when damaged.

#### Caution:

- Install connector in place and tighten fixing nuts to the specified torque, when installing the outside rear view mirror assembly.
- Make sure the outside rear view mirror assembly can move smoothly, flexibly and reliably after installing.
- After installing outside rear view mirror assembly, it is necessary to perform panoramic image calibration.

1. Remove the outside rear view mirror assembly.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




## Reversing Radar Module

### Removal


#### Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing reversing radar control module assembly.
- Appropriate force should be applied when removing reversing radar control module assembly. Be careful not to operate roughly.
- Tighten fixing bolts to the specified torque, when installing reversing radar control module assembly.
- Install connector in place when installing reversing radar control module assembly.
- Check reversing radar system for proper operation, after installing reversing radar control module assembly.

1. Turn off all electrical equipment and the ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the luggage compartment left wheel house assembly.
4. Disconnect the reversing radar module connector.



5. Remove 2 fixing bolts from reversing radar control module assembly.



6. Remove the reversing radar module.

### Installation

Installation is in the reverse order of removal.


## Panoramic Control System Module

### Removal

#### Caution:

- Be sure to wear necessary safety equipment to prevent accidents, when removing panoramic control system module assembly.
- Appropriate force should be applied, when removing panoramic control system module assembly. Be careful not to operate roughly.
- Tighten fixing bolts to the specified torque, when installing panoramic view monitor control module assembly.
- Install connector in place when installing panoramic view monitor control module assembly.
- Check reversing radar system for proper operation, after installing panoramic view monitor control module assembly.

- Turn off all electrical equipment and the ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Remove the glove box assembly ([See page 58-13](#)).
- Remove the right soundproof board assembly.
- Disconnect the panoramic view monitor control module connector.
- Remove 2 fixing bolts and 1 fixing nut from panoramic view monitor control module.
- Remove the panoramic view monitor control module.



PM0480

دُجِيٰتَالْ خُودْرَة

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

- Remove the panoramic view monitor control module.

### Installation

Installation is in the reverse order of removal.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# LANE ASSIST SYSTEM

|                                 |              |                          |              |
|---------------------------------|--------------|--------------------------|--------------|
| <b>Lane Assist System</b>       | <b>50-3</b>  | <b>U014087</b>           | <b>50-22</b> |
| System Overview                 | 50-3         | U300051                  | 50-22        |
| Special Tools                   | 50-6         | U010087                  | 50-22        |
| Tightening Torque List          | 50-7         | U013187                  | 50-22        |
| System Circuit Diagram          | 50-8         | U015587                  | 50-22        |
| Diagnostic Information and Step | 50-9         | U024587                  | 50-22        |
| <b>C190749</b>                  | <b>50-13</b> | <b>U012687</b>           | <b>50-22</b> |
| <b>C190709</b>                  | <b>50-13</b> | <b>U012387</b>           | <b>50-22</b> |
| <b>C190116</b>                  | <b>50-14</b> | <b>U12E187</b>           | <b>50-22</b> |
| <b>C190117</b>                  | <b>50-14</b> | <b>U041881</b>           | <b>50-22</b> |
| <b>C190016</b>                  | <b>50-14</b> | <b>U042281</b>           | <b>50-22</b> |
| <b>C190017</b>                  | <b>50-14</b> | <b>U044781</b>           | <b>50-22</b> |
| <b>C190797</b>                  | <b>50-18</b> | <b>U040181</b>           | <b>50-23</b> |
| <b>C19064B</b>                  | <b>50-19</b> | <b>U042081</b>           | <b>50-23</b> |
| <b>C190346</b>                  | <b>50-20</b> | <b>U042381</b>           | <b>50-23</b> |
| <b>C190354</b>                  | <b>50-20</b> | <b>U0546-81</b>          | <b>50-23</b> |
| <b>C1905-94</b>                 | <b>50-20</b> | <b>U0428-81</b>          | <b>50-23</b> |
| <b>C1904-46</b>                 | <b>50-20</b> | <b>U051381</b>           | <b>50-23</b> |
| <b>U130055</b>                  | <b>50-21</b> | <b>U140981</b>           | <b>50-23</b> |
| <b>U007388</b>                  | <b>50-22</b> | <b>U3000-51</b>          | <b>50-23</b> |
| <b>U12A188</b>                  | <b>50-22</b> | Matching Learning        | <b>50-23</b> |
| <b>U012987</b>                  | <b>50-22</b> | Removal and Installation | <b>50-24</b> |



# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# Lane Assist System


## System Overview

### System Components Diagram



|   |                                   |   |                       |
|---|-----------------------------------|---|-----------------------|
| 1 | Instrument Cluster (ICM)          | 2 | Audio Head Unit (IHU) |
| 3 | Front Multi-function Camera (FCM) |   |                       |

## System Schematic Diagram





The lane assist system collects LDW/LKA switch signal, turn signal light signal, hazard warning light signal, vehicle speed signal and corner signal through CAN line. Through data demand analysis, steering wheel vibration and instrument cluster displays relevant alarm information.

### System Function

Lane assist system includes lane departure warning system (LDW) and lane keeping assist system (LKA), which can help drivers reduce traffic accidents caused by lane departure and improve driving safety.

Press the lane assist system switch to cycle between lane departure warning system (LDW) / lane keeping assist system (LKA) / OFF.




**Lane Departure Warning System (LDW)**

The lane departure warning system (LDW) detects the lane line through the front multi-function camera (FCM). When the wheels roll to the lane line and the vehicle departs from the driving route, the system will send out an alarm and steering wheel will vibration.

The lane departure warning system (LDW) may not operate normally in the following situations:

1. When the vehicle is changing lanes.
2. When the turning speed is too high.
3. When the accelerator pedal is pressed hard.
4. When the brake pedal is pressed hard.
5. When the hazard warning light is turned on.
6. When the departure side turn signal light is turned on.
7. When driving on a curve with a small turning radius.
8. When the lane line is too thin, broken, blurred or there is no lane line on the departure side.

**Lane Keeping Assist System (LKA)**

The lane keeping assist system (LKA) detects lane line through front multi-function camera (FCM). When the lane lines on the left and right sides are identified by the system, the system applies corrective steering intervention to make the vehicle always drive in the middle of the lane.

The lane keeping assist system (LKA) may not operate normally in the following situations:



1. When the vehicle is changing lanes.
2. When the turn signal light is turned on.
3. When the braking force is too large.
4. When the turning speed is too high.
5. When the accelerator pedal is pressed hard.
6. When the hazard warning light is turned on.
7. Lane keeping assist system (LKA) recognizes that the driver has not operated the steering wheel for a period of time.
8. The driver controls the steering wheel when lane keeping assist system (LKA) applies corrective steering intervention control.

### Identification of Lane Line Types

| No. | Road Type  | Performance Requirements  |
|-----|--|---|
| 1   | Applicable road curvature radius                           | More than 250m (class II highway standard)  |
| 2   | Effective lane width                                       | 2.5 m, 5.2 m  |
| 3   | Effective lane marker line width                           | 8cm, 60cm   |
| 4   | Visible range of lane line                                 | Influenced by environmental factors, the farthest visible range of lane line is 60-100m |
| 5   | Lane line definition                                       | Visible to the naked eye  |
| 6   | Judging accuracy of distance between vehicle and lane line | The error is less than 4 cm   |
| 7   | Lane line types  | Double line, solid line, virtual solid line, dotted line                                |
| 8   | Lane line colors   | White, yellow, orange, blue   |
| 9   | Road geometry  | Straight, curve   |
| 10  | Road conditions  | Asphalt, cement   |

## اولین سامانه دیجیتال تعمیرکاران >

### General Tools

| Tool Name          | Tool Drawing   |
|--------------------|--|
| Digital Multimeter | <br>RCH0002006 |
| Diagnostic Tester  | <br>RCH0001006 |

## Tightening Torque List

### Torque Specifications

| Description                                 | Tightening Torque |
|---|-------------------|
| Panoramic Control System Module Fixing Bolt | 7 ± 1 N·m         |

# دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## System Circuit Diagram

# Front Camera Module (FCM) Circuit Diagram



## Diagnostic Information and Step

### Diagnosis Procedure

#### Hint:

Use following procedures to troubleshoot the lane assist system.

1 Vehicle brought to workshop

NEXT

2 Check battery voltage

Check if battery voltage is normal.

OK

Standard voltage: Not less than 12 V.

#### Result

| Result | Go to |
|--------|-------|
| OK     | A     |
| NG     | B     |

B

Replace battery

A

3 Customer problem analysis

NEXT

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

4 Read DTCs

#### Result

| Result | Go to |
|--------|-------|
| DTC    | A     |
| No DTC | B     |

B

Repair according to Problem Symptoms Table

A

5 Read DTCs (current DTC and history DTC)

50

#### Result

| Result | Go to |
|--------|-------|
| DTC    | A     |
| No DTC | B     |

B

Troubleshoot according to Intermittent  
DTC Troubleshooting procedure

A

6

Repair according to Diagnostic Trouble Code (DTC) Chart

NEXT

7

Adjust, repair or replace

NEXT

8

Conduct test and confirm malfunction has been repaired

NEXT

End

### DTC Confirmation Procedure

Confirm that battery voltage is no less than 12 V before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software).
- Turn ENGINE START STOP switch to ON.
- Use the diagnostic tester to record and clear DTCs stored in the system.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Turn ENGINE START STOP switch to ON, and check DTCs in the system again.
- If DTC is detected, it indicates current malfunction.
- If no DTC is detected, malfunction indicated by the DTC is intermittent.

### Intermittent DTC Troubleshooting

- Check if connector is loose.
- Check if wire harness is worn, pierced, pinched or partially broken.
- Wiggle related wire harness and connector and observe if signal in related circuit is interrupted.
- If possible, try to duplicate conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggle test.
- Check for broken, bent, protruded or corroded terminals.
- Check and clean all wire harness connectors and ground parts related to DTC.
- If multiple trouble codes were set, refer to circuit diagrams to look for any common ground circuit or power supply circuit applied to DTC.
- Refer to any Technical Bulletin that may apply to this malfunction.

### Ground Inspection

Ground points are very important to the proper operation of circuits. Ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) may increase load resistance. This situation may change the way in which a circuit works. Circuits are very sensitive to proper grounding. A loose or corroded ground can affect the control circuit. Check the ground points as follows:

- Remove ground bolt or nut.
- Check all contact surfaces for tarnish, dirt and rust, etc.
- Clean as necessary to ensure that contact is in good condition.
- Reinstall ground bolt or nut securely.
- Check if add-on accessories interfere with ground circuit.

- If several wire harnesses are crimped into one ground terminal, check for proper crimps. Make sure that all wire harnesses are clean and securely fastened while providing a good ground path.


## Problem Symptoms Table

### Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

| Symptom                          | Possible Cause            |
|----------------------------------|---------------------------|
| LDW/LKA malfunction indicator ON | Fuse                      |
|                                  | Wire harness fault        |
|                                  | Front camera module (FCM) |
| CAN network failure              | Fuse                      |
|                                  | Wire harness fault        |
|                                  | Central gateway (CGW)     |
|                                  | Front camera module (FCM) |

## Front Camera Module (FCM) Terminal List



LD0070

50

| Terminal No. | Terminal Definition | Terminal No. | Terminal Definition |
|--------------|---------------------|--------------|---------------------|
| 1            | SCAN-L              | 7            | SCAN-H              |
| 2            | CAN-L               | 8            | CAN-H               |
| 3            | -                   | 9            | -                   |
| 4            | -                   | 10           | -                   |
| 5            | Ground              | 11           | -                   |
| 6            | KL15                | 12           | -                   |

## Front Camera Module (FCM) DTC Chart

| DTC      | DTC Definition   |
|----------|--|
| C190016  | Supply Voltage Error - Low Voltage   |
| C190017  | Supply Voltage Error - High Voltage  |
| C190116  | Circuit Voltage Error - Below Threshold  |
| C190117  | Circuit Voltage Error - Above Threshold  |
| C190244  | Parameter Error - Dataset Error  |
| C190354  | Parameter Error - Initial Calibration Data Missing                                     |
| C190346  | Parameter Error - Initial Calibration Data Out of Range                                |
| C190446  | Parameter Error - Online Calibration Data Out of Range                                 |
| C190594  | Process Error - Initial Calibration Timeout  |
| C19064B  | Temperature Error - ECU Temperature Out of Range                                       |
| C190797  | Electronic Error - Camera Blindness  |
| C190749  | Electronic Error - Internal Electronic Failure Temporary                               |
| C190709  | Electronic Error - Internal Electronic Failure Permanent                               |
| U007388  | CAN Communication Error - Vehicle CAN Controller BusOff Error                          |
| U12A188  | CAN Communication Error - Private CAN Controller BusOff Error                          |
| U012987  | CAN Communication Error - Lost Communication with BSM                                  |
| U014087  | CAN Communication Error - Lost Communication with BCM                                  |
| U300051  | Control Module-Not Programmed  |
| U010087  | CAN Communication Error - Lost Communication with EMS                                  |
| U013187  | CAN Communication Error - Lost Communication with EPS                                  |
| U015587  | CAN Communication Error - Lost Communication with ICM                                  |
| U024587  | CAN Communication Error - Lost Communication with IHU                                  |
| U012687  | CAN Communication Error - Lost Communication with SAM                                  |
| U012387  | CAN Communication Error - Lost Communication with YAS                                  |
| U12E187  | CAN Communication Error - Lost Communication with FRM                                  |
| U041881  | CAN Communication Error - Invalid Data from Brake System Control Module                |
| U042281  | CAN Communication Error - Invalid Data from BCM  |
| U044781  | CAN Communication Error - Invalid Data Received from Gateway "A"                       |
| U040181  | CAN Communication Error - Invalid Data from EMS  |
| U042081  | CAN Communication Error - Invalid Data from EPS  |
| U042381  | CAN Communication Error - Invalid Data from ICM  |
| U0546-81 | CAN Communication Error - Invalid Data from IHU  |
| U0428-81 | CAN Communication Error - Invalid Data from SAM  |
| U051381  | CAN Communication Error - Invalid Data from YAS  |
| U140981  | CAN communication error - Invalid Data from Cruise Control Front Distance Range Sensor |
| U3000-51 | Control Module-Not Programmed  |

|     |         |   |
|-----|---------|---|
| DTC | C190244 | Parameter Error - Dataset Error                             |
| DTC | C190749 | Electronic Error - Internal Electronic Failure<br>Temporary |
| DTC | C190709 | Electronic Error - Internal Electronic Failure<br>Permanent |

**Description**

| DTC     | DTC Definition  | Possible Cause              |
|---------|---|-----------------------------|
| C190244 | Parameter Error - Dataset Error                             | Damaged front camera module |
| C190749 | Electronic Error - Internal Electronic Failure<br>Temporary |                             |
| C190709 | Electronic Error - Internal Electronic Failure<br>Permanent |                             |

**1 Check for DTCs**

(a) Using diagnostic tester to clear DTC, and read front camera module DTC again.  
 (b) Check if DTCs occur again.

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

**B****System is normal****A****2 Check if front camera module operates normally****Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

**B****Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC again****A****Replace front camera module**

|     |         |   |
|-----|---------|---|
| DTC | C190116 | Circuit Voltage Error - Below Threshold |
| DTC | C190117 | Circuit Voltage Error - Above Threshold |
| DTC | C190016 | Supply Voltage Error - Low Voltage      |
| DTC | C190017 | Supply Voltage Error - High Voltage     |


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## Circuit Diagram



### Description

| DTC     | DTC Definition                          | Possible Cause                              |
|---------|---|---|
| C190116 | Circuit Voltage Error - Below Threshold | Damaged front camera module<br>Wire harness |
| C190117 | Circuit Voltage Error - Above Threshold |   |
| C190016 | Supply Voltage Error - Low Voltage      |   |
| C190017 | Supply Voltage Error - High Voltage     |   |

### Caution:

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

### Confirmation Procedure

Confirm that battery voltage is 9 to 14.5 V under starting before performing following procedures.

|          |                   |
|----------|-------------------|
| <b>1</b> | <b>Check fuse</b> |
|----------|-------------------|

(a) Check if fuse EF04 10A of engine compartment fuse and relay box is blown.

### Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |



|          |   |
|----------|---|
| <b>2</b> | <b>Check instrument panel fuse box output voltage</b> |
|----------|---|

(a) Turn ignition switch to ON.  
(b) Measure voltage between instrument panel fuse box I-004 (13) and body ground (using a digital multimeter).

### Standard Condition

| Multimeter Connection      | Condition | Specified Condition |
|----------------------------|-----------|---------------------|
| I-004 (13) and body ground | ON        | 9 - 14.5 V          |

### Result

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |



50

|          |                                    |
|----------|------------------------------------|
| <b>3</b> | <b>Check wire harness for open</b> |
|----------|------------------------------------|

(a) Turn ENGINE START STOP switch to OFF.  
(b) Disconnect the negative battery cable.  
(c) Disconnect the front camera module connector B-051.

(d) Using ohm band of digital multimeter, check resistance between I-004(13) - B-051(6) of instrument panel fuse and relay box for normal, to check wire harness for open.

**Standard Condition**

| Multimeter Connection  | Condition                    | Specified Condition |
|------------------------|------------------------------|---------------------|
| I-004 (13) - B-051 (6) | ENGINE START STOP switch OFF | $\leq 1 \Omega$     |

**Result**

| Result | Go to |
|--------|-------|
| OK     | B     |
| NG     | A     |

**B**

Replace front camera module

**A**

Repair related wire harness

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**DTC**

**C190797**

**Electronic Error - Camera Blindness**

**Description**

| <b>DTC</b> | <b>DTC Definition</b>               | <b>Possible Cause</b>       |
|------------|-------------------------------------|-----------------------------|
| C190797    | Electronic Error - Camera Blindness | Damaged front camera module |

**1 Check for DTCs**

- (a) Using diagnostic tester to clear DTC, and read front camera module DTC again.
- (b) Check if DTCs occur again.

**Result**

| <b>Result</b> | <b>Go to</b> |
|---------------|--------------|
| OK            | B            |
| NG            | A            |

**B**

**System is normal**

**A**

**2**

**Check if front camera module is covered by foreign material and clean dirt on the surface of front camera module**

**Result**

| <b>Result</b> | <b>Go to</b> |
|---------------|--------------|
| OK            | B            |
| NG            | A            |

**B**

**Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC again**

**A**

**Replace front camera module assembly**

|     |         |  |
|-----|---------|--|
| DTC | C19064B | Temperature Error - ECU Temperature Out of Range |
|-----|---------|--|

**Description**

| DTC     | DTC Definition                                   | Possible Cause      |
|---------|--|---------------------|
| C19064B | Temperature Error - ECU Temperature Out of Range | Overheat protection |

|   |  |
|---|--|
| 1 | Clear DTC to relieve overheat protection |
|---|--|

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|     |          |   |
|-----|----------|---|
| DTC | C190346  | Parameter Error - Initial Calibration Data Out of Range |
| DTC | C190354  | Parameter Error - Initial Calibration Data Missing      |
| DTC | C1905-94 | Process Error - Initial Calibration Timeout             |
| DTC | C1904-46 | Parameter Error - Online Calibration Data Out of Range  |

#### Description

| DTC     | DTC Definition  | Possible Cause |
|---------|---|----------------|
| C190346 | Parameter Error - Initial Calibration Data Out of Range | Recalibration  |
| C190354 | Parameter Error - Initial Calibration Data Missing      |                |
| C190594 | Process Error - Initial Calibration Timeout             |                |
| C190446 | Parameter Error - Online Calibration Data Out of Range  |                |

#### Caution:

Possible cause for malfunction: Front camera module calibration is not performed or does not meet related calibration condition.

|   |  |
|---|--|
| 1 | Refer to calibration method of front camera module and perform recalibration |
|---|--|

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

|            |                |                                      |
|------------|----------------|--------------------------------------|
| <b>DTC</b> | <b>U130055</b> | <b>Control Module-Not Programmed</b> |
|------------|----------------|--------------------------------------|

**Description**

| <b>DTC</b> | <b>DTC Definition</b>         | <b>Possible Cause</b>      |
|------------|-------------------------------|----------------------------|
| U130055    | Control Module-Not Programmed | Rewrite configuration data |

**Caution:**

Possible cause for malfunction: Configuration data does not write into module.

|          |                                   |
|----------|-----------------------------------|
| <b>1</b> | <b>Rewrite configuration data</b> |
|----------|-----------------------------------|

(a) Using diagnostic tester to enter the system "Special function" to perform writing configuration data.

**Result**

| <b>Result</b> | <b>Go to</b> |
|---------------|--------------|
| OK            | B            |
| NG            | A            |

|          |   |
|----------|---|
| <b>B</b> | <b>Perform running test after clearing DTCs</b> |
|----------|---|

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



|     |         |   |
|-----|---------|---|
| DTC | U007388 | CAN Communication Error - Vehicle CAN Controller BusOff Error                   |
| DTC | U12A188 | CAN Communication Error - Private CAN Controller BusOff Error                   |
| DTC | U012987 | CAN Communication Error - Lost Communication with BSM                           |
| DTC | U014087 | CAN Communication Error - Lost Communication with BCM                           |
| DTC | U300051 | Control Module-Not Programmed   |
| DTC | U010087 | CAN Communication Error - Lost Communication with EMS                           |
| DTC | U013187 | CAN Communication Error - Lost Communication with EPS                           |
| DTC | U015587 | CAN Communication Error - Lost Communication with ICM                           |
| DTC | U024587 | CAN Communication Error - Lost Communication with IHU                           |
| DTC | U012687 | CAN Communication Error - Lost Communication with SAM                           |
| DTC | U012387 | CAN Communication Error - Lost Communication with YAS                           |
| DTC | U12E187 | CAN Communication Error - Lost Communication with FRM                           |
| 50  | DTC     | U041881 CAN Communication Error - Invalid Data from Brake System Control Module |
|     | DTC     | U042281 CAN Communication Error - Invalid Data from BCM                         |
|     | DTC     | U044781 CAN Communication Error - Invalid Data Received from Gateway "A"        |

|     |          |  |
|-----|----------|--|
| DTC | U040181  | CAN Communication Error - Invalid Data from EMS  |
| DTC | U042081  | CAN Communication Error - Invalid Data from EPS  |
| DTC | U042381  | CAN Communication Error - Invalid Data from ICM  |
| DTC | U0546-81 | CAN Communication Error - Invalid Data from IHU  |
| DTC | U0428-81 | CAN Communication Error - Invalid Data from SAM  |
| DTC | U051381  | CAN Communication Error - Invalid Data from YAS  |
| DTC | U140981  | CAN communication error - Invalid Data from Cruise Control Front Distance Range Sensor |
| DTC | U3000-51 | Control Module-Not Programmed  |

Refer to CAN communication system

## Matching Learning


### Front Camera Module (FCM) Calibration

1. Click on "FCM (Front Camera Module)".
2. Click on "Special Function".
3. Click on "Online Initial Calibration (Only for After-Sales)".



4. Read precaution, click "Yes" after the information has been confirmed.

Calibration description: Initial online calibration is after-sales calibration method, which can calibrate camera when there is no calibration board. Initial online calibration is performed during driving, so it is necessary to measure wheel house height accurately before calibrating, and write camera by diagnostic instruction.



5. Drive for about 6 minutes and display countdown, after countdown is completed, there is a prompt "Calibration Completion - Successful".

## Removal and Installation

### Front Camera

#### Removal

#### Warning:

- Be sure to wear necessary safety equipment to prevent accidents, when removing front camera.
- Appropriate force should be applied when removing front camera. Be careful not to operate roughly.
- Remove front camera to perform matching calibration.

1. Turn ENGINE START STOP switch to OFF.
2. Disconnect the negative battery cable.
3. Remove the inside rear view mirror left cover.


50



4. Remove the inside rear view mirror right cover.



5. Disconnect connector from front camera.



6. Push back metal spring on bracket, meanwhile, remove front camera from rear lower area.

#### Installation

Installation is in the reverse order of removal.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

