

General Information

FLA-3

General Information

Specifications

Fuel Delivery System

Items	Specification	
Fuel Tank	Capacity	50liter. (13.2 U.S.gal, 52.8 U.S.qt., 44.0 Imp.qt)
Fuel Filter (built in Fuel Pump Assembly)	Type	Paper type
Fuel Pressure Regulator (built in Fuel Pump Assembly)	Regulated Fuel Pressure	338 ~ 348kpa(3.45 ~ 3.55kgf/cm ² , 49.0 ~ 50.5psi)
Fuel Pump	Type	Electrical, in-tank type
	Driven by	Electric motor
Fuel Retrun System	Pressure	Returnless

Sensors

Manifold Absolute Pressure Sensor (MAPS)

- ▷ Type: Piezo-resistive pressure sensor type
- ▷ Specification

Pressure (kPa)	Output voltage (V)
20	0.79
46.7	1.84
101.32	4

Intake Air Temperature Sensor (IATS)

- ▷ Type: Thermistor type
- ▷ Specification

Temperature [°C(°F)]	Resistance (kΩ)
-40(-40)	40.93 ~ 48.35
-30(-22)	23.43 ~ 27.34
-20(-4)	13.89 ~ 16.03
-10(14)	8.50 ~ 9.71
0(32)	5.38 ~ 6.09
10(50)	3.48 ~ 3.90
20(68)	2.31 ~ 2.57
25(77)	1.90 ~ 2.10
30(86)	1.56 ~ 1.74
40(104)	1.08 ~ 1.21
60(140)	0.54 ~ 0.62
80(176)	0.29 ~ 0.34

Engine Coolant Temperature Sensor (ECTS)

- ▷ Type: Thermistor type
- ▷ Specification

Temperature [°C(°F)]	Resistance(kΩ)
-40(-40)	48.14
-20(-4)	14.13 ~ 16.83
0(32)	5.79
20(68)	2.31 ~ 2.59
40(104)	1.15
60(140)	0.59
80(176)	0.32

Throttle Position Sensor (TPS)

- ▷ Type: Variable resistor type
- ▷ Specification

Throttle angle (°)	Output voltage (V) [Vref = 5.0V]	
	TPS1	TPS2
0	0	5
10	0.48	4.52
20	0.95	4.05
30	1.43	3.57
40	1.9	3.1
50	2.38	2.62
60	2.86	2.14
70	3.33	1.67
80	3.81	1.19

FLA-4

Fuel System

Throttle angle (°)	Output voltage (V) [Vref = 5.0V]	
	TPS1	TPS2
90	4.29	0.71
100	4.76	0.24
105	5	0
C.T (6~15°)	0.3 ~ 0.7	4.3 ~ 4.7
W.O.T (93~102°)	4.45 ~ 4.85	0.15 ~ 0.55

Items	Sensor resistance (k Ω)
TPS1	0.875 ~ 1.625
TPS2	0.875 ~ 1.625

Heated Oxygen Sensor (HO2S)▷ Type: Zirconia (ZrO₂) type

▷ Specification

A/F Ratio	Output Voltage (V)
Rich	0.6 ~ 1.0
Lean	0 ~ 0.4

Items	Specification
Heater Resistance (Ω)	3.1 ~ 4.1 [20°C (68°F)]

Camshaft Position Sensor (CMPS)

▷ Type: Hall effect type

Crankshaft Position Sensor (CKPS)

▷ Type: Magnetic field sensitive type

Knock Sensor (KS)

▷ Type: Piezo-electricity type

▷ Specification

Items	Specification
Capacitance (pF)	1,480 ~ 2,220
Resistance (M Ω)	1.0

Accelerator Position Sensor (APS)

▷ Type: Variable resistor type

▷ Specification

Pedal P- osition	Output voltage (V) [Vref = 5.0V]	
	APS1	APS2
C.T	0.7 ~ 0.8	0.275 ~ 0.475
W.O.T	3.85 ~ 4.35	1.75 ~ 2.35

Items	Sensor resistance (k Ω)
APS1	0.8 ~ 1.6 [20°C (68°F)]
APS2	0.9 ~ 2.5 [20°C (68°F)]

General Information

FLA-5

Actuators

Injector

▷ Number: 4

▷ Specification

Items	Specification
Coil Resistance (Ω)	13.8 ~ 15.2 [20°C(68°F)]

Purge Control Solenoid Valve (PCSV)

▷ Specification

Items	Specification
Coil Resistance (Ω)	19.0 ~ 22.0 [20°C(68°F)]

CVVT Oil Control Valve (OCV)

▷ Specification

Items	Specification
Coil Resistance (Ω)	6.9 ~ 7.9 [20°C(68°F)]

Ignition Coil

▷ Type: Stick type

▷ Specification

Items	Specification
Primary Coil Resistance (Ω)	$0.62 \pm 10\%$ [20°C(68°F)]
Secondary Coil Resistance (k Ω)	$7.0 \pm 15\%$ [20°C(68°F)]

ETC Motor

▷ Specification

Item	Specification
Coil Resistance (Ω)	1.2 ~ 1.8 [20°C(68°F)]



FLA-6

Fuel System

Service Standard

Ignition Timing	BTDC $10^{\circ} \pm 5^{\circ}$		
Idle Speed	A/CON OFF	Neutral (M/T)	650 ± 100 rpm
		N,P-range	620 ± 100 rpm
		D-range	
	A/CON ON	Neutral (M/T)	650 ± 100 rpm
		N,P-range	620 ± 100 rpm
		D-range	

Tightening Torques

Engine Control System

Item	Kgf.m	N.m	lb-ft
ECM installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Manifold absolute pressure sensor installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Engine coolant temperature sensor installation	3.0 ~ 4.0	29.4 ~ 39.2	21.7 ~ 28.9
Crankshaft position sensor installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Crankshaft position sensor - target wheel installation screw	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Camshaft position sensor installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Knock sensor installation bolt	1.9 ~ 2.4	18.6 ~ 23.5	13.7 ~ 17.4
Heated oxygen sensor (Bank 1 / Sensor 1) installation	3.5 ~ 4.5	34.3 ~ 44.1	25.3 ~ 32.6
Heated oxygen sensor (Bank 1 / Sensor 2) installation	3.5 ~ 4.5	34.3 ~ 44.1	25.3 ~ 32.6
CVVT Oil control valve installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Purge control solenoid valve installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
ETC (Electronic throttle control) module installation bolt	0.8 ~ 1.0	7.8 ~ 9.8	5.8 ~ 7.2
Ignition coil assembly installation bolts	0.4 ~ 0.6	3.9 ~ 5.9	2.9 ~ 4.3




Fuel Delivery System

Item	kgf.m	N.m	lb-ft
Fuel tank installation bolt	4.5 ~ 6.0	44.1 ~ 58.8	32.5 ~ 43.4
Fuel tank installation nut	4.0 ~ 5.5	39.2 ~ 53.9	28.9 ~ 39.8
Fuel pump installation bolt	0.2 ~ 0.3	2.0 ~ 2.9	1.4 ~ 2.2
Filler-neck assembly installation bolt	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Filler-neck assembly installation screw	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Delivery pipe installation bolt	2.0 ~ 2.5	19.6 ~ 24.5	14.5 ~ 18.1

General Information

FLA-7

Special Service Tools

Tool(Number and name)	Illustration	Application
09353-24100 Fuel Pressure Gauge	 <p>EFDA003A</p>	Measuring the fuel line pressure
09353-38000 Fuel Pressure Gauge Adapter	 <p>BF1A025D</p>	Connection between the delivery pipe and fuel feed line
09353-24000 Fuel Pressure Gauge Connector	 <p>EFDA003C</p>	Connection between Fuel Pressure Gauge (09353-24100) and Fuel Pressure Gauge Adapter (09353-38000)



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FLA-8

Fuel System

Basic Troubleshooting

Basic Troubleshooting Guide

1	Bring Vehicle to Workshop
2	Analyze Customer's Problem <ul style="list-style-type: none"> Ask the customer about the conditions and environment relative to the issue (Use CUSTOMER PROBLEM ANALYSIS SHEET).
3	Verify Symptom, and then Check DTC and Freeze Frame Data <ul style="list-style-type: none"> Connect Hi-Scan (Pro) to Diagnostic Link Connector (DLC). Record the DTC and freeze frame data. <p> NOTE To erase DTC and freeze frame data, refer to Step 5.</p>
4	Confirm the Inspection Procedure for the System or Part <ul style="list-style-type: none"> Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked.
5	Erase the DTC and Freeze Frame Data <p> WARNING NEVER erase DTC and freeze frame data before completing Step 2 MIL/DTC in "CUSTOMER PROBLEM ANALYSIS SHEET".</p>
6	Inspect Vehicle Visually <ul style="list-style-type: none"> Go to Step 11, if you recognize the problem.
7	Recreate (Simulate) Symptoms of the DTC <ul style="list-style-type: none"> Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC.
8	Confirm Symptoms of Problem <ul style="list-style-type: none"> If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11.
9	Recreate (Simulate) Symptom <ul style="list-style-type: none"> Try to recreate or simulate the condition of the malfunction as described by the customer.
10	Check the DTC <ul style="list-style-type: none"> If DTC(s) does(do) not occur, refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE. If DTC(s) occur(s), go to Step 11.
11	Perform troubleshooting procedure for DTC
12	Adjust or repair the vehicle
13	Confirmation test
14	END

LW8F1001

General Information

FLA-9

Customer Problem Analysis Sheet

1. VEHICLE INFORMATION

VIN No.		Transmission	<input type="checkbox"/> M/T <input type="checkbox"/> A/T <input type="checkbox"/> CVT <input type="checkbox"/> etc.
Production date		Driving type	<input type="checkbox"/> 2WD (FF) <input type="checkbox"/> 2WD (FR) <input type="checkbox"/> 4WD
Odometer Reading	_____km/mile	CPF (Diesel Engine)	<input type="checkbox"/> With CPF <input type="checkbox"/> Without CPF

2. SYMPTOMS

<input type="checkbox"/> Unable to start	<input type="checkbox"/> Engine does not turn over <input type="checkbox"/> Incomplete combustion <input type="checkbox"/> Initial combustion does not occur
<input type="checkbox"/> Difficult to start	<input type="checkbox"/> Engine turns over slowly <input type="checkbox"/> Other_____
<input type="checkbox"/> Poor idling	<input type="checkbox"/> Rough idling <input type="checkbox"/> Incorrect idling <input type="checkbox"/> Unstable idling (High:_____ rpm, Low:_____ rpm) <input type="checkbox"/> Other_____
<input type="checkbox"/> Engine stall	<input type="checkbox"/> Soon after starting <input type="checkbox"/> After accelerator pedal depressed <input type="checkbox"/> After accelerator pedal released <input type="checkbox"/> During A/C ON <input type="checkbox"/> Shifting from N to D-range <input type="checkbox"/> Other_____
<input type="checkbox"/> Others	<input type="checkbox"/> Poor driving (Surge) <input type="checkbox"/> Knocking <input type="checkbox"/> Poor fuel economy <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> Other_____

3. ENVIRONMENT

Problem frequency	<input type="checkbox"/> Constant <input type="checkbox"/> Sometimes (_____) <input type="checkbox"/> Once only <input type="checkbox"/> Other_____
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Other_____
Outdoor temperature	Approx. _____ °C/°F
Place	<input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner City <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Other_____
Engine temperature	<input type="checkbox"/> Cold <input type="checkbox"/> Warming up <input type="checkbox"/> After warming up <input type="checkbox"/> Any temperature
Engine operation	<input type="checkbox"/> Starting <input type="checkbox"/> Just after starting (____ min) <input type="checkbox"/> Idling <input type="checkbox"/> Racing <input type="checkbox"/> Driving <input type="checkbox"/> Constant speed <input type="checkbox"/> Acceleration <input type="checkbox"/> Deceleration <input type="checkbox"/> A/C switch ON/OFF <input type="checkbox"/> Other_____

4. MIL/DTC

MIL (Malfunction Indicator Lamp)	<input type="checkbox"/> Remains ON <input type="checkbox"/> Sometimes lights up <input type="checkbox"/> Does not light	
DTC	Normal check (Pre-check)	<input type="checkbox"/> Normal <input type="checkbox"/> DTC (_____) <input type="checkbox"/> Freeze Frame Data
	Check mode	<input type="checkbox"/> Normal <input type="checkbox"/> DTC (_____) <input type="checkbox"/> Freeze Frame Data

5. ECM/PCM INFORMATION

ECM/PCM Part No.	
ROM ID	

SFDF28233L

FLA-10

Fuel System

Basic Inspection Procedure

Measuring Condition of Electronic Parts' Resistance

The measured resistance at high temperature after vehicle running may be high or low. So all resistance must be measured at ambient temperature (20°C, 68°F), unless stated otherwise.


NOTICE

The measured resistance in except for ambient temperature (20°C, 68°F) is reference value.

Intermittent Problem Inspection Procedure

Sometimes the most difficult case in troubleshooting is when a problem symptom occurs but does not occur again during testing. An example would be if a problem appears only when the vehicle is cold but has not appeared when warm. In this case, the technician should thoroughly make out a "Customer Problem Analysis Sheet" and recreate (simulate) the environment and condition which occurred when the vehicle was having the issue.

1. Clear Diagnostic Trouble Code (DTC).
2. Inspect connector connection, and check terminal for poor connections, loose wires, bent, broken or corroded pins, and then verify that the connectors are always securely fastened.



BFGE321A

3. Slightly shake the connector and wiring harness vertically and horizontally.
4. Repair or replace the component that has a problem.
5. Verify that the problem has disappeared with the road test.

● Simulating Vibration

- a. Sensors and Actuators

: Slightly vibrate sensors, actuators or relays with finger.

⊗WARNING

Strong vibration may break sensors, actuators or relays

- b. Connectors and Harness

: Lightly shake the connector and wiring harness vertically and then horizontally.

● Simulating Heat

- a. Heat components suspected of causing the malfunction with a hair dryer or other heat source.

⊗WARNING

• **DO NOT heat components to the point where they may be damaged.**

• **DO NOT heat the ECM directly.**

● Simulating Water Sprinkling

- a. Sprinkle water onto vehicle to simulate a rainy day or a high humidity condition.

⊗WARNING

DO NOT sprinkle water directly into the engine compartment or electronic components.

● Simulating Electrical Load

- a. Turn on all electrical systems to simulate excessive electrical loads (Radios, fans, lights, rear window defogger, etc.).


General Information

FLA-11

Connector Inspection Procedure


1. Handling of Connector

- a. Never pull on the wiring harness when disconnecting connectors.




BFGE015F

- b. When removing the connector with a lock, press or pull locking lever.




BFGE015G

- c. Listen for a click when locking connectors. This sound indicates that they are securely locked.



BFGE015H

- d. When a tester is used to check for continuity, or to measure voltage, always insert tester probe from wire harness side.




BFGE015I

FLA-12

Fuel System

- e. Check waterproof connector terminals from the connector side. Waterproof connectors cannot be accessed from harness side.



BFGE015J


NOTICE

- Use a fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.

2. Checking Point for Connector

- a. While the connector is connected:
Hold the connector, check connecting condition and locking efficiency.
- b. When the connector is disconnected:
Check missed terminal, crimped terminal or broken core wire by slightly pulling the wire harness.
Visually check for rust, contamination, deformation and bend.
- c. Check terminal tightening condition:
Insert a spare male terminal into a female terminal, and then check terminal tightening conditions.

- d. Pull lightly on individual wires to ensure that each wire is secured in the terminal.



BFGE015K

3. Repair Method of Connector Terminal

- a. Clean the contact points using air gun and/or shop rag.

NOTICE

Never use sand paper when polishing the contact points, otherwise the contact point may be damaged.

- b. In case of abnormal contact pressure, replace the female terminal.

Wire Harness Inspection Procedure

1. Before removing the wire harness, check the wire harness position and crimping in order to restore it correctly.
2. Check whether the wire harness is twisted, pulled or loosened.
3. Check whether the temperature of the wire harness is abnormally high.
4. Check whether the wire harness is rotating, moving or vibrating against the sharp edge of a part.
5. Check the connection between the wire harness and any installed part.
6. If the covering of wire harness is damaged; secure, repair or replace the harness.

General Information

FLA-13

Electrical Circuit Inspection Procedure


● Check Open Circuit

1. Procedures for Open Circuit

- Continuity Check
- Voltage Check

If an open circuit occurs (as seen in [FIG. 1]), it can be found by performing Step 2 (Continuity Check Method) or Step 3 (Voltage Check Method) as shown below.

FIG 1



BFG501A

2. Continuity Check Method

NOTICE

When measuring for resistance, lightly shake the wire harness above and below or from side to side.

Specification (Resistance)


1Ω or less → Normal Circuit

1MΩ or Higher → Open Circuit

- Disconnect connectors (A), (C) and measure resistance between connector (A) and (C) as shown in [FIG. 2].

In [FIG.2.] the measured resistance of line 1 and 2 is higher than 1MΩ and below 1 Ω respectively. Specifically the open circuit is line 1 (Line 2 is normal). To find exact break point, check sub line of line 1 as described in next step.

FIG 2




BFG501B

- Disconnect connector (B), and measure for resistance between connector (C) and (B1) and between (B2) and (A) as shown in [FIG. 3].

In this case the measured resistance between connector (C) and (B1) is higher than 1MΩ and the open circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).

FIG 3



BFG501C

3. Voltage Check Method

- With each connector still connected, measure the voltage between the chassis ground and terminal 1 of each connectors (A), (B) and (C) as shown in [FIG. 4].


FLA-14

Fuel System

The measured voltage of each connector is 5V, 5V and 0V respectively. So the open circuit is between connector (C) and (B).

a. Disconnect connectors (A), (C) and measure for resistance between connector (A) and Chassis Ground as shown in [FIG. 6].

FIG 4



BFGE501D


● Check Short Circuit

1. Test Method for Short to Ground Circuit

- Continuity Check with Chassis Ground

If short to ground circuit occurs as shown in [FIG. 5], the broken point can be found by performing Step 2 (Continuity Check Method with Chassis Ground) as shown below.

FIG 5



BFGE501E

2. Continuity Check Method (with Chassis Ground)

NOTICE

Lightly shake the wire harness above and below, or from side to side when measuring the resistance.


Specification (Resistance)

1Ω or less → Short to Ground Circuit

1MΩ or Higher → Normal Circuit

The measured resistance of line 1 and 2 in this example is below 1 Ω and higher than 1MΩ respectively. Specifically the short to ground circuit is line 1 (Line 2 is normal). To find exact broken point, check the sub line of line 1 as described in the following step.

FIG 6




BFGE501F

b. Disconnect connector (B), and measure the resistance between connector (A) and chassis ground, and between (B1) and chassis ground as shown in [FIG. 7].

The measured resistance between connector (B1) and chassis ground is 1Ω or less. The short to ground circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).

FIG 7



BFGE501G


General Information

FLA-15

● Testing For Voltage Drop

This test checks for voltage drop along a wire, or through a connection or switch.

- Connect the positive lead of a voltmeter to the end of the wire (or to the side of the connector or switch) closest to the battery.
- Connect the negative lead to the other end of the wire. (or the other side of the connector or switch)
- Operate the circuit.
- The voltmeter will show the difference in voltage between the two points. A difference, or drop of more than 0.1 volts (50mV in 5V circuits), may indicate a problem. Check the circuit for loose or dirty connections.



SHMFL9331N



FLA-16

Fuel System

Symptom Troubleshooting Guide Chart

Main symptom	Diagnostic procedure	Also check for
Unable to start (Engine does not turn over)	<ol style="list-style-type: none"> 1. Test the battery 2. Test the starter 3. Inhibitor switch (A/T) or clutch start switch (M/T) 	
Unable to start (Incomplete combustion)	<ol style="list-style-type: none"> 1. Test the battery 2. Check the fuel pressure 3. Check the ignition circuit 4. Troubleshooting the immobilizer system (In case of immobilizer lamp flashing) 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Slipped or broken timing belt • Contaminated fuel
Difficult to start	<ol style="list-style-type: none"> 1. Test the battery 2. Check the fuel pressure 3. Check the ECT sensor and circuit (Check DTC) 4. Check the ignition circuit 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark
Poor idling (Rough, unstable or incorrect Idle)	<ol style="list-style-type: none"> 1. Check the fuel pressure 2. Check the Injector 3. Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM) 4. Check the idle speed control circuit (Check DTC) 5. Inspect and test the Throttle Body 6. Check the ECT sensor and circuit (Check DTC) 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark
Engine stall	<ol style="list-style-type: none"> 1. Test the Battery 2. Check the fuel pressure 3. Check the idle speed control circuit (Check DTC) 4. Check the ignition circuit 5. Check the CKPS Circuit (Check DTC) 	<ul style="list-style-type: none"> • DTC • Intake air leaks • Contaminated fuel • Weak ignition spark
Poor driving (Surge)	<ol style="list-style-type: none"> 1. Check the fuel pressure 2. Inspect and test Throttle Body 3. Check the ignition circuit 4. Check the ECT Sensor and Circuit (Check DTC) 5. Test the exhaust system for a possible restriction 6. Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM) 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark
Knocking	<ol style="list-style-type: none"> 1. Check the fuel pressure 2. Inspect the engine coolant 3. Inspect the radiator and the electric cooling fan 4. Check the spark plugs 	<ul style="list-style-type: none"> • DTC • Contaminated fuel
Poor fuel economy	<ol style="list-style-type: none"> 1. Check customer's driving habits <ul style="list-style-type: none"> · A/C on full time or the defroster mode on? · Are tires at correct pressure? · Is excessively heavy load being carried? · Is acceleration too much, too often? 2. Check the fuel pressure 3. Check the injector 4. Test the exhaust system for a possible restriction 5. Check the ECT sensor and circuit 	<ul style="list-style-type: none"> • DTC • Low compression • Intake air leaks • Contaminated fuel • Weak ignition spark

General Information

FLA-17

Main symptom	Diagnostic procedure	Also check for
Hard to refuel (Overflow during refueling)	<ol style="list-style-type: none"> 1. Test the canister close valve 2. Inspect the fuel filler hose/pipe <ul style="list-style-type: none"> · Pinched, kinked or blocked? · Filler hose is torn 3. Inspect the fuel tank vapor vent hose between the EVAP. canister and air filter 4. Check the EVAP. canister 	<ul style="list-style-type: none"> • Malfunctioning gas station filling nozzle (If this problem occurs at a specific gas station during refueling)

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA-18

Fuel System

Engine Control System

Description

If the Gasoline Engine Control system components (sensors, ECM, injector, etc.) fail, interruption to the fuel supply or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered.

1. Engine is hard to start or does not start at all.
2. Unstable idle.
3. Poor driveability

If any of the above conditions are noted, first perform a routine diagnosis that includes basic engine checks (ignition system malfunction, incorrect engine adjustment, etc.). Then, inspect the Gasoline Engine Control system components with the HI-SCAN (Pro).

NOTICE

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the ECM.
- The control harnesses between the ECM and heated oxygen sensor are shielded with the shielded ground wires to the body in order to prevent the influence of ignition noises and radio interference. When the shielded wire is faulty, the control harness must be replaced.
- When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the ECM.

Malfunction Indicator Lamp (MIL)

[EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL.

- Catalyst
- Fuel system
- Mass Air Flow Sensor (MAFS)
- Intake Air Temperature Sensor (IATS)
- Engine Coolant Temperature Sensor (ECTS)
- Throttle Position Sensor (TPS)
- Upstream Oxygen Sensor
- Upstream Oxygen Sensor Heater
- Downstream Oxygen Sensor
- Downstream Oxygen Sensor Heater
- Injector
- Misfire
- Crankshaft Position Sensor (CKPS)
- Camshaft Position Sensor (CMPS)
- Evaporative Emission Control System
- Vehicle Speed Sensor (VSS)
- Idle Speed Control Actuator (ISCA)
- Power Supply
- ECM/ PCM
- MT/AT Encoding
- Acceleration Sensor
- MIL-on Request Signal
- Power Stage

NOTICE

Refer to "Inspection Chart For Diagnostic Trouble Codes (DTC)" for more information.

Engine Control System

FLA-19

[NON-EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- Heated oxygen sensor (HO2S)
- Mass Air Flow sensor (MAFS)
- Throttle position sensor (TPS)
- Engine coolant temperature sensor (ECTS)
- Idle speed control actuator (ISCA)
- Injectors
- ECM

NOTICE

Refer to "Inspection Chart For Diagnostic Trouble Codes (DTC)" for more information.

[Inspection]

1. After turning ON the ignition key, ensure that the light illuminates for about 5 seconds and then goes out.
2. If the light does not illuminate, check for an open circuit in the harness, a blown fuse or a blown bulb.


Self-Diagnosis

The ECM monitors the input/output signals (some signals at all times and the others under specified conditions). When the ECM detects an irregularity, it records the diagnostic trouble code, and outputs the signal to the Data Link connector. The diagnosis results can be read with the MIL or HI-SCAN (Pro). Diagnostic Trouble Codes (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble codes will, however, be erased when the battery terminal or ECM connector is disconnected, or by the HI-SCAN (Pro).

NOTICE

If a sensor connector is disconnected with the ignition switch turned on, the diagnostic trouble code (DTC) is recorded. In this case, disconnect the battery negative terminal (-) for 15 seconds or more, and the diagnosis memory will be erased.

The Relation Between Dtc And Driving Pattern In Eobd System



LGIF601Q

FLA-20

Fuel System

1. When the same malfunction is detected and maintained during two sequential driving cycles, the MIL will automatically illuminate.
2. The MIL will go off automatically if no fault is detected after 3 sequential driving cycles.
3. A Diagnostic Trouble Code(DTC) is recorded in ECM memory when a malfunction is detected after two sequential driving cycles. The MIL will illuminate when the malfunction is detected on the second driving cycle.

If a misfire is detected, a DTC will be recorded, and the MIL will illuminate, immediately after a fault is first detected.

4. A Diagnostic Trouble Code(DTC) will automatically erase from ECM memory if the same malfunction is not detected for 40 driving cycles.

NOTICE

- A "warm-up cycle" means sufficient vehicle operation such that the coolant temperature has risen by at least 40 degrees Fahrenheit from engine starting and reaches a minimum temperature of 160 degrees Fahrenheit.
- A "driving cycle" consists of engine startup, vehicle operation beyond the beginning of closed loop operation.




دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Engine Control System

FLA-21

Component Location




STDF19200L

- | | |
|--------------------------------------------------|--------------------------------------------|
| 1. Engine Control Module (ECM) | 11. A/C Pressure Transducer (APT) |
| 2. Manifold Absolute Pressure Sensor (MAPS) | 12. ETC Module (Including TPS & ETC Motor) |
| 3. Intake Air Temperature Sensor (IATS) | 13. Injector |
| 4. Engine Coolant Temperature Sensor (ECTS) | 14. Purge Control Solenoid Valve (PCSV) |
| 5. Crankshaft Position Sensor (CKPS) | 15. CVVT Oil Control Valve (OCV) |
| 6. Camshaft Position Sensor (CMPS) | 16. Ignition Coil |
| 7. Knock Sensor (KS) | 17. Main Relay |
| 8. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] | 18. Fuel Pump Relay |
| 9. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] | 19. Data Link Connector (DLC) |
| 10. Accelerator Position Sensor (APS) | 20. Multi-Purpose Check Connector |


FLA-22

Fuel System


1. Engine Control Module (ECM)




2. Manifold Absolute Pressure Sensor (MAPS)
3. Intake Air Temperature Sensor (IATS)




4. Engine Coolant Temperature Sensor (ECTS)
5. Crankshaft Position Sensor (CKPS)




6. Camshaft Position Sensor (CMPS)



7. Knock Sensor (KS)




8. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]




Engine Control System

FLA-23


9. Heated Oxygen Sensor(HO2S) [Bank 1/Sensor 2]




10. Accelerator Position Sensor (APS)




11. A/C Pressure Transducer (APT)




12. ETC Module (Including TPS & ETC Motor)



13. Injector
16. Ignition coil




14. Purge Control Solenoid Valve (PCSV)




FLA-24

Fuel System

15. CVT Oil Control Valve (OCV)



STDF19112L

17. Main relay
18. Fuel pump relay

STDF19113L

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Engine Control System

FLA-25

Engine Control Module (ECM)

Engine Control Module (ECM)

ECM Harness Connector



STDF19201L

ECM Terminal Function

Connector [CHG-K]

Pin	Description	Connected to
1	Power ground	Chassis ground
2	Battery voltage supply after ignition switch	Ignition Switch
3	Power ground	Chassis ground
4	Battery voltage supply after main relay	Main Relay
5	Power ground	Chassis ground
6	Battery voltage supply	Battery
7	Wheel speed sensor (WSS) [+] signal input	Wheel speed sensor (WSS)
8	-	
9	-	
10	-	
11	-	
12	Knock sensor (KS) signal input	Knock sensor (KS)
13	Sensor ground	Accelerator position sensor #2
14	Sensor ground	Engine coolant temperature sensor (ECTS)
15	-	
16	Sensor ground	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]
17	Crankshaft position sensor (CKPS) signal input	Crankshaft position sensor (CKPS)
18	-	
19	-	

FLA-26

Fuel System

Pin	Description	Connected to
20	-	
21	-	
22	-	
23	Fuel consumption signal output	Trip computer
24	-	
25	Injector (Cylinder #1) control output	Injector (Cylinder #1)
26	Injector (Cylinder #3) control output	Injector (Cylinder #3)
27	Injector (Cylinder #4) control output	Injector (Cylinder #4)
28	Injector (Cylinder #2) control output	Injector (Cylinder #2)
29	Wheel speed sensor (WSS) [-] signal input	Wheel speed sensor (WSS)
30	Sensor power (+5V)	Manifold absolute pressure sensor (MAPS)
31	Manifold absolute pressure sensor (MAPS) signal input	Manifold absolute pressure sensor (MAPS)
32	Throttle position sensor (TPS) #2 signal input	Throttle position sensor (TPS) #2 [ETC module]
33	Engine coolant temperature sensor (ECTS) signal input	Engine coolant temperature sensor (ECTS)
34	Sensor ground	Knock sensor (KS)
35	Accelerator Position Sensor (APS) #2 signal input	Accelerator Position Sensor (APS) #2
36	Sensor power (+5V)	Accelerator Position Sensor (APS) #2
37	-	
38	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] signal input	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]
39	Sensor ground	Crankshaft position sensor (CKPS)
40	Vehicle speed signal input	ABS/VDC control module / Vehicle Speed Sensor
41	-	
42	-	
43	Sensor power (+5V)	A/C pressure transducer (APT)
44	-	
45	-	
46	-	
47	-	
48	-	
49	-	
50	-	
51	Battery voltage supply after main relay	Main relay
52	-	

Engine Control System

FLA-27

Pin	Description	Connected to
53	Intake Air temperature sensor (IATS) signal input	Intake Air temperature sensor (IATS)
54	A/C pressure transducer (APT) signal input	A/C pressure transducer (APT)
55	-	
56	-	
57	Sensor ground	A/C pressure transducer (APT)
58	-	
59	Sensor ground	Throttle position sensor (TPS) #1,2 [ETC module]
60	Sensor power (+5V)	Accelerator Position Sensor (APS) #1
61	Sensor ground	Accelerator Position Sensor (APS) #1
62	Camshaft position sensor (CMPS) #1 signal input	Camshaft position sensor (CMPS) #1
63	Sensor power (+5V)	Throttle position sensor (TPS) #1,2 [ETC module]
64	Main relay control output	Main relay
65	Fan relay control output [Low]	Fan relay [Low]
66	CVVT Oil control valve (OCV) #1 control output	CVVT Oil control valve (OCV) #1
67	Purge control solenoid valve (PCSV) control output	Purge control solenoid valve (PCSV)
68	-	
69	Immobilizer lamp control output	Immobilizer lamp (Cluster)
70	Fuel pump relay control output	Fuel pump relay
71	ETC motor [A] control output	ETC motor [ETC module]
72	ETC motor [B] control output	ETC motor [ETC module]
73	-	
74	Sensor ground	Manifold absolute pressure sensor (MAPS), Intake Air temperature sensor (IATS)
75	Immobilizer communication line	Immobilizer control module
76	-	
77	CAN [High]	ABS/VDC control module
78	CAN [Low]	ABS/VDC control module
79	-	
80	Throttle position sensor (TPS) #1 signal input	Throttle position sensor (TPS) #1 [ETC module]
81	-	
82	Accelerator Position Sensor (APS) #1 signal input	Accelerator Position Sensor (APS) #1
83	Sensor ground	Camshaft position sensor (CMPS)
84	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] signal input	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]
85	Sensor ground	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]
86	Engine speed signal output	Tachometer (Cluster)

FLA-28

Fuel System

Pin	Description	Connected to
87	A/C compressor relay control output	A/C compressor relay
88	Fan realy control output [High]	Fan realy [High]
89	Cruise control main lamp	Cluster
90	Cruise control set lamp	Cluster
91	-	
92	Malfunction Indicator Lamp (MIL) control output	Malfunction Indicator Lamp (Cluster)
93	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] heater control output	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]
94	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] heater control output	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]

Connector [CHG-A]

Pin	Description	Connected to
1	Ignition coil (Cylinder #1) control output (Non-Immobilizer)	Ignition coil (Cylinder #1)
	Ignition coil (Cylinder #4) control output (With-Immobilizer)	Ignition coil (Cylinder #4)
2	Ignition coil shield ground	Ignition coil (Cylinder #1,2,3,4)
3	Transaxle control output	
4	Transaxle control output	
5	Transaxle control output	
6	-	
7	-	
8	-	
9	Transaxle control output	
10	Transaxle control output	
11	Transaxle control output	
12	Transaxle control output	
13	-	
14	Alternator signal	Alternator
15	Cruise control switch ground	Multi - function switch
16	Ignition coil (Cylinder #3) control output (Non-Immobilizer)	Ignition coil (Cylinder #3)
	Ignition coil (Cylinder #2) control output (With-Immobilizer)	Ignition coil (Cylinder #2)
17	Transaxle control output	
18	Transaxle control output	
19	-	

Engine Control System

FLA-29

Pin	Description	Connected to
20	Transaxle control output	
21	-	
22	-	
23	-	
24	Transaxle control output	
25	Transaxle control output	
26	Transaxle control output	
27	-	
28	-	
29	Brake lamp switch signal input	Brake switch
30	Cruise control switch signal	Multi - function switch
31	Ignition coil (Cylinder #4) control output (Non-Immobilizer)	Ignition coil (Cylinder #4)
	Ignition coil (Cylinder #1) control output (With-Immobilizer)	Ignition coil (Cylinder #1)
32	Transaxle control output	
33	Transaxle control output	
34	Transaxle control output	
35	Transaxle control output	
36	Transaxle control output	
37	-	
38	Transaxle control output	
39	Transaxle control output	
40	Transaxle control output	
41	-	
42	Blower switch input	Blower switch
43	Clutch switch signal	Clutch switch
44	Brake switch signal input	Brake switch
45	-	
46	Ignition coil (Cylinder #2) control output (Non-Immobilizer)	Ignition coil (Cylinder #2)
	Ignition coil (Cylinder #3) control output (With-Immobilizer)	Ignition coil (Cylinder #3)
47	Transaxle control output	
48	Transaxle control output	
49	Transaxle control output	

FLA-30

Fuel System

Pin	Description	Connected to
50	Transaxle control output	
51	Transaxle control output	
52	-	
53	Transaxle control output	
54	Transaxle control output	
55	Transaxle control output	
56	-	
57	A/C switch ON input	A/C switch
58	Power steering switch signal output	Power steering switch
59	-	
60	-	

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System

FLA-31

IN/OUTPUT Signal Connector [CHG-K]

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
1	Power ground	Idle	DC voltage	Max. 50 mV		
2	Ignition switch signal input	IG OFF	DC voltage	Max. 0.5 V	10.2 mV	
		IG ON		Battery voltage	12.02 V	
3	Power ground	Idle	DC voltage	Max. 50 mV	2.8 mV	
4	Battery voltage supply after main relay	IG OFF	DC voltage	Max. 1.0 V	3.1 mV	
		IG ON		Battery voltage	12.1 V	
5	ECU ground	Idle	DC voltage	Max. 50 mV	1.8 mV	
6	Battery voltage supply after main relay	Removing the key	Current	Below 2.0 mA	0.38 mA	
		Always	DC voltage	Battery voltage	12.7 V	
7	Wheel speed sensor (WSS) [+] signal input	Engine run (30KPH)	SINE WAVE	15Hz :Min. 0.13Vpp 1000Hz :Min. 0.2Vpp Through :Max. 250Vpp		
8	-					
9	-					
10	-					
11	-					
12	Knock sensor (KS) signal input	Knocking	Irregular Frequency	0.3 ~ 0.3 V	Normal	
		Normal		0 V		
13	Sensor ground	Idle	DC voltage	Max. 50 mV	30 mV	
14	Sensor ground	Idle	DC voltage	Max. 50 mV	12.4 mV	
15	-					
16	Sensor ground	Idle	DC voltage	Max. 50 mV	29 mV	
17	Crankshaft position sensor (CMPS) signal input	Idle	PULSE	High : Battery voltage	5.00 V	Frequency : 600 Hz (Idle)
				Low : Max. 0.5V	40 mV	
18	-					
19	-					
20	-					
21	-					
22	-					
23	Fuel consumption signal output	Idle	PULSE	High : Battery voltage	13.7 V	Frequency :3.33 Hz
				Low : Max. 0.5V	0 V	PULSE Width : 500 μs

FLA-32

Fuel System

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
24	-					
25	Injector (Cylinder #1) control output	Idle	PULSE	High :Battery voltage	13.8 V	Frequency : 5.21 Hz (Idle)/Injection time : 2.74 ms
				Low : Max . 1.0V	200 mV	
				Vpeak : Max. 80V	54.1 V	
26	Injector (Cylinder #3) control output	Idle	PULSE	High :Battery voltage	13.9 V	Frequency : 5.18 Hz (Idle)/Injection time : 2.73 ms
				Low : Max . 1.0V	170 mV	
				Vpeak : Max. 80V	53.9 V	
27	Injector (Cylinder #4) control output	Idle	PULSE	High :Battery voltage	14 V	Frequency : 5.24 Hz (Idle)/Injection time : 2.70 ms
				Low : Max . 1.0V	160 mV	
				Vpeak : Max. 80V	54.3 V	
28	Injector (Cylinder #2) control output	Idle	PULSE	High :Battery voltage	14.1 V	Frequency : 5.21 Hz (Idle)/Injection time : 2.73 ms
				Low : Max . 1.0V	160 mV	
				Vpeak : Max. 80V	53.9 V	
29	Wheel speed sensor (WSS) [-] signal input [with ABS]	Engine run (30KPH)	SINE WAVE	15Hz :Min. 0.13Vpp 1000Hz :Min. 0.2Vpp Through :Max. 250Vpp		
30	Sensor power (+5V)	IG OFF	DC voltage	Max. 0.5V	0 mV	
		IG ON		5±0.1V	4.98 V	
31	Manifold absolute pressure sensor (MAPS) signal input	Idle	Analog	0.8 V ~ 1.6 V	1.37 V	
32	Throttle position sensor (TPS) #2 signal input	C.T	Analog	4.2 ~ 5.0V	4.52 V	
		W.O.T		3.3 ~ 3.8V	3.68 V	
33	Engine coolant temperature sensor (ECTS) signal input	Idle	Analog	0.5V ~ 4.5V	1.02 V	
34	Sensor ground	Idle	DC voltage	Max. 50 mV	8 mV	
35	Accelerator Position Sensor (APS) #2 signal input	C.T	Analog	0.3 ~ 0.9V	0.4 V	
		W.O.T		1.5 ~ 3.0V	1.9 V	
36	Sensor power (+5V)	IG OFF	DC voltage	Max. 0.5V	5 mV	
		IG ON		5±0.1V	5.02 V	
37	-					
38	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] signal input	Idle	DC voltage	Rich : 0.6 ~ 1.0V	926 mV	
				Lean : Max. 0.4V	20 mV	
39	Sensor ground	Idle	DC voltage	Max. 50 mV	11 mV	

Engine Control System

FLA-33

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
40	Vehicle speed signal input	Engine run	PULSE	High : Min. 4.5V	5 V	Frequency : 46.9 Hz (Idle)
				Low : Max. 0.5V	0 V	Duty(-) : 50.4% (Idle)
41	-					
42	-					
43	Sensor power (+5V)	IG OFF	DC voltage	Max. 0.5V		N.A.
		IG ON		5±0.1V		
44	-					
45	-					
46	-					
47	-					
48	-					
49	-					
50	-					
51	Battery voltage supply after main relay	IG OFF	DC voltage	Max. 1.0 V	3.1 mV	
		IG ON		Battery voltage	12.3 V	
52	-					
53	Intake Air temperature sensor (IATS) signal input	Idle	Analog	0V ~ 5V	2.55 V	
54	A/C pressure transducer (APT) signal input	Idle	DC voltage	0.4 ~ 4.6V	A/C OFF : 1.29 V	
					A/C ON : 2.01 V	
55	-					
56	-					
57	Sensor ground	Idle	DC voltage	Max. 50 mV	11 mV	
58	-					
59	Sensor ground	Idle	DC voltage	Max. 50 mV	6 mV	
60	Sensor power (+5V)	IG OFF	DC voltage	Max. 0.5V	10 mV	
		IG ON		5±0.1V	5.02 V	
61	Sensor ground	Idle	DC voltage	Max. 50 mV	30 mV	
62	Camshaft position sensor (CMPS) signal input	Idle	PULSE	High : Battery voltage	5.0 V	Frequency : 5.2 Hz (Idle)
				Low : Max. 0.5V	0.2 V	
63	Sensor power (+5V)	IG OFF	DC voltage	Max. 0.5V	0 mV	
		IG ON		5±0.1V	4.98 V	

FLA-34

Fuel System

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
64	Main relay control output	relay OFF	DC voltage	Battery voltage	12.3 V	
		relay ON		Max. 1.0 V	730 mV	
				Vpeak : Max. 70V	52.1 V	
65	Fan relay control output [Low]					
66	CVVT Oil control valve (OCV) control output	Idle	PULSE	High :Battery voltage	15.0 V	Frequency : 300 Hz Duty(+) : 84.7% (Idle)
				Low : Max. 1.0V	120 mV	
				Vpeak : Max. 70V	15.0 V	
67	Purge control solenoid valve (PCSV) control output	Inactive	PULSE	High :Battery voltage	14.3 V	Frequency : 16 Hz
		Active		Low : Max. 1.0V	80 mV	
				Vpeak : Max. 70V	57 V	
68	-					
69	Immobilizer lamp control output	lamp OFF	DC voltage	High :Battery voltage	13.2 V	
		lamp ON		Low : Max . 2.0V	40 mV	
70	Fuel pump relay control output	relay OFF	DC voltage	Battery voltage	12.8 V	
		relay ON		Max. 1.0V	40 mV	
				Vpeak : Max. 70V	47.3 V	
				Resistance : 680 Ω	680 Ω	
71	ETC motor [A] control output	Idle	PULSE	High :Battery voltage	13.4 V	
				Low : Max . 1.0V	0 V	
72	ETC motor [B] control output	Idle	PULSE	High :Battery voltage	13.3 V	
				Low : Max . 1.0V	0 V	
73	-					
74	Sensor ground	Idle	DC voltage	Max. 50 mV	7 mV	
75	Immobilizer communication line	After IG.ON	PULSE	High : Min. 8.5V	11.8 V	
		Communication		Low : Max . 3.5V	1.0 V	
76	-					
77	CAN [High]	RECESSIVE	PULSE	2.0 ~ 3.0 V	2.58 V	Communication speed : 500kbps
		DOMINANT		2.75~4.5 V	3.54 V	
78	CAN [Low]	RECESSIVE	PULSE	2.0 ~ 3.0 V	2.64 V	Communication speed : 500kbps
		DOMINANT		0.5~2.25 V	1.52 V	
79	-					
80	Throttle position sensor (TPS) #1 signal input	C.T	Analog	0.3 ~ 0.9V	0.65 V	
		W.O.T		1.5 ~ 3.0V	1.63 V	

Engine Control System

FLA-35

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
81	-					
82	Accelerator Position Sensor (APS) #1 signal input	C.T	Analog	0.3 ~ 0.9V	0.8 V	
		W.O.T		1.5 ~ 3.0V	4 V	
83	Sensor ground	Idle	DC voltage	Max. 50 mV	12 mV	
84	Heated Oxygen Sensor (H-O2S) [Bank 1/Sensor 2] signal input	Idle	DC voltage	Rich : 0.6 ~ 1.0V	740 mV	
				Lean : Max. 0.4V	70 mV	
85	Sensor ground	Idle	DC voltage	Max. 50 mV	10 mV	
86	Engine speed signal output	Idle	PULSE	High : Battery voltage	14.0 V	Duty(+) : 50% (Idle)
				Low : Max. 0.5V	60 mV	
				Idle = 20~26Hz (Reference)	21 Hz	
87	A/C compressor relay control output	A/C OFF	DC voltage	Battery voltage	14.3 V	Resistance : 680 Ohm
		A/C ON		Max. 1.0V	102 mV	
88	Fan relay control output [High]					
89	Cruise control main lamp					
90	Cruise control set lamp					
91	-					
92	Malfunction Indicator Lamp (MIL) control output	lamp OFF	DC voltage	Battery voltage	13.8 V	
		lamp ON		Max. 1.0V	54 mV	
93	Heated Oxygen Sensor (H-O2S) [Bank 1/Sensor 1] heater control output	Engine run	PULSE	High : Battery voltage	14.4 V	Frequency : 10 Hz
				Low : Max. 1.0V	0.36 V	Duty(+) : 58.3%
94	Heated Oxygen Sensor (H-O2S) [Bank 1/Sensor 2] heater control output	Engine run	PULSE	High : Battery voltage	14V	Frequency : 7.68Hz
				Low : Max. 1.0V	0.31V	Duty(+) : 53.9%

FLA-36

Fuel System

Connector [CHG-A]

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
1	Ignition coil (Cylinder #1) control output (Non-Immobilizer)	Idle	PULSE	1st voltage : 300~400V	416 V	Frequency : 5.2 Hz (Idle) Injection time : 2.78 ms
	Ignition coil (Cylinder #4) control output (With-Immobilizer)			ON voltage : Max. 2V	1.4 V	
2	Ignition coil shield ground	Idle	DC voltage	Max. 50 mV	16.8 mV	
3	Transaxle control output					
4	Transaxle control output					
5	Transaxle control output					
6	-					
7	-					
8	-					
9	Transaxle control output					
10	Transaxle control output					
11	Transaxle control output					
12	Transaxle control output					
13	-					
14	Alternator signal	Idle	PULSE	High : Battery voltage	13.4 V	
				Low : Max 1.5 V	40 mV	
15	Cruise control switch ground					
16	Ignition coil (Cylinder #3) control output (Non-Immobilizer)	Idle	PULSE	1st voltage : 300~400V	416 V	Frequency : 5.2 Hz (Idle)
	Ignition coil (Cylinder #2) control output (With-Immobilizer)			ON voltage : Max. 2V	1.3 V	Injection time : 2.73 ms
17	Transaxle control output					
18	Transaxle control output					
19	Transaxle control output					
20	Transaxle control output					
21	-					
22	-					
23	-					
24	Transaxle control output					

Engine Control System

FLA-37

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
25	Transaxle control output					
26	Transaxle control output					
27	-					
28	-					
29	Brake lamp switch signal input	Brake ON	DC voltage	Battery voltage		
		Brake OFF		Max. 0.5 V		
30	Cruise control switch signal					
31	Ignition coil (Cylinder #4) control output (Non-Immobilizer)	Idle	PULSE	1st voltage : 300~400V	408 V	Frequency : 5.2 Hz (Idle) Injection time : 2.74 ms
	Ignition coil (Cylinder #1) control output (With-Immobilizer)			ON voltage : Max. 2V	1.6 V	
32	Transaxle control output					
33	Transaxle control output					
34	Transaxle control output					
35	Transaxle control output					
36	Transaxle control output					
37	-					
38	Transaxle control output					
39	Transaxle control output					
40	Transaxle control output					
41	-					
42	Blower switch input	A/C OFF	DC voltage	Max. 0.5V	20 mV	
		A/C ON		Battery voltage	11.8 V	
43	Clutch switch signal	RELEASE	DC voltage	Max. 0.5V		
		PUSH		Battery voltage		
44	Brake switch signal input	PUSH	DC voltage	Max. 0.5 V		
		Normal		Battery voltage		
45	-					
46	Ignition coil (Cylinder #2) control output (Non-Immobilizer)	Idle	PULSE	1st voltage : 300~400V	410 V	Frequency : 5.2 Hz (Idle)
	Ignition coil (Cylinder #3) control output (With-Immobilizer)			ON voltage : Max. 2V	1.5 V	Injection time : 2.78 ms


FLA-38

Fuel System

Pin	Description	Condition	In/Output Signal		Test result	Remark
			Type	Level		
47	Transaxle control output					
48	Transaxle control output					
49	Transaxle control output					
50	Transaxle control output					
51	Transaxle control output					
52	-					
53	Transaxle control output					
54	Transaxle control output					
55	Transaxle control output					
56	-					
57	A/C switch ON input	A/C OFF	DC voltage	Max. 0.5V	0 V	
		A/C ON		Battery voltage	14 V	
58	Power steering switch signal output					
59	-					
60	-					

شرکت دیجیتال خودرو (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Control System

FLA-39


Circuit Diagram



STDF19202L

FLA-40


Fuel System



STDF19203L

Engine Control System


FLA-41



STDF19205L

FLA-42

Fuel System




STDF19206L

Engine Control System

FLA-43


Removal

1. Turn the ignition switch off and disconnect the battery (-) terminal.
2. Disconnect the ECM connector (A).
3. Remove the air cleaner (B). (Refer to Engine and Transaxle Assembly in EM group.)



STDF19114L

4. Unscrew 4 mounting bolts behind the air cleaner.
5. Remove the ECM.



STDF19115L

Installation

Installation is the reverse of removal.

Tightening Torque : 9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)

ECM Problem Inspection Procedure

1. TEST ECM GROUND CIRCUIT: Measure resistance between ECM and chassis ground using the backside of ECM harness connector as ECM side check point. If the problem is found, repair it.

Specification (Resistance): 1Ω or less

2. TEST ECM CONNECTOR: Disconnect the ECM connector and visually check the ground terminals on ECM side and harness side for bent pins or poor contact pressure.
3. If problem is not found in Step 1 and 2, the ECM could be faulty. If so, replace the ECM with a new one, and then check the vehicle again. If the vehicle operates normally then the problem was likely with the ECM.
4. RE-TEST THE ORIGINAL ECM : Install the original ECM (may be broken) into a known-good vehicle and check the vehicle. If the problem occurs again, replace the original ECM with a new one. If problem does not occur, this is intermittent problem (Refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE).


FLA-44

Fuel System

ETC (Electronic Throttle control) System


Description

ETC (Electronic Throttle Control) system is electronically controlled throttle device which controls the throttle valve. It consists of ETC motor, throttle body and throttle position sensor (TPS). A mechanical throttle control system receives a driver's intention via a wire cable between the accelerator and the throttle valve, while this ETC system does the signal from the Accelerator Position Sensor (APS) installed on the accelerator pedal. After the ECM receives the APS signal and calculates the throttle opening angle, it activates the throttle valve by using the ETC motor. Additionally, it can materialize cruise control function without any special devices.



STDF19109L

Schematic Diagram



STDF19207L

Engine Control System


FLA-45

Specification

[Throttle Position Sensor]

Throttle Angle (°)	Output Voltage (V)[Vref = 5.0V]	
	TPS1	TPS2
0	0	5.00
10	0.48	4.52
20	0.95	4.05
30	1.43	3.57
40	1.90	3.10
50	2.38	2.62
60	2.86	2.14
70	3.33	1.67
80	3.81	1.19
90	4.29	0.71
100	4.76	0.24
105	5.00	0
C.T (6 ~ 15°)	0.3 ~ 0.7	4.3 ~ 4.7
W.O.T (93 ~ 102°)	4.45 ~ 4.85	0.15 ~ 0.55

Item	Sensor Resistance (kΩ)
TPS1	0.875 ~ 1.625
TPS2	0.875 ~ 1.625



EGRF235A

[ETC Motor]


Item	Sensor Resistance
Coil Resistance (Ω)	1.2 ~ 1.8 [20°C (68°F)]



FLA-46

Fuel System

Circuit Diagram



STDF19208L

Fail-safe Mode

Items	Fail-safe	
ETC Motor	Throttle valve stuck at 5°	
TPS	TPS 1 fault	Replace it with TPS2
	TPS 2 fault	Replace it with TPS1
	TPS 1,2 fault	Throttle valve stuck at 5°
APS	APS 1 fault	Replace it with APS2
	APS 2 fault	Replace it with APS1
	APS 1,2 fault	Throttle valve stuck at 5°

NOTICE

When throttle value is stuck at 5°, engine speed is limited at below 1,500rpm and vehicle speed at maximum 40 ~ 50 km/h (25 ~ 31mph).

Engine Control System

FLA-47

Inspection

Throttle Position Sensor (TPS)

1. Connect a scantool on the Data Link Connector (DLC).
2. Start engine and check output voltages of TPS 1 and 2 at C.T and W.O.T.

Specification: Refer to Specification Section.

3. Turn ignition switch OFF and disconnect the scantool from the DLC.
4. Disconnect ETC module connector and measure resistance between ETC module terminals 1 and 2.

Specification: Refer to Specification Section.

ETC Motor

1. Disconnect ETC module connector and measure resistance between ETC module terminals 3 and 6.

Specification: Refer to Specification Section.

ETC System Initialization

When ignition switch is turned from OFF to ON, ETC system learns the throttle angle in 1 sec.

1. Throttle valve moves from limp-home position to close position.
2. And then, it opens to about 15° and moves to limp-home position.




FLA-48

Fuel System

Manifold Absolute Pressure Sensor (MAPS)

Description



STDF19209L

Manifold Absolute Pressure Sensor (MAPS) is speed-density type sensor and is installed on the surge tank. This MAPS senses absolute pressure in surge tank and transfers this analog signal proportional to the pressure to the ECM. The ECM calculates the intake air quantity and engine speed based on this signal. This MAPS consists of piezo-electric element and hybrid IC that amplifies the element output signal. The element is silicon diaphragm type and adapts pressure sensitive variable resistor effect of semi-conductor. 100% vacuum and the manifold pressure applies to both sides of it respectively. That is, this sensor outputs the silicon variation proportional to pressure change by voltage.


Specification

Pressure(kPa)	Output Voltage (V)
20.0	0.79
46.66	1.84
101.32	4.0

Engine Control System

FLA-49

Circuit Diagram




STDF19210L

Inspection

1. Connect a scantool on Diagnosis Link Connector (DLC).
2. Check MAPS output voltage at idle and IG ON.

Condition	Output Voltage (V)
Idle	0.8 ~ 1.6
IG ON	3.9 ~ 4.1




FLA-50

Fuel System

Intake Air Temperature Sensor (IATS)

Description



STDF19211L

Intake Air Temperature Sensor (IATS) is installed inside the Manifold Absolute Pressure Sensor (MAPS) and detects the intake air temperature. To calculate precise air quantity, correction of the air temperature is needed because air density varies according to the temperature. So the ECM uses not only MAPS signal but also IATS signal. This sensor has a Negative Temperature Coefficient (NTC) and its resistance is in inverse proportion to the temperature.


Specification

Temperature [°C (°F)]	Resistance (kΩ)
-40 (-40)	40.93 ~ 48.35
-30 (-22)	23.43 ~ 27.34
-20 (-4)	13.89 ~ 16.03
-10 (14)	8.50 ~ 9.71
0 (32)	5.38 ~ 6.09
10 (50)	3.48 ~ 3.90
20 (68)	2.31 ~ 2.57
25 (77)	1.90 ~ 2.10
30 (86)	1.56 ~ 1.74
40 (104)	1.08 ~ 1.21
60 (140)	0.54 ~ 0.62
80 (176)	0.29 ~ 0.34

Engine Control System

FLA-51

Circuit Diagram



STDF19210L

Inspection

1. Turn ignition switch OFF.
2. Disconnect IATS connector.
3. Measure resistance between IATS terminals 3 and 4.
4. Check that the resistance is within the specification.

Specification: Refer to Specification Section.

FLA-52

Fuel System


Engine Coolant Temperature Sensor (ECTS)

Description


Engine Coolant Temperature Sensor (ECTS) is located in the engine coolant passage of the cylinder head for detecting the engine coolant temperature. The ECTS uses a thermistor whose resistance changes with the temperature. The electrical resistance of the ECTS decreases as the temperature increases, and increases as the temperature decreases. The reference 5 V in the ECM is supplied to the ECTS via a resistor in the ECM. That is, the resistor in the ECM and the thermistor in the ECTS are connected in series. When the resistance value of the thermistor in the ECTS changes according to the engine coolant temperature, the output voltage also changes. During cold engine operation the ECM increases the fuel injection duration and controls the ignition timing using the information of engine coolant temperature to avoid engine stalling and improve drivability.

Specification

Temperature [$^{\circ}$ C ($^{\circ}$ F)]	Resistance($k\Omega$)
-40(-40)	48.14
-20(-4)	14.13 ~ 16.83
0(32)	5.79
20(68)	2.31 ~ 2.59
40(104)	1.15
60(140)	0.59
80(176)	0.32



STDF19104L




EGRF241A

Engine Control System

FLA-53

Circuit Diagram



STDF19212L

Inspection

1. Turn ignition switch OFF.
2. Disconnect ECTS connector.
3. Remove the ECTS.
4. After immersing the thermistor of the sensor into engine coolant, measure resistance between ECTS terminals 3 and 4.
5. Check that the resistance is within the specification.

Specification: Refer to Specification Section.


FLA-54

Fuel System

Camshaft Position Sensor (CMPS)


Description

Camshaft Position Sensor (CMPS) is a hall sensor and detects the camshaft position by using a hall element. It is related with Crankshaft Position Sensor (CKPS) and detects the piston position of each cylinder which the CKPS can't detect. The CMPS are installed on engine head cover and uses a target wheel installed on the camshaft. This sensor has a hall-effect IC which output voltage changes when magnetic field is made on the IC with current flow.



STDF19105L

Waveform



SNFFL9613L


1) There are 60 signals of CKPS(Including missing tooth) during the semi-cycle of CMPS.

2) There are 3~5 signals of CKPS between the switching point of CMPS and the missing tooth of CKPS.

Engine Control System

FLA-55

Circuit Diagram



STDF19213L

Inspection

1. Check signal waveform of CMPS and CKPS using a scantool.

Specification : Refer to "WAVE FORM"


FLA-56

Fuel System

Crankshaft Position Sensor (CKPS)


Description

Crankshaft Position Sensor (CKPS) detects the crankshaft position and is one of the most important sensors of the engine control system. If there is no CKPS signal input, the engine may stop because of CKPS signal missing. This sensor is installed on transaxle housing and generates alternating current by magnetic flux field which is made by the sensor and the target wheel when engine runs. The target wheel consists of 58 slots and 2 missing slots on 360 degrees CA (Crank Angle).



STDF19104L

Waveform



SNFFL9613L


1) There are 60 signals of CKPS(Including missing tooth) during the semi-cycle of CMPS.

2) There are 3~5 signals of CKPS between the switching point of CMPS and the missing tooth of CKPS.

Engine Control System

FLA-57

Circuit Diagram



STDF19214L

Inspection

1. Check signal waveform of CKPS and CMPS using a scantool.

Specification : Refer to "WAVE FORM"


FLA-58

Fuel System


Heated Oxygen Sensor (HO2S)

Description

Heated Oxygen Sensor (HO2S) consists of zirconium and alumina and is installed on upstream and downstream of the Manifold Catalyst Converter (MCC). After it compares oxygen consistency of the atmosphere with the exhaust gas, it transfers the oxygen consistency of the exhaust gas to the ECM. When A/F ratio is rich or lean, it generates approximately 1V or 0V respectively. In order that this sensor normally operates, the temperature of the sensor tip is higher than 370°C (698°F). So it has a heater which is controlled by the ECM duty signal. When the exhaust gas temperature is lower than the specified value, the heater warms the sensor tip.



EGRF247A



EGRF248A

Engine Control System

FLA-59


Specification

A/F Ratio	Output Voltage (V)
RICH	0.6 ~ 1.0
LEAN	0.1 ~ 0.4

Item	Specification
Heater Resistance (Ω)	3.1 ~ 4.1 [20°C (68°F)]

Circuit Diagram

[Circuit Diagram]



[Connection Information]

HO2S (B1/S1)

Terminal	Connected to	Function
1	ECM CHG-K (38)	HO2S (B1/S1) Signal
2	ECM CHG-K (16)	Sensor Ground
3	Main Relay	Power Supply (B+)
4	ECM CHG-K (93)	Heater Control


HO2S (B1/S2)

Terminal	Connected to	Function
1	ECM CHG-K (85)	Sensor Ground
2	ECM CHG-K (84)	HO2S (B1/S2) Signal
3	ECM CHG-K (94)	Heater Control
4	Main Relay	Power Supply (B+)


[Harness Connector]



CHG16
HO2S (B1/S1)



CHG22
HO2S (B1/S2)



CHG-K
ECM

STDF19215L

Inspection

1. Disconnect the HO2S connector.
2. Measure resistance between HO2S heater terminals 3 and 4.
3. Check that the resistance is within the specification.

Specification: Refer to Specification Section.


FLA-60

Fuel System


Knock Sensor (KS)

Description

Knocking is a phenomenon characterized by undesirable vibration and noise and can cause engine damage. Knock Sensor (KS) senses engine knocking and the cylinder block. When knocking occurs, the vibration from the cylinder block is applied as pressure to the piezoelectric element. At this time, this sensor transfers the voltage signal higher than the specified value to the ECM and the ECM retards the ignition timing. If the knocking disappears after retarding the ignition timing, the ECM will advance the ignition timing. This sequential control can improve engine power, torque and fuel economy.



SNFFL9003N



EGRF252A

Specification


Item	Specification
Capacitance (pF)	1,480 ~ 2,220
Resistance (MΩ)	1.0

Engine Control System

FLA-61

Circuit Diagram


[Circuit Diagram]




[Connection Information]

Terminal	Connected to	Function
1	ECM CHG-K (34)	Sensor Ground
2	ECM CHG-K (12)	Knock Sensor Signal

[Harness Connector]




CHG23
KNOCK SENSOR



CHG-K
ECM

دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

STDF19216L



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


FLA-62

Fuel System

Injector

Description

Based on information from various sensors, the ECM measures the fuel injection amount. The fuel injector is a solenoid-operated valve and the fuel injection amount is controlled by length of time that the fuel injector is held open. The ECM controls each injector by grounding the control circuit. When the ECM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the ECM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should momentarily peak.



Specification

Item	Specification
Coil Resistance (Ω)	13.8 ~ 15.2 [20°C (68°F)]



دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

KFCF1026

Engine Control System

FLA-63

Circuit Diagram



STDF19217L

Inspection

1. Turn ignition switch OFF.
2. Disconnect injector connector.
3. Measure resistance between injector terminals 1 and 2.
4. Check that the resistance is within the specification.

Specification: Refer to Specification Section.

FLA-64


Fuel System

CVT Oil Control Valve (OCV)

Description

The Continuously Variable Valve Timing (CVVT) system controls the amount of valve over-lap by varying the amount of oil flow into an assembly mounted on the intake camshaft through ECM control of an oil control valve. As oil is directed into the chambers of the CVVT assembly, the cam phase is changed to suit various performance and emissions requirements.

1. When camshaft rotates engine rotation-wise: Intake-Advance / Exhaust-Retard
2. When camshaft rotates counter engine rotation-wise: Intake- Retard / Exhaust- Advance



STDF19112L

Specification

Item	Specification
Coil Resistance (Ω)	6.9 ~ 7.9 [20°C (68°F)]

Circuit Diagram

[Circuit Diagram]

[Connection Information]

Terminal	Connected to	Function
1	ECM CHG-K (66)	OCV control
2	Main relay	Power supply (B+)

[Harness Connector]

CHG05
OCV

CHG-K
ECM

STDF19218L

Inspection

1. Turn ignition switch OFF.
2. Disconnect OCV connector.
3. Measure resistance between OCV terminals 1 and 2.
4. Check that the resistance is within the specification.

Specification: Refer to Specification Section.


Engine Control System

FLA-65

Purge Control Solenoid Valve (PCSV)

Description

Purge Control Solenoid Valve (PCSV) is installed on the surge tank and controls the passage between the canister and the intake manifold. It is a solenoid valve and is open when the ECM grounds the valve control line. When the passage is open (PCSV ON), fuel vapors stored in the canister is transferred to the intake manifold.




STDF19111L

Specification

Item	Specification
Coil Resistance (Ω)	19.0 ~ 22.0 [20°C (68°F)]

Circuit Diagram



STDF19219L

Inspection

1. Turn ignition switch OFF.
2. Disconnect PCSV connector.
3. Measure resistance between PCSV terminals 1 and 2.
4. Check that the resistance is within the specification.


Specification: Refer to Specification Section.

FLA-66

Fuel System

Accelerator Position Sensor (APS)

Description



STDF19220L

Accelerator Position Sensor (APS) is installed on the accelerator pedal module and detects the rotation angle of the accelerator pedal. The APS is one of the most important sensors in engine control system, so it consists of the two sensors which adapt individual sensor power and ground line. The second sensor monitors the first sensor and its output voltage is half of the first one. If the ratio of the sensor 1 and 2 is out of the range (approximately 1/2), the diagnostic system judges that it is abnormal.

Specification

Pedal Position	Output Voltage (V) [Vref = 5.0V]	
	APS1	APS2
C.T	0.7 ~ 0.8	0.275 ~ 0.475
W.O.T	3.85 ~ 4.35	1.75 ~ 2.35


Items	Sensor Resistance (kΩ)
APS1	0.8 ~ 1.6 [20°C (68°F)]
APS2	0.9 ~ 2.5 [20°C (68°F)]

Engine Control System

FLA-67

Circuit Diagram


[Circuit Diagram]




[Connection Information]

Terminal	Connected to	Function
1	ECM CHG-K (35)	APS 2 Signal
2	ECM CHG-K (13)	Sensor ground
3	ECM CHG-K (82)	APS 1 Signal
4	ECM CHG-K (61)	Sensor ground
5	ECM CHG-K (60)	Sensor power (+5V)
6	ECM CHG-K (36)	Sensor power (+5V)

[Harness Connector]



CHG60
APS



CHG-K
ECM

STDF19221L

Inspection

1. Connect a scan tool to the Diagnosis Link Connector (DLC).
2. Start engine and check output voltages of APS 1 and 2 at C.T and W.O.T.

Specification: Refer to Specification Section.

3. Turn ignition switch OFF and disconnect the scan tool from the DLC.
4. Disconnect APS connector and measure resistance between APS terminals 4 and 5 (APS 1).

Specification: Refer to Specification Section.

5. Disconnect APS connector and measure resistance between APS terminals 1 and 6 (APS 2).


Specification: Refer to Specification Section.

FLA-68

Fuel System

Fuel Delivery System

Component Location



STDFL9150L

- | | |
|--------------------------------------|--------------------------------------------|
| 1. Fuel Tank | 6. Canister |
| 2. Fuel Pump (Including Fuel Filter) | 7. Vapor Hose (Canister → Intake Manifold) |
| 3. Fuel Pressure Regulator | 8. Vapor Hose (Canister ↔ Fuel Tank) |
| 4. Fuel Filler Pipe | 9. Vapor Hose (Canister ↔ Atmosphere) |
| 5. Leveling Pipe | |


Fuel Delivery System

FLA-69

Fuel Pressure Test


1. PREPARING

1. Remove the rear seat cushion (Refer to "SEAT" in BD group).
2. Open the service cover (A).



2. RELEASE THE INTERNAL PRESSURE

1. Disconnect the fuel pump connector (A).
2. Start the engine and wait until fuel in fuel line is exhausted.
3. After the engine stalls, turn the ignition switch to OFF position and disconnect the negative (-) terminal from the battery.



NOTE

Be sure to reduce the fuel pressure before disconnecting the fuel feed hose, otherwise fuel will spill out.



3. INSTALL THE SPECIAL SERVICE TOOL (SST) FOR MEASURING THE FUEL PRESSURE

1. Disconnect the fuel feed hose from the delivery pipe.

CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

2. Install the Fuel Pressure Gauge Adapter (09353-38000) between the delivery pipe and the fuel feed hose.
3. Connect the Fuel Pressure Gauge Connector (09353-24000) to the Fuel Pressure Gauge Adapter (09353-38000).
4. Connect the Fuel Pressure Gauge and Hose (09353-24100) to Fuel Pressure Gauge Connector (09353-24000).
5. Connect the fuel feed hose to the Fuel Pressure Gauge Adapter (09353-38000).



STDF19222L

FLA-70

Fuel System

4. INSPECT FUEL LEAKAGE ON CONNECTION

1. Connect the battery negative (-) terminal.
2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.

5. FUEL PRESSURE TEST

1. Disconnect the negative (-) terminal from the battery.
2. Connect the fuel pump connector.
3. Connect the battery negative (-) terminal.
4. Start the engine and measure the fuel pressure at idle.

Standard Value: 345 ~ 355 kpa (3.5 ~ 3.6 kgf/cm², 50.0 ~ 51.5 psi)

- If the measured fuel pressure differs from the standard value, perform the necessary repairs using the table below.

Condition	Probable Cause	Suspected Area
Fuel Pressure too low	Clogged fuel filter	Fuel filter
	Fuel leak on the fuel-pressure regulator that is assembled on fuel pump because of poor sealing of the fuel-pressure regulator.	Fuel Pressure Regulator
Fuel Pressure too High	Sticking fuel pressure regulator	Fuel Pressure Regulator

5. Stop the engine and check for a change in the fuel pressure gauge reading.

After engine stops, the gage reading should hold for about 5 minutes

- Observing the declination of the fuel pressure when the gage reading drops and perform the necessary repairs using the table below.

Condition	Probable Cause	Supected Area
Fuel pressure drops slowly after engine is stopped	Injector leak	Injector
Fuel pressure drops immediately after engine is stopped	The check valve within the fuel pump is open	Fuel Pump


STDFL9152L

Fuel Delivery System

FLA-71

6. RELEASE THE INTERNAL PRESSURE

1. Disconnect the fuel pump connector (A).
2. Start the engine and wait until fuel in fuel line is exhausted.
3. After the engine stalls, turn the ignition switch to OFF position and disconnect the negative (-) terminal from the battery.



NOTE

Be sure to reduce the fuel pressure before disconnecting the fuel feed hose, otherwise fuel will spill out.

7. REMOVE THE SPECIAL SERVICE TOOL (SST) AND CONNECT THE FUEL LINE

1. Disconnect the Fuel Pressure Gage and Hose (09353-24100) from the Fuel Pressure Gage Connector (09353-24000).
2. Disconnect the Fuel Pressure Gage Connector (09353-24000) from the Fuel Pressure Gage Adapter (09353-38000).
3. Disconnect the fuel feed hose from the Fuel Pressure Gage Adapter (09353-38000).
4. Disconnect the Fuel Pressure Gage Adapter (09353-38000) from the delivery pipe.

CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

5. Connect the fuel feed hose to the delivery pipe.

8. INSPECT FUEL LEAKAGE ON CONNECTION

1. Connect the battery negative (-) terminal.
2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.
3. If the vehicle is normal, connect the fuel pump connector.

STDFL9153L

FLA-72


Fuel System

Fuel Tank

Removal


1. Preparation

- 1) Remove the rear seat cushion (Refer to "Seat" in BD group).
- 2) Open the service cover (A).



STDFL9159D


- 3) Disconnect the fuel pump connector (A).



STDFL9154L


- 4) Start the engine and wait until fuel in fuel line is exhausted.
- 5) After engine stalls, turn the ignition switch to OFF position.

2. Disconnect the fuel feed quick-connector (A) and the vapor tube quick-connector (B).



STDFL9156L


3. Lift the vehicle and support the fuel tank with a jack.
4. Remove the center muffler (Refer to "Intake And Exhaust System" in EM group).
5. Disconnect the fuel filler hose (A), the leveling hose (B) and the vapor hose (C).



STDFL9157L


Fuel Delivery System

FLA-73



STDFL9158L

6. Remove the fuel tank mounting bolts (A) and nuts (B), and then remove the fuel tank (C).



SHDFL8170C

Installation

Installation is reverse of removal.

Fuel tank installation bolt: 44.1 ~ 58.8 N.m (4.5 ~ 6.0 kgf.m, 32.5 ~ 43.4 lb-ft)

Fuel tank installation nut: 39.2 ~ 53.9 N.m (4.0 ~ 5.5 kgf.m, 28.9 ~ 39.8 lb-ft)

FLA-74


Fuel System

Fuel Pump

Removal


1. Preparation

- 1) Remove the rear seat cushion (Refer to "Seat" in BD group).
- 2) Open the service cover (A).



STDFL9159D


- 3) Disconnect the fuel pump connector (A).



STDFL9154L


- 4) Start the engine and wait until fuel in fuel line is exhausted.
- 5) After engine stalls, turn the ignition switch to OFF position.

2. Disconnect the fuel feed tube quick-connector (A), the vapor hose (B) and the vapor tube quick-connector (C).



STDFL9160L

3. Remove the fuel pump installation bolts (D) and remove the fuel pump assembly.



SHDFL8172C

Installation

Installation is reverse of removal.

Fuel pump installation bolt: 2.0 ~ 2.9 N.m (0.2 ~ 0.3 kgf.m, 1.4 ~ 2.2 lb-ft)

CAUTION

When installing the fuel pump module, be careful not to get the seal-ring entangled.


Fuel Delivery System

FLA-75

Fuel Filter


Replacement

1. Remove the fuel pump (Refer to "Fuel Pump" in this group).
2. Disconnect the electric pump wiring connector (A) and the fuel sender wiring connector (B).



SHDFL8173C


3. Disconnect the electric pump wiring connector (A) from the pump.



SHDFL8174C


4. Remove the fuel sender (B) with sliding it downward after releasing the latch (C).

5. Remove the fuel pressure regulator & hose assembly (A) after releasing the cap (B).



SHDFL8175C

6. Remove the reservoir cup (A) after releasing the three fixing hooks (B).




SHDFL8176C

FLA-76


Fuel System

- Remove the fuel feed tube (A) from the fuel filter after releasing the two fixing hooks.




SHDFL8177C


- Remove the plate assembly (B) after removing the cushion pipe fixing clip (C).
- Extract the fuel filter (A) upward after releasing the two fixing hooks (B)



SHDFL8178C



SHDFL8179C



SHDFL8183C




Fuel Delivery System

FLA-77

Filler-Neck Assembly


Removal

1. Disconnect the fuel filler hose (A), the leveling hose (B) and the vapor hose (C).



STDFL9161L


2. Open the fuel filler door and unfasten the filler-neck assembly mounting screws (A).



SCMFL6655D

3. Remove the rear-LH wheel, tire, and the inner wheel house.

4. Remove the bracket mounting bolt (A) and remove the filler-neck assembly.



SHDFL8181C

Installation

1. Installation is reverse of removal.

Filler-neck assembly installation bolt:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)

Filler-neck assembly installation screw:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)