

# HORN SYSTEM

GENERAL INFORMATION			
System Overview	31 - 2	Horn Relay Inspection	31 - 5
Description	31 - 2	Horn Ground Point Inspection	31 - 5
Tool	31 - 2	ON-VEHICLE SERVICE	31 - 6
Torque specification	31 - 3	High Pitched Horn Assembly	31 - 6
	31 - 3	Removal	31 - 6
DIAGNOSIS & TESTING	31 - 4	Inspection	31 - 7
Problem Symptoms Table	31 - 4	Installation	31 - 7
Horn System Inspection	31 - 4	Low Pitched Horn Assembly	31 - 7
Troubleshooting for Abnormal Horn		Removal	31 - 7
Sound	31 - 5	Inspection	31 - 8
Horn Fuse Inspection	31 - 5	Installation	31 - 8

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## GENERAL INFORMATION

### System Overview

#### Description




1	Horn Switch	2	Engine Compartment Fuse and Relay Box
3	High Pitched Horn	4	Low Pitched Horn

This vehicle is equipped with dual electronic horn (high pitched, low pitched) system. Horn system consists of following components:

- Horn: High pitched horn is installed in groove of front bumper crossmember left mounting plate, and low pitched horn is installed in groove of front bumper crossmember right mounting plate.
- Horn switch: Horn switch is installed on steering wheel.
- Horn fuse: Horn fuse is located in engine compartment fuse and relay box.
- Horn relay: Horn relay is located in engine compartment fuse and relay box.

**Tool**

Tool Name	Tool Drawing
Digital Multimeter	 RCH0002006

**Torque specification**

Description	Torque (N·m)
Horn Bracket Fixing Nut	16 ± 2

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## DIAGNOSIS & TESTING

### Problem Symptoms Table

#### Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

Symptom	Suspected Area
Low pitched horn does not sound	Low pitched horn is damaged
	Wire harness (open)
	Connector (loose)
High pitched horn does not sound	High pitched horn is damaged
	Wire harness (open)
	Connector (loose)
Horn does not sound	Horn fuse (blown)
	Horn relay
	Horn switch (damaged)
	Spiral cable (damaged)
	Wire harness (short or open)

### Horn System Inspection

Press and release the horn button

Measure	OK	NG
Press and release the horn button	Horn sounding when horn button is pressed, and horn stops sounding when horn button is released.	Horn does not sound and sounds abnormally

Horn does not sound or sounds abnormally

Symptom	Troubleshooting
Horn sounds hoarsely	Check the battery or power supply circuit
Only high pitched horn or low pitched horn sounds	Check and repair wire harness of horn that does not sound or replace horn
Both high pitched and low pitched horns do not sound	Check horn fuse or relay box
Button horn sounds, but wireless door locking does not sound	Check if the audio setting is “only fortify light”, and reset it to “fortify horn + light” if it is possible. If setting is correct and the fault still exists, check and repair BCM and line
Horn does not sound when pressing button, and sounds when locking vehicle with remote controller	Check and repair horn button and its circuit

## Troubleshooting for Abnormal Horn Sound

1. If horn sound is obviously abnormal, perform the following routine inspection:
  - a. Check terminals for poor contact; repair any poor contact problem;
  - b. Check ground circuit; if there is poor contact, repair it;
  - c. Make sure horn assembly fixing bolt is properly fastened;
  - d. Make sure there is no contact between horn assembly and any other objects; if contact occurs, determine the correct position of other objects again, bend the horn assembly bracket if necessary, and operate horn to determine if the situation still exists.
2. If the situation is still obvious, perform the following specific inspection:
  - a. Determine the type of sound produced by horn: grave, sharp.
  - b. If it is obviously grave, it indicates that the current is too high and the horn assembly must be replaced.
  - c. If it is obviously sharp, foreign matters may attach to horn, remove horn assembly and check for foreign matters.
  - d. Remove any attached foreign matters and reinstall the horn assembly.

### WARNING

If no foreign matter is found, or if the foreign matter cannot be removed, replace horn assembly.

## Horn Fuse Inspection

1. Identify the horn fuse in engine compartment fuse and relay box.
2. Check the horn fuse.
  - a. Using a fuse puller, remove the horn fuse.
  - b. Check if fuse is blown. Replace fuse if it is blown.

### CAUTION

Use a fuse with the same specification as original fuse to avoid affecting the normal use of electrical equipment.

## Horn Relay Inspection

1. Identify the horn relay in engine compartment fuse and relay box.
2. Check the horn relay.
  - a. Remove the horn relay and press the multimeter to check.

Multimeter Connection	Condition	Specified Condition
Terminal 3 - Terminal 5	When battery voltage is not applied between terminal 2 and terminal 2	$\infty$
Terminal 3 - Terminal 5	When battery voltage is applied between terminal 2 and terminal 1	$\leq 1 \Omega$

If result is not as specified, replace relay.

## Horn Ground Point Inspection


Ground position of horn is located in steering wheel, it is grounded over steering column and body, and the resistance cannot be greater than  $1 \Omega$ .

## ON-VEHICLE SERVICE

### High Pitched Horn Assembly

#### Removal

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the front bumper assembly.
4. Disconnect the high pitched horn wire harness connector.




5. Remove high pitched horn fixing nut.

#### Tightening torque

$16 \pm 2 \text{ N m}$


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## Inspection

1. Apply battery voltage to high pitched horn and check operation of high pitched horn.

Measurement Condition	Condition	Specified Condition
Battery positive (+) - Terminal 1	Always	Horn sounds
Battery negative (-) - Terminal 2	Always	Horn sounds



### Hint:

If result is not as specified, replace high pitched horn.

2. Using a digital multimeter, check horn system wire harness for open, short or ground failure. Replace them if necessary.

## Installation

### Caution


- Tighten the fixing nuts to the specified torque.
- Install connectors securely.

1. Installation is in the reverse order of removal.

## Low Pitched Horn Assembly

### Removal

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the front bumper assembly.
4. Disconnect the low pitched horn wire harness connector.




## 31 - HORN SYSTEM

- Remove low pitched horn fixing nut.

**Tightening torque**

16 ± 2 N m




HO0030

**Inspection**

- Apply battery voltage to low pitched horn and check operation of low pitched horn.

Measurement Condition	Condition	Specified Condition
Battery positive (+) - Terminal 1	Always	Horn sounds
Battery negative (-) - Terminal 2	Always	Horn sounds



HO0070

**Hint:**

If result is not as specified, replace low pitched horn.

- Using a digital multimeter, check horn system wire harness for open, short or ground failure. Replace them if necessary.

**Installation****Caution**

- Tighten the fixing nuts to the specified torque.
- Install connectors securely.

- Installation is in the reverse order of removal.