

# SQRD4T20 IGNITION SYSTEM

<b>GENERAL INFORMATION</b>	<b>12-3</b>	<b>ON-VEHICLE SERVICE</b>	<b>12-7</b>
Overview	12-3	<b>Ignition Coil Assembly</b>	<b>12-7</b>
Description	12-3	Removal	12-7
Operation	12-4	Ignition Circuit	12-8
Specifications	12-4	Inspection	12-9
Tools	12-4	Installation	12-9
<b>DIAGNOSIS &amp; TESTING</b>	<b>12-5</b>	<b>Spark Plug</b>	<b>12-9</b>
<b>Diagnostic Content</b>	<b>12-5</b>	Removal	12-9
Problem Symptoms Table	12-5	Inspection	12-10
Service precautions	12-6	Spark Jump Test Method	12-10
		Spark Plug Common Problems	12-10
		Installation	12-12

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



12

12

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## GENERAL INFORMATION

### Overview

### Description



1 - Spark Plug	2 - Cylinder 4 Ignition Coil Assembly
3 - Cylinder 3 Ignition Coil Assembly	4 - Cylinder 2 Ignition Coil Assembly
5 - Cylinder 1 Ignition Coil Assembly	

## Operation

- Ignition system mainly consists of sensors, Engine Control Module (ECM), ignition coils, spark plugs, etc. Ignition advance angle is controlled by Engine Control Module (ECM) directly.
- As an integrated module, the ignition coil cannot be disassembled. D4T20 adapts independent ignition, secondary high terminal of each ignition coil is connected to ignition spark in engine cylinder separately through high-voltage connecting rod. Low-voltage terminal of ignition primary coil is connected to Engine Control Module (ECM) through wire harness.
- Engine Control Module (ECM) receives the Top Dead Center (TDC) position of each cylinder piston via input signal of phase sensor, and uses the speed sensor signal to make ignition coil to operate.

## Specifications

### Torque Specifications

Description	Torque (N·m)
Spark Plug	20 + 3
Ignition Coil Fixing Bolt	8 + 2


### Spark Plug Specifications

Description	Specifications
Engine Type	SQRD4T20
Spark Plug Gap (mm)	0.7 - 0.8

## Tools

### General Tools

12

<p>شرکت دیجیتال خودرو سامانه (مسئولیت محدود)</p> <p>اولین سامانه دیجیتال تعمیرکاران خودرو در ایران</p> <p>Digital Multimeter</p>	 <p>002</p>
--	---

# DIAGNOSIS & TESTING

## Diagnostic Content

### Problem Symptoms Table

#### Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

Symptom	Suspected Area
Stall	Ignition coil
	Camshaft position sensor
	Spark plug
	Intake camshaft phaser control valve
	Exhaust camshaft phaser control valve
	Wire harness
Knock	ECU
	Ignition coil
	Knock sensor
Difficult to start	ECU
	Battery
	Ignition coil
	Spark Plug
Engine hesitation, power drop, unstable performance	Engine speed sensor
	Ignition coil
	Engine speed sensor
	Intake camshaft phaser control valve
	Exhaust camshaft phaser control valve
	Spark plug
Rough, unstable idling or stall	Camshaft position sensor
	ECU
	Ignition coil
	Camshaft position sensor
Spark plug	Spark plug
	ECU

## **Service precautions**

Visual inspection can reduce the unnecessary test and diagnostic time, so pay attention to the following inspection items:

1. Check the line and hose for obvious looseness, and if they are disconnected or routed improperly.
2. Make sure that the battery connections are clean and fixed firmly.
3. Check if the generator wire and belt are installed correctly and securely.
4. Check if the engine wire harness connectors are inserted fully.
5. Check if all electrical connectors are installed correctly and securely.
6. Check the following electrical connections
  - (a) Engine speed sensor
  - (b) Oxygen sensor
  - (c) Intake pressure/temperature sensor
  - (d) Oil pressure switch
  - (e) Ignition coil
  - (f) Canister solenoid valve
  - (g) Camshaft position sensor
  - (h) Electronic throttle
  - (i) Intake Variable Valve Timing (VVT) control valve
  - (j) Exhaust Variable Valve Timing (VVT) control valve
  - (k) Fuel injector
7. Check the routing of all vacuum hoses.
8. Confirm that the following vacuum hoses are connected securely without any leakage
  - (a) Canister solenoid valve
  - (b) PCV valve
  - (c) Brake booster
9. Check the fuel pump hose and wire connection to make sure that they are connected securely.

## ON-VEHICLE SERVICE

### Ignition Coil Assembly


#### Removal

##### Warning/Caution/Hint


###### Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.
- It is prohibited to use short circuit spark test to test ignition function during repair, otherwise it may damage the module.
- During usage, do not remove ignition coil from spark plug with bare hands with power on, and do not contact the metal part directly, to avoid electric shock.

1. Turn off all electrical equipment and the ignition switch.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover.
4. Remove the ignition coil.
  - (a) Disconnect ignition coil connectors (arrow), and move away wire harness from ignition coil.



12




(b) Remove 8 fixing bolts (arrow) from ignition coils.

#### Tightening torque

$8 \pm 2 \text{ N}\cdot\text{m}$

## Ignition Circuit



## Inspection

1. Check appearance of ignition coil
  - (a) It is necessary to use "Substitution Method" to confirm if this coil is in good condition.

## Installation

1. Installation is in the reverse order of removal.

### Caution:

- Make sure that the connection of ignition coil high-voltage output terminal and spark plug is reliable, or it may cause high-voltage leakage, resulting in poor ignition.
- Before installation, check cylinder head spark plug mounting hole. Never allow impurities entering during assembly.
- Install the ignition coil into cylinder head cover mounting hole and press it to close to mounting boss on cylinder head cover. Never turn ignition coil to left/right after pressing and do not tap ignition coil with a hammer etc.

## Spark Plug

### Removal

#### Warning/Caution/Hint


##### Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.
- DO NOT remove the spark plugs when engine is hot; failure to do this may cause damage to the spark plug thread holes on cylinder head.
- Before removal, remove the dirt and foreign matter around spark plug holes to prevent them from dropping into cylinders.

1. Turn off all electrical equipment and the ignition switch. Wait until engine cools down and then perform removal to avoid "sliding wire" with hot engine.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover assembly.
4. Remove the ignition coil.
5. Remove the spark plug.
  - (a) Using a special spark plug socket ratchet wrench (1), loosen the spark plug.

#### Tightening torque

$20 \pm 3 \text{ N}\cdot\text{m}$




IG0005002

- (b) Remove the spark plug (2).

## Inspection

1. Check the spark plug gap.
  - (a) Check the spark plug gap  $a$ : 0.7 - 0.8 mm.  
**Hint:**  
It is not necessary to adjust the gap.




## Spark Jump Test Method

1. Remove the spark plug from engine and connect it to high-voltage cable, put the spark plug case 5 - 7 mm away from engine body and start vehicle to check the spark jump.

### Warning:

- Always disconnect the injector circuit before test to avoid injection during spark jump test.

- (a) If there is a thick spark with blue-white color and popping occurs between spark plug and engine body and also spark generated between center electrode and side electrode, that indicates ignition system is normal.



- (b) If there is a thick spark with blue-white color between spark plug and engine body and no spark between center electrode and side electrode, but spark is in inside of center electrode, that indicates inside of spark plug is damaged.
- (c) If the spark is red and short or there is no spark, check ignition coil or others.

## Spark Plug Common Problems

### Normal

- Spark plug porcelain small end is between white and yellowish, gray or brownish.
- Air-fuel ratio and ignition time are normal, there is no misfire, and cold-start enriching function is normal.
- There are no fuel or oil deposits.

### Carbon Accumulation

A layer of velvety black charcoal smoke attaches on the insulator small end, electrode and spark plug body		
Cause	Result	Treatment
Mixture is excessively rich due to improper adjustment of air fuel mixture.		
Traveling distance of vehicle is too short (at high gear and low speed), engine temperature is low, and combustion is incomplete.	Poor starting ability	Adjust air-fuel ratio and cold starting system, and check air filter.
Fuel quality is poor or fuel deteriorates, combustion is incomplete.		
Spark plug type is incorrect.		

**Oil Dirt**

A layer of black oily charcoal smoke and dirt attach on the insulator small end, electrode and spark plug body		
Cause	Result	Treatment
Piston ring has bad elasticity or is worn excessively, and oil breaks into combustion chamber.		
Excessive matching clearance between piston skirt and cylinder wall causes oil breaking and air leakage.		
Air leakage occurs due to incorrect installation of piston ring in direction of inside and outside tangent angle, causing oil breaking into combustion chamber.	Difficult to start	Check and repair engine, or replace spark plug.
Excessive clearance occurs between valve stem and valve guide due to excessive wear, or valve guide oil seal fails, causing oil leakage.		
Oil level is too high and oil breaks into combustion chamber.		

**Lead Deposits**

Brownish yellow enamels or greenish deposits exist on the insulator small end		
Cause	Result	Treatment
The fuel additive contains lead, when engine runs under high load conditions with throttle partially opened for a long time, enamel is formed.	Causing misfire	Replace spark plug

**Lead Deposits**

There are severe dust deposits from oil additives on the insulator small end, even on the entire insulator skirt and electrode; there are loose cinder deposits on spark plug and combustion chamber		
Cause	Result	Treatment
Additives, especially the oil additives, can form these dust deposits in spark plug and combustion chamber.	Causing misfire, resulting in power loss or engine damage	Check and repair engine, replace spark plug or change oil type.

**Red deposits**

There are severe red brown deposits on insulator skirt and electrodes, and clear radial discharge traces can be seen on the surface of insulator small end		
Cause	Result	Treatment
In the unleaded gasoline, Mn-based anti-riot agent MMT is used instead of lead tetraethyl, the oxide of Mn after combustion adheres on the surface of insulator and electrode.	At high temperature, these deposits are easily conductive, resulting in flashover on insulator skirt surface, unstable combustion, high engine speed, and jitter under heavy load conditions.	Use qualified fuel, replace spark plug.

**Melting on center electrode**

Electrode melts, insulator small end softens, expands, and becomes sponge-like		
Cause	Result	Treatment
Overheating caused by self-ignition, excessively large ignition advance angle, deposits in combustion chamber, valve damage, inferior fuel, incorrect spark plug type.	A misfire, power loss or engine damage.	Check engine, ignition, injection and air intake system, and install spark plug with correct type

### Serious Burn in Side Electrode

Serious burn in side electrode		
Cause	Result	Treatment
Corrosive fuel and oil additives, deposits or other factors affect the way of air flowing in combustion chamber, engine knocking without overheating.	A misfire, especially a misfire during acceleration (ignition voltage is insufficient to break through the severely increased electrode gap), it is difficult to start.	Replace spark plug.

### Damage on Insulator Small End

Damage on insulator small end		
Cause	Result	Treatment
Mechanical damage (center electrode is stressed due to hitting, dropping, or incorrect handling), caused by severe expansion of deposits between insulator and center electrode or severe corrosion of center electrode.	A misfire, spark occurs at the damage point.	Replace spark plug

### Cracks on insulator big end

Cracks on insulator big end		
Cause	Result	Treatment
Mechanical action, caused by hitting, dropping or use of incorrect handling tool	Mechanical damage, electrode cannot jump normally.	Replace spark plug

## Installation

### Warning/Caution/Hint

#### Caution:

- Check the spark plug type to confirm if it is suitable.
- Please install spark plug with a special spark plug socket, and never damage the normal spark plug gap.
- Avoid to install the spark plug from higher position from mounting hole during installation to prevent spark plug side electrode gap from damaging, resulting in poor ignition.
- Always tighten the spark plug according to specified torque using a torque wrench when installing and replacing it.

1. Install the spark plug.

(a) Install 4 spark plugs respectively into the cylinder head mounting holes for pre-tightening, and then retighten the spark plugs with a torque wrench.

#### Tightening torque

$20 \pm 3 \text{ N}\cdot\text{m}$

2. Other installation procedures are in the reverse order of removal.