

SQRE4T15C IGNITION SYSTEM

| | | | |
|----------------------------------|-------------|-------------------------------|--------------|
| SQRE4T15C IGNITION SYSTEM | 20-3 | Ignition Coil Assembly | 20-7 |
| GENERAL INFORMATION | 20-3 | Removal | 20-7 |
| Component | 20-3 | Ignition Circuit | 20-8 |
| Operation | 20-4 | Inspection | 20-8 |
| Specifications | 20-4 | Installation | 20-9 |
| Tool | 20-4 | | |
| DIAGNOSIS & TESTING | 20-5 | Spark Plug | 20-10 |
| Problem Symptoms Table | 20-5 | Removal | 20-10 |
| Repair Precaution | 20-5 | Inspection | 20-10 |
| | | Spark Jump Test Method | 20-10 |
| | | Spark Plug Common Problems | 20-11 |
| | | Installation | 20-13 |

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



SQRE4T15C IGNITION SYSTEM**GENERAL INFORMATION****Component****Description**

| | |
|---------------------------------------|---------------------------------------|
| 1 - Spark Plug | 2 - Cylinder 4 Ignition Coil Assembly |
| 3 - Cylinder 3 Ignition Coil Assembly | 4 - Cylinder 2 Ignition Coil Assembly |
| 5 - Cylinder 1 Ignition Coil Assembly | |

Operation

- Ignition system mainly consists of sensors, Engine Control Module (ECM), ignition coils, spark plugs, etc. Ignition advance angle is controlled by Engine Control Module (ECM) directly.
- As an integrated module, the ignition coil cannot be disassembled. SQRE4T15C uses coil-on-plug system. Secondary high-voltage terminal of each ignition coil is connected to spark plugs in engine cylinder respectively via high-voltage post. Ignition coil primary low-voltage terminal is connected to Engine Control Module (ECM) via wire harness.
- Engine Control Module (ECM) receives the Top Dead Center (TDC) position of each cylinder piston via input signal of phase sensor, and uses the speed sensor signal to make ignition coil to operate.

Specifications

Torque Specifications


| Description | Torque (N·m) |
|---------------------------|--------------|
| Spark Plug | 20 ± 3 |
| Ignition Coil Fixing Bolt | 9 ± 1 |

Spark Plug Specifications

| Description | Specifications |
|---------------------|----------------|
| Engine Type | SQRE4T15C |
| Spark Plug Type | 3707AAG |
| Spark Plug Gap (mm) | 0.7 - 0.8 |

Tool

General Tool

| | |
|---|--|
| شرکت دیجیتال خودرو سامانه (مسئولیت محدود) | اولین سامانه دیجیتال تعمیکلران خودرو در ایران |
| Digital Multimeter |  RCH0002006 |

DIAGNOSIS & TESTING

Problem Symptoms Table

Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

| Symptom | Suspected Area |
|---|---------------------------------------|
| Stall | Ignition coil |
| | Camshaft position sensor |
| | Spark plug |
| | Intake camshaft phaser control valve |
| | Exhaust camshaft phaser control valve |
| | Wire harness |
| | ECM |
| Knock | Ignition coil |
| | Knock sensor |
| | ECM |
| Difficult to start | Battery |
| | Ignition coil |
| | Spark plug |
| | Engine speed sensor |
| Engine hesitation, power drop, unstable performance | Ignition coil |
| | Engine speed sensor |
| | Intake camshaft phaser control valve |
| | Exhaust camshaft phaser control valve |
| | Spark plug |
| | Camshaft position sensor |
| | ECM |
| Rough, unstable idling or stall | Ignition coil |
| | Camshaft position sensor |
| | Spark Plug |
| | ECM |

Repair Precaution

Visual inspection can reduce the unnecessary test and diagnostic time, so pay attention to the following inspection items:

1. Check the line and hose for obvious looseness, and if they are disconnected or routed improperly.
2. Make sure that the battery connections are clean and fixed firmly.
3. Check if the generator wire and belt are installed correctly and securely.
4. Check if the engine wire harness connectors are inserted fully.
5. Check if all electrical connectors are installed correctly and securely.
6. Check the following electrical connections.
 - (a) Engine speed sensor
 - (b) Oxygen sensor
 - (c) Intake pressure/temperature sensor
 - (d) Oil pressure switch
 - (e) Ignition coil
 - (f) Canister solenoid valve
 - (g) Camshaft position sensor

- (h) Electronic throttle
- (i) Intake Variable Valve Timing (VVT) control valve
- (j) Exhaust Variable Valve Timing (VVT) control valve
- (k) Fuel injector

7. Check the routing of all vacuum hoses.
8. Confirm that the following vacuum hoses are connected securely without any leakage
 - (a) Canister solenoid valve
 - (b) PCV valve
 - (c) Brake booster
9. Check the fuel pump hose and wire connection to make sure that they are connected securely.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Ignition Coil Assembly



Removal

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.
- It is prohibited to use short circuit spark test to test ignition function during repair, otherwise it may damage the module.
- During using, do not remove ignition coil from spark plug with bare hands with power on, and do not contact the metal part directly, to avoid electric shock.

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover.
4. Remove the ignition coil.
 - (a) Disconnect the ignition coil connectors (1), and move away the wire harness from ignition coil.
 - (b) Disconnect the ignition coil connectors (2), and move away the wire harness from ignition coil.
 - (c) Remove 8 fixing bolts (arrow) from ignition coil.



Tightening torque


$8 \pm 2 \text{ N}\cdot\text{m}$

جیتال خودکار

(حدود) از تعمیرات سامانه دیجیتال خودکار

ولین سامانه دیجیتال تعمیرات خودکار ایران


Ignition Circuit



Inspection

1. Inspect the resistance of ignition coil.
 (a) Turn digital multimeter to ohm band, and check the resistance between terminals 1 and 2.

| Terminal | Terminal Definition |
|----------|---------------------|
| 1 | Power Supply |
| 2 | Ground |
| 3 | Ground |
| 4 | Signal |



| Multimeter Connection | Condition | Specification (Ω) |
|-------------------------|--------------------|----------------------------|
| Terminal 1 - Terminal 2 | Normal temperature | 9.3M Ω |
| Terminal 1 - Terminal 3 | Normal temperature | ∞ |
| Terminal 1 - Terminal 4 | Normal temperature | 9.3M Ω |
| Terminal 2 - Terminal 3 | Normal temperature | ∞ |
| Terminal 2 - Terminal 4 | Normal temperature | 1.097K Ω |
| Terminal 3 - Terminal 4 | Normal temperature | ∞ |

Hint:

Replace ignition coil if difference is great.

Installation

1. Installation is in the reverse order of removal.

Caution:

- Make sure that the connection of ignition coil high-voltage output terminal and spark plug is reliable, or it may cause high-voltage leakage, resulting in poor ignition.
- Inspect installation hole of cylinder head spark plug. Do not allow foreign objects to enter it during assembly.
- Install the ignition coil into cylinder head cover mounting hole and press it to close to mounting boss on cylinder head cover. Never turn ignition coil to left/right after pressing and do not tap ignition coil with a hammer etc.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Spark Plug


Removal

Warning/Caution/Hint

Caution:

- Be sure to wear necessary safety equipment to prevent accidents when repairing.
- Try to prevent body paint surface from being scratched during removal and installation.
- DO NOT remove the spark plugs when engine is hot; failure to do this may cause damage to the spark plug thread holes on cylinder head.
- Before removal, remove the dirt and foreign matter around spark plug holes to prevent them from dropping into cylinders.

1. Turn off all electrical equipment and the start button. Wait until engine cools down and then perform removal to avoid "sliding wire" with hot engine.
2. Disconnect the negative battery cable.
3. Remove the engine trim cover assembly.
4. Remove the ignition coil.
5. Remove the spark plug.
 - (a) Using a special spark plug socket ratchet wrench (1), loosen the spark plug.




اولین سامانه دیجیتال تعمیرکاران خودرو سامانه (مسئولیت محدود)

Inspection

1. Check the spark plug gap.
 - (a) Check the spark plug gap a : 0.7 - 0.8 mm.

Hint:

It is not necessary to adjust the gap.



20


Spark Jump Test Method

1. Remove the spark plug from engine and connect it to high-voltage cable, put the spark plug case 5 - 7 mm away from engine body and start vehicle to check the spark jump.

Warning:

- Always disconnect the injector circuit before test to avoid injection during spark jump test.

(a) If there is a thick spark with blue-white color and popping occurs between spark plug and engine body and also spark generated between center electrode and side electrode, that indicates ignition system is normal.



(b) If there is a thick spark with blue-white color between spark plug and engine body and no spark between center electrode and side electrode, but spark is in inside of center electrode, that indicates inside of spark plug is damaged.

(c) If the spark is red and short or there is no spark, check ignition coil or others.

Spark Plug Common Problems

Normal

- Spark plug porcelain small end is between white and yellowish, gray or brownish.
- Air-fuel ratio and ignition time are normal, there is no misfire, and cold-start enriching function is normal.
- There are no fuel or oil deposits.

Carbon Accumulation

| A layer of velvety black charcoal smoke attaches on the insulator small end, electrode and spark plug body | | |
|---|-----------------------|---|
| Cause | Result | Treatment |
| Mixture is excessively rich due to improper adjustment of air fuel mixture. | | |
| Traveling distance of vehicle is too short (at high gear and low speed), engine temperature is low, and combustion is incomplete. | Poor starting ability | Adjust air-fuel ratio and cold starting system, and check air filter. |
| Fuel quality is poor or fuel deteriorates, combustion is incomplete. | | |
| Spark plug type is incorrect. | | |

Oil Dirt

| A layer of black oily charcoal smoke and dirt attach on the insulator small end, electrode and spark plug body | | |
|---|--------------------|---|
| Cause | Result | Treatment |
| Piston ring has bad elasticity or is worn excessively, and oil breaks into combustion chamber. | | |
| Excessive matching clearance between piston skirt and cylinder wall causes oil breaking and air leakage. | | |
| Air leakage occurs due to incorrect installation of piston ring in direction of inside and outside tangent angle, causing oil breaking into combustion chamber. | Difficult to start | Check and repair engine, or replace spark plug. |
| Excessive clearance occurs between valve stem and valve guide due to excessive wear, or valve guide oil seal fails, causing oil leakage. | | |
| Oil level is too high and oil breaks into combustion chamber. | | |

Lead Deposits

Brownish yellow enamels or greenish deposits exist on the insulator small end

| Cause | Result | Treatment |
|--|-----------------|---------------------|
| The fuel additive contains lead, when engine runs under high load conditions with throttle partially opened for a long time, enamel is formed. | Causing misfire | Replace spark plug. |

Lead Deposits

There are severe dust deposits from oil additives on the insulator small end, even on the entire insulator skirt and electrode; there are loose cinder deposits on spark plug and combustion chamber

| Cause | Result | Treatment |
|---|---|---|
| Additives, especially the oil additives, can form these dust deposits in spark plug and combustion chamber. | Causing misfire, resulting in power loss or engine damage | Check and repair engine, replace spark plug or change oil type. |

Red Deposits

There are severe red brown deposits on insulator skirt and electrodes, and clear radial discharge traces can be seen on the surface of insulator small end

| Cause | Result | Treatment |
|--|---|---|
| In the unleaded gasoline, Mn-based anti-riot agent MMT is used instead of lead tetraethyl, the oxide of Mn after combustion adheres to the surface of insulator and electrode. | At high temperature, these deposits are easily conductive, resulting in flashover on insulator skirt surface, unstable combustion, high engine speed, and jitter under heavy load conditions. | Use qualified fuel, replace spark plug. |

Melting on Center Electrode

Electrode melts, insulator small end softens, expands, and becomes sponge-like

| Cause | Result | Treatment |
|--|---|---|
| Overheating caused by self-ignition, excessively large ignition advance angle, deposits in combustion chamber, valve damage, inferior fuel, incorrect spark plug type. | A misfire, power loss or engine damage. | Check engine, ignition, injection and air intake system, and install spark plug with correct type |

Serious Burn in Side Electrode

Serious burn in side electrode

| Cause | Result | Treatment |
|---|---|---------------------|
| Corrosive fuel and oil additives, deposits or other factors affect the way of air flowing in combustion chamber, engine knocking without overheating. | A misfire, especially a misfire during acceleration (ignition voltage is insufficient to break through the severely increased electrode gap), it is difficult to start. | Replace spark plug. |

20

Damage on Insulator Small End

Damage on insulator small end

| Cause | Result | Treatment |
|--|--|---------------------|
| Mechanical damage (center electrode is stressed due to hitting, dropping, or incorrect handling), caused by severe expansion of deposits between insulator and center electrode or severe corrosion of center electrode. | A misfire, spark occurs at the damage point. | Replace spark plug. |

Flashover on Insulator Surface

| There is obvious arc burning trace on porcelain surface in axial direction | | |
|--|----------------------------------|---|
| Cause | Result | Treatment |
| Long time use of spark plug, excessive gap, excessive ignition voltage, high-voltage cable jacket aging, poor insulation performance, excessive clearance between high-voltage cable jacket and porcelain. | Spark plug cannot jump properly. | Replace high-voltage cable. Or apply silicone oil to high-voltage cable and replace spark plug. |

Cracks on Insulator Big End

| Cracks on insulator big end | | |
|--|--|---------------------|
| Cause | Result | Treatment |
| Mechanical action, caused by hitting, dropping or use of incorrect handling tool | Mechanical damage, electrode cannot jump normally. | Replace spark plug. |

Installation**Warning/Caution/Hint****Caution:**

- Check the spark plug type to confirm if it is suitable.
- Please install spark plug with a special spark plug socket, and never damage the normal spark plug gap.
- Avoid to install the spark plug from higher position from mounting hole during installation to prevent spark plug side electrode gap from damaging, resulting in poor ignition.
- Always tighten the spark plug according to specified torque using a torque wrench when installing and replacing it.

- Install the spark plug.
 - Install 4 spark plugs respectively into the cylinder head mounting holes for pre-tightening, and then retighten the spark plugs with a torque wrench.

Tightening torque $20 \pm 3 \text{ N}\cdot\text{m}$

- Other installation procedures are in the reverse order of removal.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

