


Brake light



Harness connector	Name	Page
A5	ECU harness connector	16
A7	Engine control harness connector 1	16
MEC01	Main harness to engine control harness 1	26
M18	Brake switch harness connector	26
ME03	Main harness to engine harness 3	26
EM03	Engine harness to main harness 3	16
MR01	Main harness to left roof harness 1	17
RM01	Left roof harness to main harness 1	34
MR03	Main harness to right roof harness 1	26
RM03	Right roof harness to main harness 1	35
R06	Right rear lamp harness connector	34
R14	Left rear lamp harness connector	34
RH01	Left roof harness to brake harness	34
HR01	Brake light to left roof harness	56
H01	Brake light harness connector	56
G15	Ground	64
G21	Ground	65

Harness connector	Name	Page
R14-5	To ABS module E05-15	123

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران