


< ECU DIAGNOSIS >

Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM -


INFOID:000000004902126

SEAT BELT WARNING LAMP



- SA : For South Africa
- XS : For except South Africa
- VD : With VDC
- OV : Without VDC

Refer to the following.
 (M77) SUPER MULTIPLE JUNCTION (SMU)
 (E34) (E38) -ELECTRICAL UNIS



Fail Safe

The combination meter activates the fail-safe control if the CAN communication lines between each unit are malfunctioning.

JM-HWA0005G1

INFOID:000000004939914