


CAN System

Circuit Diagram (Page 1 of 3)



09 - SYSTEM CIRCUITS

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	08-8	I-013	08-8	I-026	08-8
B-071	08-12				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF20	06-9	Instrument Panel Fuse And Relay Box

Location of Junction Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-016, B-039	08-8				

Form of Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	12-4	I-013	12-4	I-026	12-4
B-071	12-7	I-016, B-039	12-4		

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 3)



09 - SYSTEM CIRCUITS

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-001	08-12	I-009	08-8	I-013	08-8
B-071	08-12	I-011	08-8	I-012	08-8
B-007	08-12	I-024	08-8		

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-040, B-013	08-8				


Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-001	12-7	I-009	12-4	I-013	12-4
B-071	12-7	I-011	12-4	I-012	12-4
B-007	12-7	I-024	12-4	I-040, B-013	12-4

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 3)

