



- UHC-engine compartment fuse box
- UHB(BAT)-connection, engine compartment fuse box connecting to positive pole of battery
- IP-dashboard fuse box
- BAT-battery
- M14-generator
- M15-starter
- X06-AD Y06-PD connector of main cable and engine compartment cable, 20-hole, blue
- X07_AA Y07_EA-engine compartment wiring harness splicing to EFI wiring harness connector 42 holes black
- G05_A-negative pole of battery to ground point of vehicle body
- G09_A-engine compartment ground point of the left front shock absorber