

◊ harness plug

No.	No.	Description of harness plug
C24	E24	Engine control harness – engine harness (on the right of brake oil tank)
E18	M42	Engine harness – main harness (below and on the left of dashboard)
M12	F11	Engine harness – vehicle frame harness (below and on the left of dashboard)

□: switch and electrical device

No.	Description	Position
C25	To brake lamp switch	Engine control harness
C27	To ECM	Engine control harness
E15	To ABS control unit	Engine harness
F1	To rear left combined lamp	Vehicle frame harness
F21	To high-position brake lamp	Vehicle frame harness
F24	To rear right combined lamp	Vehicle frame harness

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

