




Service Hints**HORN Relay**

5-3 : Closed with the horn SW on

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C12	36 (LHD)	H9	32 (LHD 1MZ-FE)	J2	37 (LHD)
	46 (RHD)		42 (RHD 1MZ-FE)		47 (RHD)
H8	32 (LHD 1MZ-FE)		34 (LHD 2AZ-FE)		
	34 (LHD 2AZ-FE)		44 (RHD 2AZ-FE)		

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	24	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1H	24	Engine Room Main Wire and Engine Room J/B
2G	26	Engine Room Main Wire and Driver Side J/B
2Q	27	Instrument Panel Wire and Driver Side J/B

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IK	55 (LHD)	Instrument Panel Brace
	67 (RHD)	

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

