

< COMPONENT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]


# NATS (NISSAN ANTI-THEFT SYSTEM)

## Wiring Diagram - NATS -


INFOID:000000004898856

- ◊ES◊ : With 6-speakers
- ◊G◊ : With gasoline engine
- ◊MB◊ : With MSR engine
- \*1 84 : ◊G◊
- 100 : ◊MB◊
- \*2 83 : ◊G◊
- 99 : ◊MB◊

### NATS (NISSAN ANTI-THEFT SYSTEM) / WITHOUT INTELLIGENT KEY



\*: This connector is not shown in Harness Layout, PG section.  
 Refer to the following:  
 (M77) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M55) (M56) (M57) (E16) (E12)  
 -ELECTRICAL UNITS



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

JMKWA0080Gf