


SQRD4G15B Charging System

Circuit Diagram (Page 1 of 1)



دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

02 09 52 99 92 92

www.digitalkhodro.com

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-067	08-5 (MT) 08-7 (AT)	P-005	08-9	I-011	08-10
P-001	08-9	E-017	08-3		

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF09	06-2	Engine Compartment Fuse and Relay Box
MF01	06-2	Engine Compartment Fuse and Relay Box

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-035, E-029	08-10, 08-5 (MT) 08-10, 08-7 (AT)	E-035, E-007	08-5, 08-3 (MT) 08-7, 08-3 (AT)		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-067	12-6	P-005	12-16	I-011	12-7
P-001	12-16	E-017	12-3	I-035, E-029	12-9
E-035, E-007	12-4				