



چراغ راهنما و فلاشر




ID CODE	DEVICE CONNECTOR	DEVICE IDENTIFICATION
S1	X20	(4x,10M1)-Ignition & Starting SW 2F(B)
S22A	X28	Omni Direction Indicator SW 2F(W)
S22B	X29	Hazard Light SW 10F
A1	...	Fuse Box
F12	...	METER - 10A
F15	...	HAZARD - 15A
A3	X29	Flasher Unit 2F(B)
P1	X29A, X29B	Meter-Set
H14	X29A	Meter-Set 18(B)
H15	X29A	Meter-Set 18(B)
...	X29	Inner Connector BH W/H 2(I)
...	X40A	Inner Connector Rear W/H 12(W)
...	X30B	Inher Connector 18S7 W/H 8(W)
E22	X34A	Front Turn Lamp 2F(W) LH
E23	X34C	Front Turn Lamp 2F(W) RH
E24	X34B	Front Turn(Small) Lamp 2F(BL) LH
E25	X34D	Front Turn(Small) Lamp 2F(BL) RH
E43	X31B	Rear Turn Lamp 2F(W) LH
E44	X31A	Rear Turn Lamp 2F(W) RH
COMBINATION	...	***Locations of Ground***
S01, S02, S03, S04	...	Earth Point (S02, S03, S04)
S05	...	Earth Point (S5)
S06, S07	...	Earth Point (S6, S06, S07)

دسته راهنما



کلید فلاشر X28



واحد فلاشر X61

