


# Radar System

Circuit Diagram (Page 1 of 2)



09

**Parts Location**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	08-10	B-003	08-36	B-002	08-36

**Fuse and Relay**

Fuse/Relay	See Page	Fuse and Relay Box
EF08	06-2	Engine Compartment Fuse and Relay Box

**Location of Junction Connector**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-007, B-018	08-10, 08-36				

**Form of Connector**


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	12-17	B-003	12-8	B-002	12-8
Q-007, B-018	12-17, 12-8				

شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 2)



09

PME002001