



BM1.5 AMT EFI unit circuit diagram

- UHC-engine compartment fuse box
- E11-AMT gearbox TCU 66 holes black
- M22_EA-AMT generator1
- M23_EA-AMT generator2
- S23_EA-clutch electrode&sensor
- X07_AA Y07_EA-EFI wiring harness splicing to main wiring harness 42 holes black
- X06_AA Y06_PA-dash-board splicing to engine compartment connector 20 holes blue
- S25_EA-speed sensor
- S26_EA-tempreture sensor
- E02_PA-anti-theft ECU connector 8 holes black
- D11_PA-AMT gearshift ECU connector 8 holes black
- G08_P-ground point below left pillar-A
- G11_E-ground point on AMT