



Radio,lighter circuit diagram

- UHC-engine compartment fuse box
- IP-dash-board fuse box
- C04-cigar lighter connector 3 holes black
- C03_D1A-left front door woofer connector 2 holes black
- C02_P1A-tweeter connector 2 holes white
- C03_D2A-right front door woofer connector 2 holes black
- C02_P2A-tweeter connector 2 holes white
- C03_D1B-left rear door woofer connector 2 holes black
- C03_D2B-right rear door tweeter connector 2 holes black
- X06_AC Y06_PC-dash-board wiring harness splicing to enging compartment wiring harness 6 holes black

- E05_PA-radio connector A 8 holes white
- E05_PB-radio connector B 8 holes black
- X01_P1A Y01_D1A-dash-board main wiring harness and left front door wiring harness splicing connector 18 holes black
- X01_P1B Y01_D1A-dash-board main wiring harness and left front door wiring harness splicing connector 14 holes white
- X01_P2A Y01_D2A-dash-board main wiring harness and right front door wiring harness splicing connector 18 holes black
- Y02_P1A X02_D1B-left rear door wiring harness and main wiring harness splicing connector 14 holes white
- Y02_P2A X02_D2B-right rear door wiring harness and main wiring harness splicing connector 14 holes white