

No.	Description	No.	Description
FB 1	HVAC panel	FB 27	Cigarette lighter
FB 2	Audio system	FB 28	Reserve
FB 3	Audio system	FB 29	Spare
FB 4	Key switch	FB 30	Reverse light switch
FB 5	Sunroof	FB 31	Spare
FB 6	BCM/Reversing radar	FB 32	Brake light
FB 7	Instrument cluster	FB 33	Spare
FB 8	Luggage compartment light	FB 34	Reserve
FB 9	Instrument cluster/Diagnosis connector	FB 35	Reserve
FB 10	Diagnosis connector	FB 36	Ignition coil
FB 11	Speed sensor	FB 37	Reserve
FB 12	Fuel pump	R 1	Starter relay
FB 13	A/C compressor	R 2	Blower relay
FB 14	ECM	R 3	High beam headlight relay
FB 15	ECM	R 4	-
FB 16	Spare	R 5	-
FB 17	Cooling fan	R 6	-
FB 18	Oxygen sensor	R 7	Fuel pump relay
FB 19	Fuel injector/Canister purge valve/Fuel pump relay	R 8	ECM main relay
FB 20	High beam headlight LH	R 9	A/C compressor relay
FB 21	High beam headlight RH	R 10	Low beam headlight relay
FB 22	Low beam headlight LH		