WWW.DIGITALKHODRO.COM 021 62 99 92 92



Interior dome lamp, sunroof ECU circuit diagram

IP-dashboard fuse box
L07_PA-front interior dome lamp connector(without sunroof) 3 holes white
L07_PB-front interior dome lamp connector(with sunroof) 6 holes white
M11-sunroof ECU
X06_AB Y06_PB-dashboard splicing to engine compartment wiring harness 20 holes white
G01_P-ground point on the pillar-A at the left of main wiring harness
G13_P-ground point on the pillar-A at the left of main wiring harness

WWW.DIGITALKHODRO.COM 021 62 99 92 92